

Your Ultimate Source for OEM Repair Manuals

FactoryManuals.net is a great resource for anyone who wants to save money on repairs by doing their own work. The manuals provide detailed instructions and diagrams that make it easy to understand how to fix a vehicle.

1978 MAZDA RX-7 (SA/FB) OEM Service and Repair Workshop Manual

[Go to manual page](#)

STEP	INSPECTION	RESULTS	ACTION
11	VERIFY AFTER REPAIR PROCEDURE <ul style="list-style-type: none">• Perform the "AFTER REPAIR PROCEDURE". (See AFTER REPAIR PROCEDURE [PCM (SKYACTIV-D 2.2)].)• Are any DTCs present?	Yes	Go to the applicable DTC inspection. (See DTC TABLE [PCM (SKYACTIV-D 2.2)] .)
		No	DTC troubleshooting completed.

Sample

STEP	INSPECTION		ACTION
3	INSPECT GLOW CONTROL MODULE CONNECTOR CONDITION <ul style="list-style-type: none"> • Switch the ignition off. • Disconnect the glow control module connector. • Inspect for poor connection (such as damaged/pulled-out pins, corrosion). • Is there any malfunction? 	Yes	Repair or replace the connector and/or terminals, then go to Step 11.
		No	Go to the next step.
4	INSPECT GLOW CONTROL MODULE POWER SUPPLY CIRCUIT FOR SHORT TO GROUND OR OPEN CIRCUIT <ul style="list-style-type: none"> • Verify that the glow control module connector is disconnected. • Switch the ignition ON (engine off). <p>Note</p> <ul style="list-style-type: none"> • Another DTC may be stored by the PCM detecting an open circuit. • Measure the voltage at the glow control module terminal H (wiring harness-side). • Is the voltage B+? 	Yes	Go to the next step.
		No	Inspect the ENGINE1 15 A fuse. <ul style="list-style-type: none"> • If the fuse is blown: <ul style="list-style-type: none"> — Refer to the wiring diagram and verify whether or not there is a common connector between ENGINE1 15 A fuse and glow control module terminal H. <p>If there is a common connector:</p> <ul style="list-style-type: none"> • Determine the malfunctioning part by inspecting the common connector and the terminal for corrosion, damage, or pin disconnection, and the common wiring harness for a short to ground. • Repair or replace the malfunctioning part. <p>If there is no common connector:</p> <ul style="list-style-type: none"> • Repair or replace the wiring harness which has a short to ground. • Replace the fuse. <ul style="list-style-type: none"> • If the fuse is damaged: <ul style="list-style-type: none"> — Replace the fuse. • If all fuses are normal: <ul style="list-style-type: none"> — Refer to the wiring diagram and verify whether or not there is a common connector between main relay terminal C and glow control module terminal H. <p>If there is a common connector:</p> <ul style="list-style-type: none"> • Determine the malfunctioning part by inspecting the common connector and the terminal for corrosion, damage, or pin disconnection, and the common wiring harness for an open circuit. • Repair or replace the malfunctioning part. <p>If there is no common connector:</p> <ul style="list-style-type: none"> • Repair or replace the wiring harness which has an open circuit. Go to Step 11.

SM2895999

id0102j505840

DTC P2471:00	Exhaust gas temperature sensor No.4 circuit high input
DETECTION CONDITION	<ul style="list-style-type: none"> • If the PCM detects that the exhaust gas temperature sensor No.4 voltage at the PCM terminal 1DU is above 4.88 V for 5 s with the following condition met, the PCM determines that the exhaust gas temperature sensor No.4 circuit voltage is high. <p>MONITORING CONDITIONS</p> <ul style="list-style-type: none"> — Battery voltage: 8 V or more <p>Diagnostic support note</p> <ul style="list-style-type: none"> • This is a continuous monitor (CCM). • The check engine light illuminates if the PCM detects the above malfunction condition during the first drive cycle. • FREEZE FRAME DATA/Snapshot data is available. • DTC is stored in the PCM memory. <p>Note</p> <ul style="list-style-type: none"> • When this DTC is detected, inducement DTC P2BAF:00 is also detected. • This DTC is established to record that the inducement warning has been activated with the remaining distance to empty at 402 km {250 miles} or less due to an inducement malfunction.
FAIL-SAFE FUNCTION	<ul style="list-style-type: none"> • Not applicable
POSSIBLE CAUSE	<ul style="list-style-type: none"> • Exhaust gas temperature sensor No.4 connector or terminals malfunction • PCM connector or terminals malfunction • Short to power supply in wiring harness between exhaust gas temperature sensor No.4 terminal A and PCM terminal 1DU • Open circuit in wiring harness between the following terminals: <ul style="list-style-type: none"> — Exhaust gas temperature sensor No.4 terminal A-PCM terminal 1DU — Exhaust gas temperature sensor No.4 terminal B-PCM terminal 1DR • Exhaust gas temperature sensor No.4 malfunction • PCM malfunction


STEP	INSPECTION	RESULTS	ACTION
8	VERIFY DTC TROUBLESHOOTING COMPLETED <ul style="list-style-type: none"> • Always reconnect all disconnected connectors. • Clear the DTC from the PCM memory using the M-MDS. (See CLEARING DTC [PCM (SKYACTIV-D 2.2)].) • Perform the KOEO or KOER self test. (See KOEO/KOER SELF TEST [PCM (SKYACTIV-D 2.2)].) • Is the same DTC present? 	Yes	Repeat the inspection from Step 1. <ul style="list-style-type: none"> • If the malfunction recurs, replace the PCM. (See PCM REMOVAL/INSTALLATION [SKYACTIV-D 2.2].) Go to the next step.
		No	Go to the next step.
9	VERIFY AFTER REPAIR PROCEDURE <ul style="list-style-type: none"> • Perform the "AFTER REPAIR PROCEDURE". (See AFTER REPAIR PROCEDURE [PCM (SKYACTIV-D 2.2)].) • Are any DTCs present? 	Yes	Go to the applicable DTC inspection. (See DTC TABLE [PCM (SKYACTIV-D 2.2)] .)
		No	DTC troubleshooting completed.

System Wiring Diagram

- Not applicable

Function Explanation (DTC Detection Outline)

- The PCM diagnoses whether the diesel particulate filter regeneration is completed normally by monitoring the diesel particulate filter before and after pressure difference after diesel particulate filter regeneration is completed.
- The PCM monitors the diesel particulate filter before and after pressure difference using exhaust gas pressure sensor No.2.
- If the diesel particulate filter before and after pressure difference is higher than the standard, the PCM determines that the diesel particulate filter regeneration is incomplete.
- When the PCM determines that the diesel particulate filter regeneration is incomplete during 1 drive cycle, it determines a malfunction, stores a pending code and DTC, and turns on the check engine light.



Repeatability Verification Procedure

1. After diesel particulate filter regeneration is completed, maintain an engine speed of 2,000 rpm or more for 5 s or more.

PID Item/Simulation Item Used In Diagnosis

PID/DATA monitor item table

Item	Definition	Unit	Condition/Specification
PM_ACC_DSD	PM accumulation amount desired	-(g/l, lb/ft ³)i	• Displays the PM accumulation amount desired

Function Inspection Using M-MDS

STEP	INSPECTION	RESULTS	ACTION
1	PURPOSE: VERIFY RELATED REPAIR INFORMATION AVAILABILITY <ul style="list-style-type: none">• Verify related Service Bulletins and/or on-line repair information availability.• Is any related repair information available?	Yes	Perform repair or diagnosis according to the available repair information. <ul style="list-style-type: none">• If the vehicle is not repaired, go to the next step.
		No	Go to the next step.

DTC P24A4:00 [PCM (SKYACTIV-D 2.2)]

SM2896001

id0102j505870

DTC P24A4:00	Diesel particulate filter restriction - Soot accumulation too high
DETECTION CONDITION	<ul style="list-style-type: none">The PCM detects any of the following for a continuous 125 s.<ul style="list-style-type: none">PM accumulation amount calculated by exhaust gas pressure sensor No.2: 13 g/L or morePM accumulation amount calculated from fuel injection amount: 13 g/L or more Diagnostic support note <ul style="list-style-type: none">This is a continuous monitor (CCM).The check engine light illuminates if the PCM detects the above malfunction condition during the first drive cycle.FREEZE FRAME DATA/Snapshot data is available.DTC is stored in the PCM memory.
FAIL-SAFE FUNCTION	<ul style="list-style-type: none">PCM restricts engine torque.Inhibits the auto diesel particulate filter regeneration control.Inhibits the DENOx/DESOx control.Inhibits the EGR control.
POSSIBLE CAUSE	<ul style="list-style-type: none">Pipe between exhaust gas pressure sensor No.2 and catalytic converter restriction and/or damagedExhaust gas pressure sensor No.2 malfunctionDiesel particulate filter restriction and/or damagedPCM malfunction
SYSTEM WIRING DIAGRAM	Not applicable

Diagnostic Procedure

STEP	INSPECTION		ACTION
1	IDENTIFY TRIGGER DTC FOR FREEZE FRAME DATA <ul style="list-style-type: none">Perform the Freeze Frame PID Data Access Procedure. (See ON-BOARD DIAGNOSTIC TEST [PCM (SKYACTIV-D 2.2)].)Is the DTC P24A4:00 on FREEZE FRAME DATA?	Yes	Go to the next step.
		No	Go to the troubleshooting procedure for DTC on FREEZE FRAME DATA. (See DTC TABLE [PCM (SKYACTIV-D 2.2)] .)
2	RECORD VEHICLE STATUS AT TIME OF DTC DETECTION TO UTILIZE WITH REPEATABILITY VERIFICATION Note <ul style="list-style-type: none">Recording can be facilitated using the screen capture function of the PC.Record the FREEZE FRAME DATA/snapshot data on the repair order.	–	Go to the next step.
3	VERIFY RELATED SERVICE INFORMATION AVAILABILITY <ul style="list-style-type: none">Verify related Service Bulletins and/or on-line repair information availability.Is any related Service Information available?	Yes	Perform repair or diagnosis according to the available repair information. <ul style="list-style-type: none">If the vehicle is not repaired, go to the next step.
		No	Go to the next step.

STEP	INSPECTION		ACTION
4	INSPECT EGR COOLER BYPASS VALVE/EGR COOLER BYPASS VALVE POSITION SENSOR CONNECTOR CONDITION <ul style="list-style-type: none"> • Switch the ignition off. • Disconnect the EGR cooler bypass valve/EGR cooler bypass valve position sensor connector. • Inspect for poor connection (such as damaged/pulled-out pins, corrosion). • Is there any malfunction? 	Yes	Repair or replace the connector and/or terminals, then go to Step 8.
		No	Go to the next step.
5	INSPECT PCM CONNECTOR CONDITION <ul style="list-style-type: none"> • Disconnect the PCM connector. • Inspect for poor connection (such as damaged/pulled-out pins, corrosion). • Is there any malfunction? 	Yes	Repair or replace the malfunctioning part according to the inspection results, then go to Step 7.
		No	Go to the next step.
6	INSPECT EGR COOLER BYPASS VALVE <ul style="list-style-type: none"> • Inspect the EGR cooler bypass valve. (See EGR COOLER BYPASS VALVE INSPECTION [SKYACTIV-D 2.2].) • Is there any malfunction? 	Yes	Replace the EGR cooler bypass valve, then go to Step 8. (See EGR COOLER BYPASS VALVE REMOVAL/INSTALLATION [SKYACTIV-D 2.2].)
		No	Go to the next step.
7	INSPECT EGR COOLER BYPASS VALVE POSITION SENSOR <ul style="list-style-type: none"> • Reconnect all disconnected connectors. • Inspect the EGR cooler bypass valve position sensor. (See EGR COOLER BYPASS VALVE POSITION SENSOR INSPECTION [SKYACTIV-D 2.2].) • Is there any malfunction? 	Yes	Replace the EGR cooler bypass valve, then go to the next step. (See EGR COOLER BYPASS VALVE REMOVAL/INSTALLATION [SKYACTIV-D 2.2].)
		No	Go to the next step.
8	VERIFY DTC TROUBLESHOOTING COMPLETED <ul style="list-style-type: none"> • Always reconnect all disconnected connectors. • Clear the DTC from the PCM memory using the M-MDS. (See AFTER REPAIR PROCEDURE [PCM (SKYACTIV-D 2.2)].) • Start the engine and warm it up completely. • Drive the vehicle under the snapshot data condition or. <p>Warning</p> <ul style="list-style-type: none"> • When the M-MDS is used to observe monitor system status while driving, be sure to have another technician with you, or record the data in the M-MDS using the PID/DATA MONITOR AND RECORD capturing function and inspect later. • While performing this step, always operate the vehicle in a safe and lawful manner. <p>Note</p> <ul style="list-style-type: none"> • Snapshot data, the vehicle speed, and engine speed values to the best extent possible while driving the vehicle. <ul style="list-style-type: none"> • Perform the DTC Reading Procedure. (See ON-BOARD DIAGNOSTIC TEST [PCM (SKYACTIV-D 2.2)].) • Is the same DTC present? 	Yes	Repeat the inspection from Step 1. • If the malfunction recurs, replace the PCM. (See PCM REMOVAL/INSTALLATION [SKYACTIV-D 2.2].) Go to the next step.
		No	Go to the next step.
9	VERIFY AFTER REPAIR PROCEDURE <ul style="list-style-type: none"> • Perform the "AFTER REPAIR PROCEDURE". (See AFTER REPAIR PROCEDURE [PCM (SKYACTIV-D 2.2)].) • Are any DTCs present? 	Yes	Go to the applicable DTC inspection. (See DTC TABLE [PCM (SKYACTIV-D 2.2)].)
		No	DTC troubleshooting completed.

STEP	INSPECTION		ACTION
1	<p>RECORD VEHICLE STATUS AT TIME OF DTC DETECTION TO UTILIZE WITH REPEATABILITY VERIFICATION</p> <p>Note</p> <ul style="list-style-type: none"> Recording can be facilitated using the screen capture function of the PC. Record the FREEZE FRAME DATA/snapshot data on the repair order. 	–	Go to the next step.
2	<p>VERIFY RELATED REPAIR INFORMATION AVAILABILITY</p> <ul style="list-style-type: none"> Verify related Service Bulletins and/or on-line repair information availability. Is any related repair information available? 	Yes	Perform repair or diagnosis according to the available repair information. • If the vehicle is not repaired, go to the next step.
		No	Go to the next step.
3	<p>VERIFY RELATED PENDING CODE AND/OR DTC</p> <ul style="list-style-type: none"> Switch the ignition off, then ON (engine off). Perform the Pending Trouble Code Access Procedure and DTC Reading Procedure. (See ON-BOARD DIAGNOSTIC TEST [PCM (SKYACTIV-D 2.2)].) Are any other PENDING CODEs and/or DTCs present? 	Yes	Go to the applicable PENDING CODE or DTC inspection. (See DTC TABLE [PCM (SKYACTIV-D 2.2)] .)
		No	Go to the next step.
4	<p>INSPECT APP SENSOR CONNECTOR CONDITION</p> <ul style="list-style-type: none"> Switch the ignition off. Disconnect the APP sensor connector. Inspect for poor connection (such as damaged/pulled-out pins, corrosion). Is there any malfunction? 	Yes	Repair or replace the connector and/or terminals, then go to Step 14.
		No	Go to the next step.
5	<p>INSPECT CMP SENSOR CONNECTOR CONDITION</p> <ul style="list-style-type: none"> Disconnect the CMP sensor connector. Inspect for poor connection (such as damaged/pulled-out pins, corrosion). Is there any malfunction? 	Yes	Repair or replace the connector and/or terminals, then go to Step 14.
		No	Go to the next step.
6	<p>INSPECT EGR COOLER BYPASS VALVE CONNECTOR CONDITION</p> <ul style="list-style-type: none"> Disconnect the EGR cooler bypass valve connector. Inspect for poor connection (such as damaged/pulled-out pins, corrosion). Is there any malfunction? 	Yes	Repair or replace the connector and/or terminals, then go to Step 14.
		No	Go to the next step.
7	<p>INSPECT EGR VALVE CONNECTOR CONDITION</p> <ul style="list-style-type: none"> Disconnect the EGR valve connector. Inspect for poor connection (such as damaged/pulled-out pins, corrosion). Is there any malfunction? 	Yes	Repair or replace the connector and/or terminals, then go to Step 14.
		No	Go to the next step.
8	<p>INSPECT INTAKE SHUTTER VALVE CONNECTOR CONDITION</p> <ul style="list-style-type: none"> Disconnect the intake shutter valve connector. Inspect for poor connection (such as damaged/pulled-out pins, corrosion). Is there any malfunction? 	Yes	Repair or replace the connector and/or terminals, then go to Step 14.
		No	Go to the next step.

DTC P06DB:00 [PCM (SKYACTIV-D 2.2)]

SM2896079

id0102j521390

DTC P06DB:00	Engine oil solenoid valve circuit low input
DETECTION CONDITION	<div><div>• If the PCM detects that the engine oil solenoid valve voltage at the PCM terminal 1CH is below specified value for 5 s with the following condition met, the PCM determines that the engine oil solenoid valve circuit voltage is low.</div><div><div>MONITORING CONDITIONS</div><div>— Battery voltage: 8 V or more</div></div><div><div>Diagnostic support note</div><div>• This is a continuous monitor (CCM).</div><div>• The check engine light illuminates if the PCM detects the above malfunction condition during the first drive cycle.</div><div>• FREEZE FRAME DATA/Snapshot data is available.</div><div>• DTC is stored in the PCM memory.</div></div></div>
FAIL-SAFE FUNCTION	<div>• Limits the engine torque or the upper limit of the engine speed.</div>
POSSIBLE CAUSE	<div><div>• Engine oil solenoid valve connector or terminals malfunction</div><div>• Short to ground or open circuit in engine oil solenoid valve power supply circuit</div><div>— Short to ground in wiring harness between ENGINE1 15 A fuse and engine oil solenoid valve terminal A</div><div>— ENGINE1 15 A fuse malfunction</div><div>— Open circuit in wiring harness between main relay terminal C and engine oil solenoid valve terminal A</div><div>• PCM connector or terminals malfunction</div><div>• Short to ground in wiring harness between engine oil solenoid valve terminal B and PCM terminal 1CH</div><div>• Open circuit in wiring harness between engine oil solenoid valve terminal B and PCM terminal 1CH</div><div>• Engine oil solenoid valve malfunction</div><div>• PCM malfunction</div></div>