

# Your Ultimate Source for OEM Repair Manuals

FactoryManuals.net is a great resource for anyone who wants to save money on repairs by doing their own work. The manuals provide detailed instructions and diagrams that make it easy to understand how to fix a vehicle.

## 1979 MAZDA RX-7 (SA/FB) OEM Service and Repair Workshop Manual

[Go to manual page](#)

STEP	INSPECTION	RESULTS	ACTION
6	<b>INSPECT ENGINE OIL SOLENOID VALVE CONTROL CIRCUIT FOR SHORT TO GROUND</b> <ul style="list-style-type: none"> <li>• Verify that the engine oil solenoid valve and PCM connectors are disconnected.</li> <li>• Inspect for continuity between engine oil solenoid valve terminal B (wiring harness-side) and body ground.</li> <li>• Is there continuity?</li> </ul>	Yes	Refer to the wiring diagram and verify whether or not there is a common connector between engine oil solenoid valve terminal B and PCM terminal 1CH. <b>If there is a common connector:</b> <ul style="list-style-type: none"> <li>• Determine the malfunctioning part by inspecting the common connector and the terminal for corrosion, damage, or pin disconnection, and the common wiring harness for a short to ground.</li> <li>• Repair or replace the malfunctioning part.</li> </ul> <b>If there is no common connector:</b> <ul style="list-style-type: none"> <li>• Repair or replace the wiring harness which has a short to ground.</li> </ul> Go to Step 9.
		No	Go to the next step.
7	<b>INSPECT ENGINE OIL SOLENOID VALVE CONTROL CIRCUIT FOR OPEN CIRCUIT</b> <ul style="list-style-type: none"> <li>• Verify that the engine oil solenoid valve and PCM connectors are disconnected.</li> <li>• Inspect for continuity between engine oil solenoid valve terminal B (wiring harness-side) and PCM terminal 1CH (wiring harness-side).</li> <li>• Is there continuity?</li> </ul>	Yes	Go to the next step.
		No	Refer to the wiring diagram and verify whether or not there is a common connector between engine oil solenoid valve terminal B and PCM terminal 1CH. <b>If there is a common connector:</b> <ul style="list-style-type: none"> <li>• Determine the malfunctioning part by inspecting the common connector and the terminal for corrosion, damage, or pin disconnection, and the common wiring harness for an open circuit.</li> <li>• Repair or replace the malfunctioning part.</li> </ul> <b>If there is no common connector:</b> <ul style="list-style-type: none"> <li>• Repair or replace the wiring harness which has an open circuit.</li> </ul> Go to Step 9.
8	<b>INSPECT ENGINE OIL SOLENOID VALVE</b> <ul style="list-style-type: none"> <li>• Inspect the engine oil solenoid valve. (See <b>ENGINE OIL SOLENOID VALVE INSPECTION [SKYACTIV-D 2.2].</b>)</li> <li>• Is there any malfunction?</li> </ul>	Yes	Replace the engine oil solenoid valve, then go to the next step. (See <b>ENGINE OIL SOLENOID VALVE REMOVAL/INSTALLATION [SKYACTIV-D 2.2].</b> )
		No	Go to the next step.
9	<b>VERIFY DTC TROUBLESHOOTING COMPLETED</b> <ul style="list-style-type: none"> <li>• Always reconnect all disconnected connectors.</li> <li>• Clear the DTC from the PCM memory using the M-MDS. (See <b>CLEARING DTC [PCM (SKYACTIV-D 2.2)].</b>)</li> <li>• Perform the KOEO or KOER self test. (See <b>KOEO/KOER SELF TEST [PCM (SKYACTIV-D 2.2)].</b>)</li> <li>• Is the same DTC present?</li> </ul>	Yes	Repeat the inspection from Step 1. <ul style="list-style-type: none"> <li>• If the malfunction recurs, replace the PCM. (See <b>PCM REMOVAL/INSTALLATION [SKYACTIV-D 2.2].</b>)</li> </ul> Go to the next step.
		No	Go to the next step.
10	<b>VERIFY AFTER REPAIR PROCEDURE</b> <ul style="list-style-type: none"> <li>• Perform the "AFTER REPAIR PROCEDURE". (See <b>AFTER REPAIR PROCEDURE [PCM (SKYACTIV-D 2.2)].</b>)</li> <li>• Are any DTCs present?</li> </ul>	Yes	Go to the applicable DTC inspection. (See <b>DTC TABLE [PCM (SKYACTIV-D 2.2)].</b> )
		No	DTC troubleshooting completed.

STEP	INSPECTION	RESULTS	ACTION
7	<b>VERIFY DTC TROUBLESHOOTING COMPLETED</b> <ul style="list-style-type: none"> <li>• Always reconnect all disconnected connectors.</li> <li>• Clear the DTC from the PCM memory using the M-MDS. (See <b>CLEARING DTC [PCM (SKYACTIV-D 2.2)]</b>.)</li> <li>• Perform the KOEO or KOER self test. (See <b>KOEO/KOER SELF TEST [PCM (SKYACTIV-D 2.2)]</b>.)</li> <li>• Is the same DTC present?</li> </ul>	Yes	Repeat the inspection from Step 1. <ul style="list-style-type: none"> <li>• If the malfunction recurs, replace the PCM. (See <b>PCM REMOVAL/INSTALLATION [SKYACTIV-D 2.2]</b>.)</li> </ul> Go to the next step.
		No	Go to the next step.
8	<b>VERIFY AFTER REPAIR PROCEDURE</b> <ul style="list-style-type: none"> <li>• Perform the “AFTER REPAIR PROCEDURE”. (See <b>AFTER REPAIR PROCEDURE [PCM (SKYACTIV-D 2.2)]</b>.)</li> <li>• Are any DTCs present?</li> </ul>	Yes	Go to the applicable DTC inspection. (See <b>DTC TABLE [PCM (SKYACTIV-D 2.2)]</b> .)
		No	DTC troubleshooting completed.

STEP	INSPECTION	ACTION
7	<b>VERIFY DTC TROUBLESHOOTING COMPLETED</b> <ul style="list-style-type: none"> <li>• Always reconnect all disconnected connectors.</li> <li>• Clear the DTC from the PCM memory using the M-MDS. (See <b>CLEARING DTC [PCM (SKYACTIV-D 2.2)]</b>.)</li> <li>• Perform the KOEO self test. (See <b>KOEO/KOER SELF TEST [PCM (SKYACTIV-D 2.2)]</b>.)</li> <li>• Is the same DTC present?</li> </ul>	Yes  Repeat the inspection from Step 1. • If the malfunction recurs, replace the PCM. (See <b>PCM REMOVAL/INSTALLATION [SKYACTIV-D 2.2]</b> .) Go to the next step.
		No  Go to the next step.
8	<b>VERIFY AFTER REPAIR PROCEDURE</b> <ul style="list-style-type: none"> <li>• Perform the "AFTER REPAIR PROCEDURE". (See <b>AFTER REPAIR PROCEDURE [PCM (SKYACTIV-D 2.2)]</b>.)</li> <li>• Are any DTCs present?</li> </ul>	Yes  Go to the applicable DTC inspection. (See <b>DTC TABLE [PCM (SKYACTIV-D 2.2)]</b> .)
		No  DTC troubleshooting completed.

DTC P2118:00 [PCM (SKYACTIV-D 2.2)]

SM2896083

id0102j521450

DTC P2118:00	Intake shutter valve control duty signal error
DETECTION CONDITION	<ul style="list-style-type: none"><li>When any of the following conditions are met:<ul style="list-style-type: none"><li>The intake air shutter valve control duty value is 90 % for a continuous 2.2 s.<ul style="list-style-type: none"><li>Intake air shutter valve is operating</li></ul></li><li>Difference between actual opening angle and target opening angle of intake air shutter valve is larger than 4.2 ° for a continuous 2 s<ul style="list-style-type: none"><li>Battery voltage: 8 V or more</li><li>Intake air shutter valve is operating</li><li>Target opening angle of intake air shutter valve: 75 ° or less</li></ul></li><li>Difference between actual opening angle and target opening angle of intake air shutter valve is smaller than -4.2 ° for a continuous 2 s<ul style="list-style-type: none"><li>Battery voltage: 8 V or more</li><li>Intake air shutter valve is operating</li><li>Target opening angle of intake air shutter valve: 10 ° or more</li></ul></li></ul></li></ul> <p><b>Diagnostic support note</b></p> <ul style="list-style-type: none"><li>This is a continuous monitor (CCM).</li><li>The check engine light illuminates if the PCM detects the above malfunction condition during the first drive cycle.</li><li>FREEZE FRAME DATA/Snapshot data is available.</li><li>DTC is stored in the PCM memory.</li></ul>
FAIL-SAFE FUNCTION	<ul style="list-style-type: none"><li>Inhibits the automatic diesel particulate filter regeneration control/compulsory diesel particulate filter regeneration control.</li><li>Inhibits the DENOx/DESOx control.</li><li>Fully opens the intake shutter valve opening angle.</li><li>Inhibits the EGR control.</li><li>PCM restricts engine-transaxle integration control.</li></ul>
POSSIBLE CAUSE	<ul style="list-style-type: none"><li>Intake shutter valve connector or terminals malfunction</li><li>Open circuit in wiring harness between the following terminals:<ul style="list-style-type: none"><li>Intake shutter valve terminal A and PCM terminal 1AS</li><li>Intake shutter valve terminal B and PCM terminal 1AX</li></ul></li><li>Intake shutter valve sticking, operation malfunction</li><li>Intake shutter valve freezing</li><li>Intake shutter valve foreign matter penetration</li><li>PCM connector or terminals malfunction</li><li>Intake shutter valve malfunction</li><li>Intake shutter valve position sensor malfunction</li><li>PCM malfunction</li></ul>

STEP	INSPECTION	ACTION
9	<b>VERIFY DTC TROUBLESHOOTING COMPLETED</b> <ul style="list-style-type: none"> <li>• Always reconnect all disconnected connectors.</li> <li>• Clear the DTC from the PCM memory using the M-MDS. (See <b>AFTER REPAIR PROCEDURE [PCM (SKYACTIV-D 2.2)]</b>.)</li> <li>• Start the engine and idle it.</li> <li>• Wait until the ECT PID value is above 80 °C {176 °F}.</li> <li>• Wait for 1 min (idle).</li> <li>• Perform the Pending Trouble Code Access Procedure. (See <b>ON-BOARD DIAGNOSTIC TEST [PCM (SKYACTIV-D 2.2)]</b>.)</li> <li>• Is the PENDING CODE for this DTC present?</li> </ul>	Yes  Repeat the inspection from Step 1. • If the malfunction recurs, replace the PCM. (See <b>PCM REMOVAL/INSTALLATION [SKYACTIV-D 2.2]</b> .) Go to the next step.
		No  Go to the next step.
10	<b>VERIFY AFTER REPAIR PROCEDURE</b> <ul style="list-style-type: none"> <li>• Perform the "AFTER REPAIR PROCEDURE". (See <b>AFTER REPAIR PROCEDURE [PCM (SKYACTIV-D 2.2)]</b>.)</li> <li>• Are any DTCs present?</li> </ul>	Yes  Go to the applicable DTC inspection. (See <b>DTC TABLE [PCM (SKYACTIV-D 2.2)]</b> .)
		No  DTC troubleshooting completed.

## SM2896159

id0102j538520

DTC P10C2:00	Fuel pressure sensor No.1 (built-into fuel injector No.1) circuit low input
DETECTION CONDITION	<ul style="list-style-type: none"> <li>• If the PCM detects the fuel pressure sensor No.1 (built-into fuel injector No.1) voltage at the PCM terminal 1AG is 0.55 V or less for 0.7 s with the following condition met, the PCM determines that the fuel pressure sensor No.1 (built-into fuel injector No.1) circuit voltage is low.</li> </ul> <p><b>MONITORING CONDITIONS</b></p> <ul style="list-style-type: none"> <li>— Battery voltage: 8 V or more</li> <li>— Cylinder identification (initialization) for fuel injector installation is not performed directly after ignition is switched ON</li> </ul> <p><b>Diagnostic support note</b></p> <ul style="list-style-type: none"> <li>• This is a continuous monitor (CCM).</li> <li>• The check engine light illuminates if the PCM detects the above malfunction condition during the first drive cycle.</li> <li>• FREEZE FRAME DATA/Snapshot data is available.</li> <li>• DTC is stored in the PCM memory.</li> </ul>
FAIL-SAFE FUNCTION	<ul style="list-style-type: none"> <li>• Inhibits the DENOX/DESOx control.</li> </ul>
POSSIBLE CAUSE	<ul style="list-style-type: none"> <li>• Fuel injector No.1 connectors or terminals malfunction</li> <li>• PCM connector or terminals malfunction</li> <li>• Open circuit in wiring harness between fuel injector No.1 terminal C and PCM terminal 1M</li> <li>• Short to ground in wiring harness between the following terminals:             <ul style="list-style-type: none"> <li>— Fuel injector No.1 terminal C–PCM terminal 1M</li> <li>— Fuel injector No.1 terminal B–PCM terminal 1AG</li> </ul> </li> <li>• Fuel pressure sensor No.1 (built-into fuel injector No.1) circuits are shorted to each other</li> <li>• Fuel pressure sensor No.1 (built-into fuel injector No.1) malfunction</li> <li>• PCM malfunction</li> </ul>

STEP	INSPECTION	RESULTS	ACTION
7	<b>INSPECT FUEL PRESSURE SENSOR No.1 CIRCUITS FOR SHORT TO EACH OTHER</b> <ul style="list-style-type: none"> <li>• Verify that the fuel injector No.1 and PCM connectors are disconnected.</li> <li>• Inspect for continuity fuel injector No.1 terminals D, B and A (wiring harness-side).</li> <li>• Is there continuity?</li> </ul>	Yes	Refer to the wiring diagram and verify whether or not there is a common connector between the following terminals: <ul style="list-style-type: none"> <li>• Fuel injector No.1 terminal D–PCM terminal 1T</li> <li>• Fuel injector No.1 terminal B–PCM terminal 1AG</li> <li>• Fuel injector No.1 terminal A–PCM terminal 1R</li> </ul> <b>If there is a common connector:</b> <ul style="list-style-type: none"> <li>• Determine the malfunctioning part by inspecting the common connector and the terminal for corrosion, damage, or pin disconnection, and the common wiring harness for a short to each other.</li> <li>• Repair or replace the malfunctioning part.</li> </ul> <b>If there is no common connector:</b> <ul style="list-style-type: none"> <li>• Repair or replace the wiring harness which has a short to each other.</li> </ul> Go to Step 9.
		No	Go to the next step.
8	<b>INSPECT FUEL PRESSURE SENSOR No.1</b> <ul style="list-style-type: none"> <li>• Inspect the fuel pressure sensor No.1. (See <b>FUEL PRESSURE SENSOR INSPECTION [SKYACTIV-D 2.2].</b>)</li> <li>• Is there any malfunction?</li> </ul>	Yes	Replace the fuel injector No.1, then go to the next step. (See <b>FUEL INJECTOR REMOVAL/INSTALLATION [SKYACTIV-D 2.2].</b> )
		No	Go to the next step.
9	<b>VERIFY DTC TROUBLESHOOTING COMPLETED</b> <ul style="list-style-type: none"> <li>• Always reconnect all disconnected connectors.</li> <li>• Clear the DTC from the PCM memory using the M-MDS. (See <b>CLEARING DTC [PCM (SKYACTIV-D 2.2)].</b>)</li> <li>• Perform the KOEO or KOER self test. (See <b>KOEO/KOER SELF TEST [PCM (SKYACTIV-D 2.2)].</b>)</li> <li>• Is the same DTC present?</li> </ul>	Yes	Repeat the inspection from Step 1. <ul style="list-style-type: none"> <li>• If the malfunction recurs, replace the PCM. (See <b>PCM REMOVAL/INSTALLATION [SKYACTIV-D 2.2].</b>)</li> </ul> Go to the next step.
		No	Go to the next step.
10	<b>VERIFY AFTER REPAIR PROCEDURE</b> <ul style="list-style-type: none"> <li>• Perform the “AFTER REPAIR PROCEDURE”. (See <b>AFTER REPAIR PROCEDURE [PCM (SKYACTIV-D 2.2)].</b>)</li> <li>• Are any DTCs present?</li> </ul>	Yes	Go to the applicable DTC inspection. (See <b>DTC TABLE [PCM (SKYACTIV-D 2.2)].</b> )
		No	DTC troubleshooting completed.



STEP	INSPECTION	RESULTS	ACTION
1	<p><b>RECORD VEHICLE STATUS AT TIME OF DTC DETECTION TO UTILIZE WITH REPEATABILITY VERIFICATION</b></p> <p><b>Note</b></p> <ul style="list-style-type: none"> <li>• Recording can be facilitated using the screen capture function of the PC.</li> <li>• Record the FREEZE FRAME DATA/snapshot data on the repair order.</li> </ul>	–	Go to the next step.
2	<p><b>VERIFY RELATED REPAIR INFORMATION AVAILABILITY</b></p> <ul style="list-style-type: none"> <li>• Verify related Service Bulletins and/or on-line repair information availability.</li> <li>• Is any related repair information available?</li> </ul>	Yes	Perform repair or diagnosis according to the available repair information. • If the vehicle is not repaired, go to the next step.
		No	Go to the next step.
3	<p><b>INSPECT FUEL INJECTOR No.1 CONNECTOR CONDITION</b></p> <ul style="list-style-type: none"> <li>• Switch the ignition off.</li> <li>• Disconnect the fuel injector No.1 connector.</li> <li>• Inspect for poor connection (such as damaged/pulled-out pins, corrosion).</li> <li>• Is there any malfunction?</li> </ul>	Yes	Repair or replace the connector and/or terminals, then go to Step 9.
		No	Go to the next step.
4	<p><b>INSPECT PCM CONNECTOR CONDITION</b></p> <ul style="list-style-type: none"> <li>• Disconnect the PCM connector.</li> <li>• Inspect for poor connection (such as damaged/pulled-out pins, corrosion).</li> <li>• Is there any malfunction?</li> </ul>	Yes	Repair or replace the connector and/or terminals, then go to Step 9.
		No	Go to the next step.
5	<p><b>INSPECT FUEL PRESSURE SENSOR No.1 GROUND CIRCUIT FOR OPEN CIRCUIT</b></p> <ul style="list-style-type: none"> <li>• Verify that the fuel injector No.1 and PCM connectors are disconnected.</li> <li>• Inspect for continuity between the following temials (wiring harness-side):</li> </ul> <ul style="list-style-type: none"> <li>— Fuel injector No.1 terminal B–PCM terminal 1AG</li> <li>— Fuel injector No.1 terminal A–PCM terminal 1R</li> </ul> <ul style="list-style-type: none"> <li>• Is there continuity?</li> </ul>	Yes	Go to the next step.
		No	<p>Refer to the wiring diagram and verify whether or not there is a common connector between the following terminals:</p> <ul style="list-style-type: none"> <li>• Fuel injector No.1 terminal B–PCM terminal 1AG</li> <li>• Fuel injector No.1 terminal A–PCM terminal 1R</li> </ul> <p><b>If there is a common connector:</b></p> <ul style="list-style-type: none"> <li>• Determine the malfunctioning part by inspecting the common connector and the terminal for corrosion, damage, or pin disconnection, and the common wiring harness for an open circuit.</li> <li>• Repair or replace the malfunctioning part.</li> </ul> <p><b>If there is no common connector:</b></p> <ul style="list-style-type: none"> <li>• Repair or replace the wiring harness which has an open circuit.</li> </ul> <p>Go to Step 9.</p>

DTC P10C5:00 [PCM (SKYACTIV-D 2.2)]

SM2896162

id0102j538550

DTC P10C5:00	Fuel pressure sensor No.2 (built-into fuel injector No.2) circuit low input
DETECTION CONDITION	<div><div><div>• If the PCM detects the fuel pressure sensor No.2 (built-into fuel injector No.2) voltage at the PCM terminal 1BL is 0.55 V or less for 0.7 s with the following condition met, the PCM determines that the fuel pressure sensor No.2 (built-into fuel injector No.2) circuit voltage is low.</div><div><div>MONITORING CONDITIONS</div><div><div>— Battery voltage: 8 V or more</div><div>— Cylinder identification (initialization) for fuel injector installation is not performed directly after ignition is switched ON</div></div></div><div><div>Diagnostic support note</div><div><div>• This is a continuous monitor (CCM).</div><div>• The check engine light illuminates if the PCM detects the above malfunction condition during the first drive cycle.</div><div>• FREEZE FRAME DATA/Snapshot data is available.</div><div>• DTC is stored in the PCM memory.</div></div></div></div></div>
FAIL-SAFE FUNCTION	<div><div>• Limits the engine torque or the upper limit of the engine speed.</div><div>• Inhibits the automatic diesel particulate filter regeneration control and compulsory diesel particulate filter regeneration control.</div><div>• Inhibits the DENOx/DESOx control.</div><div>• Inhibits the EGR control.</div><div>• PCM restricts engine-transaxle integration control.</div></div>
POSSIBLE CAUSE	<div><div><div>• Fuel injector No.2 connectors or terminals malfunction</div><div>• PCM connector or terminals malfunction</div><div>• Open circuit in wiring harness between fuel injector No.2 terminal C and PCM terminal 1BX</div><div>• Short to ground in wiring harness between the following terminals:</div><div><div>— Fuel injector No.2 terminal C-PCM terminal 1BX</div><div>— Fuel injector No.2 terminal B-PCM terminal 1BL</div></div></div><div><div>• Fuel pressure sensor No.2 (built-into fuel injector No.2) circuits are shorted to each other</div><div>• Fuel pressure sensor No.2 (built-into fuel injector No.2) malfunction</div><div>• PCM malfunction</div></div></div>