

Your Ultimate Source for OEM Repair Manuals

FactoryManuals.net is a great resource for anyone who wants to save money on repairs by doing their own work. The manuals provide detailed instructions and diagrams that make it easy to understand how to fix a vehicle.

1984 MAZDA RX-7 (SA/FB) OEM Service and Repair Workshop Manual

[Go to manual page](#)

STEP	INSPECTION		ACTION
1	RECORD VEHICLE STATUS AT TIME OF DTC DETECTION TO UTILIZE WITH REPEATABILITY VERIFICATION Note <ul style="list-style-type: none"> Recording can be facilitated using the screen capture function of the PC. Record the FREEZE FRAME DATA/snapshot data and DIAGNOSTIC MONITORING TEST RESULTS (fuel system related) on the repair order. 	–	Go to the next step.
2	VERIFY RELATED REPAIR INFORMATION AVAILABILITY <ul style="list-style-type: none"> Verify related Service Bulletins and/or on-line repair information availability. Is any related repair information available? 	Yes	Perform repair or diagnosis according to the available repair information. • If the vehicle is not repaired, go to the next step.
		No	Go to the next step.
3	VERIFY RELATED PENDING CODE AND/OR DTC <ul style="list-style-type: none"> Switch the ignition off, then ON (engine off). Perform the Pending Trouble Code Access Procedure and DTC Reading Procedure. (See ON-BOARD DIAGNOSTIC TEST [PCM (SKYACTIV-D 2.2)].) Are any other PENDING CODEs and/or DTCs present? 	Yes	Go to the applicable PENDING CODE or DTC inspection. (See DTC TABLE [PCM (SKYACTIV-D 2.2)] .)
		No	Go to the next step.
4	INSPECT FUEL FILTER <ul style="list-style-type: none"> Inspect the fuel filter for clogging. (See FUEL FILTER INSPECTION [SKYACTIV-D 2.2].) Is there any malfunction? 	Yes	Repair or replace the malfunctioning part according to the inspection results, then go to Step 9. (See FUEL FILTER REMOVAL/INSTALLATION [SKYACTIV-D 2.2] .)
		No	Go to the next step.
5	INSPECT FUEL PRESSURE RELIEF VALVE <ul style="list-style-type: none"> Inspect the fuel pressure relief valve. (See FUEL PRESSURE RELIEF VALVE INSPECTION [SKYACTIV-D 2.2].) Is there any malfunction? 	Yes	Replace the common rail, then go to Step 9. (See COMMON RAIL REMOVAL/INSTALLATION [SKYACTIV-D 2.2] .)
		No	Go to the next step.
6	INSPECT SUCTION CONTROL VALVE <ul style="list-style-type: none"> Inspect the suction control valve. (See SUCTION CONTROL VALVE INSPECTION [SKYACTIV-D 2.2].) Is there any malfunction? 	Yes	Replace the suction control valve, then go to Step 9. (See SUCTION CONTROL VALVE REMOVAL/INSTALLATION [SKYACTIV-D 2.2] .)
		No	Go to the next step.
7	INSPECT SUPPLY PUMP <ul style="list-style-type: none"> Inspect the supply pump. (See SUPPLY PUMP INSPECTION [SKYACTIV-D 2.2].) Is there any malfunction? 	Yes	Replace the supply pump, then go to the Step 9. (See SUPPLY PUMP REMOVAL/INSTALLATION [SKYACTIV-D 2.2] .)
		No	Go to the next step.
8	INSPECT FUEL PRESSURE SENSOR <ul style="list-style-type: none"> Inspect the fuel pressure sensor No.2 and fuel pressure sensor No.3. (See FUEL PRESSURE SENSOR INSPECTION [SKYACTIV-D 2.2].) Is there any malfunction? 	Yes	Replace the fuel injector No.2 and/or fuel injector No.3, then go to the next step. (See FUEL INJECTOR REMOVAL/INSTALLATION [SKYACTIV-D 2.2] .)
		No	Go to the next step.


STEP	INSPECTION	RESULTS	ACTION
1	<p>RECORD VEHICLE STATUS AT TIME OF DTC DETECTION TO UTILIZE WITH REPEATABILITY VERIFICATION</p> <p>Note</p> <ul style="list-style-type: none"> Recording can be facilitated using the screen capture function of the PC. Record the snapshot data on the repair order. 	–	Go to the next step.
2	<p>VERIFY RELATED REPAIR INFORMATION AVAILABILITY</p> <ul style="list-style-type: none"> Verify related Service Bulletins and/or on-line repair information availability. Is any related repair information available? 	Yes	Perform repair or diagnosis according to the available repair information.
		No	Go to the next step.
3	<p>INSPECT AMBIENT TEMPERATURE SENSOR CONNECTOR CONDITION</p> <ul style="list-style-type: none"> Switch the ignition off. Disconnect the ambient temperature sensor connector. Inspect for poor connection (such as damaged/pulled-out pins, corrosion). Is there any malfunction? 	Yes	Repair or replace the connector and/or terminals, then go to Step 8.
		No	Go to the next step.
4	<p>INSPECT PCM CONNECTOR CONDITION</p> <ul style="list-style-type: none"> Disconnect the PCM connector. Inspect for poor connection (such as damaged/pulled-out pins, corrosion). Is there any malfunction? 	Yes	Repair or replace the connector and/or terminals, then go to Step 8.
		No	Go to the next step.
5	<p>INSPECT AMBIENT TEMPERATURE SENSOR SIGNAL CIRCUIT FOR SHORT TO POWER SUPPLY</p> <ul style="list-style-type: none"> Verify that the ambient temperature sensor and PCM connectors are disconnected. Switch the ignition ON (engine off). <p>Note</p> <ul style="list-style-type: none"> Another DTC may be stored by the PCM detecting an open circuit. Measure the voltage at the ambient temperature sensor terminal A (wiring harness-side). Is the voltage 0 V? 	Yes	Go to the next step.
		No	Refer to the wiring diagram and verify whether or not there is a common connector between ambient temperature sensor terminal A and PCM terminal 2AX. If there is a common connector: <ul style="list-style-type: none">Determine the malfunctioning part by inspecting the common connector and the terminal for corrosion, damage, or pin disconnection, and the common wiring harness for a short to power supply.Repair or replace the malfunctioning part. If there is no common connector: <ul style="list-style-type: none">Repair or replace the wiring harness which has a short to power supply. Go to Step 8.
6	<p>INSPECT AMBIENT TEMPERATURE SENSOR CIRCUIT FOR OPEN CIRCUIT</p> <ul style="list-style-type: none"> Verify that the ambient temperature sensor and PCM connectors are disconnected. Switch the ignition off. Inspect for continuity between the following terminals (wiring harness-side): <ul style="list-style-type: none"> — Ambient temperature sensor terminal A–PCM terminal 2AX — Ambient temperature sensor terminal B–PCM terminal 2AY <ul style="list-style-type: none"> Is there continuity? 	Yes	Go to the next step.
		No	Refer to the wiring diagram and verify whether or not there is a common connector between the following terminals: <ul style="list-style-type: none">Ambient temperature sensor terminal A–PCM terminal 2AXAmbient temperature sensor terminal B–PCM terminal 2AY If there is a common connector: <ul style="list-style-type: none">Determine the malfunctioning part by inspecting the common connector and the terminal for corrosion, damage, or pin disconnection, and the common wiring harness for an open circuit.Repair or replace the malfunctioning part. If there is no common connector: <ul style="list-style-type: none">Repair or replace the wiring harness which has an open circuit. Go to Step 8.

STEP	INSPECTION		ACTION
2	VERIFY RELATED REPAIR INFORMATION AVAILABILITY <ul style="list-style-type: none"> • Verify related Service Bulletins and/or on-line repair information availability. • Is any related repair information available? 	Yes	Perform repair or diagnosis according to the available repair information. • If the vehicle is not repaired, go to the next step.
		No	Go to the next step.
3	VERIFY RELATED PENDING CODE AND/OR DTC <ul style="list-style-type: none"> • Switch the ignition off, then ON (engine off). • Perform the Pending Trouble Code Access Procedure and DTC Reading Procedure. (See ON-BOARD DIAGNOSTIC TEST [PCM (SKYACTIV-D 2.2)].) • Are any other PENDING CODEs and/or DTCs present? 	Yes	Go to the applicable PENDING CODE or DTC inspection. (See DTC TABLE [PCM (SKYACTIV-D 2.2)] .)
		No	Go to the next step.
4	INSPECT FUEL PRESSURE RELIEF VALVE <ul style="list-style-type: none"> • Inspect the fuel pressure relief valve. (See FUEL PRESSURE RELIEF VALVE INSPECTION [SKYACTIV-D 2.2].) • Is there any malfunction? 	Yes	Replace the common rail, then go to Step 11. (See COMMON RAIL REMOVAL/INSTALLATION [SKYACTIV-D 2.2] .)
		No	Go to the next step.
5	INSPECT SUCTION CONTROL VALVE <ul style="list-style-type: none"> • Inspect the suction control valve. (See SUCTION CONTROL VALVE INSPECTION [SKYACTIV-D 2.2].) • Is there any malfunction? 	Yes	Replace the suction control valve, then go to Step 11. (See SUCTION CONTROL VALVE REMOVAL/INSTALLATION [SKYACTIV-D 2.2] .)
		No	Go to the next step.
6	INSPECT FUEL PRESSURE SENSOR <ul style="list-style-type: none"> • Inspect the fuel pressure sensor. (See FUEL PRESSURE SENSOR INSPECTION [SKYACTIV-D 2.2].) • Is there any malfunction? 	Yes	Replace the common rail, then go to Step 11. (See COMMON RAIL REMOVAL/INSTALLATION [SKYACTIV-D 2.2] .)
		No	Go to the next step.
7	INSPECT FUEL INJECTOR <ul style="list-style-type: none"> • Inspect the fuel injector. (See FUEL INJECTOR INSPECTION [SKYACTIV-D 2.2].) • Is there any malfunction? 	Yes	Replace the fuel injector, then go to Step 11. (See FUEL INJECTOR REMOVAL/INSTALLATION [SKYACTIV-D 2.2] .)
		No	Go to the next step.
8	INSPECT FUEL PIPE <ul style="list-style-type: none"> • Inspect the fuel pipe installation condition. (See FUEL SYSTEM LOCATION INDEX [SKYACTIV-D 2.2].) • Is there any malfunction? 	Yes	Install the fuel pipe properly, then go to Step 11.
		No	Go to the next step.
9	INSPECT FOR FUEL LEAKAGE FROM FUEL LINE OR CLOGGING <ul style="list-style-type: none"> • Inspect the following fuel line for fuel leakage or clogging. <ul style="list-style-type: none"> — Between supply pump and common rail — Between common rail and fuel injector • Is there any malfunction? 	Yes	Repair or replace the malfunctioning part according to the inspection results then go to Step 11.
		No	Go to the next step.
10	INSPECT SUPPLY PUMP <ul style="list-style-type: none"> • Inspect the supply pump. (See SUPPLY PUMP INSPECTION [SKYACTIV-D 2.2].) • Is there any malfunction? 	Yes	Replace the supply pump, then go to the next step. (See SUPPLY PUMP REMOVAL/INSTALLATION [SKYACTIV-D 2.2] .)
		No	Go to the next step.

STEP	INSPECTION		ACTION
1	RECORD FREEZE FRAME DATA/SNAPSHOT DATA AND DIAGNOSTIC MONITORING TEST RESULTS TO UTILIZE WITH REPEATABILITY VERIFICATION Note <ul style="list-style-type: none"> Recording can be facilitated using the screen capture function of the PC. Record the FREEZE FRAME DATA/snapshot data on the repair order. 	–	Go to the next step.
2	VERIFY RELATED REPAIR INFORMATION AVAILABILITY <ul style="list-style-type: none"> Verify related Service Bulletins and/or on-line repair information availability. Is any related repair information available? 	Yes	Perform repair or diagnosis according to the available repair information. • If the vehicle is not repaired, go to the next step.
		No	Go to the next step.
3	INSPECT WHETHER MALFUNCTION IS WIRING HARNESS OR OTHER <ul style="list-style-type: none"> Perform the KOEO self test. (See KOEO/KOER SELF TEST [PCM (SKYACTIV-D 2.2)].) Is the IAT sensor No.2, Boost air temperature sensor, and/or EGR temperature sensor related DTC present? 	Yes	Go to the applicable DTC inspection. (See DTC TABLE [PCM (SKYACTIV-D 2.2)] .)
		No	Go to the next step.
4	INSPECT IAT SENSOR NO.2 CONNECTOR CONDITION <ul style="list-style-type: none"> Switch the ignition off. Disconnect the IAT sensor No.2 connector. Inspect for poor connection (such as damaged/pulled-out pins, corrosion). Is there any malfunction? 	Yes	Repair or replace the connector and/or terminals, then go to Step 7.
		No	Go to the next step.
5	INSPECT IAT SENSOR NO.2 <ul style="list-style-type: none"> Inspect the IAT sensor No.2. (See INTAKE AIR TEMPERATURE (IAT) SENSOR INSPECTION [SKYACTIV-D 2.2].) Is there any malfunction? 	Yes	Replace the IAT sensor No.2, then go to Step 7. (See INTAKE AIR TEMPERATURE (IAT) SENSOR NO.2 REMOVAL/INSTALLATION [SKYACTIV-D 2.2] .)
		No	Go to the next step.
6	INSPECT PCM CONNECTOR CONDITION <ul style="list-style-type: none"> Disconnect the PCM connector. Inspect for poor connection (such as damaged/pulled-out pins, corrosion). Is there any malfunction? 	Yes	Repair or replace the connector and/or terminals, then go to the next step.
		No	Go to the next step.
7	VERIFY DTC TROUBLESHOOTING COMPLETED <ul style="list-style-type: none"> Always reconnect all disconnected connectors. Clear the DTC from the PCM memory using the M-MDS. (See AFTER REPAIR PROCEDURE [PCM (SKYACTIV-D 2.2)].) Leave the vehicle for 6 hours or more. Start the engine and idle it for 1 min. Perform the Pending Trouble Code Access Procedure. (See ON-BOARD DIAGNOSTIC TEST [PCM (SKYACTIV-D 2.2)].) Is the PENDING CODE for this DTC present? 	Yes	Repeat the inspection from Step 1. • If the malfunction recurs, replace the PCM. (See PCM REMOVAL/INSTALLATION [SKYACTIV-D 2.2] .) Go to the next step.
		No	Go to the next step.
8	VERIFY AFTER REPAIR PROCEDURE <ul style="list-style-type: none"> Perform the "AFTER REPAIR PROCEDURE". (See AFTER REPAIR PROCEDURE [PCM (SKYACTIV-D 2.2)].) Are any DTCs present? 	Yes	Go to the applicable DTC inspection. (See DTC TABLE [PCM (SKYACTIV-D 2.2)] .)
		No	DTC troubleshooting completed.

STEP	INSPECTION	RESULTS	ACTION
6	INSPECT IAT SENSOR No.2 SIGNAL CIRCUIT FOR SHORT TO GROUND <ul style="list-style-type: none"> • Verify that the IAT sensor No.2 and PCM connectors are disconnected. • Inspect for continuity between IAT sensor No.2 terminal A (wiring harness-side) and body ground. • Is there continuity? 	Yes	Refer to the wiring diagram and verify whether or not there is a common connector between IAT sensor No.2 terminal A and PCM terminal 2Q. If there is a common connector: <ul style="list-style-type: none"> • Determine the malfunctioning part by inspecting the common connector and the terminal for corrosion, damage, or pin disconnection, and the common wiring harness for a short to ground. • Repair or replace the malfunctioning part. If there is no common connector: <ul style="list-style-type: none"> • Repair or replace the wiring harness which has a short to ground. Go to Step 8.
		No	Go to the next step.
7	INSPECT IAT SENSOR No.2 SIGNAL CIRCUIT AND GROUND CIRCUIT FOR SHORT TO EACH OTHER <ul style="list-style-type: none"> • Verify that the IAT sensor No.2 and PCM connectors are disconnected. • Inspect for continuity between IAT sensor No.2 terminals A and B (wiring harness-side). • Is there continuity? 	Yes	Refer to the wiring diagram and verify whether or not there is a common connector between the following terminals: <ul style="list-style-type: none"> • IAT sensor No.2 terminal A–PCM terminal 2Q • IAT sensor No.2 terminal B–PCM terminal 2R If there is a common connector: <ul style="list-style-type: none"> • Determine the malfunctioning part by inspecting the common connector and the terminal for corrosion, damage, or pin disconnection, and the common wiring harness for a short to each other. • Repair or replace the malfunctioning part. If there is no common connector: <ul style="list-style-type: none"> • Repair or replace the wiring harness which has a short to each other. Go to the next step.
		No	Go to the next step.
8	VERIFY DTC TROUBLESHOOTING COMPLETED <ul style="list-style-type: none"> • Always reconnect all disconnected connectors. • Clear the DTC from the PCM memory using the M-MDS. (See CLEARING DTC [PCM (SKYACTIV-D 2.2)].) • Perform the KOEO or KOER self test. (See KOEO/KOER SELF TEST [PCM (SKYACTIV-D 2.2)].) • Is the PENDING CODE for this DTC present? 	Yes	Repeat the inspection from Step 1. <ul style="list-style-type: none"> • If the malfunction recurs, replace the PCM. (See PCM REMOVAL/INSTALLATION [SKYACTIV-D 2.2].) Go to the next step.
		No	Go to the next step.
9	VERIFY AFTER REPAIR PROCEDURE <ul style="list-style-type: none"> • Perform the “AFTER REPAIR PROCEDURE”. (See AFTER REPAIR PROCEDURE [PCM (SKYACTIV-D 2.2)].) • Are any DTCs present? 	Yes	Go to the applicable DTC inspection. (See DTC TABLE [PCM (SKYACTIV-D 2.2)] .)
		No	DTC troubleshooting completed.

STEP	INSPECTION		ACTION
3	VERIFY RELATED PENDING CODE AND/OR DTC <ul style="list-style-type: none"> • Switch the ignition off, then ON (engine off). • Perform the Pending Trouble Code Access Procedure and DTC Reading Procedure. (See ON-BOARD DIAGNOSTIC TEST [PCM (SKYACTIV-D 2.2)].) • Are any other PENDING CODEs and/or DTCs present? 	Yes	Go to the applicable PENDING CODE or DTC inspection. (See DTC TABLE [PCM (SKYACTIV-D 2.2)] .)
		No	Go to the next step.
4	INSPECT ENGINE OIL LEAKAGE <ul style="list-style-type: none"> • Start the engine. • Verify that there is no engine oil leakage in the oil passage. • Is there any leakage? 	Yes	Repair or replace the malfunctioning part according to the inspection results, then add genuine engine oil. Go to Step 12.
		No	Go to the next step.
5	INSPECT ENGINE OIL LEVEL <ul style="list-style-type: none"> • Inspect the engine oil level. (See ENGINE OIL LEVEL INSPECTION [SKYACTIV-D 2.2].) • Is the engine oil level sufficient? 	Yes	Go to the next step.
		No	Add genuine engine oil, then go to the next step.
6	INSPECT ENGINE OIL TEMPERATURE SENSOR/ENGINE OIL PRESSURE SENSOR CONNECTOR CONDITION <ul style="list-style-type: none"> • Switch the ignition off. • Disconnect the engine oil temperature sensor/engine oil pressure sensor connector. • Inspect for poor connection (such as damaged/pulled-out pins, corrosion). • Is there any malfunction? 	Yes	Repair or replace the connector and/or terminals, then go to Step 12.
		No	Go to the next step.
7	INSPECT ENGINE OIL PRESSURE SENSOR CIRCUIT FOR SHORT TO GROUND <ul style="list-style-type: none"> • Verify that the engine oil temperature sensor/engine oil pressure sensor connector is disconnected. • Inspect for continuity between the following terminals (wiring harness-side) and body ground: <ul style="list-style-type: none"> — Engine oil temperature sensor/engine oil pressure sensor terminal A — Engine oil temperature sensor/engine oil pressure sensor terminal D • Is there continuity? 	Yes	<p>If the short to ground circuit could be detected in the wiring harness:</p> <ul style="list-style-type: none"> • Refer to the wiring diagram and verify whether or not there is a common connector between the following terminals: <ul style="list-style-type: none"> — Engine oil temperature sensor/engine oil pressure sensor terminal A–PCM terminal 1DN — Engine oil temperature sensor/engine oil pressure sensor terminal D–PCM terminal 1DM <p>If there is a common connector:</p> <ul style="list-style-type: none"> — Determine the malfunctioning part by inspecting the common connector and the terminal for corrosion, damage, or pin disconnection, and the common wiring harness for a short to ground. — Repair or replace the malfunctioning part. <p>If there is no common connector:</p> <ul style="list-style-type: none"> — Repair or replace the wiring harness which has a short to ground. <p>If the short to ground circuit could not be detected in the wiring harness:</p> <ul style="list-style-type: none"> • Replace the PCM (short to ground in the PCM internal circuit). (See PCM REMOVAL/INSTALLATION [SKYACTIV-D 2.2].) <p>Go to Step 12.</p>
			Go to the next step.
		No	Go to the next step.



Diagnostic Procedure

STEP	INSPECTION	ACTION
1	<p>RECORD VEHICLE STATUS AT TIME OF DTC DETECTION TO UTILIZE WITH REPEATABILITY VERIFICATION</p> <p>Note</p> <ul style="list-style-type: none">Recording can be facilitated using the screen capture function of the PC.Record the FREEZE FRAME DATA/snapshot data on the repair order.	<p>Go to the next step.</p>

STEP	INSPECTION	ACTION	
7	INSPECT ENGINE OIL SOLENOID VALVE CIRCUIT AND ENGINE OIL PRESSURE SENSOR CIRCUIT FOR SHORT TO GROUND <ul style="list-style-type: none"> • Verify that the engine oil solenoid valve and engine oil temperature sensor/engine oil pressure sensor connectors are disconnected. • Switch the ignition off. • Inspect for continuity between the following terminals (wiring harness-side) and body ground: <ul style="list-style-type: none"> — Engine oil solenoid valve terminal B — Engine oil temperature sensor/engine oil pressure sensor terminal A — Engine oil temperature sensor/engine oil pressure sensor terminal D • Is there continuity? 	Yes	<p>If the short to ground circuit could be detected in the wiring harness:</p> <ul style="list-style-type: none"> • Refer to the wiring diagram and verify whether or not there is a common connector between the following terminals: <ul style="list-style-type: none"> — Engine oil solenoid valve terminal B–PCM terminal 1CH — Engine oil temperature sensor/engine oil pressure sensor terminal A–PCM terminal 1DN — Engine oil temperature sensor/engine oil pressure sensor terminal D–PCM terminal 1DM <p>If there is a common connector:</p> <ul style="list-style-type: none"> — Determine the malfunctioning part by inspecting the common connector and the terminal for corrosion, damage, or pin disconnection, and the common wiring harness for a short to ground. — Repair or replace the malfunctioning part. <p>If there is no common connector:</p> <ul style="list-style-type: none"> — Repair or replace the wiring harness which has a short to ground. <p>If the short to ground circuit could not be detected in the wiring harness:</p> <ul style="list-style-type: none"> • Replace the PCM (short to ground in the PCM internal circuit). (See PCM REMOVAL/INSTALLATION [SKYACTIV-D 2.2].) <p>Go to Step 12.</p>
		No	Go to the next step.
8	INSPECT PCM CONNECTOR CONDITION <ul style="list-style-type: none"> • Disconnect the PCM connector. • Inspect for poor connection (such as damaged/pulled-out pins, corrosion). • Is there any malfunction? 	Yes	Repair or replace the connector and/or terminals, then go to Step 12.
		No	Go to the next step.
9	INSPECT ENGINE OIL SOLENOID VALVE CIRCUIT AND ENGINE OIL PRESSURE SENSOR CIRCUIT FOR OPEN CIRCUIT <ul style="list-style-type: none"> • Verify that the engine oil solenoid valve and engine oil temperature sensor/engine oil pressure sensor and PCM connectors are disconnected. • Inspect for continuity between the following terminals (wiring harness-side): <ul style="list-style-type: none"> — Engine oil solenoid valve terminal B–PCM terminal 1CH — Engine oil temperature sensor/engine oil pressure sensor terminal A–PCM terminal 1DN • Is there continuity? 	Yes	Go to the next step.
		No	<p>Refer to the wiring diagram and verify whether or not there is a common connector between the following terminals:</p> <ul style="list-style-type: none"> • Engine oil solenoid valve terminal B–PCM terminal 1CH • Engine oil temperature sensor/engine oil pressure sensor terminal A–PCM terminal 1DN <p>If there is a common connector:</p> <ul style="list-style-type: none"> • Determine the malfunctioning part by inspecting the common connector and the terminal for corrosion, damage, or pin disconnection, and the common wiring harness for an open circuit. • Repair or replace the malfunctioning part. <p>If there is no common connector:</p> <ul style="list-style-type: none"> • Repair or replace the wiring harness which has an open circuit. <p>Go to Step 12.</p>

diesel particulate filter regeneration control.

- If the exhaust gas temperature sensor No.3 value is higher than the threshold even though the feedback amount of the fuel injection control post-injection during diesel particulate filter regeneration control reaches the minimum, the PCM determines that the diesel particulate filter regeneration control is not operating normally.
- If the PCM detects the malfunction condition during first drive cycle, a malfunction is determined and a pending code is stored.
- If the PCM determines that the malfunction recurs from the next drive cycle and thereafter, it stores a DTC and turns on the check engine light.

Repeatability Verification Procedure

- Perform diesel particulate filter regeneration. (See [COMPULSORY DIESEL PARTICULATE FILTER REGENERATION \[SKYACTIV-D 2.2\]](#).)

PID Item/Simulation Item Used In Diagnosis

PID/DATA monitor item table

Item	Definition	Unit	Condition/Specification
EXHTEMP2	Exhaust gas temperature sensor No.3	°C, °F	• Displays the exhaust gas temperature (No.3).
O2S11	A/F sensor current	μA	• Idle: Approx. 1.01 mA • Deceleration fuel cut: Approx. 3.84 mA
	A/F sensor voltage	V	• Switch ignition ON (engine off): 3.24 V • Deceleration fuel cut: Approx. 3.74 V

Function Inspection Using M-MDS

STEP	INSPECTION	RESULTS	ACTION
1	PURPOSE: VERIFY RELATED REPAIR INFORMATION AVAILABILITY <ul style="list-style-type: none">• Verify related Service Bulletins and/or on-line repair information availability.• Is any related repair information available?	Yes	Perform repair or diagnosis according to the available repair information. <ul style="list-style-type: none">• If the vehicle is not repaired, go to the next step.
		No	Go to the next step.
2	PURPOSE: IDENTIFY TRIGGER DTC FOR FREEZE FRAME DATA <ul style="list-style-type: none">• Is the DTC P106B:00 on FREEZE FRAME DATA?	Yes	Go to the next step.
		No	Go to the troubleshooting procedure for DTC on FREEZE FRAME DATA. (See DTC TABLE [PCM (SKYACTIV-D 2.2)] .)
3	PURPOSE: RECORD FREEZE FRAME DATA/SNAPSHOT DATA AND DIAGNOSTIC MONITORING TEST RESULTS TO UTILIZE WITH REPEATABILITY VERIFICATION Note <ul style="list-style-type: none">• Recording can be facilitated using the screen capture function of the PC.• Record the FREEZE FRAME DATA/Snapshot data and DIAGNOSTIC MONITORING TEST RESULTS (A/F sensor related) on the repair order.	–	Go to the next step.