

# Your Ultimate Source for OEM Repair Manuals

FactoryManuals.net is a great resource for anyone who wants to save money on repairs by doing their own work. The manuals provide detailed instructions and diagrams that make it easy to understand how to fix a vehicle.

## 1990 MAZDA 323 (BG) Hatchback OEM Service and Repair Workshop Manual

[Go to manual page](#)

DTC No.	Check engine light	Master warning indication/master warning light	Charging system warning indication/charging system warning light	Engine oil warning indication/engine oil warning light	Engine oil level warning indication/Engine oil level warning light	Wrench warning indication	Diesel particulate filter indication/Diesel particulate filter indicator light	Glow Indicator Light	SCR warning indicator/SCR warning light
P10CD:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	OFF	
P10D1:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	OFF	
P10D2:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	OFF	
P10D3:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	OFF	
P10D4:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	OFF	
P10D5:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	OFF	

DTC No.	Check engine light	Master warning indication/master warning light	Charging system warning indication/charging system warning light	Engine oil warning indication/engine oil warning light	Engine oil level warning indication/Engine oil level warning light	Wrench warning indication	Diesel particulate filter indication/Diesel particulate filter indicator light	Glow Indicator Light	SCR warning indicator/CR warning light
P166D:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	OFF	
P166E:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	OFF	
P1905:00	OFF	Indication/illumination	OFF	OFF	OFF	OFF	OFF	OFF	
P2000:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	OFF	
P2031:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	OFF	
P2032:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	OFF	
P2033:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	OFF	
P203F:00	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	0 *9/
P206B:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	OFF	

[illegible]



[illegible]

DTC No.	Check engine light	Master warning indication/master warning light	Charging system warning indication/charging system warning light	Engine oil warning indication/engine oil warning light	Engine oil level warning indication/Engine oil level warning light	Wrench warning indication	Diesel particulate filter indication/Diesel particulate filter indicator light	Glow Indicator Light	SCR warning indicator/SCR warning light
P2A02:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	OFF	
P2BA9:00	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	
P2BAF:00	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	
P3101:00	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	
P3102:00	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	
P3103:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	OFF	
P3104:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	OFF	
P3105:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	OFF	

DTC No.	Check engine light	Master warning indication/master warning light	Charging system warning indication/charging system warning light	Engine oil warning indication/engine oil warning light	Engine oil level warning indication/Engine oil level warning light	Wrench warning indication	Diesel particulate filter indication/Diesel particulate filter indicator light	Glow Indicator Light	SCR warning indicator/CR warning light
U0101:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	OFF	
U0104:00 <sup>*8</sup>	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	
U0106:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	OFF	
U010E:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	OFF	

DTC No.	Check engine light	Master warning indication/master warning light	Charging system warning indication/charging system warning light	Engine oil warning indication/engine oil warning light	Engine oil level warning indication/Engine oil level warning light	Wrench warning indication	Diesel particulate filter indication/Diesel particulate filter indicator light	Glow Indicator Light	SCR warning indicator/SCR warning light
U053B:00	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	
U1100:00	OFF	Indication/illumination <sup>*3</sup>	OFF	OFF	OFF	OFF	OFF	OFF	
U1201:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	OFF	
U1202:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	OFF	
U1203:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	OFF	
U1204:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	OFF	
U2300:00	OFF	Indication/illumination <sup>*3</sup>	OFF	OFF	OFF	OFF	OFF	OFF	

STEP	INSPECTION	RESULTS	ACTION
1	<p><b>RECORD VEHICLE STATUS AT TIME OF DTC DETECTION TO UTILIZE WITH REPEATABILITY VERIFICATION</b></p> <p><b>Note</b></p> <ul style="list-style-type: none"> <li>• Recording can be facilitated using the screen capture function of the PC.</li> <li>• Record the snapshot data on the repair order.</li> </ul>	–	Go to the next step.
2	<p><b>VERIFY RELATED REPAIR INFORMATION AVAILABILITY</b></p> <ul style="list-style-type: none"> <li>• Verify related Service Bulletins and/or on-line repair information availability.</li> <li>• Is any related repair information available?</li> </ul>	Yes	Perform repair or diagnosis according to the available repair information.
		No	Go to the next step.
3	<p><b>INSPECT REFRIGERANT PRESSURE SENSOR CONNECTOR CONDITION</b></p> <ul style="list-style-type: none"> <li>• Switch the ignition off.</li> <li>• Disconnect the refrigerant pressure sensor connector.</li> <li>• Inspect for poor connection (such as damaged/pulled-out pins, corrosion).</li> <li>• Is there any malfunction?</li> </ul>	Yes	Repair or replace the connector and/or terminals, then go to Step 9.
		No	Go to the next step.
4	<p><b>INSPECT PCM CONNECTOR CONDITION</b></p> <ul style="list-style-type: none"> <li>• Disconnect the PCM connector.</li> <li>• Inspect for poor connection (such as damaged/pulled-out pins, corrosion).</li> <li>• Is there any malfunction?</li> </ul>	Yes	Repair or replace the connector and/or terminals, then go to Step 9.
		No	Go to the next step.
5	<p><b>INSPECT REFRIGERANT PRESSURE SENSOR CIRCUIT FOR SHORT TO GROUND</b></p> <ul style="list-style-type: none"> <li>• Verify that the refrigerant pressure sensor and PCM connectors are disconnected.</li> <li>• Inspect for continuity between the following terminals (wiring harness-side) and body ground: <ul style="list-style-type: none"> <li>— Refrigerant pressure sensor terminal A</li> <li>— Refrigerant pressure sensor terminal B</li> </ul> </li> <li>• Is there continuity?</li> </ul>	Yes	<p>Refer to the wiring diagram and verify whether or not there is a common connector between the following terminals:</p> <ul style="list-style-type: none"> <li>• Refrigerant pressure sensor terminal A–PCM terminal 2BB</li> <li>• Refrigerant pressure sensor terminal B–PCM terminal 2BH</li> </ul> <p><b>If there is a common connector:</b></p> <ul style="list-style-type: none"> <li>• Determine the malfunctioning part by inspecting the common connector and the terminal for corrosion, damage, or pin disconnection, and the common wiring harness for a short to ground.</li> <li>• Repair or replace the malfunctioning part.</li> </ul> <p><b>If there is no common connector:</b></p> <ul style="list-style-type: none"> <li>• Repair or replace the wiring harness which has a short to ground.</li> </ul> <p>Go to Step 9.</p>
		No	Go to the next step.

STEP	INSPECTION	RESULTS	ACTION
1	<p><b>RECORD VEHICLE STATUS AT TIME OF DTC DETECTION TO UTILIZE WITH REPEATABILITY VERIFICATION</b></p> <p><b>Note</b></p> <ul style="list-style-type: none"> <li>Recording can be facilitated using the screen capture function of the PC.</li> <li>Record the snapshot data on the repair order.</li> </ul>	–	Go to the next step.
2	<p><b>VERIFY RELATED REPAIR INFORMATION AVAILABILITY</b></p> <ul style="list-style-type: none"> <li>Verify related Service Bulletins and/or on-line repair information availability.</li> <li>Is any related repair information available?</li> </ul>	Yes	Perform repair or diagnosis according to the available repair information.
		No	Go to the next step.
3	<p><b>INSPECT REFRIGERANT PRESSURE SENSOR CONNECTOR CONDITION</b></p> <ul style="list-style-type: none"> <li>Switch the ignition off.</li> <li>Disconnect the refrigerant pressure sensor connector.</li> <li>Inspect for poor connection (such as damaged/pulled-out pins, corrosion).</li> <li>Is there any malfunction?</li> </ul>	Yes	Repair or replace the connector and/or terminals, then go to Step 9.
		No	Go to the next step.
4	<p><b>INSPECT PCM CONNECTOR CONDITION</b></p> <ul style="list-style-type: none"> <li>Disconnect the PCM connector.</li> <li>Inspect for poor connection (such as damaged/pulled-out pins, corrosion).</li> <li>Is there any malfunction?</li> </ul>	Yes	Repair or replace the connector and/or terminals, then go to Step 9.
		No	Go to the next step.
5	<p><b>INSPECT REFRIGERANT PRESSURE SENSOR CIRCUIT FOR SHORT TO POWER SUPPLY</b></p> <ul style="list-style-type: none"> <li>Verify that the refrigerant pressure sensor and PCM connectors are disconnected.</li> <li>Switch the ignition ON (engine off).</li> </ul> <p><b>Note</b></p> <ul style="list-style-type: none"> <li>Another DTC may be stored by the PCM detecting an open circuit.</li> <li>Measure the voltage at the refrigerant pressure sensor terminal B (wiring harness-side).</li> <li>Is the voltage 0 V?</li> </ul>	Yes	Go to the next step.
		No	<p>Refer to the wiring diagram and verify whether or not there is a common connector between refrigerant pressure sensor terminal B and PCM terminal 2BH.</p> <p><b>If there is a common connector:</b></p> <ul style="list-style-type: none"> <li>Determine the malfunctioning part by inspecting the common connector and the terminal for corrosion, damage, or pin disconnection, and the common wiring harness for a short to power supply.</li> <li>Repair or replace the malfunctioning part.</li> </ul> <p><b>If there is no common connector:</b></p> <ul style="list-style-type: none"> <li>Repair or replace the wiring harness which has a short to power supply.</li> </ul> <p>Go to Step 9.</p>
6	<p><b>INSPECT REFRIGERANT PRESSURE SENSOR POWER SUPPLY CIRCUIT AND SIGNAL CIRCUIT FOR SHORT TO EACH OTHER</b></p> <ul style="list-style-type: none"> <li>Verify that the refrigerant pressure sensor and PCM connectors are disconnected.</li> <li>Switch the ignition off.</li> <li>Inspect for continuity between refrigerant pressure sensor terminals A and B (wiring harness-side).</li> <li>Is there continuity?</li> </ul>	Yes	<p>Refer to the wiring diagram and verify whether or not there is a common connector between the following terminals:</p> <ul style="list-style-type: none"> <li>Refrigerant pressure sensor terminal A–PCM terminal 2BB</li> <li>Refrigerant pressure sensor terminal B–PCM terminal 2BH</li> </ul> <p><b>If there is a common connector:</b></p> <ul style="list-style-type: none"> <li>Determine the malfunctioning part by inspecting the common connector and the terminal for corrosion, damage, or pin disconnection, and the common wiring harness for a short to each other.</li> <li>Repair or replace the malfunctioning part.</li> </ul> <p><b>If there is no common connector:</b></p> <ul style="list-style-type: none"> <li>Repair or replace the wiring harness which has a short to each other.</li> </ul> <p>Go to Step 9.</p>
		No	Go to the next step.