


Your Ultimate Source for OEM Repair Manuals

FactoryManuals.net is a great resource for anyone who wants to save money on repairs by doing their own work. The manuals provide detailed instructions and diagrams that make it easy to understand how to fix a vehicle.

1990 MAZDA 626 (Mk.3) Hatchback OEM Service and Repair Workshop Manual


[Go to manual page](#)

STEP	INSPECTION		ACTION
3	VERIFY RELATED PENDING CODE AND/OR DTC <ul style="list-style-type: none"> • Switch the ignition off, then ON (engine off). • Perform the Pending Trouble Code Access Procedure and DTC Reading Procedure. (See ON-BOARD DIAGNOSTIC TEST [PCM (SKYACTIV-D 2.2)].) • Are any other PENDING CODEs and/or DTCs present? 	Yes	Go to the applicable PENDING CODE or DTC inspection. (See DTC TABLE [PCM (SKYACTIV-D 2.2)] .)
		No	Go to the next step.
4	INSPECT EXHAUST GAS PRESSURE SENSOR No.1 CONNECTOR CONDITION <ul style="list-style-type: none"> • Switch the ignition off. • Disconnect the exhaust gas pressure sensor No.1 connector. • Inspect for poor connection (such as damaged/pulled-out pins, corrosion). • Is there any malfunction? 	Yes	Repair or replace the connector and/or terminals, then go to Step 10.
		No	Go to the next step.
5	INSPECT PCM CONNECTOR CONDITION <ul style="list-style-type: none"> • Disconnect the PCM connector. • Inspect for poor connection (such as damaged/pulled-out pins, corrosion). • Is there any malfunction? 	Yes	Repair or replace the connector and/or terminals, then go to Step 10.
		No	Go to the next step.
6	INSPECT EXHAUST GAS PRESSURE SENSOR No.1 SIGNAL CIRCUIT FOR SHORT TO POWER SUPPLY <ul style="list-style-type: none"> • Verify that the exhaust gas pressure sensor No.1 and PCM connectors are disconnected. • Switch the ignition ON (engine off). <p>Note</p> <ul style="list-style-type: none"> • Another DTC may be stored by the PCM detecting an open circuit. • Measure the voltage at the exhaust gas pressure sensor No.1 terminal B (wiring harness-side). • Is the voltage 0 V? 	Yes	Go to the next step.
		No	Refer to the wiring diagram and verify whether or not there is a common connector between exhaust gas pressure sensor No.1 terminal B and PCM terminal 1CE. If there is a common connector: <ul style="list-style-type: none"> • Determine the malfunctioning part by inspecting the common connector and the terminal for corrosion, damage, or pin disconnection, and the common wiring harness for a short to power supply. • Repair or replace the malfunctioning part. If there is no common connector: <ul style="list-style-type: none"> • Repair or replace the wiring harness which has a short to power supply. Go to Step 10.
7	INSPECT EXHAUST GAS PRESSURE SENSOR No.1 POWER SUPPLY CIRCUIT AND SIGNAL CIRCUIT FOR SHORT TO EACH OTHER <ul style="list-style-type: none"> • Verify that the exhaust gas pressure sensor No.1 and PCM connectors are disconnected. • Switch the ignition off. • Inspect for continuity between exhaust gas pressure sensor No.1 terminals A and B (wiring harness-side). • Is there continuity? 	Yes	Refer to the wiring diagram and verify whether or not there is a common connector between the following terminals: <ul style="list-style-type: none"> • Exhaust gas pressure sensor No.1 terminal A–PCM terminal 1CJ • Exhaust gas pressure sensor No.1 terminal B–PCM terminal 1CE If there is a common connector: <ul style="list-style-type: none"> • Determine the malfunctioning part by inspecting the common connector and the terminal for corrosion, damage, or pin disconnection, and the common wiring harness for a short to each other. • Repair or replace the malfunctioning part. If there is no common connector: <ul style="list-style-type: none"> • Repair or replace the wiring harness which has a short to each other. Go to Step 10.
		No	Go to the next step.



Diagnostic Procedure

STEP	INSPECTION		ACTION
1	<p>RECORD VEHICLE STATUS AT TIME OF DTC DETECTION TO UTILIZE WITH REPEATABILITY VERIFICATION</p> <p>Note</p> <ul style="list-style-type: none">Recording can be facilitated using the screen capture function of the PC.Record the snapshot data on the repair order.	–	Go to the next step.
2	<p>VERIFY RELATED SERVICE INFORMATION AVAILABILITY</p> <ul style="list-style-type: none">Verify related Service Information availability.Is any related Service Information available?	Yes	Perform repair or diagnosis according to the available Service Information. <ul style="list-style-type: none">If the vehicle is not repaired, go to the next step.
		No	Go to the next step.



Diagnostic Procedure

STEP	INSPECTION	ACTION
1	<p>RECORD VEHICLE STATUS AT TIME OF DTC DETECTION TO UTILIZE WITH REPEATABILITY VERIFICATION</p> <p>Note</p> <ul style="list-style-type: none">Recording can be facilitated using the screen capture function of the PC.Record the FREEZE FRAME DATA/snapshot data on the repair order.	<p>Go to the next step.</p>
2	<p>VERIFY RELATED REPAIR INFORMATION AVAILABILITY</p> <ul style="list-style-type: none">Verify related Service Bulletins and/or on-line repair information availability.Is any related repair information available?	<p>Yes</p> <p>Perform repair or diagnosis according to the available repair information.</p> <ul style="list-style-type: none">If the vehicle is not repaired, go to the next step. <p>No</p> <p>Go to the next step.</p>

DTC P0130:00 [PCM (SKYACTIV-D 2.2)]

SM2896213

id0102j570210

DTC P0130:00	A/F sensor circuit range/performance problem
DETECTION CONDITION	<ul style="list-style-type: none">• If the PCM detects that the difference between the positive and negative terminals of the A/F sensor is less than 0.1 V for 5 s with the following conditions met, the PCM determines that the A/F sensor circuit has a problem. <p>MONITORING CONDITIONS</p> <ul style="list-style-type: none">— A/F sensor control IC output voltage: 4.7 V or more— A/F sensor terminal B voltage: 1.8 V or less— Battery voltage: 11–16 V— The following DTCs are not detected:<ul style="list-style-type: none">• A/F sensor: P0131:00, P0132:00 <p>Diagnostic support note</p> <ul style="list-style-type: none">• This is a continuous monitor (A/F sensor).• The check engine light illuminates if the PCM detects the above malfunction condition during the first drive cycle.• FREEZE FRAME DATA/Snapshot data is available.• DTC is stored in the PCM memory.
FAIL-SAFE FUNCTION	<ul style="list-style-type: none">• PCM restricts engine torque.• Inhibits the automatic diesel particulate filter regeneration control and compulsory diesel particulate filter regeneration control.• Inhibits the DENOx/DESOx control.• Stops activation of the A/F sensor heater.• Inhibits the EGR control.
POSSIBLE CAUSE	<ul style="list-style-type: none">• A/F sensor connector or terminals malfunction• PCM connector or terminals malfunction• A/F sensor positive circuit and negative circuit are shorted to each other• A/F sensor malfunction<ul style="list-style-type: none">— A/F sensor deterioration• PCM malfunction

SM2896217

DTC P0134:00	A/F sensor circuit no activity detected
DETECTION CONDITION	<ul style="list-style-type: none"> • The PCM monitors the A/F sensor impedance when the following conditions are met. If the impedance is more than threshold for 5 s, the PCM determines that A/F sensor is not activated. <p>MONITORING CONDITIONS</p> <ul style="list-style-type: none"> — Battery voltage: 11–16 V — A/F sensor feedback correction is actuated <p>Diagnostic support note</p> <ul style="list-style-type: none"> • This is a continuous monitor (A/F sensor). • The check engine light illuminates if the PCM detects the above malfunction condition during the first drive cycle. • FREEZE FRAME DATA/Snapshot data is available. • DTC is stored in the PCM memory.
FAIL-SAFE FUNCTION	<ul style="list-style-type: none"> • PCM restricts engine torque. • Inhibits the auto diesel particulate filter regeneration control. • Inhibits the compulsory diesel particulate filter regeneration control. • Inhibits the DENOx/DESOx control. • Stops activation of the A/F sensor heater. • Inhibits the EGR control.
POSSIBLE CAUSE	<ul style="list-style-type: none"> • Erratic signal from A/F sensor <ul style="list-style-type: none"> — A/F sensor connector or terminals malfunction — A/F sensor loose • PCM connector or terminals malfunction • Open circuit in wiring harness between the following terminals: <ul style="list-style-type: none"> — A/F sensor terminal A–PCM terminal 1H — A/F sensor terminal B–PCM terminal 1I • A/F sensor heater malfunction • A/F sensor malfunction <ul style="list-style-type: none"> — A/F sensor deterioration • PCM malfunction

STEP	INSPECTION		ACTION
11	VERIFY DTC TROUBLESHOOTING COMPLETED <ul style="list-style-type: none"> • Always reconnect all disconnected connectors. • Clear the DTC from the PCM memory using the M-MDS. (See AFTER REPAIR PROCEDURE [PCM (SKYACTIV-D 2.2)].) • Start the engine and idle it. • Wait until the ECT PID value is above 80 °C {176 °F}. • Wait for 1 min (idle). • Perform the DTC Reading Procedure. (See ON-BOARD DIAGNOSTIC TEST [PCM (SKYACTIV-D 2.2)].) • Is the same DTC present? 	Yes	Repeat the inspection from Step 1. <ul style="list-style-type: none"> • If the malfunction recurs, replace the PCM. (See PCM REMOVAL/INSTALLATION [SKYACTIV-D 2.2].) Go to the next step.
		No	Go to the next step.
12	VERIFY AFTER REPAIR PROCEDURE <ul style="list-style-type: none"> • Perform the "AFTER REPAIR PROCEDURE". (See AFTER REPAIR PROCEDURE [PCM (SKYACTIV-D 2.2)].) • Are any DTCs present? 	Yes	Go to the applicable DTC inspection. (See DTC TABLE [PCM (SKYACTIV-D 2.2)] .)
		No	DTC troubleshooting completed.

STEP	INSPECTION		ACTION
3	INSPECT A/F SENSOR CONNECTOR CONDITION <ul style="list-style-type: none"> • Switch the ignition off. • Disconnect the A/F sensor connector. • Inspect for poor connection (such as damaged/pulled-out pins, corrosion). • Is there any malfunction? 	Yes	Repair or replace the connector and/or terminals, then go to Step 7.
		No	Go to the next step.
4	INSPECT PCM CONNECTOR CONDITION <ul style="list-style-type: none"> • Disconnect the PCM connector. • Inspect for poor connection (such as damaged/pulled-out pins, corrosion). • Is there any malfunction? 	Yes	Repair or replace the connector and/or terminals, then go to Step 7.
		No	Go to the next step.
5	INSPECT A/F SENSOR CIRCUIT FOR SHORT TO GROUND <ul style="list-style-type: none"> • Verify that the A/F sensor and PCM connectors are disconnected. • Inspect for continuity between the following terminals (wiring harness-side) and body ground: <ul style="list-style-type: none"> — A/F sensor terminal A — A/F sensor terminal B • Is there continuity? 	Yes	Refer to the wiring diagram and verify whether or not there is a common connector between the following terminals: <ul style="list-style-type: none"> • A/F sensor terminal A–PCM terminal 1H • A/F sensor terminal B–PCM terminal 1I If there is a common connector: <ul style="list-style-type: none"> • Determine the malfunctioning part by inspecting the common connector and the terminal for corrosion, damage, or pin disconnection, and the common wiring harness for a short to ground. • Repair or replace the malfunctioning part. If there is no common connector: <ul style="list-style-type: none"> • Repair or replace the wiring harness which has a short to ground. Go to Step 7.
		No	Go to the next step.
6	INSPECT A/F SENSOR <ul style="list-style-type: none"> • Reconnect all disconnected connectors. • Inspect the A/F sensor. (See AIR FUEL RATIO (A/F) SENSOR INSPECTION [SKYACTIV-D 2.2].) • Is there any malfunction? 	Yes	Replace the A/F sensor, then go to the next step. (See AIR FUEL RATIO (A/F) SENSOR REMOVAL/INSTALLATION [SKYACTIV-D 2.2].)
		No	Go to the next step.
7	VERIFY DTC TROUBLESHOOTING COMPLETED <ul style="list-style-type: none"> • Always reconnect all disconnected connectors. • Clear the DTC from the PCM memory using the M-MDS. (See CLEARING DTC [PCM (SKYACTIV-D 2.2)].) • Perform the KOEO or KOER self test. (See KOEO/KOER SELF TEST [PCM (SKYACTIV-D 2.2)].) • Is the same DTC present? 	Yes	Repeat the inspection from Step 1. <ul style="list-style-type: none"> • If the malfunction recurs, replace the PCM. (See PCM REMOVAL/INSTALLATION [SKYACTIV-D 2.2].) Go to the next step.
		No	Go to the next step.
8	VERIFY AFTER REPAIR PROCEDURE <ul style="list-style-type: none"> • Perform the “AFTER REPAIR PROCEDURE”. (See AFTER REPAIR PROCEDURE [PCM (SKYACTIV-D 2.2)].) • Are any DTCs present? 	Yes	Go to the applicable DTC inspection. (See DTC TABLE [PCM (SKYACTIV-D 2.2)].)
		No	DTC troubleshooting completed.

STEP	INSPECTION		ACTION
3	INSPECT A/F SENSOR CONNECTOR CONDITION <ul style="list-style-type: none"> • Switch the ignition off. • Disconnect the A/F sensor connector. • Inspect for poor connection (such as damaged/pulled-out pins, corrosion). • Is there any malfunction? 	Yes	Repair or replace the connector and/or terminals, then go to Step 7.
		No	Go to the next step.
4	INSPECT PCM CONNECTOR CONDITION <ul style="list-style-type: none"> • Disconnect the PCM connector. • Inspect for poor connection (such as damaged/pulled-out pins, corrosion). • Is there any malfunction? 	Yes	Repair or replace the connector and/or terminals, then go to Step 7.
		No	Go to the next step.
5	INSPECT A/F SENSOR CIRCUIT FOR SHORT TO POWER SUPPLY <ul style="list-style-type: none"> • Verify that the A/F sensor and PCM connectors are disconnected. • Switch the ignition ON (engine off). <p>Note</p> <ul style="list-style-type: none"> • Another DTC may be stored by the PCM detecting an open circuit. • Measure the voltage at the following terminals (wiring harness-side): <ul style="list-style-type: none"> — A/F sensor terminal A — A/F sensor terminal B • Is the voltage 0 V? 	Yes	Go to the next step.
		No	Refer to the wiring diagram and verify whether or not there is a common connector between the following terminals: <ul style="list-style-type: none"> • A/F sensor terminal A–PCM terminal 1H • A/F sensor terminal B–PCM terminal 1I If there is a common connector: <ul style="list-style-type: none"> • Determine the malfunctioning part by inspecting the common connector and the terminal for corrosion, damage, or pin disconnection, and the common wiring harness for a short to power supply. • Repair or replace the malfunctioning part. If there is no common connector: <ul style="list-style-type: none"> • Repair or replace the wiring harness which has a short to power supply. Go to Step 7.
6	INSPECT A/F SENSOR <ul style="list-style-type: none"> • Switch the ignition off. • Reconnect all disconnected connectors. • Inspect the A/F sensor. (See AIR FUEL RATIO (A/F) SENSOR INSPECTION [SKYACTIV-D 2.2].) • Is there any malfunction? 	Yes	Replace the A/F sensor, then go to the next step. (See AIR FUEL RATIO (A/F) SENSOR REMOVAL/INSTALLATION [SKYACTIV-D 2.2].)
		No	Go to the next step.
7	VERIFY DTC TROUBLESHOOTING COMPLETED <ul style="list-style-type: none"> • Always reconnect all disconnected connectors. • Clear the DTC from the PCM memory using the M-MDS. (See CLEARING DTC [PCM (SKYACTIV-D 2.2)].) • Perform the KOEO or KOER self test. (See KOEO/KOER SELF TEST [PCM (SKYACTIV-D 2.2)].) • Is the same DTC present? 	Yes	Repeat the inspection from Step 1. <ul style="list-style-type: none"> • If the malfunction recurs, replace the PCM. (See PCM REMOVAL/INSTALLATION [SKYACTIV-D 2.2].) Go to the next step.
		No	Go to the next step.
8	VERIFY AFTER REPAIR PROCEDURE <ul style="list-style-type: none"> • Perform the "AFTER REPAIR PROCEDURE". (See AFTER REPAIR PROCEDURE [PCM (SKYACTIV-D 2.2)].) • Are any DTCs present? 	Yes	Go to the applicable DTC inspection. (See DTC TABLE [PCM (SKYACTIV-D 2.2)].)
		No	DTC troubleshooting completed.

- If the PCM determines that the malfunction recurs from the next drive cycle and thereafter, it stores a DTC and turns on the check engine light.

Repeatability Verification Procedure

1.Start the engine and warm up for 12 min or more with the engine coolant temperature at 60 °C {140 °F} or more.

2.Perform the following acceleration/deceleration driving 10 times repeatedly.

- Between a vehicle speed of 40–80 km/h {25–49 mph}, accelerate taking 15 s, and decelerate taking 10 s.

PID Item/Simulation Item Used In Diagnosis

PID/DATA monitor item table

Item	Definition	Unit	Condition/Specification
BARO	Barometric pressure	KPa {MPa}, mBar {BAR}, psi	• Displays the BARO.
EGRP	EGR valve	%	• Displays the EGR valve position.
EGRP_ACT	EGR valve actual opening angle	%	ECT: above 70 °C {158 °F} <ul style="list-style-type: none"> • Idle: 0 % (after 20–30 s have elapsed since start the engine) • Racing (engine speed 2,000 rpm): Approx. 60 %
EGR_C_BP	EGR cooler bypass valve	%	• Displays the EGR cooler bypass valve position.
EGR_C_BP_ACT	Actual measured EGR cooler bypass valve opening angle	%	ECT: above 70 °C {158 °F} <ul style="list-style-type: none"> • Idle: 0 % (after 20–30 s have elapsed since start the engine) • Racing (engine speed 2,000 rpm): 0 %
EXHTEMP1	Exhaust gas temperature (No.2)	°C, °F	• Displays the exhaust gas temperature.
EXHTEMP2	Exhaust gas temperature (No.3)	°C, °F	• Displays the exhaust gas temperature.
EXHTEMP4	Exhaust gas temperature (No.4)	°C, °F	• Displays the exhaust gas temperature.
EXHPRESS_DIF	Exhaust gas pressure (No.2)	KPa {MPa}, mBar {BAR}, psi	• Displays the difference in pressure between exhaust gas pressure before and after passing the diesel particulate filter.
HTR11	A/F sensor heater operation status	Off/On	• Ignition switched ON (engine off): Off
	A/F sensor heater control duty value	%	• Idle (after warm up): On
IAT	Intake air temperature (No.1)	°C, °F	• Ignition switched ON (engine off): 0 %
ISV_ACT	Intake shutter valve control actual value	°(deg)	• Idle (after warm up): Approx. 43 %
ISV_DSD	Intake shutter valve control desired value	°(deg)	• Displays the intake shutter valve control desired value.
O2S11	A/F sensor current	%	• Displays the intake shutter valve control desired value.
		μA	• Idle (after warm up): Approx. –39 μA
			• Deceleration fuel cut (accelerator pedal released from engine speed of 4,000 rpm or more): Approx. 3.84 mA