

# Your Ultimate Source for OEM Repair Manuals

FactoryManuals.net is a great resource for anyone who wants to save money on repairs by doing their own work. The manuals provide detailed instructions and diagrams that make it easy to understand how to fix a vehicle.

## **1991 MAZDA 323 (BF) Station Wagon OEM Service and Repair Workshop Manual**

[Go to manual page](#)

DTC P0506:00	Idle speed control system: RPM lower than expected
POSSIBLE CAUSE	<ul style="list-style-type: none"> <li>• Fuel freezing</li> <li>• Intake air system malfunction (air suction, leakage, perforation)</li> <li>• Fuel system malfunction               <ul style="list-style-type: none"> <li>— Fuel injector No.1–No.4 malfunction</li> <li>— Fuel injector No.1–No.4 connectors or terminals malfunction</li> <li>— Fuel leakage from fuel system or trapped air</li> <li>— Supply pump malfunction</li> <li>— Fuel feed valve malfunction</li> <li>— Fuel check valve malfunction</li> <li>— Fuel pressure relief valve malfunction</li> <li>— Fuel pipe improper routing (improper connection)</li> <li>— Fuel filter clogged</li> </ul> </li> <li>• Erratic signal to PCM               <ul style="list-style-type: none"> <li>— CKP sensor malfunction</li> <li>— Engine oil temperature sensor malfunction</li> </ul> </li> <li>• EGR valve malfunction</li> <li>• EGR cooler bypass valve malfunction</li> <li>• Refrigerant pressure sensor malfunction</li> <li>• Engine mechanical system malfunction               <ul style="list-style-type: none"> <li>— Large mechanical resistance</li> <li>— Insufficient engine compression</li> <li>— Improper valve timing</li> <li>— Engine oil malfunction (oil working up or down/poor engine oil quality/improper engine oil level/dilution)</li> <li>— Piston ring malfunction</li> <li>— Slippage of belts for engine accessories</li> <li>— Excessive load on generator</li> </ul> </li> <li>• A/C relay malfunction</li> <li>• Magnetic clutch (A/C system) malfunction</li> <li>• A/C compressor malfunction</li> <li>• ATX malfunction</li> <li>• NSC (NOx Storage Catalyst) malfunction (deterioration)</li> <li>• PCM malfunction</li> <li>• Misfire</li> </ul>
SYSTEM WIRING DIAGRAM	Not applicable

#### Caution

- If a hand or tool touches a fuel injector terminal or fuel injector connector terminal, the fuel injector might be damaged. To prevent damage to a fuel injector, do not touch the terminals.
- If high-voltage generating parts or components and electronic devices come near a fuel injector, the fuel injector could be damaged. To prevent damage to a fuel injector, always keep high-voltage generating parts or components and electronic devices away from it.

#### Diagnostic Procedure

STEP	INSPECTION		ACTION
14	<b>INSPECT EGR VALVE</b> <ul style="list-style-type: none"> <li>Inspect the EGR valve. (See <b>EGR VALVE INSPECTION [SKYACTIV-D 2.2].</b>)</li> <li>Is there any malfunction?</li> </ul>	Yes	Replace the EGR valve, then go to Step 28. (See <b>EGR VALVE REMOVAL/INSTALLATION [SKYACTIV-D 2.2].</b> )
		No	Go to the next step.
15	<b>INSPECT EGR VALVE POSITION SENSOR</b> <ul style="list-style-type: none"> <li>Reconnect all disconnected connectors.</li> <li>Inspect the EGR valve position sensor. (See <b>EGR VALVE POSITION SENSOR INSPECTION [SKYACTIV-D 2.2].</b>)</li> <li>Is there any malfunction?</li> </ul>	Yes	Replace the EGR valve, then go to Step 28. (See <b>EGR VALVE REMOVAL/INSTALLATION [SKYACTIV-D 2.2].</b> )
		No	Go to the next step.
16	<b>INSPECT EGR COOLER BYPASS VALVE</b> <ul style="list-style-type: none"> <li>Inspect the EGR cooler bypass valve. (See <b>EGR COOLER BYPASS VALVE INSPECTION [SKYACTIV-D 2.2].</b>)</li> <li>Is there any malfunction?</li> </ul>	Yes	Replace the EGR cooler bypass valve, then go to Step 28. (See <b>EGR COOLER BYPASS VALVE REMOVAL/INSTALLATION [SKYACTIV-D 2.2].</b> )
		No	Go to the next step.
17	<b>INSPECT EGR COOLER BYPASS VALVE POSITION SENSOR</b> <ul style="list-style-type: none"> <li>Reconnect all disconnected connectors.</li> <li>Inspect the EGR cooler bypass valve position sensor. (See <b>EGR VALVE POSITION SENSOR INSPECTION [SKYACTIV-D 2.2]</b>)</li> <li>Is there any malfunction?</li> </ul>	Yes	Replace the EGR cooler bypass valve, then go to Step 28. (See <b>EGR COOLER BYPASS VALVE REMOVAL/INSTALLATION [SKYACTIV-D 2.2].</b> )
		No	Go to the next step.
18	<b>INSPECT ENGINE OIL TEMPERATURE SENSOR</b> <ul style="list-style-type: none"> <li>Inspect the engine oil temperature sensor. (See <b>ENGINE OIL TEMPERATURE SENSOR INSPECTION [SKYACTIV-D 2.2].</b>)</li> <li>Is there any malfunction?</li> </ul>	Yes	Replace the engine oil temperature sensor/engine oil pressure sensor, then go to Step 28. (See <b>ENGINE OIL TEMPERATURE SENSOR/ENGINE OIL PRESSURE SENSOR REMOVAL/INSTALLATION [SKYACTIV-D 2.2].</b> )
		No	Go to the next step.
19	<b>INSPECT REFRIGERANT PRESSURE SENSOR</b> <ul style="list-style-type: none"> <li>Inspect the refrigerant pressure sensor. (See <b>REFRIGERANT PRESSURE SENSOR INSPECTION [MANUAL AIR CONDITIONER].</b>) (See <b>REFRIGERANT PRESSURE SENSOR INSPECTION [FULL-AUTO AIR CONDITIONER].</b>)</li> <li>Is there any malfunction?</li> </ul>	Yes	Replace the refrigerant pressure sensor, then go to Step 28. (See <b>REFRIGERANT PRESSURE SENSOR REMOVAL/INSTALLATION [MANUAL AIR CONDITIONER].</b> ) (See <b>REFRIGERANT PRESSURE SENSOR REMOVAL/INSTALLATION [FULL-AUTO AIR CONDITIONER].</b> )
		No	Go to the next step.
20	<b>INSPECT ENGINE COMPRESSION</b> <ul style="list-style-type: none"> <li>Inspect the engine compression. (See <b>COMPRESSION INSPECTION [SKYACTIV-D 2.2].</b>)</li> <li>Are compression pressures within specification?</li> </ul>	Yes	Go to Step 22.
		No	Go to the next step.
21	<b>INSPECT FOR MALFUNCTION DUE TO DEVIATED VALVE TIMING</b> <ul style="list-style-type: none"> <li>Inspect the valve timing (timing chain installation condition). (See <b>TIMING CHAIN REMOVAL/INSTALLATION [SKYACTIV-D 2.2].</b>)</li> <li>Is the valve timing normal?</li> </ul>	Yes	Go to the next step.
		No	Adjust the valve timing to the correct timing, then go to Step 28. (See <b>TIMING CHAIN REMOVAL/INSTALLATION [SKYACTIV-D 2.2].</b> )

DTC P0602:00 [PCM (SKYACTIV-D 2.2)]

SM2896227

id0102j570570

DTC P0602:00	PCM Programming Error
DETECTION CONDITION	<ul style="list-style-type: none"><li>• With the following conditions met, the vehicle recognition is not stored in the PCM for a continuous 1 s.</li></ul> <b>MONITORING CONDITIONS</b> <ul style="list-style-type: none"><li>• When all of the following conditions are met:<ul style="list-style-type: none"><li>— Ignition switched ON (engine off or on)</li></ul></li></ul> <b>Diagnostic support note</b> <ul style="list-style-type: none"><li>• This is a continuous monitor (CCM).</li><li>• The check engine light illuminates if the PCM detects the above malfunction condition during the first drive cycle.</li><li>• FREEZE FRAME DATA/Snapshot data is available.</li><li>• DTC is stored in the PCM memory.</li></ul>
FAIL-SAFE FUNCTION	<ul style="list-style-type: none"><li>• Not applicable</li></ul>
POSSIBLE CAUSE	<ul style="list-style-type: none"><li>• Configuration has not been completed</li><li>• PCM connector or terminals malfunction</li><li>• PCM malfunction</li></ul>
SYSTEM WIRING DIAGRAM	Not applicable

Diagnostic Procedure

STEP	INSPECTION		ACTION
1	<b>RECORD VEHICLE STATUS AT TIME OF DTC DETECTION TO UTILIZE WITH REPEATABILITY VERIFICATION</b>  <b>Note</b> <ul style="list-style-type: none"><li>• Recording can be facilitated using the screen capture function of the PC.</li><li>• Record the FREEZE FRAME DATA/snapshot data on the repair order.</li></ul>	–	Go to the next step.
2	<b>VERIFY RELATED REPAIR INFORMATION AVAILABILITY</b> <ul style="list-style-type: none"><li>• Verify related Service Bulletins and/or on-line repair information availability.</li><li>• Is any related repair information available?</li></ul>	Yes	Perform repair or diagnosis according to the available repair information. <ul style="list-style-type: none"><li>• If the vehicle is not repaired, go to the next step.</li></ul>
		No	Go to the next step.
3	<b>PERFORM PCM CONFIGURATION</b> <ul style="list-style-type: none"><li>• Perform the PCM configuration (using read/write function). (See <b>PCM CONFIGURATION (USING READ/WRITE FUNCTION) [SKYACTIV-D 2.2].</b>)</li><li>• Clear the DTC from the PCM memory using the M-MDS. (See <b>CLEARING DTC [PCM (SKYACTIV-D 2.2)].</b>)</li><li>• Perform the DTC Reading Procedure. (See <b>ON-BOARD DIAGNOSTIC TEST [PCM (SKYACTIV-D 2.2)].</b>)</li><li>• Is the same DTC present?</li></ul>	Yes	Go to the next step.
		No	Go to Step 6.



DTC P0507:00	Idle speed control system: RPM higher than expected
POSSIBLE CAUSE	<ul style="list-style-type: none"> <li>• Fuel freezing</li> <li>• Intake air system malfunction (air suction, leakage, perforation)</li> <li>• Fuel system malfunction               <ul style="list-style-type: none"> <li>— Fuel injector No.1–No.4 malfunction</li> <li>— Fuel injector No.1–No.4 connectors or terminals malfunction</li> <li>— Fuel leakage from fuel system or trapped air</li> <li>— Supply pump malfunction</li> <li>— Fuel feed valve malfunction</li> <li>— Fuel check valve malfunction</li> <li>— Fuel pressure relief valve malfunction</li> <li>— Fuel pipe improper routing (improper connection)</li> <li>— Fuel filter clogged</li> </ul> </li> <li>• Erratic signal to PCM               <ul style="list-style-type: none"> <li>— CKP sensor malfunction</li> <li>— Engine oil temperature sensor malfunction</li> </ul> </li> <li>• EGR valve malfunction</li> <li>• EGR cooler bypass valve malfunction</li> <li>• Refrigerant pressure sensor malfunction</li> <li>• Engine mechanical system malfunction               <ul style="list-style-type: none"> <li>— Large mechanical resistance</li> <li>— Insufficient engine compression</li> <li>— Improper valve timing</li> <li>— Engine oil malfunction (oil working up or down/poor engine oil quality/improper engine oil level/dilution)</li> <li>— Piston ring malfunction</li> <li>— Slippage of belts for engine accessories</li> <li>— Excessive load on generator</li> </ul> </li> <li>• A/C relay malfunction</li> <li>• Magnetic clutch (A/C system) malfunction</li> <li>• A/C compressor malfunction</li> <li>• ATX malfunction</li> <li>• NSC (NOx Storage Catalyst) malfunction (deterioration)</li> <li>• PCM malfunction</li> </ul>
SYSTEM WIRING DIAGRAM	Not applicable

#### Caution

- If a hand or tool touches a fuel injector terminal or fuel injector connector terminal, the fuel injector might be damaged. To prevent damage to a fuel injector, do not touch the terminals.
- If high-voltage generating parts or components and electronic devices come near a fuel injector, the fuel injector could be damaged. To prevent damage to a fuel injector, always keep high-voltage generating parts or components and electronic devices away from it.

#### Diagnostic Procedure

STEP	INSPECTION		ACTION
16	<b>INSPECT EGR COOLER BYPASS VALVE POSITION SENSOR</b> <ul style="list-style-type: none"> <li>• Reconnect all disconnected connectors.</li> <li>• Inspect the EGR cooler bypass valve position sensor. (See <b>EGR VALVE POSITION SENSOR INSPECTION [SKYACTIV-D 2.2]</b>)</li> <li>• Is there any malfunction?</li> </ul>	Yes	Replace the EGR cooler bypass valve, then go to Step 26. (See <b>EGR COOLER BYPASS VALVE REMOVAL/INSTALLATION [SKYACTIV-D 2.2]</b> .)
		No	Go to the next step.
17	<b>INSPECT ENGINE OIL TEMPERATURE SENSOR</b> <ul style="list-style-type: none"> <li>• Inspect the engine oil temperature sensor. (See <b>ENGINE OIL TEMPERATURE SENSOR INSPECTION [SKYACTIV-D 2.2]</b>.)</li> <li>• Is there any malfunction?</li> </ul>	Yes	Replace the engine oil temperature sensor/engine oil pressure sensor, then go to Step 26. (See <b>ENGINE OIL TEMPERATURE SENSOR/ENGINE OIL PRESSURE SENSOR REMOVAL/INSTALLATION [SKYACTIV-D 2.2]</b> .)
		No	Go to the next step.
18	<b>INSPECT REFRIGERANT PRESSURE SENSOR</b> <ul style="list-style-type: none"> <li>• Inspect the refrigerant pressure sensor. (See <b>REFRIGERANT PRESSURE SENSOR INSPECTION [MANUAL AIR CONDITIONER]</b>.) (See <b>REFRIGERANT PRESSURE SENSOR INSPECTION [FULL-AUTO AIR CONDITIONER]</b>.)</li> <li>• Is there any malfunction?</li> </ul>	Yes	Replace the refrigerant pressure sensor, then go to Step 26. (See <b>REFRIGERANT PRESSURE SENSOR REMOVAL/INSTALLATION [MANUAL AIR CONDITIONER]</b> .) (See <b>REFRIGERANT PRESSURE SENSOR REMOVAL/INSTALLATION [FULL-AUTO AIR CONDITIONER]</b> .)
		No	Go to the next step.
19	<b>INSPECT ENGINE COMPRESSION</b> <ul style="list-style-type: none"> <li>• Inspect the engine compression. (See <b>COMPRESSION INSPECTION [SKYACTIV-D 2.2]</b>.)</li> <li>• Are compression pressures within specification?</li> </ul>	Yes	Go to Step 22.
		No	Go to the next step.
20	<b>INSPECT FOR MALFUNCTION DUE TO DEVIATED VALVE TIMING</b> <ul style="list-style-type: none"> <li>• Inspect the valve timing (timing chain installation condition). (See <b>TIMING CHAIN REMOVAL/INSTALLATION [SKYACTIV-D 2.2]</b>.)</li> <li>• Is the valve timing normal?</li> </ul>	Yes	Go to the next step.
		No	Adjust the valve timing to the correct timing, then go to Step 26. (See <b>TIMING CHAIN REMOVAL/INSTALLATION [SKYACTIV-D 2.2]</b> .)
21	<b>INSPECT FOR MALFUNCTION DUE TO INTERNAL ENGINE WEAR, DAMAGE</b> <ul style="list-style-type: none"> <li>• Inspect for the following engine internal parts: <ul style="list-style-type: none"> <li>— Cylinder</li> <li>— Piston ring</li> <li>— Intake valve</li> <li>— Exhaust valve</li> <li>— Such as cylinder head gasket</li> </ul> </li> <li>• Are all items normal?</li> </ul>	Yes	Go to the next step.
		No	Repair or replace the malfunctioning part according to the inspection results, then go to Step 26.
22	<b>INSPECT DRIVE BELT</b> <ul style="list-style-type: none"> <li>• Inspect the drive belt. (See <b>DRIVE BELT INSPECTION [SKYACTIV-D 2.2]</b>.)</li> <li>• Is there any malfunction?</li> </ul>	Yes	Replace the drive belt, then go to Step 26. (See <b>DRIVE BELT REMOVAL/INSTALLATION [SKYACTIV-D 2.2]</b> .)
		No	Go to the next step.
23	<b>INSPECT GENERATOR</b> <ul style="list-style-type: none"> <li>• Inspect the generator. (See <b>GENERATOR INSPECTION [SKYACTIV-D 2.2]</b>.)</li> <li>• Is there any malfunction?</li> </ul>	Yes	Replace the generator, then go to the next step. (See <b>GENERATOR REMOVAL/INSTALLATION [SKYACTIV-D 2.2]</b> .)
		No	Go to the next step.

STEP	INSPECTION		ACTION
4	<b>VERIFY DTC TROUBLESHOOTING COMPLETED</b> <ul style="list-style-type: none"> <li>• Always reconnect all disconnected connectors.</li> <li>• Clear the DTC from the PCM memory using the M-MDS. (See <b>AFTER REPAIR PROCEDURE [PCM (SKYACTIV-D 2.2)]</b>.)</li> <li>• Perform the KOEO or KOER self test. (See <b>KOEO/KOER SELF TEST [PCM (SKYACTIV-D 2.2)]</b>.)</li> <li>• Is the same DTC present?</li> </ul>	Yes	Replace the PCM, then go to the next step. (See <b>PCM REMOVAL/INSTALLATION [SKYACTIV-D 2.2]</b> .)
		No	Go to the next step.
5	<b>VERIFY AFTER REPAIR PROCEDURE</b> <ul style="list-style-type: none"> <li>• Perform the "AFTER REPAIR PROCEDURE". (See <b>AFTER REPAIR PROCEDURE [PCM (SKYACTIV-D 2.2)]</b>.)</li> <li>• Are any DTCs present?</li> </ul>	Yes	Go to the applicable DTC inspection. (See <b>DTC TABLE [PCM (SKYACTIV-D 2.2)]</b> .)
		No	DTC troubleshooting completed.

STEP	INSPECTION		ACTION
3	<b>INSPECT EGR COOLER BYPASS VALVE CONNECTOR CONDITION</b> <ul style="list-style-type: none"> <li>• Switch the ignition off.</li> <li>• Disconnect the EGR cooler bypass valve connector.</li> <li>• Inspect for poor connection (such as damaged/pulled-out pins, corrosion).</li> <li>• Is there any malfunction?</li> </ul>	Yes	Repair or replace the connector and/or terminals, then go to Step 10.
		No	Go to the next step.
4	<b>INSPECT PCM CONNECTOR CONDITION</b> <ul style="list-style-type: none"> <li>• Disconnect the PCM connector.</li> <li>• Inspect for poor connection (such as damaged/pulled-out pins, corrosion).</li> <li>• Is there any malfunction?</li> </ul>	Yes	Repair or replace the connector and/or terminals, then go to Step 10.
		No	Go to the next step.
5	<b>INSPECT EGR COOLER BYPASS VALVE CIRCUIT FOR OPEN CIRCUIT</b> <ul style="list-style-type: none"> <li>• Verify that the EGR cooler bypass valve and PCM connectors are disconnected.</li> <li>• Inspect for continuity between the following terminals (wiring harness-side): <ul style="list-style-type: none"> <li>— EGR cooler bypass valve terminal E–PCM terminal 1BH</li> <li>— EGR cooler bypass valve terminal A–PCM terminal 1BC</li> </ul> </li> <li>• Is there continuity?</li> </ul>	Yes	Go to the next step.
		No	Refer to the wiring diagram and verify whether or not there is a common connector between the following terminals: <ul style="list-style-type: none"> <li>• EGR cooler bypass valve terminal E–PCM terminal 1BH</li> <li>• EGR cooler bypass valve terminal A–PCM terminal 1BC</li> </ul> <b>If there is a common connector:</b> <ul style="list-style-type: none"> <li>• Determine the malfunctioning part by inspecting the common connector and the terminal for corrosion, damage, or pin disconnection, and the common wiring harness for an open circuit.</li> <li>• Repair or replace the malfunctioning part.</li> </ul> <b>If there is no common connector:</b> <ul style="list-style-type: none"> <li>• Repair or replace the wiring harness which has an open circuit.</li> </ul> Go to Step 10.
6	<b>INSPECT EGR COOLER BYPASS VALVE CIRCUIT FOR SHORT TO GROUND</b> <ul style="list-style-type: none"> <li>• Verify that the EGR cooler bypass valve and PCM connectors are disconnected.</li> <li>• Inspect for continuity between the following terminals (wiring harness-side) and body ground: <ul style="list-style-type: none"> <li>— EGR cooler bypass valve terminal E</li> <li>— EGR cooler bypass valve terminal A</li> </ul> </li> <li>• Is there continuity?</li> </ul>	Yes	Refer to the wiring diagram and verify whether or not there is a common connector between the following terminals: <ul style="list-style-type: none"> <li>• EGR cooler bypass valve terminal E–PCM terminal 1BH</li> <li>• EGR cooler bypass valve terminal A–PCM terminal 1BC</li> </ul> <b>If there is a common connector:</b> <ul style="list-style-type: none"> <li>• Determine the malfunctioning part by inspecting the common connector and the terminal for corrosion, damage, or pin disconnection, and the common wiring harness for a short to ground.</li> <li>• Repair or replace the malfunctioning part.</li> </ul> <b>If there is no common connector:</b> <ul style="list-style-type: none"> <li>• Repair or replace the wiring harness which has a short to ground.</li> </ul> Go to Step 10.
		No	Go to the next step.

DTC P151B:00	Idle speed control system: RPM lower than expected
POSSIBLE CAUSE	<ul style="list-style-type: none"> <li>• Fuel freezing</li> <li>• Intake air system malfunction (air suction, leakage, perforation)</li> <li>• Fuel system malfunction               <ul style="list-style-type: none"> <li>— Fuel injector No.1–No.4 malfunction</li> <li>— Fuel injector No.1–No.4 connectors or terminals malfunction</li> <li>— Fuel leakage from fuel system or trapped air</li> <li>— Supply pump malfunction</li> <li>— Fuel feed valve malfunction</li> <li>— Fuel check valve malfunction</li> <li>— Fuel pressure relief valve malfunction</li> <li>— Fuel pipe improper routing (improper connection)</li> <li>— Fuel filter clogged</li> </ul> </li> <li>• Erratic signal to PCM               <ul style="list-style-type: none"> <li>— CKP sensor malfunction</li> <li>— Engine oil temperature sensor malfunction</li> </ul> </li> <li>• EGR valve malfunction</li> <li>• EGR cooler bypass valve malfunction</li> <li>• Refrigerant pressure sensor malfunction</li> <li>• Engine mechanical system malfunction               <ul style="list-style-type: none"> <li>— Large mechanical resistance</li> <li>— Insufficient engine compression</li> <li>— Improper valve timing</li> <li>— Engine oil malfunction (oil working up or down/poor engine oil quality/improper engine oil level/dilution)</li> <li>— Piston ring malfunction</li> <li>— Slippage of belts for engine accessories</li> <li>— Excessive load on generator</li> </ul> </li> <li>• A/C relay malfunction</li> <li>• Magnetic clutch (A/C system) malfunction</li> <li>• A/C compressor malfunction</li> <li>• ATX malfunction</li> <li>• NSC (NOx Storage Catalyst) malfunction (deterioration)</li> <li>• Misfire</li> <li>• PCM malfunction</li> </ul>
SYSTEM WIRING DIAGRAM	Not applicable

#### Caution

- If a hand or tool touches a fuel injector terminal or fuel injector connector terminal, the fuel injector might be damaged. To prevent damage to a fuel injector, do not touch the terminals.
- If high-voltage generating parts or components and electronic devices come near a fuel injector, the fuel injector could be damaged. To prevent damage to a fuel injector, always keep high-voltage generating parts or components and electronic devices away from it.

#### Diagnostic Procedure

STEP	INSPECTION		ACTION
15	<b>INSPECT EGR COOLER BYPASS VALVE</b> <ul style="list-style-type: none"> <li>Inspect the EGR cooler bypass valve. (See <b>EGR COOLER BYPASS VALVE INSPECTION [SKYACTIV-D 2.2].</b>)</li> <li>Is there any malfunction?</li> </ul>	Yes	Replace the EGR cooler bypass valve, then go to Step 27. (See <b>EGR COOLER BYPASS VALVE REMOVAL/INSTALLATION [SKYACTIV-D 2.2].</b> )
		No	Go to the next step.
16	<b>INSPECT EGR COOLER BYPASS VALVE POSITION SENSOR</b> <ul style="list-style-type: none"> <li>Reconnect all disconnected connectors.</li> <li>Inspect the EGR cooler bypass valve position sensor. (See <b>EGR COOLER BYPASS VALVE POSITION SENSOR INSPECTION [SKYACTIV-D 2.2]</b>)</li> <li>Is there any malfunction?</li> </ul>	Yes	Replace the EGR cooler bypass valve, then go to Step 27. (See <b>EGR COOLER BYPASS VALVE REMOVAL/INSTALLATION [SKYACTIV-D 2.2].</b> )
		No	Go to the next step.
17	<b>INSPECT ENGINE OIL TEMPERATURE SENSOR</b> <ul style="list-style-type: none"> <li>Inspect the engine oil temperature sensor. (See <b>ENGINE OIL TEMPERATURE SENSOR INSPECTION [SKYACTIV-D 2.2].</b>)</li> <li>Is there any malfunction?</li> </ul>	Yes	Replace the engine oil temperature sensor/engine oil pressure sensor, then go to Step 27. (See <b>ENGINE OIL TEMPERATURE SENSOR/ENGINE OIL PRESSURE SENSOR REMOVAL/INSTALLATION [SKYACTIV-D 2.2].</b> )
		No	Go to the next step.
18	<b>INSPECT REFRIGERANT PRESSURE SENSOR</b> <ul style="list-style-type: none"> <li>Inspect the refrigerant pressure sensor. (See <b>REFRIGERANT PRESSURE SENSOR INSPECTION [MANUAL AIR CONDITIONER].</b>) (See <b>REFRIGERANT PRESSURE SENSOR INSPECTION [FULL-AUTO AIR CONDITIONER].</b>)</li> <li>Is there any malfunction?</li> </ul>	Yes	Replace the refrigerant pressure sensor, then go to Step 27. (See <b>REFRIGERANT PRESSURE SENSOR REMOVAL/INSTALLATION [MANUAL AIR CONDITIONER].</b> ) (See <b>REFRIGERANT PRESSURE SENSOR REMOVAL/INSTALLATION [FULL-AUTO AIR CONDITIONER].</b> )
		No	Go to the next step.
19	<b>INSPECT ENGINE COMPRESSION</b> <ul style="list-style-type: none"> <li>Inspect the engine compression. (See <b>COMPRESSION INSPECTION [SKYACTIV-D 2.2].</b>)</li> <li>Are compression pressures within specification?</li> </ul>	Yes	Go to Step 22.
		No	Go to the next step.
20	<b>INSPECT FOR MALFUNCTION DUE TO DEVIATED VALVE TIMING</b> <ul style="list-style-type: none"> <li>Inspect the valve timing (timing chain installation condition). (See <b>TIMING CHAIN REMOVAL/INSTALLATION [SKYACTIV-D 2.2].</b>)</li> <li>Is the valve timing normal?</li> </ul>	Yes	Go to the next step.
		No	Adjust the valve timing to the correct timing, then go to Step 27. (See <b>TIMING CHAIN REMOVAL/INSTALLATION [SKYACTIV-D 2.2].</b> )
21	<b>INSPECT FOR MALFUNCTION DUE TO INTERNAL ENGINE WEAR, DAMAGE</b> <ul style="list-style-type: none"> <li>Inspect for the following engine internal parts: <ul style="list-style-type: none"> <li>— Cylinder</li> <li>— Piston ring</li> <li>— Intake valve</li> <li>— Exhaust valve</li> <li>— Such as cylinder head gasket</li> </ul> </li> <li>Are all items normal?</li> </ul>	Yes	Go to the next step.
		No	Repair or replace the malfunctioning part according to the inspection results then go to Step 27.
22	<b>INSPECT DRIVE BELT</b> <ul style="list-style-type: none"> <li>Inspect the drive belt. (See <b>DRIVE BELT INSPECTION [SKYACTIV-D 2.2].</b>)</li> <li>Is there any malfunction?</li> </ul>	Yes	Replace the drive belt, then go to Step 27. (See <b>DRIVE BELT REMOVAL/INSTALLATION [SKYACTIV-D 2.2].</b> )
		No	Go to the next step.