

Your Ultimate Source for OEM Repair Manuals

FactoryManuals.net is a great resource for anyone who wants to save money on repairs by doing their own work. The manuals provide detailed instructions and diagrams that make it easy to understand how to fix a vehicle.

1991 MAZDA 626 (Mk.3) Hatchback OEM Service and Repair Workshop Manual

[Go to manual page](#)

DTC P0610:00 [PCM (SKYACTIV-D 2.2)]

SM2896229

id0102j570600

DTC P0610:00	PCM Vehicle Options Error
DETECTION CONDITION	• With the following conditions met, the PCM check sum is incorrect for a continuous 1 s. MONITORING CONDITIONS • When all of the following conditions are met: — Ignition switched ON (engine off or on) — DTC P0602:00 not detected Diagnostic support note • This is a continuous monitor (CCM). • The check engine light illuminates if the PCM detects the above malfunction condition during the first drive cycle. • FREEZE FRAME DATA/Snapshot data is available. • DTC is stored in the PCM memory.
FAIL-SAFE FUNCTION	• Not applicable
POSSIBLE CAUSE	• Configuration has not been completed • PCM connector or terminals malfunction • PCM malfunction
SYSTEM WIRING DIAGRAM	Not applicable

Diagnostic Procedure

STEP	INSPECTION	ACTION
1	RECORD VEHICLE STATUS AT TIME OF DTC DETECTION TO UTILIZE WITH REPEATABILITY VERIFICATION Note • Recording can be facilitated using the screen capture function of the PC. • Record the FREEZE FRAME DATA/snapshot data on the repair order.	- Go to the next step.
2	VERIFY RELATED REPAIR INFORMATION AVAILABILITY • Verify related Service Bulletins and/or on-line repair information availability. • Is any related repair information available?	Yes Perform repair or diagnosis according to the available repair information. • If the vehicle is not repaired, go to the next step. No Go to the next step.

Sample

STEP	INSPECTION		ACTION
4	INSPECT BRAKE SWITCH No.1 POWER SUPPLY CIRCUIT FOR SHORT TO GROUND OR OPEN CIRCUIT • Verify that the brake switch connector is disconnected. • Measure the voltage at the brake switch terminal A (wiring harness-side). • Is the voltage B+?	Yes	Go to the next step.
		No	Inspect the MAIN 200 A fuse and STOP 10 A fuse. • If the fuse is blown: — Refer to the wiring diagram and verify whether or not there is a common connector between MAIN 200 A fuse and brake switch terminal A. If there is a common connector: • Determine the malfunctioning part by inspecting the common connector and the terminal for corrosion, damage, or pin disconnection, and the common wiring harness for a short to ground. • Repair or replace the malfunctioning part. If there is no common connector: • Repair or replace the wiring harness which has a short to ground. • Replace the malfunctioning fuse. • If the fuse is damaged: — Replace the malfunctioning fuse. • If all fuses are normal: — Refer to the wiring diagram and verify whether or not there is a common connector between battery positive terminal and brake switch terminal A. If there is a common connector: • Determine the malfunctioning part by inspecting the common connector and the terminal for corrosion, damage, or pin disconnection, and the common wiring harness for an open circuit. • Repair or replace the malfunctioning part. If there is no common connector: • Repair or replace the wiring harness which has an open circuit. Go to Step 10.

DTC U0302:00 [PCM (SKYACTIV-D 2.2)]

SM2896310

id0102j590100

DTC U0302:00	TCM processor error
DETECTION CONDITION	• With the battery voltage 10 V or more, any of the following conditions is continuously met for 3.5 s. — Check sum error in signal from TCM — Counter error in signal from TCM Diagnostic support note • This is a continuous monitor (CCM). • The check engine light illuminates if the PCM detects the above malfunction condition during the first drive cycle. • FREEZE FRAME DATA/Snapshot data is available. • DTC is stored in the PCM memory.
FAIL-SAFE FUNCTION	• Not applicable
POSSIBLE CAUSE	• TCM connector or terminals malfunction • PCM connector or terminals malfunction • CAN communication line malfunction between PCM and TCM (local CAN between PCM and TCM) — TCM terminal G–PCM terminal 1AD — TCM terminal H–PCM terminal 1Y • TCM DTC is stored. • CAN drive error (TCM or PCM) • PCM malfunction • TCM malfunction

STEP	INSPECTION		ACTION
7	VERIFY DTC TROUBLESHOOTING COMPLETED • Always reconnect all disconnected connectors. • Clear the DTC from the PCM memory using the M-MDS. (See AFTER REPAIR PROCEDURE [PCM (SKYACTIV-D 2.2)].) • Perform the DTC Reading Procedure. (See ON-BOARD DIAGNOSTIC TEST [PCM (SKYACTIV-D 2.2)].) • Is the same DTC present?	Yes	Repeat the inspection from Step 1. • If the malfunction recurs, replace the control valve body. (See CONTROL VALVE BODY REMOVAL/INSTALLATION [GW6A-EL, GW6AX-EL].) Go to the next step.
		No	Go to the next step.
8	VERIFY AFTER REPAIR PROCEDURE • Perform the "AFTER REPAIR PROCEDURE". (See AFTER REPAIR PROCEDURE [PCM (SKYACTIV-D 2.2)].) • Are any DTCs present?	Yes	Go to the applicable DTC inspection. (See DTC TABLE [PCM (SKYACTIV-D 2.2)] .)
		No	DTC troubleshooting completed.

STEP	INSPECTION	RESULTS	ACTION
6	INSPECT EGR TEMPERATURE SENSOR CIRCUIT FOR OPEN CIRCUIT • Verify that the EGR temperature sensor and PCM connectors are disconnected. • Switch the ignition off. • Inspect for continuity between the following terminals (wiring harness-side): — EGR temperature sensor terminal A–PCM terminal 1AB — EGR temperature sensor terminal C–PCM terminal 1CZ • Is there continuity?	Yes	Go to the next step.
		No	Refer to the wiring diagram and verify whether or not there is a common connector between the following terminals: • EGR temperature sensor terminal A–PCM terminal 1AB • EGR temperature sensor terminal C–PCM terminal 1CZ If there is a common connector: • Determine the malfunctioning part by inspecting the common connector and the terminal for corrosion, damage, or pin disconnection, and the common wiring harness for an open circuit. • Repair or replace the malfunctioning part. If there is no common connector: • Repair or replace the wiring harness which has an open circuit. Go to Step 8.
7	INSPECT EGR TEMPERATURE SENSOR • Inspect the EGR temperature sensor. (See EGR TEMPERATURE SENSOR INSPECTION [SKYACTIV-D 2.2].) • Is there any malfunction?	Yes	Replace the EGR temperature sensor, then go to the next step. (See EGR TEMPERATURE SENSOR REMOVAL/INSTALLATION [SKYACTIV-D 2.2].)
		No	Go to the next step.
8	VERIFY DTC TROUBLESHOOTING COMPLETED • Always reconnect all disconnected connectors. • Clear the DTC from the PCM memory using the M-MDS. (See CLEARING DTC [PCM (SKYACTIV-D 2.2)].) • Perform the KOEO or KOER self test. (See KOEO/KOER SELF TEST [PCM (SKYACTIV-D 2.2)].) • Is the PENDING CODE for this DTC present?	Yes	Repeat the inspection from Step 1. • If the malfunction recurs, replace the PCM. (See PCM REMOVAL/INSTALLATION [SKYACTIV-D 2.2].) Go to the next step.
		No	Go to the next step.
9	VERIFY AFTER REPAIR PROCEDURE • Perform the “AFTER REPAIR PROCEDURE”. (See AFTER REPAIR PROCEDURE [PCM (SKYACTIV-D 2.2)].) • Are any DTCs present?	Yes	Go to the applicable DTC inspection. (See DTC TABLE [PCM (SKYACTIV-D 2.2)].)
		No	DTC troubleshooting completed.

STEP	INSPECTION	RESULTS	ACTION
3	INSPECT WASTEGATE SOLENOID VALVE CONNECTOR CONDITION • Switch the ignition off. • Disconnect the wastegate solenoid valve connector. • Inspect for poor connection (such as damaged/pulled-out pins, corrosion). • Is there any malfunction?	Yes	Repair or replace the connector and/or terminals, then go to Step 9.
		No	Go to the next step.
4	INSPECT WASTEGATE SOLENOID VALVE POWER SUPPLY CIRCUIT FOR SHORT TO GROUND OR OPEN CIRCUIT • Verify that the wastegate solenoid valve connector is disconnected. • Switch the ignition ON (engine off). Note • Another DTC may be stored by the PCM detecting an open circuit. • Measure the voltage at the wastegate solenoid valve terminal A (wiring harness-side). • Is the voltage B+?	Yes	Go to the next step.
		No	Inspect the ENGINE2 15 A fuse. • If the fuse is blown: — Refer to the wiring diagram and verify whether or not there is a common connector between ENGINE2 15 A fuse and wastegate solenoid valve terminal A. If there is a common connector: • Determine the malfunctioning part by inspecting the common connector and the terminal for corrosion, damage, or pin disconnection, and the common wiring harness for a short to ground. • Repair or replace the malfunctioning part. If there is no common connector: • Repair or replace the wiring harness which has a short to ground. • Replace the fuse. • If the fuse is damaged: — Replace the fuse. • If the fuse is normal: — Refer to the wiring diagram and verify whether or not there is a common connector between main relay terminal C and wastegate solenoid valve terminal A. If there is a common connector: • Determine the malfunctioning part by inspecting the common connector and the terminal for corrosion, damage, or pin disconnection, and the common wiring harness for an open circuit. • Repair or replace the malfunctioning part. If there is no common connector: • Repair or replace the wiring harness which has an open circuit. Go to Step 9.
5	INSPECT PCM CONNECTOR CONDITION • Switch the ignition off. • Disconnect the PCM connector. • Inspect for poor connection (such as damaged/pulled-out pins, corrosion). • Is there any malfunction?	Yes	Repair or replace the connector and/or terminals, then go to Step 9.
		No	Go to the next step.

STEP	INSPECTION		ACTION
1	RECORD VEHICLE STATUS AT TIME OF DTC DETECTION TO UTILIZE WITH REPEATABILITY VERIFICATION Note - Recording can be facilitated using the screen capture function of the PC. - Record the snapshot data on the repair order.	–	Go to the next step.
2	VERIFY RELATED REPAIR INFORMATION AVAILABILITY - Verify related Service Bulletins and/or on-line repair information availability. - Is any related repair information available?	Yes	Perform repair or diagnosis according to the available repair information. • If the vehicle is not repaired, go to the next step.
		No	Go to the next step.
3	VERIFY DTC FOR MODULE COMMUNICATION - Switch the ignition off, then ON (engine off). - Perform the DTC Reading Procedure. (See ON-BOARD DIAGNOSTIC TEST [PCM (SKYACTIV-D 2.2)].) - Are any other PENDING CODEs and/or DTCs present?	Yes	Go to the applicable PENDING CODE or DTC inspection. (See DTC TABLE [PCM (SKYACTIV-D 2.2)] .)
		No	Go to the next step.
4	CONFIRM RADAR UNIT DTC - Perform the radar unit DTC inspection using the M-MDS. (See DTC INSPECTION [RADAR UNIT].) - Are any DTCs present?	Yes	Go to the applicable DTC inspection. (See DTC TABLE [RADAR UNIT] .)
		No	Go to the next step.
5	CONFIRM INSTRUMENT CLUSTER DTC - Perform the instrument cluster DTC inspection using the M-MDS. (See DTC INSPECTION [INSTRUMENT CLUSTER].) - Are any DTCs present?	Yes	Go to the applicable DTC inspection. (See DTC TABLE [INSTRUMENT CLUSTER] .)
		No	Go to the next step.
6	INSPECT RADAR UNIT CONNECTOR CONDITION - Switch the ignition off. - Disconnect the radar unit connector. - Inspect for poor connection (such as damaged/pulled-out pins, corrosion). - Is there any malfunction?	Yes	Repair or replace the connector and/or terminals, then go to Step 8.
		No	Go to the next step.

STEP	INSPECTION	RESULTS	ACTION
1	RECORD VEHICLE STATUS AT TIME OF DTC DETECTION TO UTILIZE WITH REPEATABILITY VERIFICATION Note - Recording can be facilitated using the screen capture function of the PC. - Record the FREEZE FRAME DATA/snapshot data on the repair order.	–	Go to the next step.
2	VERIFY RELATED REPAIR INFORMATION AVAILABILITY - Verify related Service Bulletins and/or on-line repair information availability. - Is any related repair information available?	Yes	Perform repair or diagnosis according to the available repair information. • If the vehicle is not repaired, go to the next step.
		No	Go to the next step.
3	INSPECT WASTEGATE SOLENOID VALVE CONNECTOR CONDITION - Switch the ignition off. - Disconnect the wastegate solenoid valve connector. - Inspect for poor connection (such as damaged/pulled-out pins, corrosion). - Is there any malfunction?	Yes	Repair or replace the connector and/or terminals, then go to Step 7.
		No	Go to the next step.
4	INSPECT PCM CONNECTOR CONDITION - Disconnect the PCM connector. - Inspect for poor connection (such as damaged/pulled-out pins, corrosion). - Is there any malfunction?	Yes	Repair or replace the connector and/or terminals, then go to Step 7.
		No	Go to the next step.
5	INSPECT WASTEGATE SOLENOID VALVE CONTROL CIRCUIT FOR SHORT TO POWER SUPPLY - Verify that the wastegate solenoid valve and PCM connectors are disconnected. - Switch the ignition ON (engine off). Note - Another DTC may be stored by the PCM detecting an open circuit. - Measure the voltage at the wastegate solenoid valve terminal B (wiring harness-side). - Is the voltage 0 V?	Yes	Go to the next step.
		No	Refer to the wiring diagram and verify whether or not there is a common connector between wastegate solenoid valve terminal B and PCM terminal 1CL. If there is a common connector: - Determine the malfunctioning part by inspecting the common connector and the terminal for corrosion, damage, or pin disconnection, and the common wiring harness for a short to power supply. - Repair or replace the malfunctioning part. If there is no common connector: - Repair or replace the wiring harness which has a short to power supply. Go to Step 7.
6	INSPECT WASTEGATE SOLENOID VALVE - Inspect the wastegate solenoid valve. (See WASTEGATE SOLENOID VALVE INSPECTION [SKYACTIV-D 2.2].) - Is there any malfunction?	Yes	Replace the wastegate solenoid valve, then go to the next step. (See WASTEGATE SOLENOID VALVE REMOVAL/INSTALLATION [SKYACTIV-D 2.2].)
		No	Go to the next step.