

Your Ultimate Source for OEM Repair Manuals

FactoryManuals.net is a great resource for anyone who wants to save money on repairs by doing their own work. The manuals provide detailed instructions and diagrams that make it easy to understand how to fix a vehicle.

1992 MAZDA 323 (BF) Station Wagon OEM Service and Repair Workshop Manual

[Go to manual page](#)

STEP	INSPECTION	RESULTS	ACTION
4	<p>INSPECT DOSING CONTROL UNIT POWER SUPPLY CIRCUIT FOR SHORT TO GROUND OR OPEN CIRCUIT</p> <ul style="list-style-type: none"> • Verify that the selected catalytic relay No.1 is removed. • Switch the ignition ON (engine off). <p>Note</p> <ul style="list-style-type: none"> • Another DTC may be stored by the dosing control unit detecting an open circuit. • Measure the voltage at the following terminals (wiring harness-side): <ul style="list-style-type: none"> — Selected catalytic relay No.1 terminal A — Selected catalytic relay No.1 terminal D • Is the voltage 0 V? 	<p>Yes</p>	<p>Inspect the MAIN 200 A fuse and SCR1 20 A fuse.</p> <ul style="list-style-type: none"> • If the fuse is blown: <ul style="list-style-type: none"> — Refer to the wiring diagram and verify whether or not there is a common connector between the following terminals: <ul style="list-style-type: none"> • MAIN 200 A fuse–Selected catalytic relay No.1 terminal A • MAIN 200 A fuse–Selected catalytic relay No.1 terminal D <p>If there is a common connector:</p> <ul style="list-style-type: none"> • Determine the malfunctioning part by inspecting the common connector and the terminal for corrosion, damage, or pin disconnection, and the common wiring harness for a short to ground. • Repair or replace the malfunctioning part. <p>If there is no common connector:</p> <ul style="list-style-type: none"> • Repair or replace the wiring harness which has a short to ground. • Replace the malfunctioning fuse. <ul style="list-style-type: none"> • If the fuse is damaged: <ul style="list-style-type: none"> — Replace the malfunctioning fuse. • If all fuses are normal: <ul style="list-style-type: none"> — Refer to the wiring diagram and verify whether or not there is a common connector between the following terminals: <ul style="list-style-type: none"> • Battery positive terminal–Selected catalytic relay No.1 terminal A • Battery positive terminal–Selected catalytic relay No.1 terminal D <p>If there is a common connector:</p> <ul style="list-style-type: none"> • Determine the malfunctioning part by inspecting the common connector and the terminal for corrosion, damage, or pin disconnection, and the common wiring harness for an open circuit. • Repair or replace the malfunctioning part. <p>If there is no common connector:</p> <ul style="list-style-type: none"> • Repair or replace the wiring harness which has an open circuit. <p>Go to Step 8.</p>
		No	Go to the next step.

DTC P20FF:00 [DOSING CONTROL UNIT (SKYACTIV-D 2.2)]


SM2896362

id0102k172480

DTC P20FF:00	Dosing control unit malfunction
DETECTION CONDITION	<div><div>• With the following conditions met, there is a malfunction inside the dosing control unit (read/write error, communication error, internal supply voltage malfunction).</div><div>MONITORING CONDITIONS</div><div>• Ignition switched ON (engine off or on)</div><div>Note</div><div>• DTC P1640:00 is also stored in the PCM.</div><div>Diagnostic support note</div><div>• This is a continuous monitor (CCM).</div><div>• The check engine light illuminates if the dosing control unit detects the above malfunction condition during the first drive cycle.</div><div>• FREEZE FRAME DATA/Snapshot data is available.</div><div>• DTC is stored in the dosing control unit memory.</div></div>
FAIL-SAFE FUNCTION	• Not applicable
POSSIBLE CAUSE	• Dosing control unit malfunction
SYSTEM WIRING DIAGRAM	• Not applicable


Diagnostic Procedure

STEP	INSPECTION	RESULTS	ACTION
1	<div>RECORD VEHICLE STATUS AT TIME OF DTC DETECTION TO UTILIZE WITH REPEATABILITY VERIFICATION</div> <div>Note</div> <div>• Recording can be facilitated using the screen capture function of the PC.</div> <div>• Record the FREEZE FRAME DATA/snapshot data on the repair order.</div>	–	Go to the next step.
2	<div>VERIFY RELATED REPAIR INFORMATION AVAILABILITY</div> <div>• Verify related Service Bulletins and/or on-line repair information availability.</div> <div>• Is any related repair information available?</div>	Yes	Perform repair or diagnosis according to the available repair information. <div>• If the vehicle is not repaired, go to the next step.</div>
		No	Go to the next step.



Diagnostic Procedure

STEP	INSPECTION	RESULTS	ACTION
1	<p>RECORD VEHICLE STATUS AT TIME OF DTC DETECTION TO UTILIZE WITH REPEATABILITY VERIFICATION</p> <p>Note</p> <ul style="list-style-type: none">Recording can be facilitated using the screen capture function of the PC.Record the snapshot data on the repair order.	-	Go to the next step.
2	<p>VERIFY RELATED REPAIR INFORMATION AVAILABILITY</p> <ul style="list-style-type: none">Verify related Service Bulletins and/or on-line repair information availability.Is any related repair information available?	<div>Yes</div> <div>No</div>	<div>Perform repair or diagnosis according to the available repair information.</div> <div>• If the vehicle is not repaired, go to the next step.</div> <div>Go to the next step.</div>



Diagnostic Procedure

STEP	INSPECTION	RESULTS	ACTION
1	<p>RECORD VEHICLE STATUS AT TIME OF DTC DETECTION TO UTILIZE WITH REPEATABILITY VERIFICATION</p> <p>Note</p> <ul style="list-style-type: none">Recording can be facilitated using the screen capture function of the PC.Record the snapshot data on the repair order.	-	Go to the next step.

STEP	INSPECTION	RESULTS	ACTION
10	VERIFY IF MALFUNCTION CAUSE IS DIESEL EXHAUST FLUID (DEF) OVERFILLING <ul style="list-style-type: none"> • Verify the diesel exhaust fluid (DEF) amount. (See DIESEL EXHAUST FLUID (DEF) REPLACEMENT [SKYACTIV-D 2.2]) • Is the diesel exhaust fluid (DEF) amount appropriate? 	Yes	Adjust the diesel exhaust fluid (DEF) to the appropriate amount. (See DIESEL EXHAUST FLUID (DEF) REPLACEMENT [SKYACTIV-D 2.2] .)
		No	Go to the next step.
11	VERIFY DTC TROUBLESHOOTING COMPLETED <ul style="list-style-type: none"> • Always reconnect all disconnected connectors. • Clear the DTC from the dosing control unit memory using the M-MDS. (See CLEARING DTC [DOSING CONTROL UNIT (SKYACTIV-D 2.2)].) <p>Warning</p> <ul style="list-style-type: none"> • While performing this step, always operate the vehicle in a safe and lawful manner. • When the M-MDS is used to observe monitor system status while driving, be sure to have another technician with you, or record the data in the M-MDS using the PID/DATA MONITOR AND RECORD capturing function and inspect later. <ul style="list-style-type: none"> • Perform the followings: <ol style="list-style-type: none"> 1. Perform the "COMPULSORY DIESEL PARTICULATE FILTER REGENERATION". (See COMPULSORY DIESEL PARTICULATE FILTER REGENERATION [SKYACTIV-D 2.2].) 2. After accelerating to 100 km/h {62.1 mph}, stop the vehicle at the deceleration speed exceeding 9 km/h {6 mph} for 1 s. 3. Stop the vehicle for 20 s. 4. Repeat Steps 2 and 3 four times or more. • Retrieve the dosing control unit DTCs using the M-MDS. (See ON-BOARD DIAGNOSTIC TEST [DOSING CONTROL UNIT (SKYACTIV-D 2.2)].) • Is the same Pending DTC present? 	Yes	Repeat the inspection from Step 1. <ul style="list-style-type: none"> • If the malfunction recurs, replace the dosing control unit. (See DOSING CONTROL UNIT REMOVAL/INSTALLATION [SKYACTIV-D 2.2].) Go to the next step.
		No	Go to the next step.
12	VERIFY IF OTHER DTCs DISPLAYED <ul style="list-style-type: none"> • Are any other DTCs displayed? 	Yes	Repair or replace the malfunctioning part according to the applicable DTC troubleshooting. (See DTC TABLE [DOSING CONTROL UNIT (SKYACTIV-D 2.2)] .)
		No	DTC troubleshooting completed.

STEP	INSPECTION	RESULTS	ACTION
7	VERIFY IF OTHER DTCs DISPLAYED • Are any other DTCs displayed?	Yes	Repair or replace the malfunctioning part according to the applicable DTC troubleshooting. (See DTC TABLE [DOSING CONTROL UNIT (SKYACTIV-D 2.2)] .)
		No	DTC troubleshooting completed.

Sample

STEP	INSPECTION	RESULTS	ACTION
3	INSPECT UREA LEVEL SENSOR/UREA TEMPERATURE SENSOR/UREA TANK HEATER CONNECTOR CONDITION <ul style="list-style-type: none"> • Switch the ignition off. • Disconnect the urea level sensor/urea temperature sensor/urea tank heater connector. • Inspect for poor connection (such as damaged/pulled-out pins, corrosion). • Is there any malfunction? 	Yes	Repair or replace the connector and/or terminals, then go to Step 8.
		No	Go to the next step.
4	INSPECT DOSING CONTROL UNIT CONNECTOR CONDITION <ul style="list-style-type: none"> • Disconnect the dosing control unit connector. • Inspect for poor connection (such as damaged/pulled-out pins, corrosion). • Is there any malfunction? 	Yes	Repair or replace the connector and/or terminals, then go to Step 8.
		No	Go to the next step.
5	INSPECT UREA TANK HEATER CONTROL CIRCUIT FOR SHORT TO POWER SUPPLY <ul style="list-style-type: none"> • Verify that the urea level sensor/urea temperature sensor/urea tank heater and dosing control unit connectors are disconnected. • Switch the ignition ON (engine off). • Measure the voltage at the urea level sensor/urea temperature sensor/urea tank heater terminal D (wiring harness-side). • Is the voltage 0 V? 	Yes	Refer to the wiring diagram and verify whether or not there is a common connector between urea level sensor/urea temperature sensor/urea tank heater terminal D and dosing control unit terminal D. If there is a common connector: <ul style="list-style-type: none"> • Determine the malfunctioning part by inspecting the common connector and the terminal for corrosion, damage, or pin disconnection, and the common wiring harness for a short to power supply. • Repair or replace the malfunctioning part. If there is no common connector: <ul style="list-style-type: none"> • Repair or replace the wiring harness which has a short to power supply. Go to Step 8.
		No	Go to the next step.
6	INSPECT UREA TANK HEATER GROUND CIRCUIT FOR OPEN CIRCUIT <ul style="list-style-type: none"> • Switch the ignition off. • Verify that the urea level sensor/urea temperature sensor/urea tank heater connector is disconnected. • Inspect for continuity between the following terminals (wiring harness-side): <ul style="list-style-type: none"> — Urea tank heater terminal D–Dosing control unit terminal D — Urea tank heater terminal E–Body ground • Is there continuity? 	Yes	Go to the next step.
		No	Refer to the wiring diagram and verify whether or not there is a common connector between the following terminals: <ul style="list-style-type: none"> • Urea tank heater terminal D–Dosing control unit terminal D • Urea tank heater terminal E–Body ground If there is a common connector: <ul style="list-style-type: none"> • Determine the malfunctioning part by inspecting the common connector and the terminal for corrosion, damage, or pin disconnection, and the common wiring harness for an open circuit. • Repair or replace the malfunctioning part. If there is no common connector: <ul style="list-style-type: none"> • Repair or replace the wiring harness which has a open circuit. Go to Step 8.
7	INSPECT UREA TANK HEATER <ul style="list-style-type: none"> • Inspect the urea tank heater. (See UREA TANK HEATER INSPECTION [SKYACTIV-D 2.2].) • Is there any malfunction? 	Yes	Replace the DEF pump, then go to the next step. (See UREA TANK REMOVAL/INSTALLATION [SKYACTIV-D 2.2].)
		No	Go to the next step.

PID Item/Simulation Item Used In Diagnosis


PID/DATA monitor item table

—: Not applicable

Item	Definition	Unit	Condition/Specification
NOX_C_B1S1	NOx sensor No.1	— (ppm)	• Displays the exhaust gas NOx concentration before SCR converter

Function Inspection Using M-MDS

STEP	INSPECTION	RESULTS	ACTION
1	PURPOSE: VERIFY RELATED REPAIR INFORMATION AVAILABILITY <ul style="list-style-type: none"> • Verify related Service Bulletins and/or on-line repair information availability. • Is any related repair information available? 	Yes	Perform repair or diagnosis according to the available repair information.
		No	• If the vehicle is not repaired, go to the next step.
2	PURPOSE: RECORD FREEZE FRAME DATA/SHOT DATA AND DIAGNOSTIC MONITORING TEST RESULTS TO UTILIZE WITH REPEATABILITY VERIFICATION <p>Note</p> <ul style="list-style-type: none"> • Recording can be facilitated using the screen capture function of the PC. • Record the FREEZE FRAME DATA/snapshot data and DIAGNOSTIC MONITORING TEST RESULTS (NOx sensor No.1) on the repair order. 	—	Go to the next step.
3	PURPOSE: VERIFY IF DIAGNOSTIC RESULT IS AFFECTED BY OTHER RELATED DTCs OCCURRING <ul style="list-style-type: none"> • Switch the ignition off, then ON (engine off). • Perform the Pending Trouble Code Access Procedure and DTC Reading Procedure. • Is the PENDING CODE/DTC P2200:00 or U029D:00 also present? 	Yes	Go to the applicable DTC inspection. (See DTC P2200:00 [DOSING CONTROL UNIT (SKYACTIV-D 2.2)] .) (See DTC U029D:00 [DOSING CONTROL UNIT (SKYACTIV-D 2.2)] .) Repair or replace the applicable wiring harness or connector parts. Go to the troubleshooting procedure to perform the procedure from Step 2.
		No	Go to the next step.
4	PURPOSE: VERIFY IF THERE IS PID ITEM CAUSING DRASTIC CHANGES OF ACCELERATION FLUCTUATION BY INPUT SIGNAL TO PCM OR DOSING CONTROL UNIT <ul style="list-style-type: none"> • Access the following PIDs using the M-MDS: (See ON-BOARD DIAGNOSTIC TEST [DOSING CONTROL UNIT (SKYACTIV-D 2.2)].) — NOX_C_B1S1 • Is there any signal that is far out of specification? 	Yes	Go to the next step.
		No	Go to Troubleshooting Diagnostic Procedure to perform the procedure from step 1.



Function Explanation (DTC Detection Outline)

- NOx sensor No.1 performs diagnosis independently and if it detects an open or short circuit, it sends a malfunction signal to the dosing control unit. When the malfunction signal is received from NOx sensor No.1, the dosing control unit stores a DTC.

Repeatability Verification Procedure

- 1.Perform the "COMPULSORY DIESEL PARTICULATE FILTER REGENERATION". (See [COMPULSORY DIESEL PARTICULATE FILTER REGENERATION \[SKYACTIV-D 2.2\].](#))
- 2.Idle the engine for 1 min.

PID Item/Simulation Item Used In Diagnosis

PID/DATA monitor item table

—: Not applicable

Item	Definition	Unit	Condition/Specification
NOX_C_B1S1	NOx sensor No.1	— (ppm)	• Displays the exhaust gas NOx concentration before SCR converter

Function Inspection Using M-MDS