

Your Ultimate Source for OEM Repair Manuals

FactoryManuals.net is a great resource for anyone who wants to save money on repairs by doing their own work. The manuals provide detailed instructions and diagrams that make it easy to understand how to fix a vehicle.

1992 NISSAN 300 ZX OEM Service and Repair Workshop Manual

[Go to manual page](#)

DTC DETECTION LOGIC

DTC No.		CONSULT screen terms	DTC detection condition		
B14E4	64	Wheel sensor	1	Diagnosis condition	Power switch is ON.
				Signal (terminal)	Wheel sensor signal
				Threshold	When difference between the wheel sensors for two or more wheels among all wheel sensors is 6 km/h (4MPH) or more [when driving 100 km/h (62 MPH) or less].
				Diagnosis delay time	18 seconds or more
			2	Diagnosis condition	Power switch is ON.
				Signal (terminal)	Wheel sensor signal
				Threshold	When difference between the wheel sensors for two or more wheels among all wheel sensors is 6 % or more [when driving 100 km/h (62 MPH) or less].
				Diagnosis delay time	1 second or less
			3	Diagnosis condition	Power switch is ON.
				Signal (terminal)	Wheel sensor signal
				Threshold	When two or more wheel sensors out of all wheel sensors rotate in different directions.
				Diagnosis delay time	1 second or less

POSSIBLE CAUSE

- Front left wheel sensor
- Front right wheel sensor
- Rear left wheel sensor
- Rear right wheel sensor
- Electrically-driven intelligent brake unit

FAIL-SAFE

The following functions are suspended.

- Cooperative regenerative brake function
- e-Step function

1. PRECONDITIONING

If “Confirmation Procedure” has been previously conducted, always power switch OFF, get out of the vehicle, close all doors (other than hood assembly), check that the combination meter is OFF, and wait for 1 minute or more without opening these doors.

CAUTION:
Never operate the vehicle.

>>

[GO TO 2.](#)

2. CHECK DTC DETECTION

 With CONSULT

1. Power switch OFF to ON without depressing the brake pedal.

CAUTION:
Never set the vehicle to READY.

2. Power switch OFF and disconnect CONSULT from data link connector.

3. Get out of the vehicle, close all doors (other than hood assembly), check that the combination meter is OFF, and wait for 1 minute or more without opening these doors.

CAUTION:
Never operate the vehicle.

4. Power switch ON without depressing the brake pedal.

CAUTION:
Never set the vehicle to READY.

5. Erase self-diagnosis result for “BRAKE”.

6. Power switch OFF and disconnect CONSULT from data link connector.

7. Get out of the vehicle, close all doors (other than hood assembly), check that the combination meter is OFF, and wait for 1 minute or more without opening these doors.

CAUTION:
Never operate the vehicle.

8. Power switch ON without depressing the brake pedal.

CAUTION:
Never set the vehicle to READY.

9. Perform self-diagnosis for “BRAKE”.

Is DTC “B14E4-64” detected?

YES>>

Refer to [DTC Diagnosis Procedure](#).

NO-1>>

To check malfunction symptom before repair: Refer to [Intermittent Incident](#).

NO-2>>

Confirmation after repair: INSPECTION END

Sample

CAUTION:

Never check between wheel sensor harness connector terminals.

1. CHECK 12V BATTERY

1. Power switch OFF and disconnect CONSULT from data link connector.
2. Get out of the vehicle, close all doors (other than hood assembly), check that the combination meter is OFF, and wait for 1 minute or more without opening these doors.

CAUTION:

Never operate the vehicle.

3. Check the 12V battery terminal connections.
4. Check the 12V battery.

Is the inspection result normal?

YES>>

[GO TO 2.](#)

NO>>

Repair or replace error-detected parts. [GO TO 2.](#)

2. PERFORM SELF-DIAGNOSIS (1)

 With CONSULT

1. Connect 12V battery cable to negative terminal.
2. Power switch OFF to ON without depressing the brake pedal.

CAUTION:

Never set the vehicle to READY.

3. Power switch OFF and disconnect CONSULT from data link connector.
4. Get out of the vehicle, close all doors (other than hood assembly), check that the combination meter is OFF, and wait for 1 minute or more without opening these doors.

CAUTION:

Never operate the vehicle.

5. Power switch ON without depressing the brake pedal.

CAUTION:

Never set the vehicle to READY.

6. Erase self-diagnosis result for "BRAKE".
7. Power switch OFF and disconnect CONSULT from data link connector.
8. Get out of the vehicle, close all doors (other than hood assembly), check that the combination meter is OFF, and wait for 1 minute or more without opening these doors.

CAUTION:
Never operate the vehicle.

9. Power switch ON without depressing the brake pedal.

CAUTION:
Never set the vehicle to READY.

10. Perform self-diagnosis for "BRAKE".

Is DTC "B14E4-64" detected?

YES>>

[GO TO 3.](#)

NO>>

INSPECTION END

3. CHECK WHEEL SENSOR

1. Power switch OFF and disconnect CONSULT from data link connector.
2. Get out of the vehicle, close all doors (other than hood assembly), check that the combination meter is OFF, and wait for 1 minute or more without opening these doors.

CAUTION:
Never operate the vehicle.

3. Disconnect 12V battery negative terminal.
4. Check the each wheel sensor for damage.

Is the inspection result normal?

YES>>

[GO TO 5.](#)

NO>>

[GO TO 4.](#)

4. REPLACE WHEEL SENSOR (1)

 With CONSULT

1. Replace the wheel sensor.
 - Front: Refer to [FRONT WHEEL SENSOR : Removal & Installation.](#)
 - Rear: Refer to [REAR WHEEL SENSOR : Removal & Installation.](#)
2. Connect 12V battery negative terminal.
3. Power switch OFF to ON without depressing the brake pedal.

CAUTION:
Never set the vehicle to READY.

4. Power switch OFF and disconnect CONSULT from data link connector.

5. Get out of the vehicle, close all doors (other than hood assembly), check that the combination meter is OFF, and wait for 1 minute or more without opening these doors.

CAUTION:
Never operate the vehicle.

6. Power switch ON without depressing the brake pedal.

CAUTION:
Never set the vehicle to READY.

7. Erase self-diagnosis result for “BRAKE”.

8. Power switch OFF and disconnect CONSULT from data link connector.

9. Get out of the vehicle, close all doors (other than hood assembly), check that the combination meter is OFF, and wait for 1 minute or more without opening these doors.

CAUTION:
Never operate the vehicle.

10. Power switch ON without depressing the brake pedal.

CAUTION:
Never set the vehicle to READY.

11. Perform self-diagnosis for “BRAKE”.

Is DTC “B14E4-64” detected?

YES>>

[GO TO 5.](#)

NO>>

INSPECTION END

5. CHECK CONNECTOR

1. Power switch OFF and disconnect CONSULT from data link connector.

2. Get out of the vehicle, close all doors (other than hood assembly), check that the combination meter is OFF, and wait for 1 minute or more without opening these doors.

CAUTION:
Never operate the vehicle.

3. Disconnect 12V battery negative terminal.

4. Check the electrically-driven intelligent brake unit harness connector for disconnection or looseness.

5. Check the each wheel sensor harness connector for disconnection or looseness.

Is the inspection result normal?

YES>>

[GO TO 7.](#)

NO>>

6. PERFORM SELF-DIAGNOSIS (2)

 With CONSULT

1. Connect 12V battery negative terminal.
2. Power switch OFF to ON without depressing the brake pedal.

CAUTION:
Never set the vehicle to READY.

3. Power switch OFF and disconnect CONSULT from data link connector.
4. Get out of the vehicle, close all doors (other than hood assembly), check that the combination meter is OFF, and wait for 1 minute or more without opening these doors.

CAUTION:
Never operate the vehicle.

5. Power switch ON without depressing the brake pedal.

CAUTION:
Never set the vehicle to READY.

6. Erase self-diagnosis result for “BRAKE”.
7. Power switch OFF and disconnect CONSULT from data link connector.
8. Get out of the vehicle, close all doors (other than hood assembly), check that the combination meter is OFF, and wait for 1 minute or more without opening these doors.

CAUTION:
Never operate the vehicle.

9. Power switch ON without depressing the brake pedal.

CAUTION:
Never set the vehicle to READY.

10. Perform self-diagnosis for “BRAKE”.

Is DTC “B14E4-64” detected?

YES>>

[GO TO 7.](#)

NO>>

INSPECTION END

7. CHECK ELECTRICALLY-DRIVEN INTELLIGENT BRAKE UNIT POWER SUPPLY AND GROUND CIRCUIT

1. Power switch OFF and disconnect CONSULT from data link connector.

2. Get out of the vehicle, close all doors (other than hood assembly), check that the combination meter is OFF, and wait for 1 minute or more without opening these doors.

CAUTION:
Never operate the vehicle.

3. Disconnect 12V battery negative terminal.
4. Disconnect electrically-driven intelligent brake unit harness connector.
5. Check the electrically-driven intelligent brake unit power supply and ground circuit. Refer to [Diagnosis Procedure](#).

Is the inspection result normal?

YES>>

[GO TO 8.](#)

NO>>

Repair / replace harness, connector, terminal, fuse, or fusible link. [GO TO 8.](#)

8. PERFORM SELF-DIAGNOSIS (3)

 With CONSULT

1. Power switch OFF to ON without depressing the brake pedal.

CAUTION:
Never set the vehicle to READY.

2. Power switch OFF and disconnect CONSULT from data link connector.
3. Get out of the vehicle, close all doors (other than hood assembly), check that the combination meter is OFF, and wait for 1 minute or more without opening these doors.

CAUTION:
Never operate the vehicle.

4. Power switch ON without depressing the brake pedal.

CAUTION:
Never set the vehicle to READY.

5. Erase self-diagnosis result for "BRAKE".
6. Power switch OFF and disconnect CONSULT from data link connector.
7. Get out of the vehicle, close all doors (other than hood assembly), check that the combination meter is OFF, and wait for 1 minute or more without opening these doors.

CAUTION:
Never operate the vehicle.

8. Power switch ON without depressing the brake pedal.

CAUTION:
Never set the vehicle to READY.

9. Perform self-diagnosis for "BRAKE".

Is DTC "B14E4-64" detected?

YES>>

[GO TO 9.](#)

NO>>

INSPECTION END

9. CHECK WHEEL SENSOR HARNESS

1. Power switch OFF and disconnect CONSULT from data link connector.
2. Get out of the vehicle, close all doors (other than hood assembly), check that the combination meter is OFF, and wait for 1 minute or more without opening these doors.

CAUTION:
Never operate the vehicle.

3. Disconnect 12V battery negative terminal.
4. Disconnect electrically-driven intelligent brake unit harness connector.
5. Disconnect each wheel sensor harness connector.
6. Check the continuity between electrically-driven intelligent brake unit harness connector and each wheel sensor harness connector.
 - Measurement connector and terminal for power supply circuit

Electrically-driven intelligent brake unit		Wheel sensor			Continuity
Connector	Terminal	Connector		Terminal	
B64	4	B176	(Front left)	1	Existed
	12	E110	(Front right)		
	3	B179	(Rear left)		
	7	B181	(Rear right)		

- Measurement connector and terminal for signal circuit

Electrically-driven intelligent brake unit		Wheel sensor			Continuity
Connector	Terminal	Connector		Terminal	
B64	21	B176	(Front left)	2	Existed
	11	E110	(Front right)		
	19	B179	(Rear left)		
	15	B181	(Rear right)		

Is the inspection result normal?

YES>>

[GO TO 12.](#)

NO>>

Repair / replace harness or connector. [GO TO 10.](#)

10. PERFORM SELF-DIAGNOSIS (4)