

# Your Ultimate Source for OEM Repair Manuals

FactoryManuals.net is a great resource for anyone who wants to save money on repairs by doing their own work. The manuals provide detailed instructions and diagrams that make it easy to understand how to fix a vehicle.

## 1993 MAZDA 121/ Revue (Mk.2) OEM Service and Repair Workshop Manual

[Go to manual page](#)


STEP	INSPECTION	RESULTS	ACTION
7	<b>INSPECT THROTTLE VALVE ACTUATOR CIRCUIT FOR SHORT TO POWER SUPPLY</b> <ul style="list-style-type: none"> <li>• Verify that the throttle body and PCM connectors are disconnected.</li> <li>• Switch the ignition ON (engine off).</li> </ul> <p><b>Note</b></p> <ul style="list-style-type: none"> <li>• Another DTC may be stored by the PCM detecting an open circuit.</li> <li>• Measure the voltage at the following terminals (wiring harness-side): <ul style="list-style-type: none"> <li>— Throttle body terminal B</li> <li>— Throttle body terminal A</li> </ul> </li> <li>• Is the voltage 0 V?</li> </ul>	Yes	Go to the next step.
		No	Refer to the wiring diagram and verify whether or not there is a common connector between the following terminals: <ul style="list-style-type: none"> <li>• Throttle body terminal B–PCM terminal 1CG</li> <li>• Throttle body terminal A–PCM terminal 1CC</li> </ul> <b>If there is a common connector:</b> <ul style="list-style-type: none"> <li>• Determine the malfunctioning part by inspecting the common connector and the terminal for corrosion, damage, or pin disconnection, and the common wiring harness for a short to power supply.</li> <li>• Repair or replace the malfunctioning part.</li> </ul> <b>If there is no common connector:</b> <ul style="list-style-type: none"> <li>• Repair or replace the wiring harness which has a short to power supply.</li> </ul> Go to Step 11.
8	<b>INSPECT THROTTLE VALVE ACTUATOR CIRCUIT FOR OPEN CIRCUIT</b> <ul style="list-style-type: none"> <li>• Verify that the throttle body and PCM connectors are disconnected.</li> <li>• Switch the ignition off.</li> <li>• Inspect for continuity between the following terminals (wiring harness-side): <ul style="list-style-type: none"> <li>— Throttle body terminal B–PCM terminal 1CG</li> <li>— Throttle body terminal A–PCM terminal 1CC</li> </ul> </li> <li>• Is there continuity?</li> </ul>	Yes	Go to the next step.
		No	Refer to the wiring diagram and verify whether or not there is a common connector between the following terminals: <ul style="list-style-type: none"> <li>• Throttle body terminal B–PCM terminal 1CG</li> <li>• Throttle body terminal A–PCM terminal 1CC</li> </ul> <b>If there is a common connector:</b> <ul style="list-style-type: none"> <li>• Determine the malfunctioning part by inspecting the common connector and the terminal for corrosion, damage, or pin disconnection, and the common wiring harness for an open circuit.</li> <li>• Repair or replace the malfunctioning part.</li> </ul> <b>If there is no common connector:</b> <ul style="list-style-type: none"> <li>• Repair or replace the wiring harness which has an open circuit.</li> </ul> Go to Step 11.
9	<b>INSPECT THROTTLE VALVE</b> <ul style="list-style-type: none"> <li>• Perform the Electronic Control Throttle Operation Inspection. (See <b>ENGINE CONTROL SYSTEM OPERATION INSPECTION [SKYACTIV-G 2.5T]</b>.)</li> <li>• Is there any malfunction?</li> </ul>	Yes	Repair or replace the malfunctioning part according to the inspection results, then go to Step 11.
		No	Go to the next step.
10	<b>INSPECT THROTTLE VALVE ACTUATOR</b> <ul style="list-style-type: none"> <li>• Inspect the throttle valve actuator. (See <b>THROTTLE BODY INSPECTION [SKYACTIV-G 2.5T]</b>.)</li> <li>• Is there any malfunction?</li> </ul>	Yes	Repair or replace the malfunctioning part according to the inspection results, then go to the next step.
		No	Go to the next step.
11	<b>VERIFY DTC TROUBLESHOOTING COMPLETED</b> <ul style="list-style-type: none"> <li>• Always reconnect all disconnected connectors.</li> <li>• Clear the DTC from the PCM memory using the M-MDS. (See <b>CLEARING DTC [PCM (SKYACTIV-G 2.5T)]</b>.)</li> <li>• Perform the KOEO or KOER self test. (See <b>KOEO/KOER SELF TEST [PCM (SKYACTIV-G 2.5T)]</b>.)</li> <li>• Is the same Pending DTC present?</li> </ul>	Yes	Repeat the inspection from Step 1. <ul style="list-style-type: none"> <li>• If the malfunction recurs, replace the PCM. (See <b>PCM REMOVAL/INSTALLATION [SKYACTIV-G 2.5T]</b>.)</li> </ul> Go to the next step.
		No	Go to the next step.
12	<b>VERIFY AFTER REPAIR PROCEDURE</b> <ul style="list-style-type: none"> <li>• Perform the “AFTER REPAIR PROCEDURE”. (See <b>AFTER REPAIR PROCEDURE [PCM (SKYACTIV-G 2.5T)]</b>.)</li> <li>• Are any DTCs present?</li> </ul>	Yes	Go to the applicable DTC inspection. (See <b>DTC TABLE [PCM (SKYACTIV-G 2.5T)]</b> .)
		No	DTC troubleshooting completed.

STEP	INSPECTION	RESULTS	ACTION
1	<b>RECORD VEHICLE STATUS AT TIME OF DTC DETECTION TO UTILIZE WITH REPEATABILITY VERIFICATION</b>  <b>Note</b>  <ul style="list-style-type: none"> <li>Recording can be facilitated using the screen capture function of the PC.</li> <li>Record the FREEZE FRAME DATA/snapshot data on the repair order.</li> </ul>	–	Go to the next step.
2	<b>VERIFY RELATED REPAIR INFORMATION AVAILABILITY</b> <ul style="list-style-type: none"> <li>Verify related Service Bulletins and/or on-line repair information availability.</li> <li>Is any related repair information available?</li> </ul>	Yes	Perform repair or diagnosis according to the available repair information. • If the vehicle is not repaired, go to the next step.
		No	Go to the next step.
3	<b>INSPECT THROTTLE BODY CONNECTOR CONDITION</b> <ul style="list-style-type: none"> <li>Switch the ignition off.</li> <li>Disconnect the throttle body connector.</li> <li>Inspect for poor connection (such as damaged/pulled-out pins, corrosion).</li> <li>Is there any malfunction?</li> </ul>	Yes	Repair or replace the connector and/or terminals, then go to Step 6.
		No	Go to the next step.
4	<b>INSPECT PCM CONNECTOR CONDITION</b> <ul style="list-style-type: none"> <li>Disconnect the PCM connector.</li> <li>Inspect for poor connection (such as damaged/pulled-out pins, corrosion).</li> <li>Is there any malfunction?</li> </ul>	Yes	Repair or replace the connector and/or terminals, then go to Step 6.
		No	Go to the next step.
5	<b>INSPECT THROTTLE VALVE ACTUATOR CIRCUITS FOR SHORT TO EACH OTHER</b> <ul style="list-style-type: none"> <li>Verify that the throttle body and PCM connectors are disconnected.</li> <li>Inspect for continuity between throttle body terminals B and A (wiring harness-side).</li> <li>Is there continuity?</li> </ul>	Yes	Refer to the wiring diagram and verify whether or not there is a common connector between the following terminals: • Throttle body terminal B–PCM terminal 1CG • Throttle body terminal A–PCM terminal 1CC <b>If there is a common connector:</b> • Determine the malfunctioning part by inspecting the common connector and the terminal for corrosion, damage, or pin disconnection, and the common wiring harness for a short to each other. • Repair or replace the malfunctioning part. <b>If there is no common connector:</b> • Repair or replace the wiring harness which has a short to each other. Go to the next step.
		No	Go to the next step.
6	<b>VERIFY DTC TROUBLESHOOTING COMPLETED</b> <ul style="list-style-type: none"> <li>Always reconnect all disconnected connectors.</li> <li>Clear the DTC from the PCM memory using the M-MDS. (See <b>CLEARING DTC [PCM (SKYACTIV-G 2.5T)]</b>.)</li> <li>Perform the KOEO or KOER self test. (See <b>KOEO/KOER SELF TEST [PCM (SKYACTIV-G 2.5T)]</b>.)</li> <li>Is the same Pending DTC present?</li> </ul>	Yes	Repeat the inspection from Step 1. • If the malfunction recurs, replace the PCM. (See <b>PCM REMOVAL/INSTALLATION [SKYACTIV-G 2.5T]</b> .) Go to the next step.
		No	Go to the next step.

STEP	INSPECTION	RESULTS	ACTION
1	<b>RECORD VEHICLE STATUS AT TIME OF DTC DETECTION TO UTILIZE WITH REPEATABILITY VERIFICATION</b>  <b>Note</b> <ul style="list-style-type: none"> <li>Recording can be facilitated using the screen capture function of the PC.</li> <li>Record the FREEZE FRAME DATA/snapshot data on the repair order.</li> </ul>	–	Go to the next step.
2	<b>VERIFY RELATED REPAIR INFORMATION AVAILABILITY</b> <ul style="list-style-type: none"> <li>Verify related Service Bulletins and/or on-line repair information availability.</li> <li>Is any related repair information available?</li> </ul>	Yes	Perform repair or diagnosis according to the available repair information. • If the vehicle is not repaired, go to the next step.
		No	Go to the next step.
3	<b>INSPECT EXHAUST GAS PRESSURE SENSOR CONNECTOR CONDITION</b> <ul style="list-style-type: none"> <li>Switch the ignition off.</li> <li>Disconnect the exhaust gas pressure sensor connector.</li> <li>Inspect for poor connection (such as damaged/pulled-out pins, corrosion).</li> <li>Is there any malfunction?</li> </ul>	Yes	Repair or replace the connector and/or terminals, then go to Step 6.
		No	Go to the next step.
4	<b>INSPECT EXHAUST GAS PRESSURE SENSOR</b> <ul style="list-style-type: none"> <li>Inspect the exhaust gas pressure sensor. (See <b>EXHAUST GAS PRESSURE SENSOR INSPECTION [SKYACTIV-G 2.5T]</b>.)</li> <li>Is there any malfunction?</li> </ul>	Yes	Replace the exhaust gas pressure sensor, then go to Step 6. (See <b>EXHAUST GAS PRESSURE SENSOR REMOVAL/INSTALLATION [SKYACTIV-G 2.5T]</b> .)
		No	Go to the next step.
5	<b>INSPECT PCM CONNECTOR CONDITION</b> <ul style="list-style-type: none"> <li>Disconnect the PCM connector.</li> <li>Inspect for poor connection (such as damaged/pulled-out pins, corrosion).</li> <li>Is there any malfunction?</li> </ul>	Yes	Repair or replace the connector and/or terminals, then go to the next step.
		No	Go to the next step.
6	<b>VERIFY DTC TROUBLESHOOTING COMPLETED</b> <ul style="list-style-type: none"> <li>Always reconnect all disconnected connectors.</li> <li>Clear the DTC from the PCM memory using the M-MDS. (See <b>CLEARING DTC [PCM (SKYACTIV-G 2.5T)]</b>.)</li> <li>Leave the vehicle for 6 h or more.</li> <li>Start the engine and idle it for 1 min.</li> <li>Perform the Pending Trouble Code Access Procedure. (See <b>ON-BOARD DIAGNOSTIC TEST [PCM (SKYACTIV-G 2.5T)]</b>.)</li> <li>Is the same Pending DTC present?</li> </ul>	Yes	Repeat the inspection from Step 1. • If the malfunction recurs, replace the PCM. (See <b>PCM REMOVAL/INSTALLATION [SKYACTIV-G 2.5T]</b> .) Go to the next step.
		No	Go to the next step.
7	<b>VERIFY AFTER REPAIR PROCEDURE</b> <ul style="list-style-type: none"> <li>Perform the "AFTER REPAIR PROCEDURE". (See <b>AFTER REPAIR PROCEDURE [PCM (SKYACTIV-G 2.5T)]</b>.)</li> <li>Are any DTCs present?</li> </ul>	Yes	Go to the applicable DTC inspection. (See <b>DTC TABLE [PCM (SKYACTIV-G 2.5T)]</b> .)
		No	DTC troubleshooting completed.



STEP	INSPECTION	RESULTS	ACTION
3	<b>INSPECT ENGINE OIL PRESSURE SENSOR/ENGINE OIL TEMPERATURE SENSOR CONNECTOR CONDITION</b> <ul style="list-style-type: none"> <li>• Switch the ignition off.</li> <li>• Disconnect the engine oil pressure sensor/engine oil temperature sensor connector.</li> <li>• Inspect for poor connection (such as damaged/pulled-out pins, corrosion).</li> <li>• Is there any malfunction?</li> </ul>	Yes	Repair or replace the connector and/or terminals, then go to Step 9.
		No	Go to the next step.
4	<b>INSPECT ENGINE OIL PRESSURE SENSOR CIRCUIT FOR SHORT TO GROUND</b> <ul style="list-style-type: none"> <li>• Verify that the engine oil pressure sensor/engine oil temperature sensor connector is disconnected.</li> <li>• Inspect for continuity between the following terminals (wiring harness-side) and body ground: <ul style="list-style-type: none"> <li>— Engine oil pressure sensor/engine oil temperature sensor terminal A</li> <li>— Engine oil pressure sensor/engine oil temperature sensor terminal D</li> </ul> </li> <li>• Is there continuity?</li> </ul>	Yes	Disconnect the PCM connector and inspect the wiring harness for short to ground. <ul style="list-style-type: none"> <li>• If the short to ground circuit could be detected in the wiring harness: <ul style="list-style-type: none"> <li>— Refer to the wiring diagram and verify whether or not there is a common connector between the following terminals: <ul style="list-style-type: none"> <li>• Engine oil pressure sensor/engine oil temperature sensor terminal A–PCM terminal 1CA</li> <li>• Engine oil pressure sensor/engine oil temperature sensor terminal D–PCM terminal 1AY</li> </ul> </li> </ul> </li> <li><b>If there is a common connector:</b> <ul style="list-style-type: none"> <li>• Determine the malfunctioning part by inspecting the common connector and the terminal for corrosion, damage, or pin disconnection, and the common wiring harness for a short to ground.</li> <li>• Repair or replace the malfunctioning part.</li> </ul> </li> <li><b>If there is no common connector:</b> <ul style="list-style-type: none"> <li>• Repair or replace the wiring harness which has a short to ground.</li> </ul> </li> <li>• If the short to ground circuit could not be detected in the wiring harness: <ul style="list-style-type: none"> <li>— Replace the PCM (short to ground in the PCM internal circuit). (See <b>PCM REMOVAL/INSTALLATION [SKYACTIV-G 2.5T]</b>.)</li> </ul> </li> </ul> Go to Step 9.
		No	Go to the next step.
5	<b>INSPECT PCM CONNECTOR CONDITION</b> <ul style="list-style-type: none"> <li>• Disconnect the PCM connector.</li> <li>• Inspect for poor connection (such as damaged/pulled-out pins, corrosion).</li> <li>• Is there any malfunction?</li> </ul>	Yes	Repair or replace the connector and/or terminals, then go to Step 9.
		No	Go to the next step.



## Diagnostic Procedure

STEP	INSPECTION	RESULTS	ACTION
1	<p><b>RECORD VEHICLE STATUS AT TIME OF DTC DETECTION TO UTILIZE WITH REPEATABILITY VERIFICATION</b></p> <p><b>Note</b></p> <ul style="list-style-type: none"> <li>Recording can be facilitated using the screen capture function of the PC.</li> <li>Record the snapshot data on the repair order.</li> </ul>	–	Go to the next step.
2	<p><b>VERIFY RELATED REPAIR INFORMATION AVAILABILITY</b></p> <ul style="list-style-type: none"> <li>Verify related Service Bulletins and/or on-line repair information availability.</li> <li>Is any related repair information available?</li> </ul>	<p>Yes</p> <p>No</p>	<p>Perform repair or diagnosis according to the available repair information.</p> <ul style="list-style-type: none"> <li>If the vehicle is not repaired, go to the next step.</li> </ul> <p>Go to the next step.</p>

DTC P06DB:00 [PCM (SKYACTIV-G 2.5T)]

SM2896477


id0102s821390

DTC P06DB:00	Engine oil solenoid valve circuit low input
DETECTION CONDITION	<div><div>• If the PCM detects that the engine oil solenoid valve control voltage at the PCM terminal 1BM is specified value or less for 2 s with the following condition met, the PCM determines that the engine oil solenoid valve circuit voltage is low.</div><div><div>MONITORING CONDITIONS</div><div><div>— Battery voltage: 8 V or more</div><div>— 0.5 s have elapsed after the ignition was switched ON (engine off or on)</div><div>— Engine oil solenoid valve control duty value: 94% or less</div></div></div><div><div>Diagnostic support note</div><div><div>• This is a continuous monitor (CCM).</div><div>• The check engine light does not illuminate.</div><div>• FREEZE FRAME DATA is not available.</div><div>• Snapshot data is available.</div><div>• DTC is not stored in the PCM memory.</div></div></div></div>
FAIL-SAFE FUNCTION	<div><div>• Restricts the upper limit of the engine speed.</div><div>• Restricts engine load.</div></div>
POSSIBLE CAUSE	<div><div>• Engine oil solenoid valve connector or terminals malfunction</div><div>• Short to ground or open circuit in engine oil solenoid valve power supply circuit</div><div><div>— Short to ground in wiring harness between ENGINE3 15 A fuse and engine oil solenoid valve terminal A</div><div>— ENGINE3 15 A fuse malfunction</div><div>— Open circuit in wiring harness between main relay terminal C and engine oil solenoid valve terminal A</div></div><div><div>• Short to ground in wiring harness between engine oil solenoid valve terminal B and PCM terminal 1BM</div><div>• PCM connector or terminals malfunction</div><div>• Open circuit in wiring harness between engine oil solenoid valve terminal B and PCM terminal 1BM</div><div>• Engine oil solenoid valve malfunction</div><div>• PCM malfunction</div></div></div>

STEP	INSPECTION	RESULTS	ACTION
5	<b>INSPECT ENGINE OIL SOLENOID VALVE CONTROL CIRCUIT FOR SHORT TO GROUND</b> <ul style="list-style-type: none"> <li>• Verify that the engine oil solenoid valve connector is disconnected.</li> <li>• Switch the ignition off.</li> <li>• Inspect for continuity between engine oil solenoid valve terminal B (wiring harness-side) and body ground.</li> <li>• Is there continuity?</li> </ul>	Yes	Disconnect the PCM connector and inspect the wiring harness for short to ground. <ul style="list-style-type: none"> <li>• If the short to ground circuit could be detected in the wiring harness:               <ul style="list-style-type: none"> <li>— Refer to the wiring diagram and verify whether or not there is a common connector between engine oil solenoid valve terminal B and PCM terminal 1BM.</li> </ul> </li> </ul> <p><b>If there is a common connector:</b></p> <ul style="list-style-type: none"> <li>• Determine the malfunctioning part by inspecting the common connector and the terminal for corrosion, damage, or pin disconnection, and the common wiring harness for a short to ground.</li> <li>• Repair or replace the malfunctioning part.</li> </ul> <p><b>If there is no common connector:</b></p> <ul style="list-style-type: none"> <li>• Repair or replace the wiring harness which has a short to ground.</li> </ul> <ul style="list-style-type: none"> <li>• If the short to ground circuit could not be detected in the wiring harness:               <ul style="list-style-type: none"> <li>— Replace the PCM (short to ground in the PCM internal circuit). (See <b>PCM REMOVAL/INSTALLATION [SKYACTIV-G 2.5T]</b>.)</li> </ul> </li> </ul> Go to Step 9.
		No	Go to the next step.
6	<b>INSPECT PCM CONNECTOR CONDITION</b> <ul style="list-style-type: none"> <li>• Disconnect the PCM connector.</li> <li>• Inspect for poor connection (such as damaged/pulled-out pins, corrosion).</li> <li>• Is there any malfunction?</li> </ul>	Yes	Repair or replace the connector and/or terminals, then go to Step 9.
		No	Go to the next step.
7	<b>INSPECT ENGINE OIL SOLENOID VALVE CONTROL CIRCUIT FOR OPEN CIRCUIT</b> <ul style="list-style-type: none"> <li>• Verify that the engine oil solenoid valve and PCM connectors are disconnected.</li> <li>• Inspect for continuity between engine oil solenoid valve terminal B (wiring harness-side) and PCM terminal 1BM (wiring harness-side).</li> <li>• Is there continuity?</li> </ul>	Yes	Go to the next step.
		No	Refer to the wiring diagram and verify whether or not there is a common connector between engine oil solenoid valve terminal B and PCM terminal 1BM. <p><b>If there is a common connector:</b></p> <ul style="list-style-type: none"> <li>• Determine the malfunctioning part by inspecting the common connector and the terminal for corrosion, damage, or pin disconnection, and the common wiring harness for an open circuit.</li> <li>• Repair or replace the malfunctioning part.</li> </ul> <p><b>If there is no common connector:</b></p> <ul style="list-style-type: none"> <li>• Repair or replace the wiring harness which has an open circuit.</li> </ul> Go to Step 9.
8	<b>INSPECT ENGINE OIL SOLENOID VALVE</b> <ul style="list-style-type: none"> <li>• Inspect the engine oil solenoid valve. (See <b>ENGINE OIL SOLENOID VALVE INSPECTION [SKYACTIV-G 2.5T]</b>.)</li> <li>• Is there any malfunction?</li> </ul>	Yes	Replace the engine oil solenoid valve, then go to the next step. (See <b>ENGINE OIL SOLENOID VALVE REMOVAL/INSTALLATION [SKYACTIV-G 2.5T]</b> .)
		No	Go to the next step.

## Diagnostic Procedure

STEP	INSPECTION	RESULTS	ACTION
1	<p><b>RECORD VEHICLE STATUS AT TIME OF DTC DETECTION TO UTILIZE WITH REPEATABILITY VERIFICATION</b></p> <p><b>Note</b></p> <ul style="list-style-type: none"> <li>Recording can be facilitated using the screen capture function of the PC.</li> <li>Record the snapshot data on the repair order.</li> </ul>	–	Go to the next step.
2	<p><b>VERIFY RELATED REPAIR INFORMATION AVAILABILITY</b></p> <ul style="list-style-type: none"> <li>Verify related Service Bulletins and/or on-line repair information availability.</li> <li>Is any related repair information available?</li> </ul>	Yes	Perform repair or diagnosis according to the available repair information. • If the vehicle is not repaired, go to the next step.
		No	Go to the next step.
3	<p><b>INSPECT ENGINE OIL SOLENOID VALVE CONNECTOR CONDITION</b></p> <ul style="list-style-type: none"> <li>Switch the ignition off.</li> <li>Disconnect the engine oil solenoid valve connector.</li> <li>Inspect for poor connection (such as damaged/pulled-out pins, corrosion).</li> <li>Is there any malfunction?</li> </ul>	Yes	Repair or replace the connector and/or terminals, then go to Step 7.
		No	Go to the next step.
4	<p><b>INSPECT PCM CONNECTOR CONDITION</b></p> <ul style="list-style-type: none"> <li>Disconnect the PCM connector.</li> <li>Inspect for poor connection (such as damaged/pulled-out pins, corrosion).</li> <li>Is there any malfunction?</li> </ul>	Yes	Repair or replace the connector and/or terminals, then go to Step 7.
		No	Go to the next step.
5	<p><b>INSPECT ENGINE OIL SOLENOID VALVE CONTROL CIRCUIT FOR SHORT TO POWER SUPPLY</b></p> <ul style="list-style-type: none"> <li>Verify that the engine oil solenoid valve and PCM connectors are disconnected.</li> <li>Switch the ignition ON (engine off).</li> </ul> <p><b>Note</b></p> <ul style="list-style-type: none"> <li>Another DTC may be stored by the PCM detecting an open circuit.</li> <li>Measure the voltage at the engine oil solenoid valve terminal B (wiring harness-side).</li> <li>Is the voltage 0 V?</li> </ul>	Yes	Go to the next step.
		No	Refer to the wiring diagram and verify whether or not there is a common connector between engine oil solenoid valve terminal B and PCM terminal 1BM. <b>If there is a common connector:</b> • Determine the malfunctioning part by inspecting the common connector and the terminal for corrosion, damage, or pin disconnection, and the common wiring harness for a short to power supply. • Repair or replace the malfunctioning part. <b>If there is no common connector:</b> • Repair or replace the wiring harness which has a short to power supply. Go to Step 7.
6	<p><b>INSPECT ENGINE OIL SOLENOID VALVE</b></p> <ul style="list-style-type: none"> <li>Inspect the engine oil solenoid valve. (See <b>ENGINE OIL SOLENOID VALVE INSPECTION [SKYACTIV-G 2.5T]</b>.)</li> <li>Is there any malfunction?</li> </ul>	Yes	Replace the engine oil solenoid valve, then go to the next step. (See <b>ENGINE OIL SOLENOID VALVE REMOVAL/INSTALLATION [SKYACTIV-G 2.5T]</b> .)
		No	Go to the next step.



## Function Explanation (DTC Detection Outline)

- If the PCM detects an open circuit in the wiring harness between A/F sensor terminal D and PCM terminal 1C (COM wiring harness), it stores a DTC. In addition, when there is an open circuit in the wiring harness between A/F sensor terminal D and PCM terminal 1C (COM wiring harness), the A/F sensor terminal F (B+ terminal) becomes unstable. At this time, the PCM determines an open circuit in the wiring harness (COM wiring harness) between A/F sensor terminal D and PCM terminal 1C and stores a DTC.
- If the A/F sensor does not activate, monitoring cannot occur because the A/F sensor element has an insulation property which keeps it at a specific temperature range or less.

## Repeatability Verification Procedure

1. Warm up the engine to allow the engine coolant temperature to reach 80 °C {176 °F} or more.
2. Start the engine and leave it idling for 1 min.

### Note

- Match the engine coolant temperature in the recorded FREEZE FRAME DATA/snapshot data, the vehicle speed, and engine speed values to the best extent possible while driving the vehicle.
3. Try to reproduce the malfunction by driving the vehicle for 5 min based on the values in the FREEZE FRAME DATA/snapshot data.

## PID Item/Simulation Item Used In Diagnosis

PID/DATA monitor item table