

Your Ultimate Source for OEM Repair Manuals

FactoryManuals.net is a great resource for anyone who wants to save money on repairs by doing their own work. The manuals provide detailed instructions and diagrams that make it easy to understand how to fix a vehicle.

1994 MAZDA 323 (BF) Station Wagon OEM Service and Repair Workshop Manual

[Go to manual page](#)

DTC P1380:00 [PCM (SKYACTIV-G 2.5T)]

SM2896425

id0102s800970

DTC P1380:00	Electric variable valve timing control circuit problem
DETECTION CONDITION	• A malfunction is detected in the results of the on-board diagnostic test received from the electric variable valve timing driver. Diagnostic support note • This is a continuous monitor (CCM). • The check engine light does not illuminate. • FREEZE FRAME DATA is not available. • Snapshot data is available. • DTC is stored in the PCM memory.
FAIL-SAFE FUNCTION	• Stops activation of the electric variable valve timing driver.
POSSIBLE CAUSE	• Electric variable valve timing motor/driver connectors or terminals malfunction • Short to ground in wiring harness between electric variable valve timing motor/driver terminal 1A and PCM terminal 1P • PCM connector or terminals malfunction • Short to power supply in wiring harness between electric variable valve timing motor/driver terminal 1A and PCM terminal 1P • Open circuit in wiring harness between electric variable valve timing motor/driver terminal 1A and PCM terminal 1P • Electric variable valve timing driver malfunction • Electric variable valve timing motor malfunction • PCM malfunction

STEP	INSPECTION	RESULTS	ACTION
4	INSPECT ELECTRIC VARIABLE VALVE TIMING MOTOR/DRIVER SIGNAL CIRCUIT FOR SHORT TO GROUND • Verify that the electric variable valve timing motor/driver connector is disconnected. • Inspect for continuity between electric variable valve timing motor/driver terminal 1A (wiring harness-side) and body ground. • Is there continuity?	Yes	Disconnect the PCM connector and inspect the wiring harness for short to ground. • If the short to ground circuit could be detected in the wiring harness: — Refer to the wiring diagram and verify whether or not there is a common connector between electric variable valve timing motor/driver terminal 1A and PCM terminal 1P. If there is a common connector: • Determine the malfunctioning part by inspecting the common connector and the terminal for corrosion, damage, or pin disconnection, and the common wiring harness for a short to ground. • Repair or replace the malfunctioning part. If there is no common connector: • Repair or replace the wiring harness which has a short to ground. • If the short to ground circuit could not be detected in the wiring harness: — Replace the PCM (short to ground in the PCM internal circuit). (See PCM REMOVAL/INSTALLATION [SKYACTIV-G 2.5T].) Go to Step 10.
		No	Go to the next step.
5	INSPECT PCM CONNECTOR CONDITION • Disconnect the PCM connector. • Inspect for poor connection (such as damaged/pulled-out pins, corrosion). • Is there any malfunction?	Yes	Repair or replace the connector and/or terminals, then go to Step 10.
		No	Go to the next step.
6	INSPECT ELECTRIC VARIABLE VALVE TIMING MOTOR/DRIVER SIGNAL CIRCUIT FOR SHORT TO POWER SUPPLY • Verify that the electric variable valve timing motor/driver and PCM connectors are disconnected. • Switch the ignition ON (engine off). Note • Another DTC may be stored by the PCM detecting an open circuit. • Measure the voltage at the electric variable valve timing motor/driver terminal 1A (wiring harness-side). • Is the voltage 0 V?	Yes	Go to the next step.
		No	Refer to the wiring diagram and verify whether or not there is a common connector between electric variable valve timing motor/driver terminal 1A and PCM terminal 1P. If there is a common connector: • Determine the malfunctioning part by inspecting the common connector and the terminal for corrosion, damage, or pin disconnection, and the common wiring harness for a short to power supply. • Repair or replace the malfunctioning part. If there is no common connector: • Repair or replace the wiring harness which has a short to power supply. Go to Step 10.

Diagnostic Procedure

STEP	INSPECTION	RESULTS	ACTION
1	RECORD VEHICLE STATUS AT TIME OF DTC DETECTION TO UTILIZE WITH REPEATABILITY VERIFICATION Note • Recording can be facilitated using the screen capture function of the PC. • Record the FREEZE FRAME DATA/snapshot data on the repair order.	–	Go to the next step.
2	VERIFY RELATED REPAIR INFORMATION AVAILABILITY • Verify related Service Bulletins and/or on-line repair information availability. • Is any related repair information available?	Yes	Perform repair or diagnosis according to the available repair information. • If the vehicle is not repaired, go to the next step.
		No	Go to the next step.
3	INSPECT OCV CONNECTOR CONDITION • Switch the ignition off. • Disconnect the OCV connector. • Inspect for poor connection (such as damaged/pulled-out pins, corrosion). • Is there any malfunction?	Yes	Repair or replace the connector and/or terminals, then go to Step 9.
		No	Go to the next step.

STEP	INSPECTION	RESULTS	ACTION
9	VERIFY DTC TROUBLESHOOTING COMPLETED • Always reconnect all disconnected connectors. • Clear the DTC from the PCM memory using the M-MDS. (See CLEARING DTC [PCM (SKYACTIV-G 2.5T)].) • Perform the KOER self test. (See KOEO/KOER SELF TEST [PCM (SKYACTIV-G 2.5T)].) • Is the same Pending DTC present?	Yes	Repeat the inspection from Step 1. • If the malfunction recurs, replace the PCM. (See PCM REMOVAL/INSTALLATION [SKYACTIV-G 2.5T].) Go to the next step.
		No	Go to the next step.
10	VERIFY AFTER REPAIR PROCEDURE • Perform the “AFTER REPAIR PROCEDURE”. (See AFTER REPAIR PROCEDURE [PCM (SKYACTIV-G 2.5T)].) • Are any DTCs present?	Yes	Go to the applicable DTC inspection. (See DTC TABLE [PCM (SKYACTIV-G 2.5T)] .)
		No	DTC troubleshooting completed.

STEP	INSPECTION	RESULTS	ACTION
7	VERIFY DTC TROUBLESHOOTING COMPLETED • Always reconnect all disconnected connectors. • Clear the DTC from the PCM memory using the M-MDS. (See CLEARING DTC [PCM (SKYACTIV-G 2.5T)].) • Perform the KOER self test. (See KOEO/KOER SELF TEST [PCM (SKYACTIV-G 2.5T)].) • Is the same Pending DTC present?	Yes	Repeat the inspection from Step 1. • If the malfunction recurs, replace the PCM. (See PCM REMOVAL/INSTALLATION [SKYACTIV-G 2.5T].) Go to the next step.
		No	Go to the next step.
8	VERIFY AFTER REPAIR PROCEDURE • Perform the “AFTER REPAIR PROCEDURE”. (See AFTER REPAIR PROCEDURE [PCM (SKYACTIV-G 2.5T)].) • Are any DTCs present?	Yes	Go to the applicable DTC inspection. (See DTC TABLE [PCM (SKYACTIV-G 2.5T)] .)
		No	DTC troubleshooting completed.

DTC P061D:00 [PCM (SKYACTIV-G 2.5T)]


SM2896504

id0102s830250

DTC P061D:00	Internal control module engine air mass performance problem
DETECTION CONDITION	- Indicates an error occurred in the PCM. Diagnostic support note - This is a continuous monitor (CCM). - The check engine light illuminates if the PCM detects the above malfunction condition during the first drive cycle. - FREEZE FRAME DATA/Snapshot data is available. - DTC is stored in the PCM memory.
FAIL-SAFE FUNCTION	Restricts the upper limit of the engine speed.
POSSIBLE CAUSE	- PCM connector or terminals malfunction - Software incompatibility issue - PCM malfunction
SYSTEM WIRING DIAGRAM	Not applicable

Diagnostic Procedure

STEP	INSPECTION	RESULTS	ACTION
1	RECORD VEHICLE STATUS AT TIME OF DTC DETECTION TO UTILIZE WITH REPEATABILITY VERIFICATION Note - Recording can be facilitated using the screen capture function of the PC. - Record the FREEZE FRAME DATA/snapshot data on the repair order.	–	Go to the next step.
2	VERIFY RELATED REPAIR INFORMATION AVAILABILITY - Verify related Service Bulletins and/or on-line repair information availability. - Is any related repair information available?	Yes	Perform repair or diagnosis according to the available repair information. If the vehicle is not repaired, go to the next step.
		No	Go to the next step.
3	VERIFY RELATED PENDING CODE AND/OR DTC - Switch the ignition off, then ON (engine off). - Perform the Pending Trouble Code Access Procedure and DTC Reading Procedure. (See ON-BOARD DIAGNOSTIC TEST [PCM (SKYACTIV-G 2.5T)].) - Are any other PENDING CODEs and/or DTCs present?	Yes	Go to the applicable PENDING CODE or DTC inspection. (See DTC TABLE [PCM (SKYACTIV-G 2.5T)] .)
		No	Go to the next step.
4	INSPECT PCM CONNECTOR CONDITION - Switch the ignition off. - Disconnect the PCM connector. - Inspect for poor connection (such as damaged/pulled-out pins, corrosion). - Is there any malfunction?	Yes	Repair or replace the connector and/or terminals, then go to Step 6.
		No	Go to the next step.



Diagnostic Procedure

STEP	INSPECTION	RESULTS	ACTION
1	RECORD VEHICLE STATUS AT TIME OF DTC DETECTION TO UTILIZE WITH REPEATABILITY VERIFICATION Note • Recording can be facilitated using the screen capture function of the PC. • Record the snapshot data on the repair order.	–	Go to the next step.
2	VERIFY RELATED REPAIR INFORMATION AVAILABILITY • Verify related Service Bulletins and/or on-line repair information availability. • Is any related repair information available?	Yes No	Perform repair or diagnosis according to the available repair information. • If the vehicle is not repaired, go to the next step. Go to the next step.
3	VERIFY RELATED PENDING CODE AND/OR DTC • Switch the ignition off, then ON (engine off). • Perform the Pending Trouble Code Access Procedure and DTC Reading Procedure. (See ON-BOARD DIAGNOSTIC TEST [PCM (SKYACTIV-G 2.5T)].) • Are any other PENDING CODEs and/or DTCs present?	Yes No	Go to the applicable PENDING CODE or DTC inspection. (See DTC TABLE [PCM (SKYACTIV-G 2.5T)].) Go to the next step.

Function Inspection Using M-MDS

STEP	INSPECTION	RESULTS	ACTION
1	PURPOSE: VERIFY RELATED REPAIR INFORMATION AVAILABILITY • Verify related Service Bulletins and/or on-line repair information availability. • Is any related repair information available?	Yes	Perform repair or diagnosis according to the available repair information. • If the vehicle is not repaired, go to the next step.
		No	Go to the next step.
2	PURPOSE: RECORD FREEZE FRAME DATA/SHOT DATA AND DIAGNOSTIC MONITORING TEST RESULTS TO UTILIZE WITH REPEATABILITY VERIFICATION Note • Recording can be facilitated using the screen capture function of the PC. • Record the FREEZE FRAME DATA/snapshot data and DIAGNOSTIC MONITORING TEST RESULTS (A/F sensor, HO2S related) on the repair order.	–	Go to the Troubleshooting Diagnostic Procedure to perform the procedure from Step 1.

Troubleshooting Diagnostic Procedure

Intention of troubleshooting procedure

- Step 1
 - Verify if malfunctioning part is PCM.
- Step 2
 - Verify that there are no other malfunctions.

STEP	INSPECTION	RESULTS	ACTION
1	PURPOSE: PERFORM DTC INSPECTION AND VERIFY IF MALFUNCTIONING PART IS PCM • Clear the DTC from the PCM memory using the M-MDS. (See CLEARING DTC [PCM (SKYACTIV-G 2.5T)].) • Perform the KOER self test. (See KOEO/KOER SELF TEST [PCM (SKYACTIV-G 2.5T)].) • Is the same Pending DTC present?	Yes	Replace the PCM, then go to the next step. (See PCM REMOVAL/INSTALLATION [SKYACTIV-G 2.5T] .)
		No	Go to the next step.
2	PURPOSE: VERIFY IF THERE IS ANY OTHER MALFUNCTION • Is any other DTC or pending code stored?	Yes	Go to the applicable DTC inspection. (See DTC TABLE [PCM (SKYACTIV-G 2.5T)] .)
		No	DTC troubleshooting completed.

STEP	INSPECTION	RESULTS	ACTION
4	INSPECT MAIN RELAY POWER SUPPLY CIRCUIT FOR SHORT TO GROUND OR OPEN CIRCUIT • Verify that main relay is removed. • Measure the voltage at the main relay terminal D (wiring harness-side). • Is the voltage B+?	Yes	Go to the next step.
		No	Inspect the MAIN 200 A fuse and ENG.MAIN 40 A fuse. • If the fuse is blown: — Refer to the wiring diagram and verify whether or not there is a common connector between MAIN 200 A fuse and main relay terminal D. If there is a common connector: • Determine the malfunctioning part by inspecting the common connector and the terminal for corrosion, damage, or pin disconnection, and the common wiring harness for a short to ground. • Repair or replace the malfunctioning part. If there is no common connector: • Repair or replace the wiring harness which has a short to ground. • Replace the malfunctioning fuse. • If the fuse is damaged: — Replace the malfunctioning fuse. • If all fuses are normal: — Refer to the wiring diagram and verify whether or not there is a common connector between battery positive terminal and main relay terminal D. If there is a common connector: • Determine the malfunctioning part by inspecting the common connector and the terminal for corrosion, damage, or pin disconnection, and the common wiring harness for an open circuit. • Repair or replace the malfunctioning part. If there is no common connector: • Repair or replace the wiring harness which has an open circuit. Go to Step 10.