

Your Ultimate Source for OEM Repair Manuals

FactoryManuals.net is a great resource for anyone who wants to save money on repairs by doing their own work. The manuals provide detailed instructions and diagrams that make it easy to understand how to fix a vehicle.

1995 MAZDA 323 C (BH) OEM Service and Repair Workshop Manual

[Go to manual page](#)

PID/DATA monitor item table

Item	Definition	Unit	Condition/Specification
MAF	Mass air flow input from MAF sensor	g/Sec	• Displays MAF
	MAF sensor voltage	V	<ul style="list-style-type: none"> • Ignition switched ON (engine off) (MAF: 0.59 g/s {0.078 lb/min}): Approx. 0.72 V • Idle (after warm up) (MAF: 2.17 g/s {0.287 lb/min}): Approx. 0.97 V • Racing (engine speed is 2,000 rpm) (MAF: 4.73 g/s {0.626 lb/min}): Approx. 1.26 V
MAP	Manifold absolute pressure input from MAP sensor	KPa {MPa}, mBar {BAR}, psi, in H2O	• Displays MAP
MAP_V	MAP sensor voltage	V	<ul style="list-style-type: none"> • Ignition switched ON (engine off) (no load) (MAP: 102 kPa {1.04 kgf/cm², 14.8 psi}): Approx. 1.75 V • Idle (after warm up) (no load) (MAP: 30 kPa {0.31 kgf/cm², 4.4 psi}): Approx. 0.68 V • Racing (engine speed is 2,000 rpm) (no load) (MAP: 27 kPa {0.28 kgf/cm², 3.9 psi}): Approx. 0.61 V

Function Inspection Using M-MDS


STEP	INSPECTION	ACTION	
1	<p>PURPOSE: RECORD VEHICLE STATUS AT TIME OF DTC DETECTION TO UTILIZE WITH REPEATABILITY VERIFICATION</p> <p>Note</p> <ul style="list-style-type: none"> • Recording can be facilitated using the screen capture function of the PC. • Record the FREEZE FRAME DATA/snapshot data on the repair order. 	–	Go to the next step.
2	<p>PURPOSE: VERIFY RELATED REPAIR INFORMATION AVAILABILITY</p> <ul style="list-style-type: none"> • Verify related Service Bulletins and/or on-line repair information availability. • Is any related repair information available? 	Yes	Perform repair or diagnosis according to the available repair information. • If the vehicle is not repaired, go to the next step.
		No	Go to the next step.
3	<p>PURPOSE: IDENTIFY TRIGGER DTC FOR FREEZE FRAME DATA</p> <ul style="list-style-type: none"> • Is the DTC P0402:00 on FREEZE FRAME DATA? 	Yes	Go to the next step.
		No	Go to the troubleshooting procedure for DTC on FREEZE FRAME DATA. (See DTC TABLE [PCM (SKYACTIV-G 2.5T)] .)
4	<p>PURPOSE: VERIFY IF DIAGNOSTIC RESULT IS AFFECTED BY OTHER RELATED DTCs OCCURRING</p> <ul style="list-style-type: none"> • Switch the ignition off, then ON (engine off). • Perform the Pending Trouble Code Access Procedure and DTC Reading Procedure. (See ON-BOARD DIAGNOSTIC TEST [PCM (SKYACTIV-G 2.5T)].) • Is the other PENDING CODE/DTC also present? 	Yes	Go to the applicable DTC inspection. (See DTC TABLE [PCM (SKYACTIV-G 2.5T)] .)
		No	Go to the next step.

DTC P0112:00 [PCM (SKYACTIV-G 2.5T)]

SM2896536

id0102s870140

DTC P0112:00	IAT sensor No.1 circuit low input
DETECTION CONDITION	<ul style="list-style-type: none">• The PCM monitors the IAT sensor No.1 signal. If the PCM detects that the IAT sensor No.1 voltage at the PCM terminal 2AX is below 0.2 V for 5 s, the PCM determines that the IAT sensor No.1 circuit has a malfunction. Diagnostic support note <ul style="list-style-type: none">• This is a continuous monitor (CCM).• The check engine light illuminates if the PCM detects the above malfunction condition during the first drive cycle.• FREEZE FRAME DATA/Snapshot data is available.• DTC is stored in the PCM memory.
FAIL-SAFE FUNCTION	<ul style="list-style-type: none">• Fixes the intake air temperature (for engine control) at 20 °C {68 °F}.• Inhibits the fuel cut control during shift change.
POSSIBLE CAUSE	<ul style="list-style-type: none">• MAF sensor/IAT sensor No.1 connector or terminals malfunction• IAT sensor No.1 malfunction• PCM connector or terminals malfunction• Short to ground in wiring harness between MAF sensor/IAT sensor No.1 terminal A and PCM terminal 2AX• IAT sensor No.1 signal circuit and ground circuit are shorted to each other• PCM malfunction




Diagnostic Procedure

DTC P0113:00 [PCM (SKYACTIV-G 2.5T)]

SM2896537

id0102s870150

DTC P0113:00	IAT sensor No.1 circuit high input
DETECTION CONDITION	<ul style="list-style-type: none">• The PCM monitors the IAT sensor No.1 signal. If the PCM detects that the IAT sensor No.1 voltage at the PCM terminal 2AX is above 4.62 V for 5 s, the PCM determines that the IAT sensor No.1 circuit has a malfunction. Diagnostic support note <ul style="list-style-type: none">• This is a continuous monitor (CCM).• The check engine light illuminates if the PCM detects the above malfunction condition during the first drive cycle.• FREEZE FRAME DATA/Snapshot data is available.• DTC is stored in the PCM memory.
FAIL-SAFE FUNCTION	<ul style="list-style-type: none">• Fixes the intake air temperature (for engine control) at 20 °C {68 °F}.• Inhibits the fuel cut control during shift change.
POSSIBLE CAUSE	<ul style="list-style-type: none">• MAF sensor/IAT sensor No.1 connector or terminals malfunction• PCM connector or terminals malfunction• IAT sensor No.1 malfunction• Short to power supply in wiring harness between MAF sensor/IAT sensor No.1 terminal A and PCM terminal 2AX• Open circuit in wiring harness between the following terminals:<ul style="list-style-type: none">— MAF sensor/IAT sensor No.1 terminal A-PCM terminal 2AX— MAF sensor/IAT sensor No.1 terminal B-PCM terminal 2AY• PCM malfunction



Caution

- Verify the malfunction symptom according to not only the PID value but also the symptom troubleshooting.

Related PIDs

STEP	INSPECTION	RESULTS	ACTION
10	VERIFY DTC TROUBLESHOOTING COMPLETED <ul style="list-style-type: none"> • Always reconnect all disconnected connectors. • Clear the DTC from the PCM memory using the M-MDS. (See CLEARING DTC [PCM (SKYACTIV-G 2.5T)].) • Perform the KOEO or KOER self test. (See KOEO/KOER SELF TEST [PCM (SKYACTIV-G 2.5T)].) • Is the same Pending DTC present? 	Yes	Repeat the inspection from Step 1. <ul style="list-style-type: none"> • If the malfunction recurs, replace the PCM. (See PCM REMOVAL/INSTALLATION [SKYACTIV-G 2.5T].) Go to the next step.
		No	Go to the next step.
11	VERIFY AFTER REPAIR PROCEDURE <ul style="list-style-type: none"> • Perform the "AFTER REPAIR PROCEDURE". (See AFTER REPAIR PROCEDURE [PCM (SKYACTIV-G 2.5T)].) • Are any DTCs present? 	Yes	Go to the applicable DTC inspection. (See DTC TABLE [PCM (SKYACTIV-G 2.5T)] .)
		No	DTC troubleshooting completed.

STEP	INSPECTION	RESULTS	ACTION
5	DETERMINE IF ECT SENSOR OR WIRING HARNESS MALFUNCTION <ul style="list-style-type: none"> • Reconnect all disconnected connectors. • Access the ECT PID using the M-MDS. (See ON-BOARD DIAGNOSTIC TEST [PCM (SKYACTIV-G 2.5T)].) • Verify the ECT PID value when disconnecting the ECT sensor connector. • Does the ECT PID value change? 	Yes	Replace the ECT sensor, then go to Step 9. (See ENGINE COOLANT TEMPERATURE (ECT) SENSOR REMOVAL/INSTALLATION [SKYACTIV-G 2.5T] .)
		No	Go to the next step.
6	INSPECT ECT SENSOR SIGNAL CIRCUIT FOR SHORT TO GROUND <ul style="list-style-type: none"> • Verify that the ECT sensor connector is disconnected. • Switch the ignition off. • Inspect for continuity between ECT sensor terminal A (wiring harness-side) and body ground. • Is there continuity? 	Yes	Disconnect the PCM connector and inspect the wiring harness for short to ground. <ul style="list-style-type: none"> • If the short to ground circuit could be detected in the wiring harness: <ul style="list-style-type: none"> — Refer to the wiring diagram and verify whether or not there is a common connector between ECT sensor terminal A and PCM terminal 1BI. If there is a common connector: <ul style="list-style-type: none"> • Determine the malfunctioning part by inspecting the common connector and the terminal for corrosion, damage, or pin disconnection, and the common wiring harness for a short to ground. • Repair or replace the malfunctioning part. If there is no common connector: <ul style="list-style-type: none"> • Repair or replace the wiring harness which has a short to ground. <ul style="list-style-type: none"> • If the short to ground circuit could not be detected in the wiring harness: <ul style="list-style-type: none"> — Replace the PCM (short to ground in the PCM internal circuit). (See PCM REMOVAL/INSTALLATION [SKYACTIV-G 2.5T].) Go to Step 9.
		No	Go to the next step.
7	INSPECT PCM CONNECTOR CONDITION <ul style="list-style-type: none"> • Disconnect the PCM connector. • Inspect for poor connection (such as damaged/pulled-out pins, corrosion). • Is there any malfunction? 	Yes	Repair or replace the connector and/or terminals, then go to Step 9.
		No	Go to the next step.
8	INSPECT ECT SENSOR SIGNAL CIRCUIT AND GROUND CIRCUIT FOR SHORT TO EACH OTHER <ul style="list-style-type: none"> • Verify that the ECT sensor and PCM connectors are disconnected. • Inspect for continuity between ECT sensor terminals A and B (wiring harness-side). • Is there continuity? 	Yes	Refer to the wiring diagram and verify whether or not there is a common connector between the following terminals: <ul style="list-style-type: none"> • ECT sensor terminal A-PCM terminal 1BI • ECT sensor terminal B-PCM terminal 1AM If there is a common connector: <ul style="list-style-type: none"> • Determine the malfunctioning part by inspecting the common connector and the terminal for corrosion, damage, or pin disconnection, and the common wiring harness for a short to each other. • Repair or replace the malfunctioning part. If there is no common connector: <ul style="list-style-type: none"> • Repair or replace the wiring harness which has a short to each other. Go to the next step.
		No	Go to the next step.

- Verify the malfunction symptom according to not only the PID value but also the symptom troubleshooting.

Related PIDs

Item (definition)	Unit/Condition	Definition	Condition/Specification (Reference)
ECT	°C, °F	Engine coolant temperature input from ECT sensor	• Displays ECT
	V	ECT sensor voltage	Ignition switched ON (engine off) <ul style="list-style-type: none"> • ECT is 29 °C {84 °F}: Approx. 2.65 V Idle (after warm up) <ul style="list-style-type: none"> • ECT is 88 °C {190 °F}: Approx. 0.71 V

Diagnostic Procedure

STEP	INSPECTION	RESULTS	ACTION
1	RECORD VEHICLE STATUS AT TIME OF DTC DETECTION TO UTILIZE WITH REPEATABILITY VERIFICATION Note <ul style="list-style-type: none"> • Recording can be facilitated using the screen capture function of the PC. • Record the FREEZE FRAME DATA/snapshot data on the repair order. 	–	Go to the next step.
2	VERIFY RELATED REPAIR INFORMATION AVAILABILITY <ul style="list-style-type: none"> • Verify related Service Bulletins and/or on-line repair information availability. • Is any related repair information available? 	Yes	Perform repair or diagnosis according to the available repair information. • If the vehicle is not repaired, go to the next step.
		No	Go to the next step.
3	INSPECT ECT SENSOR CONNECTOR CONDITION <ul style="list-style-type: none"> • Switch the ignition off. • Disconnect the ECT sensor connector. • Inspect for poor connection (such as damaged/pulled-out pins, corrosion). • Is there any malfunction? 	Yes	Repair or replace the connector and/or terminals, then go to Step 8.
		No	Go to the next step.
4	DETERMINE IF ECT SENSOR OR WIRING HARNESS MALFUNCTION <ul style="list-style-type: none"> • Verify that the ECT sensor connector is disconnected. • Access the ECT PID using the M-MDS. (See ON-BOARD DIAGNOSTIC TEST [PCM (SKYACTIV-G 2.5T)].) • Connect a jumper wire between ECT sensor terminals A and B (wiring harness-side). • Verify the ECT PID value. • Is the voltage 4.9 V or below? 	Yes	Replace the ECT sensor, then go to Step 8. (See ENGINE COOLANT TEMPERATURE (ECT) SENSOR REMOVAL/INSTALLATION [SKYACTIV-G 2.5T] .)
		No	Go to the next step.

- Verify the malfunction symptom according to not only the PID value but also the symptom troubleshooting.

Related PIDs

Item (definition)	Unit/Condition	Definition	Condition/Specification (Reference)
TP1	%	Throttle valve position No.1	<ul style="list-style-type: none"> • Accelerator pedal released: Approx. 22% • Accelerator pedal fully depressed: Approx. 92%
	V	TP sensor No.1 voltage	<ul style="list-style-type: none"> • Accelerator pedal released: Approx. 3.92 V • Accelerator pedal fully depressed: Approx. 0.41 V

Diagnostic Procedure

STEP	INSPECTION	RESULTS	ACTION
1	RECORD VEHICLE STATUS AT TIME OF DTC DETECTION TO UTILIZE WITH REPEATABILITY VERIFICATION Note <ul style="list-style-type: none"> • Recording can be facilitated using the screen capture function of the PC. • Record the FREEZE FRAME DATA/snapshot data on the repair order. 	–	Go to the next step.
2	VERIFY RELATED REPAIR INFORMATION AVAILABILITY <ul style="list-style-type: none"> • Verify related Service Bulletins and/or on-line repair information availability. • Is any related repair information available? 	Yes	Perform repair or diagnosis according to the available repair information. • If the vehicle is not repaired, go to the next step.
		No	Go to the next step.
3	INSPECT THROTTLE BODY CONNECTOR CONDITION <ul style="list-style-type: none"> • Switch the ignition off. • Disconnect the throttle body connector. • Inspect for poor connection (such as damaged/pulled-out pins, corrosion). • Is there any malfunction? 	Yes	Repair or replace the connector and/or terminals, then go to Step 8.
		No	Go to the next step.
4	INSPECT PCM CONNECTOR CONDITION <ul style="list-style-type: none"> • Disconnect the PCM connector. • Inspect for poor connection (such as damaged/pulled-out pins, corrosion). • Is there any malfunction? 	Yes	Repair or replace the connector and/or terminals, then go to Step 8.
		No	Go to the next step.

Diagnostic Procedure

STEP	INSPECTION	RESULTS	ACTION
1	<p>RECORD VEHICLE STATUS AT TIME OF DTC DETECTION TO UTILIZE WITH REPEATABILITY VERIFICATION</p> <p>Note</p> <ul style="list-style-type: none">• Recording can be facilitated using the screen capture function of the PC.• Record the FREEZE FRAME DATA/snapshot data on the repair order.	–	Go to the next step.
2	<p>VERIFY RELATED REPAIR INFORMATION AVAILABILITY</p> <ul style="list-style-type: none">• Verify related Service Bulletins and/or on-line repair information availability.• Is any related repair information available?	Yes	Perform repair or diagnosis according to the available repair information. <ul style="list-style-type: none">• If the vehicle is not repaired, go to the next step.
		No	Go to the next step.
3	<p>INSPECT PURGE SOLENOID VALVE CONNECTOR CONDITION</p> <ul style="list-style-type: none">• Switch the ignition off.• Disconnect the purge solenoid valve connector.• Inspect for poor connection (such as damaged/pulled-out pins, corrosion).• Is there any malfunction?	Yes	Repair or replace the connector and/or terminals, then go to Step 10.
		No	Go to the next step.

STEP	INSPECTION	RESULTS	ACTION
11	VERIFY AFTER REPAIR PROCEDURE <ul style="list-style-type: none">• Perform the "AFTER REPAIR PROCEDURE". (See AFTER REPAIR PROCEDURE [PCM (SKYACTIV-G 2.5T)].)• Are any DTCs present?	Yes	Go to the applicable DTC inspection. (See DTC TABLE [PCM (SKYACTIV-G 2.5T)] .)
		No	DTC troubleshooting completed.

Sample