

# Your Ultimate Source for OEM Repair Manuals

FactoryManuals.net is a great resource for anyone who wants to save money on repairs by doing their own work. The manuals provide detailed instructions and diagrams that make it easy to understand how to fix a vehicle.

## 1996 MAZDA Xedos 6 OEM Service and Repair Workshop Manual

[Go to manual page](#)

STEP	INSPECTION	RESULTS	ACTION
6	<b>INSPECT BRAKE SWITCH No.2 GROUND CIRCUIT FOR OPEN CIRCUIT</b> <ul style="list-style-type: none"> <li>• Verify that the brake switch connector is disconnected.</li> <li>• Inspect for continuity between brake switch terminal B (wiring harness-side) and body ground.</li> <li>• Is there continuity?</li> </ul>	Yes	Go to the next step.
		No	Refer to the wiring diagram and verify whether or not there is a common connector between brake switch terminal B and body ground. <b>If there is a common connector:</b> <ul style="list-style-type: none"> <li>• Determine the malfunctioning part by inspecting the common connector and the terminal for corrosion, damage, or pin disconnection, and the common wiring harness for an open circuit.</li> <li>• Repair or replace the malfunctioning part.</li> </ul> <b>If there is no common connector:</b> <ul style="list-style-type: none"> <li>• Inspect for the following:               <ul style="list-style-type: none"> <li>— Open circuit between brake switch and body ground</li> <li>— Loose or lifting ground point</li> </ul> </li> <li>• Repair or replace the malfunctioning part.</li> </ul> Go to Step 12.
7	<b>INSPECT PCM CONNECTOR CONDITION</b> <ul style="list-style-type: none"> <li>• Disconnect the PCM connector.</li> <li>• Inspect for poor connection (such as damaged/pulled-out pins, corrosion).</li> <li>• Is there any malfunction?</li> </ul>	Yes	Repair or replace the connector and/or terminals, then go to Step 12.
		No	Go to the next step.
8	<b>INSPECT BRAKE SWITCH CIRCUIT FOR SHORT TO GROUND</b> <ul style="list-style-type: none"> <li>• Verify that the brake switch and PCM connectors are disconnected.</li> <li>• Inspect for continuity between the following terminals (wiring harness-side) and body ground:               <ul style="list-style-type: none"> <li>— Brake switch terminal D</li> <li>— Brake switch terminal C</li> </ul> </li> <li>• Is there continuity?</li> </ul>	Yes	Refer to the wiring diagram and verify whether or not there is a common connector between the following terminals: <ul style="list-style-type: none"> <li>• Brake switch terminal D–PCM terminal 2AB</li> <li>• Brake switch terminal C–PCM terminal 2P</li> </ul> <b>If there is a common connector:</b> <ul style="list-style-type: none"> <li>— Determine the malfunctioning part by inspecting the common connector and the terminal for corrosion, damage, or pin disconnection, and the common wiring harness for a short to ground.</li> <li>— Repair or replace the malfunctioning part.</li> </ul> <b>If there is no common connector:</b> <ul style="list-style-type: none"> <li>— Repair or replace the wiring harness which has a short to ground.</li> </ul> Go to Step 12.
		No	Go to the next step.
9	<b>INSPECT BRAKE SWITCH CIRCUIT FOR SHORT TO POWER SUPPLY</b> <ul style="list-style-type: none"> <li>• Verify that the brake switch and PCM connectors are disconnected.</li> <li>• Switch the ignition ON (engine off).</li> </ul> <p><b>Note</b></p> <ul style="list-style-type: none"> <li>• <b>Another DTC may be stored by the PCM detecting an open circuit.</b></li> <li>• Measure the voltage at the following terminals (wiring harness-side):               <ul style="list-style-type: none"> <li>— Brake switch terminal D</li> <li>— Brake switch terminal C</li> </ul> </li> <li>• Is the voltage 0 V?</li> </ul>	Yes	Go to the next step.
		No	Refer to the wiring diagram and verify whether or not there is a common connector between the following terminals: <ul style="list-style-type: none"> <li>• Brake switch terminal D–PCM terminal 2AB</li> <li>• Brake switch terminal C–PCM terminal 2P</li> </ul> <b>If there is a common connector:</b> <ul style="list-style-type: none"> <li>• Determine the malfunctioning part by inspecting the common connector and the terminal for corrosion, damage, or pin disconnection, and the common wiring harness for a short to power supply.</li> <li>• Repair or replace the malfunctioning part.</li> </ul> <b>If there is no common connector:</b> <ul style="list-style-type: none"> <li>• Repair or replace the wiring harness which has a short to power supply.</li> </ul> Go to Step 12.

DESCRIPTION	P013A:00
	<ul style="list-style-type: none"> <li>• HO2S: Slow response (during transition from rich to lean)</li> </ul>
	P013B:00
	<ul style="list-style-type: none"> <li>• HO2S: Slow response (during transition from lean to rich)</li> </ul>
POSSIBLE CAUSE	<ul style="list-style-type: none"> <li>• HO2S malfunction <ul style="list-style-type: none"> <li>— HO2S connector or terminals malfunction</li> <li>— HO2S loose</li> <li>— Exhaust system leakage</li> <li>— TWC damaged or malfunction</li> </ul> </li> <li>• HO2S deterioration</li> <li>• HO2S heater malfunction</li> <li>• Improper operation of purge control system <ul style="list-style-type: none"> <li>— Purge solenoid valve malfunction</li> <li>— Improper connection of evaporative hose (purge solenoid valve side)</li> </ul> </li> <li>• Engine malfunction <ul style="list-style-type: none"> <li>— Insufficient engine compression</li> </ul> </li> <li>• PCM malfunction</li> </ul>

## System Wiring Diagram

- Not applicable

## Function Explanation (DTC Detection Outline)

### P013A:00

- If the rate at which the HO2S output voltage is lowered is slow during fuel cut, a DTC is stored.

### P013B:00

- If the speed at which the HO2S output voltage rises is slow during fuel cut recovery, a DTC is stored.

## Repeatability Verification Procedure

1. Warm up the engine to allow the engine coolant temperature to reach 80 °C {176 °F} or more.
2. Verify that OBD-II information (such as FREEZE FRAME DATA) has been obtained and recorded.
3. Clear the DTC from the PCM memory using the M-MDS. (See **CLEARING DTC [PCM (SKYACTIV-G 2.5 (WITH CYLINDER DEACTIVATION))].**)
4. Switch the ignition off.
5. Drive the vehicle for 15 min at a speed of 40 km/h {25 mph} or more.
6. Shift to 3rd gear and rapidly accelerate the vehicle to 60 km/h {37 mph}.
7. Release the accelerator pedal and decelerate the vehicle to 40 km/h {25 mph}.
8. Repeat Step 5 to 7 operations above 5 times.
9. Try to reproduce the malfunction by driving the vehicle for 5 min based on the values in the FREEZE FRAME DATA/snapshot data.

### Note

- Match the engine coolant temperature in the recorded FREEZE FRAME DATA/snapshot data, the vehicle speed, and engine speed values to the best extent possible while driving the vehicle.

## PID Item/Simulation Item Used In Diagnosis

### PID/DATA monitor item table

— Verify that the primary malfunction is resolved and there are no other malfunctions.

STEP	INSPECTION	RESULTS	ACTION
1	<b>PURPOSE: DETERMINE INTEGRITY OF PURGE SOLENOID VALVE</b> • Inspect the purge solenoid valve. (See <b>PURGE SOLENOID VALVE INSPECTION [SKYACTIV-G 2.5 (WITH CYLINDER DEACTIVATION)]</b> .) • Is there any malfunction?	Yes	Replace the purge solenoid valve, then go to Step 10. (See <b>PURGE SOLENOID VALVE REMOVAL/INSTALLATION [SKYACTIV-G 2.5 (WITH CYLINDER DEACTIVATION)]</b> .)
		No	Go to the next step.
2	<b>PURPOSE: VERIFY IF DIAGNOSTIC RESULT IS AFFECTED BY MALFUNCTION RELATED TO POOR EVAPORATIVE HOSE CONNECTION</b> • Verify the connection condition of the evaporative hose (purge solenoid valve side). (See <b>PURGE SOLENOID VALVE REMOVAL/INSTALLATION [SKYACTIV-G 2.5 (WITH CYLINDER DEACTIVATION)]</b> .) • Is the evaporative hose (purge solenoid valve side) connection normal?	Yes	Go to the next step.
		No	Connect evaporative hose correctly, then go to Step 10. (See <b>PURGE SOLENOID VALVE REMOVAL/INSTALLATION [SKYACTIV-G 2.5 (WITH CYLINDER DEACTIVATION)]</b> .)
3	<b>PURPOSE: VERIFY IF MALFUNCTION RELATED TO ENGINE COMPRESSION AFFECTS DIAGNOSTIC RESULTS</b> • Inspect the engine compression. (See <b>COMPRESSION INSPECTION [SKYACTIV-G 2.5 (WITH CYLINDER DEACTIVATION)]</b> .) • Are compression pressures within specification?	Yes	Go to the next step.
		No	Replace or overhaul the engine, then go to Step 10.
4	<b>PURPOSE: INSPECT HO2S CONNECTOR CONDITION</b> • Switch the ignition off. • Disconnect the HO2S connector. • Inspect for poor connection (such as damaged/pulled-out pins, corrosion). • Is there any malfunction?	Yes	Repair or replace the connector and/or terminals, then go to Step 10.
		No	Go to the next step.
5	<b>PURPOSE: INSPECT INSTALLATION OF HO2S</b> • Inspect installation of HO2S. • Is the HO2S installed securely?	Yes	Go to the next step.
		No	Retighten the HO2S, then go to Step 10. (See <b>HEATED OXYGEN SENSOR (HO2S) REMOVAL/INSTALLATION [SKYACTIV-G 2.5 (WITH CYLINDER DEACTIVATION)]</b> .)
6	<b>PURPOSE: DETERMINE INTEGRITY OF HO2S</b> • Reconnect all disconnected connectors. • Inspect the HO2S. (See <b>HEATED OXYGEN SENSOR (HO2S) INSPECTION [SKYACTIV-G 2.5 (WITH CYLINDER DEACTIVATION)]</b> .) • Is there any malfunction?	Yes	Replace the HO2S, then go to Step 10. (See <b>HEATED OXYGEN SENSOR (HO2S) REMOVAL/INSTALLATION [SKYACTIV-G 2.5 (WITH CYLINDER DEACTIVATION)]</b> .)
		No	Go to the next step.
7	<b>PURPOSE: DETERMINE INTEGRITY OF HO2S HEATER</b> • Inspect the HO2S heater. (See <b>HEATED OXYGEN SENSOR (HO2S) INSPECTION [SKYACTIV-G 2.5 (WITH CYLINDER DEACTIVATION)]</b> .) • Is there any malfunction?	Yes	Replace the HO2S, then go to Step 10. (See <b>HEATED OXYGEN SENSOR (HO2S) REMOVAL/INSTALLATION [SKYACTIV-G 2.5 (WITH CYLINDER DEACTIVATION)]</b> .)
		No	Go to the next step.
8	<b>PURPOSE: INSPECT EXHAUST SYSTEM FOR LEAKAGE</b> • Visually inspect for exhaust gas leakage from the exhaust system. • Is there any malfunction?	Yes	Repair or replace the malfunctioning part according to the inspection results, then go to Step 10.
		No	Go to the next step.
9	<b>PURPOSE: VERIFY IF CATALYTIC CONVERTER DAMAGE AFFECTS HO2S SIGNAL</b> • Verify if the catalytic converter is damaged. • Is there any malfunction?	Yes	Repair or replace the malfunctioning part according to the inspection results, then go to the next step.
		No	Replace the HO2S, then go to the next step. (See <b>HEATED OXYGEN SENSOR (HO2S) REMOVAL/INSTALLATION [SKYACTIV-G 2.5 (WITH CYLINDER DEACTIVATION)]</b> .)




STEP	INSPECTION	RESULTS	ACTION
2	<b>RECORD VEHICLE STATUS AT TIME OF DTC DETECTION TO UTILIZE WITH REPEATABILITY VERIFICATION</b>  <b>Note</b> <ul style="list-style-type: none"> <li>Recording can be facilitated using the screen capture function of the PC.</li> <li>Record the FREEZE FRAME DATA/snapshot data on the repair order.</li> </ul>	–	Go to the next step.
3	<b>VERIFY RELATED REPAIR INFORMATION AVAILABILITY</b> <ul style="list-style-type: none"> <li>Verify related Service Bulletins and/or on-line repair information availability.</li> <li>Is any related repair information available?</li> </ul>	Yes	Perform repair or diagnosis according to the available repair information. • If the vehicle is not repaired, go to the next step.
		No	Go to the next step.
4	<b>INSPECT ECT SENSOR No.1 CONNECTOR CONDITION</b> <ul style="list-style-type: none"> <li>Switch the ignition off.</li> <li>Disconnect the ECT sensor No.1 connector.</li> <li>Inspect for poor connection (such as damaged/pulled-out pins, corrosion).</li> <li>Is there any malfunction?</li> </ul>	Yes	Repair or replace the connector and/or terminals, then go to Step 9.
		No	Go to the next step.
5	<b>INSPECT ENGINE OIL TEMPERATURE SENSOR CONNECTOR CONDITION</b> <ul style="list-style-type: none"> <li>Disconnect the engine oil temperature sensor connector.</li> <li>Inspect for poor connection (such as damaged/pulled-out pins, corrosion).</li> <li>Is there any malfunction?</li> </ul>	Yes	Repair or replace the connector and/or terminals, then go to Step 9.
		No	Go to the next step.
6	<b>INSPECT PCM CONNECTOR CONDITION</b> <ul style="list-style-type: none"> <li>Disconnect the PCM connector.</li> <li>Inspect for poor connection (such as damaged/pulled-out pins, corrosion).</li> <li>Is there any malfunction?</li> </ul>	Yes	Repair or replace the connector and/or terminals, then go to Step 9.
		No	Go to the next step.
7	<b>INSPECT ECT SENSOR No.1</b> <ul style="list-style-type: none"> <li>Inspect the ECT sensor No.1. (See <b>ENGINE COOLANT TEMPERATURE (ECT) SENSOR INSPECTION [SKYACTIV-G (WITHOUT EGR COOLER)]</b>.) (See <b>ENGINE COOLANT TEMPERATURE (ECT) SENSOR INSPECTION [SKYACTIV-G (WITH EGR COOLER)]</b>.)</li> <li>Is there any malfunction?</li> </ul>	Yes	Replace the ECT sensor No.1, then go to Step 9. (See <b>ENGINE COOLANT TEMPERATURE (ECT) SENSOR REMOVAL/INSTALLATION [SKYACTIV-G 2.5 (WITH CYLINDER DEACTIVATION)]</b> .)
		No	Go to the next step.
8	<b>INSPECT ENGINE OIL TEMPERATURE SENSOR</b> <ul style="list-style-type: none"> <li>Inspect the engine oil temperature sensor. (See <b>ENGINE OIL TEMPERATURE SENSOR INSPECTION [SKYACTIV-G 2.5 (WITH CYLINDER DEACTIVATION)]</b>.)</li> <li>Is there any malfunction?</li> </ul>	Yes	Replace the engine oil temperature sensor, then go to the next step. (See <b>ENGINE OIL TEMPERATURE SENSOR/ENGINE OIL PRESSURE SENSOR REMOVAL/INSTALLATION [SKYACTIV-G 2.5 (WITH CYLINDER DEACTIVATION)]</b> .)
		No	Go to the next step.
9	<b>VERIFY DTC TROUBLESHOOTING COMPLETED</b> <ul style="list-style-type: none"> <li>Always reconnect all disconnected connectors.</li> <li>Clear the DTC from the PCM memory using the M-MDS. (See <b>CLEARING DTC [PCM (SKYACTIV-G 2.5 (WITH CYLINDER DEACTIVATION))]</b>.)</li> <li>Switch the ignition off.</li> <li>Start the engine and warm it up completely.</li> <li>Perform the Pending Trouble Code Access Procedure. (See <b>ON-BOARD DIAGNOSTIC TEST [PCM (SKYACTIV-G 2.5 (WITH CYLINDER DEACTIVATION))]</b>.)</li> <li>Is the PENDING CODE for this DTC present?</li> </ul>	Yes	Repeat the inspection from Step 1. • If the malfunction recurs, replace the PCM. (See <b>PCM REMOVAL/INSTALLATION [SKYACTIV-G 2.5 (WITH CYLINDER DEACTIVATION)]</b> .) Go to the next step.
		No	Go to the next step.

STEP	INSPECTION		ACTION
2	<b>RECORD VEHICLE STATUS AT TIME OF DTC DETECTION TO UTILIZE WITH REPEATABILITY VERIFICATION</b>  <b>Note</b> <ul style="list-style-type: none"> <li>Recording can be facilitated using the screen capture function of the PC.</li> <li>Record the FREEZE FRAME DATA/snapshot data on the repair order.</li> </ul>	–	Go to the next step.
3	<b>VERIFY RELATED REPAIR INFORMATION AVAILABILITY</b> <ul style="list-style-type: none"> <li>Verify related Service Bulletins and/or on-line repair information availability.</li> <li>Is any related repair information available?</li> </ul>	Yes	Perform repair or diagnosis according to the available repair information. • If the vehicle is not repaired, go to the next step.
		No	Go to the next step.
4	<b>INSPECT ECT SENSOR No.1 CONNECTOR CONDITION</b> <ul style="list-style-type: none"> <li>Switch the ignition off.</li> <li>Disconnect the ECT sensor No.1 connector.</li> <li>Inspect for poor connection (such as damaged/pulled-out pins, corrosion).</li> <li>Is there any malfunction?</li> </ul>	Yes	Repair or replace the connector and/or terminals, then go to Step 9.
		No	Go to the next step.
5	<b>INSPECT ECT SENSOR No.2 CONNECTOR CONDITION</b> <ul style="list-style-type: none"> <li>Disconnect the ECT sensor No.2 connector.</li> <li>Inspect for poor connection (such as damaged/pulled-out pins, corrosion).</li> <li>Is there any malfunction?</li> </ul>	Yes	Repair or replace the connector and/or terminals, then go to Step 9.
		No	Go to the next step.
6	<b>INSPECT PCM CONNECTOR CONDITION</b> <ul style="list-style-type: none"> <li>Disconnect the PCM connector.</li> <li>Inspect for poor connection (such as damaged/pulled-out pins, corrosion).</li> <li>Is there any malfunction?</li> </ul>	Yes	Repair or replace the connector and/or terminals, then go to Step 9.
		No	Go to the next step.
7	<b>INSPECT ECT SENSOR No.1</b> <ul style="list-style-type: none"> <li>Inspect the ECT sensor No.1. (See <b>ENGINE COOLANT TEMPERATURE (ECT) SENSOR INSPECTION [SKYACTIV-G (WITHOUT EGR COOLER)]</b>.) (See <b>ENGINE COOLANT TEMPERATURE (ECT) SENSOR INSPECTION [SKYACTIV-G (WITH EGR COOLER)]</b>.)</li> <li>Is there any malfunction?</li> </ul>	Yes	Replace the ECT sensor No.1, then go to Step 9. (See <b>ENGINE COOLANT TEMPERATURE (ECT) SENSOR REMOVAL/INSTALLATION [SKYACTIV-G 2.5 (WITH CYLINDER DEACTIVATION)]</b> .)
		No	Go to the next step.
8	<b>INSPECT ECT SENSOR No.2</b> <ul style="list-style-type: none"> <li>Inspect the ECT sensor No.2. (See <b>ENGINE COOLANT TEMPERATURE (ECT) SENSOR INSPECTION [SKYACTIV-G (WITHOUT EGR COOLER)]</b>.) (See <b>ENGINE COOLANT TEMPERATURE (ECT) SENSOR INSPECTION [SKYACTIV-G (WITH EGR COOLER)]</b>.)</li> <li>Is there any malfunction?</li> </ul>	Yes	Replace the ECT sensor No.2, then go to the next step. (See <b>ENGINE COOLANT TEMPERATURE (ECT) SENSOR REMOVAL/INSTALLATION [SKYACTIV-G 2.5 (WITH CYLINDER DEACTIVATION)]</b> .)
		No	Go to the next step.
9	<b>VERIFY DTC TROUBLESHOOTING COMPLETED</b> <ul style="list-style-type: none"> <li>Always reconnect all disconnected connectors.</li> <li>Clear the DTC from the PCM memory using the M-MDS. (See <b>CLEARING DTC [PCM (SKYACTIV-G 2.5 (WITH CYLINDER DEACTIVATION))]</b>.)</li> <li>Switch the ignition off.</li> <li>Start the engine and warm it up completely.</li> <li>Perform the Pending Trouble Code Access Procedure. (See <b>ON-BOARD DIAGNOSTIC TEST [PCM (SKYACTIV-G 2.5 (WITH CYLINDER DEACTIVATION))]</b>.)</li> <li>Is the PENDING CODE for this DTC present?</li> </ul>	Yes	Repeat the inspection from Step 1. • If the malfunction recurs, replace the PCM. (See <b>PCM REMOVAL/INSTALLATION [SKYACTIV-G 2.5 (WITH CYLINDER DEACTIVATION)]</b> .) Go to the next step.
		No	Go to the next step.


–: Not applicable

## Function Inspection Using M-MDS


STEP	INSPECTION	RESULTS	ACTION
1	<p><b>PURPOSE: RECORD VEHICLE STATUS AT TIME OF DTC DETECTION TO UTILIZE WITH REPEATABILITY VERIFICATION</b></p> <p><b>Note</b></p> <ul style="list-style-type: none"> <li>• Recording can be facilitated using the screen capture function of the PC.</li> <li>• Record the snapshot data on the repair order.</li> </ul>	–	Go to the next step.
2	<p><b>PURPOSE: VERIFY RELATED REPAIR INFORMATION AVAILABILITY</b></p> <ul style="list-style-type: none"> <li>• Verify related Service Bulletins and/or on-line repair information availability.</li> <li>• Is any related repair information available?</li> </ul>	Yes	Perform repair or diagnosis according to the available repair information.
		No	Go to the next step.
3	<p><b>PURPOSE: VERIFY IF BATTERY VOLTAGE IS FALSELY RECOGNIZED BY DTC RELATED CURRENT SENSOR</b></p> <ul style="list-style-type: none"> <li>• Switch the ignition off, then ON (engine off).</li> <li>• Perform the Pending Trouble Code Access Procedure and DTC Reading Procedure. (See <b>ON-BOARD DIAGNOSTIC TEST [PCM (SKYACTIV-G 2.5 (WITH CYLINDER DEACTIVATION))]</b>.)</li> <li>• Is the PENDING CODE/DTC P058A:00 also present?</li> </ul>	Yes	Go to the applicable PENDING CODE or DTC inspection. (See <b>DTC P058A:00 [PCM (SKYACTIV-G 2.5 (WITH CYLINDER DEACTIVATION))]</b> .) Go to the next step.
		No	Go to the next step.
4	<p><b>PURPOSE: VERIFY IF BATTERY VOLTAGE IS FALSELY RECOGNIZED BY DTC RELATED CAN OR LIN COMMUNICATION</b></p> <ul style="list-style-type: none"> <li>• Perform the PCM and front body control module (FBCM) DTC inspection using the M-MDS. (See <b>ON-BOARD DIAGNOSTIC TEST [PCM (SKYACTIV-G 2.5 (WITH CYLINDER DEACTIVATION))]</b>.) (See <b>DTC INSPECTION [FRONT BODY CONTROL MODULE (FBCM)]</b>.)</li> <li>• Are DTCs related CAN or LIN communication recorded?</li> </ul>	Yes	Repair or replace the malfunctioning part according to the applicable DTC troubleshooting. (See <b>DTC TABLE [PCM (SKYACTIV-G 2.5 (WITH CYLINDER DEACTIVATION))]</b> .) (See <b>DTC TABLE [FRONT BODY CONTROL MODULE (FBCM)]</b> .) Go to the next step.
		No	Go to the next step



SWIRL CONTROL VALVE POSITION SENSOR  
WIRING HARNESS-SIDE  
CONNECTOR



PCM  
WIRING HARNESS-SIDE CONNECTOR



Diagnostic Procedure

STEP	INSPECTION	RESULTS	ACTION
1	<p>RECORD VEHICLE STATUS AT TIME OF DTC DETECTION TO UTILIZE WITH REPEATABILITY VERIFICATION</p> <p><b>Note</b></p> <ul style="list-style-type: none"><li>• Recording can be facilitated using the screen capture function of the PC.</li><li>• Record the snapshot data on the repair order.</li></ul>	-	Go to the next step.

DTC P2017:00 [PCM (SKYACTIV-G 2.5 (WITH CYLINDER DEACTIVATION))]

SM3511175

id0102s970720

DTC P2017:00	Swirl control valve position sensor circuit high input
DETECTION CONDITION	<ul style="list-style-type: none"><li>• If the PCM detects that the swirl control valve position sensor voltage at the PCM terminal 1BB is above 4.865 V, the PCM determines that the swirl control valve position sensor circuit has a malfunction.</li></ul> <b>Diagnostic support note</b> <ul style="list-style-type: none"><li>• This is a continuous monitor (other).</li><li>• The check engine light illuminates if the PCM detects the above malfunction condition during the first drive cycle.</li><li>• FREEZE FRAME DATA/Snapshot data is available.</li><li>• DTC is stored in the PCM memory.</li></ul>
FAIL-SAFE FUNCTION	<ul style="list-style-type: none"><li>• Increases the idle speed while idling.</li><li>• Inhibits the AWS control.</li><li>• Limits intake air amount</li><li>• Stops the swirl control.</li><li>• Stops the EGR control.</li></ul>
POSSIBLE CAUSE	<ul style="list-style-type: none"><li>• Swirl control valve position sensor connector or terminals malfunction</li><li>• PCM connector or terminals malfunction</li><li>• Short to power supply in wiring harness between swirl control valve position sensor terminal C and PCM terminal 1BB</li><li>• Open circuit in wiring harness between swirl control valve position sensor terminal B and PCM terminal 1BH</li><li>• Swirl control valve position sensor malfunction</li><li>• PCM malfunction</li></ul>

STEP	INSPECTION	RESULTS	ACTION
8	<b>VERIFY DTC TROUBLESHOOTING COMPLETED</b> <ul style="list-style-type: none"> <li>• Always reconnect all disconnected connectors.</li> <li>• Clear the DTC from the PCM memory using the M-MDS. (See <b>CLEARING DTC [PCM (SKYACTIV-G 2.5 (WITH CYLINDER DEACTIVATION))]</b>.)</li> <li>• Perform the KOEO or KOER self test. (See <b>KOEO/KOER SELF TEST [PCM (SKYACTIV-G 2.5 (WITH CYLINDER DEACTIVATION))]</b>.)</li> <li>• Is the same Pending DTC present?</li> </ul>	Yes	Repeat the inspection from Step 1. <ul style="list-style-type: none"> <li>• If the malfunction recurs, replace the PCM. (See <b>PCM REMOVAL/INSTALLATION [SKYACTIV-G 2.5 (WITH CYLINDER DEACTIVATION)]</b>.)</li> </ul> Go to the next step.
		No	Go to the next step.
9	<b>VERIFY AFTER REPAIR PROCEDURE</b> <ul style="list-style-type: none"> <li>• Perform the "AFTER REPAIR PROCEDURE". (See <b>AFTER REPAIR PROCEDURE [PCM (SKYACTIV-G 2.5 (WITH CYLINDER DEACTIVATION))]</b>.)</li> <li>• Are any DTCs present?</li> </ul>	Yes	Go to the applicable DTC inspection. (See <b>DTC TABLE [PCM (SKYACTIV-G 2.5 (WITH CYLINDER DEACTIVATION))]</b> .)
		No	DTC troubleshooting completed.