

Your Ultimate Source for OEM Repair Manuals

FactoryManuals.net is a great resource for anyone who wants to save money on repairs by doing their own work. The manuals provide detailed instructions and diagrams that make it easy to understand how to fix a vehicle.

1997 MAZDA RX-7 (FD) OEM Service and Repair Workshop Manual

[Go to manual page](#)

DTC P055F:00 [PCM (SKYACTIV-G 2.5 (WITH CYLINDER DEACTIVATION))]

SM2896684

id0102s921530

Note

- To determine the malfunctioning part, proceed with the diagnostics from "Function Inspection Using M-MDS".

Details On DTCs

DESCRIPTION	Engine oil pressure malfunction	
DETECTION CONDITION	Determination conditions	<ul style="list-style-type: none">• If any of the following conditions is met under condition A or condition B: Condition A: — The actual hydraulic pressure is extremely high for a continuous 10 s even if the PCM commands low hydraulic pressure. Condition B: — The actual hydraulic pressure is extremely low for a continuous 10 s even if the PCM commands low hydraulic pressure.
	Drive cycle	<ul style="list-style-type: none">• 1
	Self test type	<ul style="list-style-type: none">• CMDTC self test
	Sensor used	<ul style="list-style-type: none">• Engine oil pressure sensor
FAIL-SAFE FUNCTION	Condition A: <ul style="list-style-type: none">• Not applicable Condition B: <ul style="list-style-type: none">• Restricts the upper limit of the engine speed.• PCM restricts engine torque.	
VEHICLE STATUS WHEN DTCs ARE OUTPUT	<ul style="list-style-type: none">• Illuminates check engine light.• Illuminates engine oil warning light.• The engine oil warning indication is displayed on the multi-information display. (with multi-information display)	

STEP	INSPECTION	RESULTS	ACTION
1	RECORD VEHICLE STATUS AT TIME OF DTC DETECTION TO UTILIZE WITH REPEATABILITY VERIFICATION Note <ul style="list-style-type: none"> Recording can be facilitated using the screen capture function of the PC. Record the FREEZE FRAME DATA/snapshot data on the repair order. 	–	Go to the next step.
2	VERIFY RELATED REPAIR INFORMATION AVAILABILITY <ul style="list-style-type: none"> Verify related Service Bulletins and/or on-line repair information availability. Is any related repair information available? 	Yes	Perform repair or diagnosis according to the available repair information. • If the vehicle is not repaired, go to the next step.
		No	Go to the next step.
3	INSPECT ENGINE OIL LEAKAGE <ul style="list-style-type: none"> Start the engine. Verify that there is no engine oil leakage in the hydraulic circuit. Is there any leakage? 	Yes	Repair or replace the malfunctioning part according to the inspection results, then add genuine engine oil. (See ENGINE OIL REPLACEMENT [SKYACTIV-G 2.5 (WITH CYLINDER DEACTIVATION)] .) Go to the Step 13.
		No	Go to the next step.
4	INSPECT ENGINE OIL LEVEL <ul style="list-style-type: none"> Switch the ignition off. Inspect the engine oil level. (See ENGINE OIL LEVEL INSPECTION [SKYACTIV-G 2.5 (WITH CYLINDER DEACTIVATION)].) Is the engine oil level sufficient? 	Yes	Go to the next step.
		No	Add genuine engine oil. (See ENGINE OIL REPLACEMENT [SKYACTIV-G 2.5 (WITH CYLINDER DEACTIVATION)] .) Go to the Step 13.
5	INSPECT ENGINE OIL TEMPERATURE SENSOR/ENGINE OIL PRESSURE SENSOR CONNECTOR CONDITION <ul style="list-style-type: none"> Disconnect the engine oil temperature sensor/engine oil pressure sensor connector. Inspect for poor connection (such as damaged/pulled-out pins, corrosion). Is there any malfunction? 	Yes	Repair or replace the connector and/or terminals, then go to Step 13.
		No	Go to the next step.
6	INSPECT PCM CONNECTOR CONDITION <ul style="list-style-type: none"> Disconnect the PCM connector. Inspect for poor connection (such as damaged/pulled-out pins, corrosion). Is there any malfunction? 	Yes	Repair or replace the connector and/or terminals, then go to Step 13.
		No	Go to the next step.

STEP	INSPECTION	RESULTS	ACTION
13	VERIFY DTC TROUBLESHOOTING COMPLETED <ul style="list-style-type: none"> • Always reconnect all disconnected connectors. • Clear the DTC from the PCM memory using the M-MDS. (See CLEARING DTC [PCM (SKYACTIV-G 2.5 (WITH CYLINDER DEACTIVATION))].) • Implement the repeatability verification procedure. (See Repeatability Verification Procedure.) • Perform the DTC Reading Procedure. (See ON-BOARD DIAGNOSTIC TEST [PCM (SKYACTIV-G 2.5 (WITH CYLINDER DEACTIVATION))].) • Is the same Pending DTC present? 	Yes	Repeat the inspection from Step 1. <ul style="list-style-type: none"> • If the malfunction recurs, replace the PCM. (See PCM REMOVAL/INSTALLATION [SKYACTIV-G 2.5 (WITH CYLINDER DEACTIVATION)].) Go to the next step.
		No	Go to the next step.
14	VERIFY AFTER REPAIR PROCEDURE <ul style="list-style-type: none"> • Perform the "AFTER REPAIR PROCEDURE". (See AFTER REPAIR PROCEDURE [PCM (SKYACTIV-G 2.5 (WITH CYLINDER DEACTIVATION))].) • Are any DTCs present? 	Yes	Go to the applicable DTC inspection. (See DTC TABLE [PCM (SKYACTIV-G 2.5 (WITH CYLINDER DEACTIVATION))] .)
		No	DTC troubleshooting completed.

STEP	INSPECTION	RESULTS	ACTION
1	RECORD VEHICLE STATUS AT TIME OF DTC DETECTION TO UTILIZE WITH REPEATABILITY VERIFICATION Note <ul style="list-style-type: none"> Recording can be facilitated using the screen capture function of the PC. Record the snapshot data on the repair order. 	–	Go to the next step.
2	VERIFY RELATED REPAIR INFORMATION AVAILABILITY <ul style="list-style-type: none"> Verify related Service Bulletins and/or on-line repair information availability. Is any related repair information available? 	Yes	Perform repair or diagnosis according to the available repair information. • If the vehicle is not repaired, go to the next step.
		No	Go to the next step.
3	VERIFY DTC FOR MODULE COMMUNICATION <ul style="list-style-type: none"> Switch the ignition off, then ON (engine off). Perform the DTC Reading Procedure. (See ON-BOARD DIAGNOSTIC TEST [PCM (SKYACTIV-G 2.5 (WITH CYLINDER DEACTIVATION))].) Is the DTC U0155:00 also present? 	Yes	Go to the applicable DTC inspection. (See DTC U0073:00, U0101:00, U0104:00, U0121:00, U0131:00, U0140:00, U0151:00, U0155:00, U0214:00, U023A:00 [PCM (SKYACTIV-G 2.5 (WITH CYLINDER DEACTIVATION))] .)
		No	Go to the next step.
4	CONFIRM INSTRUMENT CLUSTER DTC <ul style="list-style-type: none"> Perform the instrument cluster DTC inspection using the M-MDS. (See DTC INSPECTION [INSTRUMENT CLUSTER].) Are any DTCs present? 	Yes	Go to the applicable DTC inspection. (See DTC TABLE [INSTRUMENT CLUSTER] .)
		No	Go to the next step.
5	INSPECT PCM CONNECTOR CONDITION <ul style="list-style-type: none"> Switch the ignition off. Disconnect the PCM connector. Inspect for poor connection (such as damaged/pulled-out pins, corrosion). Is there any malfunction? 	Yes	Repair or replace the connector and/or terminals, then go to Step 9.
		No	Go to the next step.
6	INSPECT INSTRUMENT CLUSTER CONNECTOR CONDITION <ul style="list-style-type: none"> Disconnect the instrument cluster connector. Inspect for poor connection (such as damaged/pulled-out pins, corrosion). Is there any malfunction? 	Yes	Repair or replace the connector and/or terminals, then go to Step 9.
		No	Go to the next step.
7	INSPECT INSTALLATION OF INSTRUMENT CLUSTER <ul style="list-style-type: none"> Inspect installation of instrument cluster. Is the instrument cluster installed securely? 	Yes	Go to the next step.
		No	Retighten the instrument cluster, then go to Step 9. (See INSTRUMENT CLUSTER REMOVAL/INSTALLATION .)
8	INSPECT INSTRUMENT CLUSTER <ul style="list-style-type: none"> Inspect the instrument cluster. (See INSTRUMENT CLUSTER INSPECTION.) Is there any malfunction? 	Yes	Replace the instrument cluster, then go to the next step. (See INSTRUMENT CLUSTER REMOVAL/INSTALLATION .)
		No	Go to the next step.

Sample

STEP	INSPECTION	RESULTS	ACTION
2	VERIFY RELATED REPAIR INFORMATION AVAILABILITY <ul style="list-style-type: none"> • Verify related Service Bulletins and/or on-line repair information availability. • Is any related repair information available? 	Yes	Perform repair or diagnosis according to the available repair information. • If the vehicle is not repaired, go to the next step.
		No	Go to the next step.
3	INSPECT A/F SENSOR CONNECTOR CONDITION <ul style="list-style-type: none"> • Switch the ignition off. • Disconnect the A/F sensor connector. • Inspect for poor connection (such as damaged/pulled-out pins, corrosion). • Is there any malfunction? 	Yes	Repair or replace the connector and/or terminals, then go to Step 9.
		No	Go to the next step.
4	INSPECT A/F SENSOR HEATER POWER SUPPLY CIRCUIT FOR SHORT TO GROUND OR OPEN CIRCUIT <ul style="list-style-type: none"> • Verify that the A/F sensor connector is disconnected. • Switch the ignition ON (engine off). <p>Note</p> <ul style="list-style-type: none"> • Another DTC may be stored by the PCM detecting an open circuit. • Measure the voltage at the A/F sensor terminal A (wiring harness-side). • Is the voltage B+? 	Yes	Go to the next step.
		No	Inspect the ENGINE2 15 A fuse. • If the fuse is blown: <ul style="list-style-type: none"> — Refer to the wiring diagram and verify whether or not there is a common connector between ENGINE2 15 A fuse and A/F sensor terminal A. <p>If there is a common connector:</p> <ul style="list-style-type: none"> • Determine the malfunctioning part by inspecting the common connector and the terminal for corrosion, damage, or pin disconnection, and the common wiring harness for a short to ground. • Repair or replace the malfunctioning part. <p>If there is no common connector:</p> <ul style="list-style-type: none"> • Repair or replace the wiring harness which has a short to ground. • Replace the fuse. <ul style="list-style-type: none"> • If the fuse is damaged: <ul style="list-style-type: none"> — Replace the fuse. • If the fuse is normal: <ul style="list-style-type: none"> — Refer to the wiring diagram and verify whether or not there is a common connector between sub relay terminal C and A/F sensor terminal A. <p>If there is a common connector:</p> <ul style="list-style-type: none"> • Determine the malfunctioning part by inspecting the common connector and the terminal for corrosion, damage, or pin disconnection, and the common wiring harness for an open circuit. • Repair or replace the malfunctioning part. <p>If there is no common connector:</p> <ul style="list-style-type: none"> • Repair or replace the wiring harness which has an open circuit. Go to Step 9.

STEP	INSPECTION	RESULTS	ACTION
1	<p>RECORD FREEZE FRAME DATA/SNAPSHOT DATA AND DIAGNOSTIC MONITORING TEST RESULTS TO UTILIZE WITH REPEATABILITY VERIFICATION</p> <p>Note</p> <ul style="list-style-type: none"> Recording can be facilitated using the screen capture function of the PC. Record the FREEZE FRAME DATA/snapshot data and DIAGNOSTIC MONITORING TEST RESULTS (A/F sensor heater, HO2S heater related) on the repair order. 	–	Go to the next step.
2	<p>VERIFY RELATED REPAIR INFORMATION AVAILABILITY</p> <ul style="list-style-type: none"> Verify related Service Bulletins and/or on-line repair information availability. Is any related repair information available? 	Yes	Perform repair or diagnosis according to the available repair information.
		No	Go to the next step.
3	<p>INSPECT A/F SENSOR CONNECTOR CONDITION</p> <ul style="list-style-type: none"> Switch the ignition off. Disconnect the A/F sensor connector. Inspect for poor connection (such as damaged/pulled-out pins, corrosion). Is there any malfunction? 	Yes	Repair or replace the connector and/or terminals, then go to Step 7.
		No	Go to the next step.
4	<p>INSPECT PCM CONNECTOR CONDITION</p> <ul style="list-style-type: none"> Disconnect the PCM connector. Inspect for poor connection (such as damaged/pulled-out pins, corrosion). Is there any malfunction? 	Yes	Repair or replace the connector and/or terminals, then go to Step 7.
		No	Go to the next step.
5	<p>INSPECT A/F SENSOR HEATER CONTROL CIRCUIT FOR SHORT TO POWER SUPPLY</p> <ul style="list-style-type: none"> Verify that the A/F sensor and PCM connectors are disconnected. Switch the ignition ON (engine off). <p>Note</p> <ul style="list-style-type: none"> Another DTC may be stored by the PCM detecting an open circuit. Measure the voltage at the A/F sensor terminal E (wiring harness-side). Is the voltage 0 V? 	Yes	Go to the next step.
		No	<p>Refer to the wiring diagram and verify whether or not there is a common connector between A/F sensor terminal E and PCM terminal 1CB.</p> <p>If there is a common connector:</p> <ul style="list-style-type: none"> Determine the malfunctioning part by inspecting the common connector and the terminal for corrosion, damage, or pin disconnection, and the common wiring harness for a short to power supply. Repair or replace the malfunctioning part. <p>If there is no common connector:</p> <ul style="list-style-type: none"> Repair or replace the wiring harness which has a short to power supply. <p>Go to Step 7.</p>
6	<p>INSPECT A/F SENSOR HEATER</p> <ul style="list-style-type: none"> Inspect the A/F sensor heater. (See AIR FUEL RATIO (A/F) SENSOR INSPECTION [SKYACTIV-G 2.5 (WITH CYLINDER DEACTIVATION)].) Is there any malfunction? 	Yes	Replace the A/F sensor, then go to the next step. (See AIR FUEL RATIO (A/F) SENSOR REMOVAL/INSTALLATION [SKYACTIV-G 2.5 (WITH CYLINDER DEACTIVATION)] .)
		No	Go to the next step.

Diagnostic Procedure

STEP	INSPECTION	RESULTS	ACTION
1	<p>RECORD FREEZE FRAME DATA/SNAPSHOT DATA AND DIAGNOSTIC MONITORING TEST RESULTS TO UTILIZE WITH REPEATABILITY VERIFICATION</p> <p>Note</p> <ul style="list-style-type: none">• Recording can be facilitated using the screen capture function of the PC.• Record the FREEZE FRAME DATA/snapshot data and DIAGNOSTIC MONITORING TEST RESULTS (A/F sensor heater, HO2S heater related) on the repair order.	–	Go to the next step.
2	<p>VERIFY RELATED REPAIR INFORMATION AVAILABILITY</p> <ul style="list-style-type: none">• Verify related Service Bulletins and/or on-line repair information availability.• Is any related repair information available?	Yes	Perform repair or diagnosis according to the available repair information. <ul style="list-style-type: none">• If the vehicle is not repaired, go to the next step.
		No	Go to the next step.
3	<p>INSPECT HO2S CONNECTOR CONDITION</p> <ul style="list-style-type: none">• Switch the ignition off.• Disconnect the HO2S connector.• Inspect for poor connection (such as damaged/pulled-out pins, corrosion).• Is there any malfunction?	Yes	Repair or replace the connector and/or terminals, then go to Step 9.
		No	Go to the next step.

DTC P2308:00 [PCM (SKYACTIV-G 2.5 (WITH CYLINDER DEACTIVATION))]

SM2896793

id0102s974320

DTC P2308:00	Ion sensor No.3 circuit problem
DETECTION CONDITION	<ul style="list-style-type: none">• After the engine is started, when the engine speed is 2,000 rpm or less, the signal input to the PCM from ion sensor No.3 is in error. Diagnostic support note <ul style="list-style-type: none">• This is a continuous monitor (other).• The check engine light does not illuminate.• FREEZE FRAME DATA is not available.• Snapshot data is available.• DTC is stored in the PCM memory.
FAIL-SAFE FUNCTION	<ul style="list-style-type: none">• Not applicable
POSSIBLE CAUSE	<ul style="list-style-type: none">• Cylinder No.3 misfire• Ignition coil/ion sensor No.3 connector or terminals malfunction• Short to ground or open circuit in ion sensor No.3 power supply circuit<ul style="list-style-type: none">— Short to ground in wiring harness between ENGINE2 15 A fuse and ignition coil/ion sensor No.3 terminal A— ENGINE2 15 A fuse malfunction— Open circuit in wiring harness between sub relay terminal C and ignition coil/ion sensor No.3 terminal A• Open circuit in wiring harness between ignition coil/ion sensor No.3 terminal D and body ground• PCM connector or terminals malfunction• Short to ground in wiring harness between ignition coil/ion sensor No.3 terminal C and PCM terminal 1AK• Short to power supply in wiring harness between ignition coil/ion sensor No.3 terminal C and PCM terminal 1AK• Open circuit in wiring harness between ignition coil/ion sensor No.3 terminal C and PCM terminal 1AK• Ion sensor No.3 malfunction• PCM malfunction