

# Your Ultimate Source for OEM Repair Manuals

FactoryManuals.net is a great resource for anyone who wants to save money on repairs by doing their own work. The manuals provide detailed instructions and diagrams that make it easy to understand how to fix a vehicle.

## 1999 MAZDA Xedos 9 OEM Service and Repair Workshop Manual

[Go to manual page](#)

STEP	INSPECTION	RESULTS	ACTION
3	<b>VERIFY RELATED PENDING CODE AND/OR DTC</b> <ul style="list-style-type: none"> <li>• Switch the ignition off, then ON (engine off).</li> <li>• Perform the Pending Trouble Code Access Procedure and DTC Reading Procedure. (See <b>ON-BOARD DIAGNOSTIC TEST [PCM (SKYACTIV-G 2.5 (WITHOUT CYLINDER DEACTIVATION))]</b>.)</li> <li>• Is the PENDING CODE/DTC P0303:00 also present?</li> </ul>	Yes	Go to the applicable PENDING CODE or DTC inspection. (See <b>DTC P0301:00, P0302:00, P0303:00, P0304:00 [PCM (SKYACTIV-G 2.5 (WITHOUT CYLINDER DEACTIVATION))]</b> .)
		No	Go to the next step.
4	<b>INSPECT IGNITION COIL/ION SENSOR No.3 CONNECTOR CONDITION</b> <ul style="list-style-type: none"> <li>• Switch the ignition off.</li> <li>• Disconnect the ignition coil/ion sensor No.3 connector.</li> <li>• Inspect for poor connection (such as damaged/pulled-out pins, corrosion).</li> <li>• Is there any malfunction?</li> </ul>	Yes	Repair or replace the connector and/or terminals, then go to Step 12.
		No	Go to the next step.

STEP	INSPECTION	RESULTS	ACTION
8	<b>INSPECT PCM CONNECTOR CONDITION</b> <ul style="list-style-type: none"> <li>• Disconnect the PCM connector.</li> <li>• Inspect for poor connection (such as damaged/pulled-out pins, corrosion).</li> <li>• Is there any malfunction?</li> </ul>	Yes	Repair or replace the connector and/or terminals, then go to Step 12.
		No	Go to the next step.
9	<b>INSPECT ION SENSOR No.3 SIGNAL CIRCUIT FOR SHORT TO POWER SUPPLY</b> <ul style="list-style-type: none"> <li>• Verify that the ignition coil/ion sensor No.3 and PCM connectors are disconnected.</li> <li>• Switch the ignition ON (engine off).</li> </ul> <p><b>Note</b></p> <ul style="list-style-type: none"> <li>• <b>Another DTC may be stored by the PCM detecting an open circuit.</b></li> <li>• Measure the voltage at the ignition coil/ion sensor No.3 terminal C (wiring harness-side).</li> <li>• Is the voltage 0 V?</li> </ul>	Yes	Go to the next step.
		No	Refer to the wiring diagram and verify whether or not there is a common connector between ignition coil/ion sensor No.3 terminal C and PCM terminal 1AK. <b>If there is a common connector:</b> <ul style="list-style-type: none"> <li>• Determine the malfunctioning part by inspecting the common connector and the terminal for corrosion, damage, or pin disconnection, and the common wiring harness for a short to power supply.</li> <li>• Repair or replace the malfunctioning part.</li> </ul> <b>If there is no common connector:</b> <ul style="list-style-type: none"> <li>• Repair or replace the wiring harness which has a short to power supply.</li> </ul> Go to Step 12.
10	<b>INSPECT ION SENSOR No.3 SIGNAL CIRCUIT FOR OPEN CIRCUIT</b> <ul style="list-style-type: none"> <li>• Verify that the ignition coil/ion sensor No.3 and PCM connectors are disconnected.</li> <li>• Switch the ignition off.</li> <li>• Inspect for continuity between ignition coil/ion sensor No.3 terminal C (wiring harness-side) and PCM terminal 1AK (wiring harness-side).</li> <li>• Is there continuity?</li> </ul>	Yes	Go to the next step.
		No	Refer to the wiring diagram and verify whether or not there is a common connector between ignition coil/ion sensor No.3 terminal C and PCM terminal 1AK. <b>If there is a common connector:</b> <ul style="list-style-type: none"> <li>• Determine the malfunctioning part by inspecting the common connector and the terminal for corrosion, damage, or pin disconnection, and the common wiring harness for an open circuit.</li> <li>• Repair or replace the malfunctioning part.</li> </ul> <b>If there is no common connector:</b> <ul style="list-style-type: none"> <li>• Repair or replace the wiring harness which has an open circuit.</li> </ul> Go to Step 12.
11	<b>INSPECT ION SENSOR No.3</b> <ul style="list-style-type: none"> <li>• Inspect the ion sensor No.3. (See <b>ION SENSOR INSPECTION [SKYACTIV-G 2.5 (WITHOUT CYLINDER DEACTIVATION)]</b>.)</li> <li>• Is there any malfunction?</li> </ul>	Yes	Replace the ignition coil/ion sensor No.3, then go to the next step. (See <b>IGNITION COIL/ION SENSOR REMOVAL/INSTALLATION [SKYACTIV-G 2.5 (WITHOUT CYLINDER DEACTIVATION)]</b> .)
		No	Go to the next step.
12	<b>VERIFY DTC TROUBLESHOOTING COMPLETED</b> <ul style="list-style-type: none"> <li>• Always reconnect all disconnected connectors.</li> <li>• Clear the DTC from the PCM memory using the M-MDS. (See <b>CLEARING DTC [PCM (SKYACTIV-G 2.5 (WITHOUT CYLINDER DEACTIVATION))]</b>.)</li> <li>• Perform the KOER self test. (See <b>KOEO/KOER SELF TEST [PCM (SKYACTIV-G 2.5 (WITHOUT CYLINDER DEACTIVATION))]</b>.)</li> <li>• Is the same Pending DTC present?</li> </ul>	Yes	Repeat the inspection from Step 1. • If the malfunction recurs, replace the PCM. (See <b>PCM REMOVAL/INSTALLATION [SKYACTIV-G 2.5 (WITHOUT CYLINDER DEACTIVATION)]</b> .) Go to the next step.
		No	Go to the next step.
13	<b>VERIFY AFTER REPAIR PROCEDURE</b> <ul style="list-style-type: none"> <li>• Perform the "AFTER REPAIR PROCEDURE". (See <b>AFTER REPAIR PROCEDURE [PCM (SKYACTIV-G 2.5 (WITHOUT CYLINDER DEACTIVATION))]</b>.)</li> <li>• Are any DTCs present?</li> </ul>	Yes	Go to the applicable DTC inspection. (See <b>DTC TABLE [PCM (SKYACTIV-G 2.5 (WITHOUT CYLINDER DEACTIVATION))]</b> .)
		No	DTC troubleshooting completed.

STEP	INSPECTION	RESULTS	ACTION
3	<b>VERIFY RELATED PENDING CODE AND/OR DTC</b> <ul style="list-style-type: none"> <li>• Switch the ignition off, then ON (engine off).</li> <li>• Perform the Pending Trouble Code Access Procedure and DTC Reading Procedure. (See <b>ON-BOARD DIAGNOSTIC TEST [PCM (SKYACTIV-G 2.5 (WITHOUT CYLINDER DEACTIVATION))]</b>.)</li> <li>• Is the PENDING CODE/DTC P0301:00 also present?</li> </ul>	Yes	Go to the applicable PENDING CODE or DTC inspection. (See <b>DTC P0301:00, P0302:00, P0303:00, P0304:00 [PCM (SKYACTIV-G 2.5 (WITHOUT CYLINDER DEACTIVATION))]</b> .)
		No	Go to the next step.
4	<b>INSPECT IGNITION COIL/ION SENSOR No.1 CONNECTOR CONDITION</b> <ul style="list-style-type: none"> <li>• Switch the ignition off.</li> <li>• Disconnect the ignition coil/ion sensor No.1 connector.</li> <li>• Inspect for poor connection (such as damaged/pulled-out pins, corrosion).</li> <li>• Is there any malfunction?</li> </ul>	Yes	Repair or replace the connector and/or terminals, then go to Step 12.
		No	Go to the next step.

STEP	INSPECTION	RESULTS	ACTION
8	<b>INSPECT PCM CONNECTOR CONDITION</b> <ul style="list-style-type: none"> <li>• Disconnect the PCM connector.</li> <li>• Inspect for poor connection (such as damaged/pulled-out pins, corrosion).</li> <li>• Is there any malfunction?</li> </ul>	Yes	Repair or replace the connector and/or terminals, then go to Step 12.
		No	Go to the next step.
9	<b>INSPECT ION SENSOR No.1 SIGNAL CIRCUIT FOR SHORT TO POWER SUPPLY</b> <ul style="list-style-type: none"> <li>• Verify that the ignition coil/ion sensor No.1 and PCM connectors are disconnected.</li> <li>• Switch the ignition ON (engine off).</li> </ul> <p><b>Note</b></p> <ul style="list-style-type: none"> <li>• <b>Another DTC may be stored by the PCM detecting an open circuit.</b></li> <li>• Measure the voltage at the ignition coil/ion sensor No.1 terminal C (wiring harness-side).</li> <li>• Is the voltage 0 V?</li> </ul>	Yes	Go to the next step.
		No	Refer to the wiring diagram and verify whether or not there is a common connector between ignition coil/ion sensor No.1 terminal C and PCM terminal 1AL. <b>If there is a common connector:</b> <ul style="list-style-type: none"> <li>• Determine the malfunctioning part by inspecting the common connector and the terminal for corrosion, damage, or pin disconnection, and the common wiring harness for a short to power supply.</li> <li>• Repair or replace the malfunctioning part.</li> </ul> <b>If there is no common connector:</b> <ul style="list-style-type: none"> <li>• Repair or replace the wiring harness which has a short to power supply.</li> </ul> Go to Step 12.
10	<b>INSPECT ION SENSOR No.1 SIGNAL CIRCUIT FOR OPEN CIRCUIT</b> <ul style="list-style-type: none"> <li>• Verify that the ignition coil/ion sensor No.1 and PCM connectors are disconnected.</li> <li>• Switch the ignition off.</li> <li>• Inspect for continuity between ignition coil/ion sensor No.1 terminal C (wiring harness-side) and PCM terminal 1AL (wiring harness-side).</li> <li>• Is there continuity?</li> </ul>	Yes	Go to the next step.
		No	Refer to the wiring diagram and verify whether or not there is a common connector between ignition coil/ion sensor No.1 terminal C and PCM terminal 1AL. <b>If there is a common connector:</b> <ul style="list-style-type: none"> <li>• Determine the malfunctioning part by inspecting the common connector and the terminal for corrosion, damage, or pin disconnection, and the common wiring harness for an open circuit.</li> <li>• Repair or replace the malfunctioning part.</li> </ul> <b>If there is no common connector:</b> <ul style="list-style-type: none"> <li>• Repair or replace the wiring harness which has an open circuit.</li> </ul> Go to Step 12.
11	<b>INSPECT ION SENSOR No.1</b> <ul style="list-style-type: none"> <li>• Inspect the ion sensor No.1. (See <b>ION SENSOR INSPECTION [SKYACTIV-G 2.5 (WITHOUT CYLINDER DEACTIVATION)]</b>.)</li> <li>• Is there any malfunction?</li> </ul>	Yes	Replace the ignition coil/ion sensor No.1, then go to the next step. (See <b>IGNITION COIL/ION SENSOR REMOVAL/INSTALLATION [SKYACTIV-G 2.5 (WITHOUT CYLINDER DEACTIVATION)]</b> .)
		No	Go to the next step.
12	<b>VERIFY DTC TROUBLESHOOTING COMPLETED</b> <ul style="list-style-type: none"> <li>• Always reconnect all disconnected connectors.</li> <li>• Clear the DTC from the PCM memory using the M-MDS. (See <b>CLEARING DTC [PCM (SKYACTIV-G 2.5 (WITHOUT CYLINDER DEACTIVATION))]</b>.)</li> <li>• Perform the KOER self test. (See <b>KOEO/KOER SELF TEST [PCM (SKYACTIV-G 2.5 (WITHOUT CYLINDER DEACTIVATION))]</b>.)</li> <li>• Is the same Pending DTC present?</li> </ul>	Yes	Repeat the inspection from Step 1. • If the malfunction recurs, replace the PCM. (See <b>PCM REMOVAL/INSTALLATION [SKYACTIV-G 2.5 (WITHOUT CYLINDER DEACTIVATION)]</b> .) Go to the next step.
		No	Go to the next step.
13	<b>VERIFY AFTER REPAIR PROCEDURE</b> <ul style="list-style-type: none"> <li>• Perform the "AFTER REPAIR PROCEDURE". (See <b>AFTER REPAIR PROCEDURE [PCM (SKYACTIV-G 2.5 (WITHOUT CYLINDER DEACTIVATION))]</b>.)</li> <li>• Are any DTCs present?</li> </ul>	Yes	Go to the applicable DTC inspection. (See <b>DTC TABLE [PCM (SKYACTIV-G 2.5 (WITHOUT CYLINDER DEACTIVATION))]</b> .)
		No	DTC troubleshooting completed.

STEP	INSPECTION	RESULTS	ACTION
3	<b>VERIFY RELATED PENDING CODE AND/OR DTC</b> <ul style="list-style-type: none"> <li>• Switch the ignition off, then ON (engine off).</li> <li>• Perform the Pending Trouble Code Access Procedure and DTC Reading Procedure. (See <b>ON-BOARD DIAGNOSTIC TEST [PCM (SKYACTIV-G 2.5 (WITHOUT CYLINDER DEACTIVATION))]</b>.)</li> <li>• Is the PENDING CODE/DTC P0302:00 also present?</li> </ul>	Yes	Go to the applicable PENDING CODE or DTC inspection. (See <b>DTC P0301:00, P0302:00, P0303:00, P0304:00 [PCM (SKYACTIV-G 2.5 (WITHOUT CYLINDER DEACTIVATION))]</b> .)
		No	Go to the next step.
4	<b>INSPECT IGNITION COIL/ION SENSOR No.2 CONNECTOR CONDITION</b> <ul style="list-style-type: none"> <li>• Switch the ignition off.</li> <li>• Disconnect the ignition coil/ion sensor No.2 connector.</li> <li>• Inspect for poor connection (such as damaged/pulled-out pins, corrosion).</li> <li>• Is there any malfunction?</li> </ul>	Yes	Repair or replace the connector and/or terminals, then go to Step 12.
		No	Go to the next step.

STEP	INSPECTION	RESULTS	ACTION
8	<b>INSPECT PCM CONNECTOR CONDITION</b> <ul style="list-style-type: none"> <li>• Disconnect the PCM connector.</li> <li>• Inspect for poor connection (such as damaged/pulled-out pins, corrosion).</li> <li>• Is there any malfunction?</li> </ul>	Yes	Repair or replace the connector and/or terminals, then go to Step 12.
		No	Go to the next step.
9	<b>INSPECT ION SENSOR No.2 SIGNAL CIRCUIT FOR SHORT TO POWER SUPPLY</b> <ul style="list-style-type: none"> <li>• Verify that the ignition coil/ion sensor No.2 and PCM connectors are disconnected.</li> <li>• Switch the ignition ON (engine off).</li> </ul> <p><b>Note</b></p> <ul style="list-style-type: none"> <li>• <b>Another DTC may be stored by the PCM detecting an open circuit.</b></li> <li>• Measure the voltage at the ignition coil/ion sensor No.2 terminal C (wiring harness-side).</li> <li>• Is the voltage 0 V?</li> </ul>	Yes	Go to the next step.
		No	Refer to the wiring diagram and verify whether or not there is a common connector between ignition coil/ion sensor No.2 terminal C and PCM terminal 1AE. <b>If there is a common connector:</b> <ul style="list-style-type: none"> <li>• Determine the malfunctioning part by inspecting the common connector and the terminal for corrosion, damage, or pin disconnection, and the common wiring harness for a short to power supply.</li> <li>• Repair or replace the malfunctioning part.</li> </ul> <b>If there is no common connector:</b> <ul style="list-style-type: none"> <li>• Repair or replace the wiring harness which has a short to power supply.</li> </ul> Go to Step 12.
10	<b>INSPECT ION SENSOR No.2 SIGNAL CIRCUIT FOR OPEN CIRCUIT</b> <ul style="list-style-type: none"> <li>• Verify that the ignition coil/ion sensor No.2 and PCM connectors are disconnected.</li> <li>• Switch the ignition off.</li> <li>• Inspect for continuity between ignition coil/ion sensor No.2 terminal C (wiring harness-side) and PCM terminal 1AE (wiring harness-side).</li> <li>• Is there continuity?</li> </ul>	Yes	Go to the next step.
		No	Refer to the wiring diagram and verify whether or not there is a common connector between ignition coil/ion sensor No.2 terminal C and PCM terminal 1AE. <b>If there is a common connector:</b> <ul style="list-style-type: none"> <li>• Determine the malfunctioning part by inspecting the common connector and the terminal for corrosion, damage, or pin disconnection, and the common wiring harness for an open circuit.</li> <li>• Repair or replace the malfunctioning part.</li> </ul> <b>If there is no common connector:</b> <ul style="list-style-type: none"> <li>• Repair or replace the wiring harness which has an open circuit.</li> </ul> Go to Step 12.
11	<b>INSPECT ION SENSOR No.2</b> <ul style="list-style-type: none"> <li>• Inspect the ion sensor No.2. (See <b>ION SENSOR INSPECTION [SKYACTIV-G 2.5 (WITHOUT CYLINDER DEACTIVATION)]</b>.)</li> <li>• Is there any malfunction?</li> </ul>	Yes	Replace the ignition coil/ion sensor No.2, then go to the next step. (See <b>IGNITION COIL/ION SENSOR REMOVAL/INSTALLATION [SKYACTIV-G 2.5 (WITHOUT CYLINDER DEACTIVATION)]</b> .)
		No	Go to the next step.
12	<b>VERIFY DTC TROUBLESHOOTING COMPLETED</b> <ul style="list-style-type: none"> <li>• Always reconnect all disconnected connectors.</li> <li>• Clear the DTC from the PCM memory using the M-MDS. (See <b>CLEARING DTC [PCM (SKYACTIV-G 2.5 (WITHOUT CYLINDER DEACTIVATION))]</b>.)</li> <li>• Perform the KOER self test. (See <b>KOEO/KOER SELF TEST [PCM (SKYACTIV-G 2.5 (WITHOUT CYLINDER DEACTIVATION))]</b>.)</li> <li>• Is the same Pending DTC present?</li> </ul>	Yes	Repeat the inspection from Step 1. • If the malfunction recurs, replace the PCM. (See <b>PCM REMOVAL/INSTALLATION [SKYACTIV-G 2.5 (WITHOUT CYLINDER DEACTIVATION)]</b> .) Go to the next step.
		No	Go to the next step.
13	<b>VERIFY AFTER REPAIR PROCEDURE</b> <ul style="list-style-type: none"> <li>• Perform the "AFTER REPAIR PROCEDURE". (See <b>AFTER REPAIR PROCEDURE [PCM (SKYACTIV-G 2.5 (WITHOUT CYLINDER DEACTIVATION))]</b>.)</li> <li>• Are any DTCs present?</li> </ul>	Yes	Go to the applicable DTC inspection. (See <b>DTC TABLE [PCM (SKYACTIV-G 2.5 (WITHOUT CYLINDER DEACTIVATION))]</b> .)
		No	DTC troubleshooting completed.

DTC P05C0:00 [PCM (SKYACTIV-G 2.5 (WITHOUT CYLINDER DEACTIVATION))]

SM2896930

id0102t340250

DTC P05C0:00	Active air shutter: Actuator temperature abnormality
DETECTION CONDITION	<ul style="list-style-type: none"><li>Internal temperature of active air shutter actuator is certain value or more.</li></ul> <b>Diagnostic support note</b> <ul style="list-style-type: none"><li>This is an intermittent monitor (other).</li><li>The check engine light does not illuminate.</li><li>FREEZE FRAME DATA is not available.</li><li>Snapshot data is available.</li><li>DTC is stored in the PCM memory.</li></ul>
FAIL-SAFE FUNCTION	<ul style="list-style-type: none"><li>Stops active air shutter control.</li></ul>
POSSIBLE CAUSE	<ul style="list-style-type: none"><li>Engine overheating</li><li>Active air shutter malfunction</li><li>PCM malfunction</li></ul>
SYSTEM WIRING DIAGRAM	<ul style="list-style-type: none"><li>Not applicable</li></ul>

Diagnostic Procedure

STEP	INSPECTION	RESULTS	ACTION
1	<b>RECORD VEHICLE STATUS AT TIME OF DTC DETECTION TO UTILIZE WITH REPEATABILITY VERIFICATION</b>  <b>Note</b> <ul style="list-style-type: none"><li>Recording can be facilitated using the screen capture function of the PC.</li><li>Record the snapshot data on the repair order.</li></ul>	–	Go to the next step.
2	<b>VERIFY RELATED REPAIR INFORMATION AVAILABILITY</b> <ul style="list-style-type: none"><li>Verify related Service Bulletins and/or on-line repair information availability.</li><li>Is any related repair information available?</li></ul>	Yes	Perform repair or diagnosis according to the available repair information. <ul style="list-style-type: none"><li>If the vehicle is not repaired, go to the next step.</li></ul>
		No	Go to the next step.
3	<b>VERIFY IF DIAGNOSTIC RESULT IS AFFECTED BY DTC RELATED TO ACTIVE AIR SHUTTER</b> <ul style="list-style-type: none"><li>Switch the ignition off, then ON (engine off).</li><li>Perform the Pending Trouble Code Access Procedure and DTC Reading Procedure. (See <b>ON-BOARD DIAGNOSTIC TEST [PCM (SKYACTIV-G 2.5 (WITHOUT CYLINDER DEACTIVATION))]</b>.)</li><li>Is the PENDING CODE/DTC U0284:00 also present?</li></ul>	Yes	Go to the applicable PENDING CODE or DTC inspection. (See <b>DTC U0284:00 [PCM (SKYACTIV-G 2.5 (WITHOUT CYLINDER DEACTIVATION))]</b> .)
		No	Go to the next step.
4	<b>VERIFY ENGINE CONDITION</b> <ul style="list-style-type: none"><li>Verify the engine condition.</li><li>Is the engine overheating?</li></ul>	Yes	Perform the symptom troubleshooting “NO.17 COOLING SYSTEM CONCERNS-OVERHEATING”. (See <b>NO.17 COOLING SYSTEM CONCERNS-OVERHEATING [SKYACTIV-G 2.5 (WITHOUT CYLINDER DEACTIVATION)]</b> .)
		No	Go to the next step.

STEP	INSPECTION	RESULTS	ACTION
4	<b>INSPECT VEHICLE CONDITION FOR EFFECT ON MALFUNCTION</b> <ul style="list-style-type: none"> <li>Verify how the customer drives the vehicle by asking the customer the following: <ul style="list-style-type: none"> <li>— Engine speed is high and remains high for continuous long periods like when climbing a long steep grade.</li> </ul> </li> <li>Is the engine generating excessive heat when driven?</li> </ul>	Yes	Go to the next step.
		No	Go to Step 6.
5	<b>DETERMINE IF MALFUNCTION CAUSE IS OVERHEATING OR OTHER</b> <p><b>Caution</b></p> <ul style="list-style-type: none"> <li>While performing this step, always operate the vehicle in a safe and lawful manner.</li> <li>When the M-MDS is used to observe monitor system status while driving, be sure to have another technician with you, or record the data in the M-MDS using the PID/DATA MONITOR AND RECORD capturing function and inspect later.</li> <li>Access the ECT PID using the M-MDS. (See <b>ON-BOARD DIAGNOSTIC TEST [PCM (SKYACTIV-G 2.5 (WITHOUT CYLINDER DEACTIVATION))]</b>.)</li> <li>Is the ECT PID value less than 122 °C {252 °F} while the vehicle is driven on a flat road?</li> </ul>	Yes	Explain to the customer that the vehicle is normal. Go to Step 8.
		No	The cause of this concern could be from the cooling system overheating. <ul style="list-style-type: none"> <li>Perform the symptom troubleshooting “NO.17 COOLING SYSTEM CONCERNS-OVERHEATING”. (See <b>NO.17 COOLING SYSTEM CONCERNS-OVERHEATING [SKYACTIV-G 2.5 (WITHOUT CYLINDER DEACTIVATION)]</b>.)</li> </ul>
6	<b>INSPECT ECT SENSOR</b> <ul style="list-style-type: none"> <li>Inspect the ECT sensor. (See <b>ENGINE COOLANT TEMPERATURE (ECT) SENSOR INSPECTION [SKYACTIV-G 2.5 (WITHOUT CYLINDER DEACTIVATION)]</b>.)</li> <li>Is there any malfunction?</li> </ul>	Yes	Replace the ECT sensor, then go to the next step. (See <b>ENGINE COOLANT TEMPERATURE (ECT) SENSOR REMOVAL/INSTALLATION [SKYACTIV-G 2.5 (WITHOUT CYLINDER DEACTIVATION)]</b> .)
		No	Go to the next step.
7	<b>VERIFY DTC TROUBLESHOOTING COMPLETED</b> <ul style="list-style-type: none"> <li>Always reconnect all disconnected connectors.</li> <li>Clear the DTC from the PCM memory using the M-MDS. (See <b>CLEARING DTC [PCM (SKYACTIV-G 2.5 (WITHOUT CYLINDER DEACTIVATION))]</b>.)</li> <li>Start the engine and warm it up completely.</li> <li>Drive the vehicle.</li> <li>Perform the DTC Reading Procedure. (See <b>ON-BOARD DIAGNOSTIC TEST [PCM (SKYACTIV-G 2.5 (WITHOUT CYLINDER DEACTIVATION))]</b>.)</li> <li>Is the same Pending DTC present?</li> </ul>	Yes	Repeat the inspection from Step 1. <ul style="list-style-type: none"> <li>If the malfunction recurs, replace the PCM. (See <b>PCM REMOVAL/INSTALLATION [SKYACTIV-G 2.5 (WITHOUT CYLINDER DEACTIVATION)]</b>.)</li> </ul> Go to the next step.
		No	Go to the next step.
8	<b>VERIFY AFTER REPAIR PROCEDURE</b> <ul style="list-style-type: none"> <li>Perform the “AFTER REPAIR PROCEDURE”. (See <b>AFTER REPAIR PROCEDURE [PCM (SKYACTIV-G 2.5 (WITHOUT CYLINDER DEACTIVATION))]</b>.)</li> <li>Are any DTCs present?</li> </ul>	Yes	Go to the applicable DTC inspection. (See <b>DTC TABLE [PCM (SKYACTIV-G 2.5 (WITHOUT CYLINDER DEACTIVATION))]</b> .)
		No	DTC troubleshooting completed.

DTC P2311:00 [PCM (SKYACTIV-G 2.5 (WITHOUT CYLINDER DEACTIVATION))]

SM2896993

id0102t374330

DTC P2311:00	Ion sensor No.4 circuit problem
DETECTION CONDITION	<ul style="list-style-type: none"><li>• After the engine is started, when the engine speed is 2,000 rpm or less, the signal input to the PCM from ion sensor No.4 is in error.</li></ul> <b>Diagnostic support note</b> <ul style="list-style-type: none"><li>• This is a continuous monitor (other).</li><li>• The check engine light does not illuminate.</li><li>• FREEZE FRAME DATA is not available.</li><li>• Snapshot data is available.</li><li>• DTC is stored in the PCM memory.</li></ul>
FAIL-SAFE FUNCTION	<ul style="list-style-type: none"><li>• Not applicable</li></ul>
POSSIBLE CAUSE	<ul style="list-style-type: none"><li>• Cylinder No.4 misfire</li><li>• Ignition coil/ion sensor No.4 connector or terminals malfunction</li><li>• Short to ground or open circuit in ion sensor No.4 power supply circuit<ul style="list-style-type: none"><li>— Short to ground in wiring harness between ENGINE2 15 A fuse and ignition coil/ion sensor No.4 terminal A</li><li>— ENGINE2 15 A fuse malfunction</li><li>— Open circuit in wiring harness between sub relay terminal C and ignition coil/ion sensor No.4 terminal A</li></ul></li><li>• Open circuit in wiring harness between ignition coil/ion sensor No.4 terminal D and body ground</li><li>• Short to ground in wiring harness between ignition coil/ion sensor No.4 terminal C and PCM terminal 1AF</li><li>• PCM connector or terminals malfunction</li><li>• Short to power supply in wiring harness between ignition coil/ion sensor No.4 terminal C and PCM terminal 1AF</li><li>• Open circuit in wiring harness between ignition coil/ion sensor No.4 terminal C and PCM terminal 1AF</li><li>• Ion sensor No.4 malfunction</li><li>• PCM malfunction</li></ul>