

Your Ultimate Source for OEM Repair Manuals

FactoryManuals.net is a great resource for anyone who wants to save money on repairs by doing their own work. The manuals provide detailed instructions and diagrams that make it easy to understand how to fix a vehicle.

2000 MAZDA RX-7 (FD) OEM Service and Repair Workshop Manual

[Go to manual page](#)

DTC No.	Check engine light	Master warning indication/master warning light	Charging system warning indication/charging system warning light	Engine oil warning indication/engine oil warning light	Check fuel cap warning indication/check fuel cap warning light	Condition	Fail-safe function	Drive cycle	Mon
P0602:00 ^{*5}	ON	OFF	OFF	OFF	OFF	PCM programming error	—	1	
P0604:00	ON	OFF	OFF	OFF	OFF	PCM RAM error	×	1	
P0606:00	ON	OFF	OFF	OFF	OFF	PCM processor error	×	1	
P0610:00 ^{*5}	ON	OFF	OFF	OFF	OFF	PCM vehicle configuration error	—	1	
P061B:00	ON	OFF	OFF	OFF	OFF	Internal control module torque calculation performance problem	×	1	
P061D:00	ON	OFF	OFF	OFF	OFF	Internal control module engine air mass performance problem	×	1	

DTC No.	Check engine light	Master warning indication/master warning light	Charging system warning indication/charging system warning light	Engine oil warning indication/engine oil warning light	Check fuel cap warning indication/check fuel cap warning light	Condition	Fail-safe function	Drive cycle	Mon
P1200:00 ^{*6}	OFF	OFF	OFF	OFF	OFF	Low fuel injection amount	–	–	0
P1260:00	OFF	OFF	OFF	OFF	OFF	Immobilizer system problem	–	–	0
P130C:00 ^{*5}	ON ^{*8}	Indication/illumination	OFF	OFF	OFF	Pre-ignition detected	–	1	0
P1380:00	OFF	OFF	OFF	OFF	OFF	Electric variable valve timing control circuit problem	×	1	
P144A:00 ^{*5}	ON	OFF	OFF	OFF	OFF	Evaporator system: clogging between fuel tank and fuel tank pressure sensor	–	2	1 S
P1450:00 ^{*5}	ON	OFF	OFF	OFF	OFF	Evaporator system: abnormal negative pressure in fuel tank	–	2	1 S

DTC No.	Check engine light	Master warning indication/master warning light	Charging system warning indication/charging system warning light	Engine oil warning indication/engine oil warning light	Check fuel cap warning indication/check fuel cap warning light	Condition	Fail-safe function	Drive cycle	Monitor
P2127:00	ON	OFF	OFF	OFF	OFF	APP sensor No.2 circuit low input	×	1	
P2128:00	ON	OFF	OFF	OFF	OFF	APP sensor No.2 circuit high input	×	1	
P2135:00	ON	OFF	OFF	OFF	OFF	TP sensor No.1/No.2 voltage correlation problem	×	1	
P2138:00	ON	OFF	OFF	OFF	OFF	APP sensor No.1/No.2 voltage correlation problem	×	1	
P2183:00 ^{*5}	ON ^{*3}	OFF	OFF	OFF	OFF	ECT sensor No.2 circuit range/performance problem	—	2	E c s
P2184:00	ON	OFF	OFF	OFF	OFF	ECT sensor No.2 circuit low input	—	1	E c s

DTC No.	Check engine light	Master warning indication/master warning light	Charging system warning indication/charging system warning light	Engine oil warning indication/engine oil warning light	Check fuel cap warning indication/check fuel cap warning light	Condition	Fail-safe function	Drive cycle	Monitor
P2311:00	OFF	OFF	OFF	OFF	OFF	Ion sensor No.4 circuit problem	—	1	0
P2502:00	OFF	OFF	Indication/illumination	OFF	OFF	Generator system: Malfunction in voltage generated by generator	×	1	0
P2503:00	OFF	OFF	Indication/illumination	OFF	OFF	Generator system: Voltage generated by generator is low	×	1	0
P2504:00	OFF	OFF	Indication/illumination	OFF	OFF	Generator system: Voltage generated by generator is high	×	1	0
P2507:00	ON	OFF	OFF	OFF	OFF	PCM battery voltage low input	—	1	0
P250A:00	OFF	Indication/illumination	OFF	Indication/illumination	OFF	Engine oil level signal: engine oil level sensor malfunction	—	1	0

DTC No.	Check engine light	Master warning indication/master warning light	Charging system warning indication/charging system warning light	Engine oil warning indication/engine oil warning light	Check fuel cap warning indication/check fuel cap warning light	Condition	Fail-safe function	Drive cycle	Mon
U0101:00	ON	OFF	OFF	OFF	OFF	CAN communication: communication error to TCM	×	1	
U0104:00 ^{*7}	OFF	OFF	OFF	OFF	OFF	CAN communication: communication error to radar unit	×	1	
U0121:00	ON	OFF	OFF	OFF	OFF	CAN communication: communication error to DSC HU/CM	×	1	
U0131:00	OFF	OFF	OFF	OFF	OFF	CAN communication: communication error to EPS control module	–	1	
U0140:00	OFF	OFF	OFF	OFF	OFF	CAN communication: communication error to front body control module (FBCM)	–	1	
U0151:00	OFF	OFF	OFF	OFF	OFF	CAN communication: communication error to SAS control module	–	1	
U0155:00	ON ^{*3}	OFF	OFF	OFF	OFF	CAN communication: communication error to instrument cluster	–	1	
U0214:00	OFF	OFF	OFF	OFF	OFF	CAN communication: communication error to start stop unit	–	1	

DTC No.	Check engine light	Master warning indication/master warning light	Charging system warning indication/charging system warning light	Engine oil warning indication/engine oil warning light	Check fuel cap warning indication/check fuel cap warning light	Condition	Fail-safe function	Drive cycle	Monitor
U1100:00	OFF	OFF	OFF	OFF	OFF	LIN communication: communication error to engine oil level sensor	–	1	C
U2300:00	OFF	Indication/illumination	OFF	OFF	OFF	Global central configuration error	×	1	C
U3000:41	OFF	OFF	OFF	OFF	OFF	PCM processor error	–	–	C

*1:C: CMDTC self test, O: KOEO self test, R: KOER self test

*2:KOER self test only

*3:The check engine light may be illuminated depending on the condition.

*4:After two drive cycle since DTC was detected

*5:Except Mexico

*6:Mexico

*7:Vehicles with mazda radar cruise control (MRCC) system

*8:Turns on in second drive cycle or later.

STEP	INSPECTION	RESULTS	ACTION
4	INSPECT REFRIGERANT PRESSURE SENSOR CIRCUIT FOR SHORT TO GROUND <ul style="list-style-type: none"> • Verify that the refrigerant pressure sensor connector is disconnected. • Inspect for continuity between the following terminals (wiring harness-side) and body ground: <ul style="list-style-type: none"> — Refrigerant pressure sensor terminal A — Refrigerant pressure sensor terminal B • Is there continuity? 	Yes	<p>Disconnect the PCM connector and inspect the wiring harness for short to ground.</p> <ul style="list-style-type: none"> • If the short to ground circuit could be detected in the wiring harness: <ul style="list-style-type: none"> — Refer to the wiring diagram and verify whether or not there is a common connector between the following terminals: <ul style="list-style-type: none"> • Refrigerant pressure sensor terminal A–PCM terminal 2AZ • Refrigerant pressure sensor terminal B–PCM terminal 2AV <p>If there is a common connector:</p> <ul style="list-style-type: none"> • Determine the malfunctioning part by inspecting the common connector and the terminal for corrosion, damage, or pin disconnection, and the common wiring harness for a short to ground. • Repair or replace the malfunctioning part. <p>If there is no common connector:</p> <ul style="list-style-type: none"> • Repair or replace the wiring harness which has a short to ground. <ul style="list-style-type: none"> • If the short to ground circuit could not be detected in the wiring harness: <ul style="list-style-type: none"> — Replace the PCM (short to ground in the PCM internal circuit). (See PCM REMOVAL/INSTALLATION [SKYACTIV-G 2.5 (WITHOUT CYLINDER DEACTIVATION)].) <p>Go to Step 9.</p>
		No	Go to the next step.
5	INSPECT PCM CONNECTOR CONDITION <ul style="list-style-type: none"> • Disconnect the PCM connector. • Inspect for poor connection (such as damaged/pulled-out pins, corrosion). • Is there any malfunction? 	Yes	Repair or replace the connector and/or terminals, then go to Step 9.
		No	Go to the next step.

Item	Definition	Unit	Condition/Specification
AC_PRES	Refrigerant pressure input from refrigerant pressure sensor	KPa {MPa}, mBar {BAR}, psi, in H2O	• Displays refrigerant pressure
	Refrigerant pressure sensor voltage	V	<ul style="list-style-type: none"> • Refrigerant pressure is 1.0 MPa {10 kgf/cm², 145 psi}: Approx. 1.58 V • Refrigerant pressure is 1.1 MPa {11 kgf/cm², 160 psi}: Approx. 1.75 V • Refrigerant pressure is 1.2 MPa {12 kgf/cm², 174 psi}: Approx. 1.88 V

STEP	INSPECTION	RESULTS	ACTION
1	<p>RECORD VEHICLE STATUS AT TIME OF DTC DETECTION TO UTILIZE WITH REPEATABILITY VERIFICATION</p> <p>Note</p> <ul style="list-style-type: none"> • Recording can be facilitated using the screen capture function of the PC. • Record the snapshot data on the repair order. 	–	Go to the next step.
2	<p>VERIFY RELATED REPAIR INFORMATION AVAILABILITY</p> <ul style="list-style-type: none"> • Verify related Service Bulletins and/or on-line repair information availability. • Is any related repair information available? 	Yes	Perform repair or diagnosis according to the available repair information.
		No	Go to the next step.
3	<p>DETERMINE IF REFRIGERANT PRESSURE SENSOR OR WIRING HARNESS MALFUNCTION</p> <ul style="list-style-type: none"> • Access the AC_PRES PID using the M-MDS. (See ON-BOARD DIAGNOSTIC TEST [PCM (SKYACTIV-G 2.5 (WITHOUT CYLINDER DEACTIVATION))].) • Verify the AC_PRES PID value. • Is the AC_PRES PID value 5 V or B+? 	Yes	Go to Step 7.
		No	Go to the next step.
4	<p>INSPECT REFRIGERANT PRESSURE SENSOR CONNECTOR CONDITION</p> <ul style="list-style-type: none"> • Switch the ignition off. • Disconnect the refrigerant pressure sensor connector. • Inspect for poor connection (such as damaged/pulled-out pins, corrosion). • Is there any malfunction? 	Yes	Repair or replace the connector and/or terminals, then go to Step 10.
		No	Go to the next step.
5	<p>INSPECT PCM CONNECTOR CONDITION</p> <ul style="list-style-type: none"> • Disconnect the PCM connector. • Inspect for poor connection (such as damaged/pulled-out pins, corrosion). • Is there any malfunction? 	Yes	Repair or replace the connector and/or terminals, then go to Step 10.
		No	Go to the next step.
6	<p>INSPECT REFRIGERANT PRESSURE SENSOR</p> <ul style="list-style-type: none"> • Reconnect all disconnected connectors. • Inspect the refrigerant pressure sensor. (See REFRIGERANT PRESSURE SENSOR INSPECTION [FULL-AUTO AIR CONDITIONER].) (See REFRIGERANT PRESSURE SENSOR INSPECTION [MANUAL AIR CONDITIONER].) • Is there any malfunction? 	Yes	Replace the refrigerant pressure sensor, then go to Step 10. (See REFRIGERANT PRESSURE SENSOR REMOVAL/INSTALLATION [FULL-AUTO AIR CONDITIONER] .) (See REFRIGERANT PRESSURE SENSOR REMOVAL/INSTALLATION [MANUAL AIR CONDITIONER] .)
		No	Go to Step 10.

DTC P0600:00 [PCM (SKYACTIV-G 2.5 (WITHOUT CYLINDER DEACTIVATION))]

SM2897011

id0102t385040

DTC P0600:00	Serial communication link
DETECTION CONDITION	<ul style="list-style-type: none">• PCM internal malfunction. Diagnostic support note <ul style="list-style-type: none">• This is a continuous monitor (CCM).• The check engine light illuminates if the PCM detects the above malfunction condition during the first drive cycle.• FREEZE FRAME DATA/Snapshot data is available.• DTC is stored in the PCM memory.
FAIL-SAFE FUNCTION	<ul style="list-style-type: none">• Not applicable
POSSIBLE CAUSE	<ul style="list-style-type: none">• PCM malfunction
SYSTEM WIRING DIAGRAM	<ul style="list-style-type: none">• Not applicable

Diagnostic Procedure

STEP	INSPECTION	RESULTS	ACTION
1	RECORD VEHICLE STATUS AT TIME OF DTC DETECTION TO UTILIZE WITH REPEATABILITY VERIFICATION Note <ul style="list-style-type: none">• Recording can be facilitated using the screen capture function of the PC.• Record the FREEZE FRAME DATA/snapshot data on the repair order.	–	Go to the next step.
2	VERIFY RELATED REPAIR INFORMATION AVAILABILITY <ul style="list-style-type: none">• Verify related Service Bulletins and/or on-line repair information availability.• Is any related repair information available?	Yes	Perform repair or diagnosis according to the available repair information. <ul style="list-style-type: none">• If the vehicle is not repaired, go to the next step.
		No	Go to the next step.
3	PERFORM DTC INSPECTION AND VERIFY IF MALFUNCTIONING PART IS PCM <ul style="list-style-type: none">• Clear the DTC from the PCM memory using the M-MDS. (See CLEARING DTC [PCM (SKYACTIV-G 2.5 (WITHOUT CYLINDER DEACTIVATION))].)• Start the engine and warm it up completely.• Perform the KOEO or KOER self test. (See KOEO/KOER SELF TEST [PCM (SKYACTIV-G 2.5 (WITHOUT CYLINDER DEACTIVATION))].)• Is the same Pending DTC present?	Yes	Replace the PCM, then go to the next step. (See PCM REMOVAL/INSTALLATION [SKYACTIV-G 2.5 (WITHOUT CYLINDER DEACTIVATION)] .)
		No	Go to the next step.
4	VERIFY AFTER REPAIR PROCEDURE <ul style="list-style-type: none">• Perform the “AFTER REPAIR PROCEDURE”. (See AFTER REPAIR PROCEDURE [PCM (SKYACTIV-G 2.5 (WITHOUT CYLINDER DEACTIVATION))].)• Are any DTCs present?	Yes	Go to the applicable DTC inspection. (See DTC TABLE [PCM (SKYACTIV-G 2.5 (WITHOUT CYLINDER DEACTIVATION))] .)
		No	DTC troubleshooting completed.