

Your Ultimate Source for OEM Repair Manuals

FactoryManuals.net is a great resource for anyone who wants to save money on repairs by doing their own work. The manuals provide detailed instructions and diagrams that make it easy to understand how to fix a vehicle.

2001 NISSAN Terrano II 5 Doors OEM Service and Repair Workshop Manual

[Go to manual page](#)

1. CHECK CONNECTOR

1. Disconnect 12V battery negative terminal.
2. Check the ABS actuator and electric unit (control unit) harness connector for disconnection or looseness.

Is the inspection result normal?

YES>>

[GO TO 3.](#)

NO>>

Repair / replace harness or connector, securely lock the connector. [GO TO 2.](#)

2. PERFORM SELF-DIAGNOSIS

 With CONSULT

1. Connect 12V battery negative terminal.
2. Power switch OFF (Auto ACC function ON).
3. Get out of the vehicle, close all doors (other than hood assembly), check that the combination meter is OFF, and wait for 1 minute or more without opening these doors.

CAUTION:
Never operate the vehicle.

4. Power switch ON without depressing the brake pedal.

CAUTION:
Never set the vehicle to READY.

5. Perform self-diagnosis for “ABS”.

Is DTC “C1047-04” detected?

YES>>

[GO TO 3.](#)

NO>>

INSPECTION END

3. CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) POWER SUPPLY AND GROUND CIRCUIT

Check the ABS actuator and electric unit (control unit) power supply and ground circuit. Refer to [Diagnosis Procedure](#).

Is the inspection result normal?

YES>>

Replace the ABS actuator and electric unit (control unit). Refer to [ABS ACTUATOR AND ELECTRIC UNIT \(CONTROL UNIT\): Removal & Installation](#).

NO>>

Sample

DTC DETECTION LOGIC

DTC No.		CONSULT screen terms	DTC detection condition	
C105E	92	Pressure sensor not calibration	Diagnosis condition	<ul style="list-style-type: none"> Power switch is ON. When the power supply voltage is normal.
			Signal (terminal)	—
			Threshold	When a malfunction is detected in electrically-driven intelligent brake unit system.
			Diagnosis delay time	1 second or less

POSSIBLE CAUSE



NOTE:

Confirm if DTC is PAST or CRNT. If DTC is CRNT, proceed with Diagnosis Procedure. If DTC is PAST, clear DTC. Do not replace the ABS actuator and electric unit (control unit) for a PAST DTC.

PAST DTC	CRNT DTC
<ul style="list-style-type: none"> Electrically-driven intelligent brake unit 	<ul style="list-style-type: none"> Electrically-driven intelligent brake unit ABS actuator and electric unit (control unit)

FAIL-SAFE

The following functions are suspended.

Cooperative regenerative brake function

1. PRECONDITIONING

If “Confirmation Procedure” has been previously conducted, always power switch OFF, get out of the vehicle, close all doors (other than hood assembly), check that the combination meter is OFF, and wait for 1 minute or more without opening these doors before conducting the next test.

>>

[GO TO 2](#)

2. CHECK DTC DETECTION

 With CONSULT

1. Power switch OFF (Auto ACC is ON).
2. Get out of the vehicle, close all doors (other than hood assembly), check that the combination meter is OFF, and wait for 1 minute or more without opening these doors.

CAUTION:
Never operate the vehicle.

3. Power switch ON without depressing the brake pedal.

CAUTION:
Never set the vehicle to READY.

4. Perform self-diagnosis for “ABS”.

Is DTC “C105E-92” detected?

YES-1>>

“CRNT” is displayed: Refer to [DTC Diagnosis Procedure](#).

YES-2>>

“PAST” is displayed: INSPECTION END (Erase the memory of self-diagnosis results.)

NO-1>>

To check malfunction symptom before repair: Refer to [Intermittent Incident](#).

NO-2>>

Confirmation after repair: INSPECTION END

1. CHECK ELECTRICALLY-DRIVEN INTELLIGENT BRAKE UNIT SYSTEM

 With CONSULT

Perform self-diagnosis for “BRAKE”.

Is DTC detected?

YES>>

Check the DTC. Refer to [DTC Index](#).

NO>>

[GO TO 2.](#)

2. CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) POWER SUPPLY AND GROUND CIRCUIT

Check the ABS actuator and electric unit (control unit) power supply and ground circuit. Refer to [Diagnosis Procedure](#).

Is the inspection result normal?

YES>>

[GO TO 3.](#)

NO>>

Repair / replace harness, connector, terminal, fuse, or fusible link.

3. PERFORM SELF-DIAGNOSIS

 With CONSULT

1. Power switch OFF (Auto ACC function ON).
2. Get out of the vehicle, close all doors (other than hood assembly), check that the combination meter is OFF, and wait for 1 minute or more without opening these doors.

CAUTION:
Never operate the vehicle.

3. Power switch ON without depressing the brake pedal.

CAUTION:
Never set the vehicle to READY.

4. Perform self-diagnosis for “ABS”.

Is DTC "C105E-92" detected?

YES>>

Replace the ABS actuator and electric unit (control unit). Refer to [ABS ACTUATOR AND ELECTRIC UNIT \(CONTROL UNIT\): Removal & Installation](#).

NO>>

INSPECTION END [Although motor built in the ABS actuator and electric unit (control unit) operates temporarily without a break, this is not a malfunction. Erase the all memory of self-diagnosis results.]

Sample

DTC DETECTION LOGIC

DTC No.		CONSULT screen terms	DTC detection condition	
C105E	93	Pressure sensor not calibration	Diagnosis condition	<ul style="list-style-type: none"> Power switch is ON. When the power supply voltage is normal.
			Signal (terminal)	—
			Threshold	When a malfunction is detected in electrically-driven intelligent brake unit system.
			Diagnosis delay time	1 second or less

POSSIBLE CAUSE



NOTE:

Confirm if DTC is PAST or CRNT. If DTC is CRNT, proceed with Diagnosis Procedure. If DTC is PAST, clear DTC. Do not replace the ABS actuator and electric unit (control unit) for a PAST DTC.

PAST DTC	CRNT DTC
<ul style="list-style-type: none"> Electrically-driven intelligent brake unit 	<ul style="list-style-type: none"> Electrically-driven intelligent brake unit ABS actuator and electric unit (control unit)

FAIL-SAFE

The following functions are suspended.

Cooperative regenerative brake function

1. PRECONDITIONING

If “Confirmation Procedure” has been previously conducted, always power switch OFF, get out of the vehicle, close all doors (other than hood assembly), check that the combination meter is OFF, and wait for 1 minute or more without opening these doors before conducting the next test.

>>

[GO TO 2](#)

2. CHECK DTC DETECTION

 With CONSULT

1. Power switch OFF (Auto ACC is ON).
2. Get out of the vehicle, close all doors (other than hood assembly), check that the combination meter is OFF, and wait for 1 minute or more without opening these doors.

CAUTION:
Never operate the vehicle.

3. Power switch ON without depressing the brake pedal.

CAUTION:
Never set the vehicle to READY.

4. Perform self-diagnosis for “ABS”.

Is DTC “C105E-93” detected?

YES-1>>

“CRNT” is displayed: Refer to [DTC Diagnosis Procedure](#).

YES-2>>

“PAST” is displayed: INSPECTION END (Erase the memory of self-diagnosis results.)

NO-1>>

To check malfunction symptom before repair: Refer to [Intermittent Incident](#).

NO-2>>

Confirmation after repair: INSPECTION END

1. CHECK ELECTRICALLY-DRIVEN INTELLIGENT BRAKE UNIT SYSTEM

 With CONSULT

Perform self-diagnosis for “BRAKE”.

Is DTC detected?

YES>>

Check the DTC. Refer to [DTC Index](#).

NO>>

[GO TO 2.](#)

2. CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) POWER SUPPLY AND GROUND CIRCUIT

Check the ABS actuator and electric unit (control unit) power supply and ground circuit. Refer to [Diagnosis Procedure](#).

Is the inspection result normal?

YES>>

[GO TO 3.](#)

NO>>

Repair / replace harness, connector, terminal, fuse, or fusible link.

3. PERFORM SELF-DIAGNOSIS

 With CONSULT

1. Power switch OFF (Auto ACC function ON).
2. Get out of the vehicle, close all doors (other than hood assembly), check that the combination meter is OFF, and wait for 1 minute or more without opening these doors.

CAUTION:
Never operate the vehicle.

3. Power switch ON without depressing the brake pedal.

CAUTION:
Never set the vehicle to READY.

4. Perform self-diagnosis for “ABS”.

Is DTC "C105E-93" detected?

YES>>

Replace the ABS actuator and electric unit (control unit). Refer to [ABS ACTUATOR AND ELECTRIC UNIT \(CONTROL UNIT\): Removal & Installation](#).

NO>>