

# Your Ultimate Source for OEM Repair Manuals

FactoryManuals.net is a great resource for anyone who wants to save money on repairs by doing their own work. The manuals provide detailed instructions and diagrams that make it easy to understand how to fix a vehicle.

## 2002 NISSAN Skyline GT-R (R34) OEM Service and Repair Workshop Manual

[Go to manual page](#)

## DTC DETECTION LOGIC

DTC No.		CONSULT screen terms	DTC detection condition	
C10AD	04	Brake backup function	Diagnosis condition	<ul style="list-style-type: none"> <li>Power switch is ON.</li> <li>When the power supply voltage is normal.</li> </ul>
			Signal (terminal)	CAN communication signal
			Threshold	When a malfunction in inpress backup function by ABS is detected. (When a malfunction is detected in electrically-driven intelligent brake unit system.)
			Diagnosis delay time	2 seconds or less

## POSSIBLE CAUSE



### NOTE:

Confirm if DTC is PAST or CRNT. If DTC is CRNT, proceed with Diagnosis Procedure. If DTC is PAST, clear DTC. Do not replace the ABS actuator and electric unit (control unit) for a PAST DTC.

PAST DTC	CRNT DTC
<ul style="list-style-type: none"> <li>Harness or connector</li> <li>CAN communication line</li> <li>ABS actuator and electric unit (control unit) power supply system</li> <li>Fuse</li> <li>Fusible link</li> <li>12V battery</li> </ul>	<ul style="list-style-type: none"> <li>Harness or connector</li> <li>CAN communication line</li> <li>Electrically-driven intelligent brake unit</li> <li>ABS actuator and electric unit (control unit)</li> <li>ABS actuator and electric unit (control unit) power supply system</li> <li>Fuse</li> <li>Fusible link</li> <li>12V battery</li> </ul>

## FAIL-SAFE

Normal control

## 1. PRECONDITIONING

---

If “Confirmation Procedure” has been previously conducted, always power switch OFF, get out of the vehicle, close all doors (other than hood assembly), check that the combination meter is OFF, and wait for 1 minute or more without opening these doors before conducting the next test.

>>

[GO TO 2](#)

## 2. CHECK DTC DETECTION

---

 With CONSULT

1. Power switch OFF (Auto ACC is ON).
2. Get out of the vehicle, close all doors (other than hood assembly), check that the combination meter is OFF, and wait for 1 minute or more without opening these doors.

**CAUTION:**  
**Never operate the vehicle.**

3. Power switch ON without depressing the brake pedal.

**CAUTION:**  
**Never set the vehicle to READY.**

4. Perform self-diagnosis for “ABS”.

Is DTC “C10AD-04” detected?

YES-1>>

“CRNT” is displayed: Refer to [DTC Diagnosis Procedure](#).

YES-2>>

“PAST” is displayed: INSPECTION END (Erase the memory of self-diagnosis results.)

NO-1>>

To check malfunction symptom before repair: Refer to [Intermittent Incident](#).

NO-2>>

Confirmation after repair: INSPECTION END

## 1. CHECK ELECTRICALLY-DRIVEN INTELLIGENT BRAKE UNIT SYSTEM

---

 With CONSULT

Perform self-diagnosis for “BRAKE”.

Is DTC detected?

YES>>

Check the DTC. Refer to [DTC Index](#).

NO>>

[GO TO 2.](#)

## 2. CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) POWER SUPPLY AND GROUND CIRCUIT

---

Check the ABS actuator and electric unit (control unit) power supply and ground circuit. Refer to [Diagnosis Procedure](#).

Is the inspection result normal?

YES>>

[GO TO 3.](#)

NO>>

Repair / replace harness, connector, terminal, fuse, or fusible link.

## 3. CHECK CONNECTOR AND TERMINAL

---

1. Disconnect 12V battery negative terminal.
2. Disconnect electrically-driven intelligent brake unit harness connector.
3. Check the electrically-driven intelligent brake unit harness connector for disconnection or looseness.
4. Check the electrically-driven intelligent brake unit terminals for damage or loose connection with harness connector.
5. Disconnect ABS actuator and electric unit (control unit) harness connector.
6. Check the ABS actuator and electric unit (control unit) harness connector for disconnection or looseness.
7. Check the ABS actuator and electric unit (control unit) terminals for damage or loose connection with harness connector.

Is the inspection result normal?

YES>>

[GO TO 4.](#)

NO>>

Repair / replace harness, connector, or terminal, securely lock the connector. [GO TO 4.](#)

## 4. PERFORM SELF-DIAGNOSIS

---

 With CONSULT

1. Connect electrically-driven intelligent brake unit harness connector.

2. Connect ABS actuator and electric unit (control unit) harness connector.
3. Connect 12V battery negative terminal.
4. Erase self-diagnosis result for “ABS”.
5. Power switch OFF (Auto ACC function ON).
6. Get out of the vehicle, close all doors (other than hood assembly), check that the combination meter is OFF, and wait for 1 minute or more without opening these doors.

**CAUTION:**  
**Never operate the vehicle.**

7. Power switch ON without depressing the brake pedal.

**CAUTION:**  
**Never set the vehicle to READY.**

8. Perform self-diagnosis for “ABS”.

Is DTC detected?

YES>>

Check the DTC. Refer to [DTC Index](#).

NO>>

INSPECTION END

## DTC DETECTION LOGIC

DTC No.		CONSULT screen terms	DTC detection condition	
C1040	63	Emergency brake	Diagnosis condition	<ul style="list-style-type: none"> <li>Power switch is ON.</li> <li>When the power supply voltage is normal.</li> </ul>
			Signal (terminal)	CAN communication signal
			Threshold	When a malfunction is detected in ADAS control unit 2 system.
			Diagnosis delay time	2 seconds or less

## POSSIBLE CAUSE



**NOTE:**

Confirm if DTC is PAST or CRNT. If DTC is CRNT, proceed with Diagnosis Procedure. If DTC is PAST, clear DTC. Do not replace the ABS actuator and electric unit (control unit) for a PAST DTC.

PAST DTC	CRNT DTC
<ul style="list-style-type: none"> <li>Harness or connector</li> <li>CAN communication line</li> <li>ABS actuator and electric unit (control unit) power supply system</li> <li>Fuse</li> <li>Fusible link</li> <li>12V battery</li> </ul>	<ul style="list-style-type: none"> <li>Harness or connector</li> <li>CAN communication line</li> <li>ADAS control unit 2</li> <li>ABS actuator and electric unit (control unit)</li> <li>ABS actuator and electric unit (control unit) power supply system</li> <li>Fuse</li> <li>Fusible link</li> <li>12V battery</li> </ul>

## FAIL-SAFE

Normal control

## 1. PRECONDITIONING

---

If “Confirmation Procedure” has been previously conducted, always power switch OFF, get out of the vehicle, close all doors (other than hood assembly), check that the combination meter is OFF, and wait for 1 minute or more without opening these doors before conducting the next test.

>>

[GO TO 2.](#)

## 2. CHECK DTC DETECTION

---

 With CONSULT

1. Power switch OFF (Auto ACC is ON).
2. Get out of the vehicle, close all doors (other than hood assembly), check that the combination meter is OFF, and wait for 1 minute or more without opening these doors.

**CAUTION:**  
**Never operate the vehicle.**

3. Power switch ON without depressing the brake pedal.

**CAUTION:**  
**Never set the vehicle to READY.**

4. Perform self-diagnosis for “ABS”.

Is DTC “C1040-63” detected?

YES-1>>

“CRNT” is displayed: Refer to [DTC Diagnosis Procedure](#).

YES-2>>

“PAST” is displayed: INSPECTION END (Erase the memory of self-diagnosis results.)

NO-1>>

To check malfunction symptom before repair: Refer to [Intermittent Incident](#).

NO-2>>

Confirmation after repair: INSPECTION END

## 1. CHECK ADAS CONTROL UNIT 2 SYSTEM

---

 With CONSULT

Perform self-diagnosis for “ICC/ADAS 2”.

Is DTC detected?

YES>>

Check the DTC. Refer to [DTC Index](#).

NO>>

[GO TO 2.](#)

## 2. CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) POWER SUPPLY AND GROUND CIRCUIT

---

Check the ABS actuator and electric unit (control unit) power supply and ground circuit. Refer to [Diagnosis Procedure](#).

Is the inspection result normal?

YES>>

[GO TO 3.](#)

NO>>

Repair / replace harness, connector, terminal, fuse, or fusible link.

## 3. CHECK CONNECTOR AND TERMINAL

---

1. Disconnect 12V battery negative terminal.
2. Disconnect ADAS control unit 2 harness connector.
3. Check the ADAS control unit 2 harness connector for disconnection or looseness.
4. Check the ADAS control unit 2 terminals for damage or loose connection with harness connector.
5. Disconnect ABS actuator and electric unit (control unit) harness connector.
6. Check the ABS actuator and electric unit (control unit) harness connector for disconnection or looseness.
7. Check the ABS actuator and electric unit (control unit) terminals for damage or loose connection with harness connector.

Is the inspection result normal?

YES>>

[GO TO 4.](#)

NO>>

Repair / replace harness, connector, or terminal, securely lock the connector. [GO TO 4.](#)

## 4. PERFORM SELF-DIAGNOSIS

---

 With CONSULT

1. Connect ADAS control unit 2 harness connector.



2. Connect ABS actuator and electric unit (control unit) harness connector.
3. Connect 12V battery negative terminal.
4. Erase self-diagnosis result for “ABS”.
5. Power switch OFF (Auto ACC function ON).
6. Get out of the vehicle, close all doors (other than hood assembly), check that the combination meter is OFF, and wait for 1 minute or more without opening these doors.

**CAUTION:**  
**Never operate the vehicle.**

7. Power switch ON without depressing the brake pedal.

**CAUTION:**  
**Never set the vehicle to READY.**

8. Perform self-diagnosis for “ABS”.

Is DTC detected?

YES>>

Check the DTC. Refer to [DTC Index](#).

NO>>

INSPECTION END

## DTC DETECTION LOGIC

DTC No.		CONSULT screen terms	DTC detection condition	
C1040	64	Emergency brake	Diagnosis condition	<ul style="list-style-type: none"> <li>Power switch is ON.</li> <li>When the power supply voltage is normal.</li> </ul>
			Signal (terminal)	CAN communication signal
			Threshold	When a malfunction is detected in ADAS control unit 2 system.
			Diagnosis delay time	2 seconds or less

## POSSIBLE CAUSE



### NOTE:

Confirm if DTC is PAST or CRNT. If DTC is CRNT, proceed with Diagnosis Procedure. If DTC is PAST, clear DTC. Do not replace the ABS actuator and electric unit (control unit) for a PAST DTC.

PAST DTC	CRNT DTC
<ul style="list-style-type: none"> <li>Harness or connector</li> <li>CAN communication line</li> <li>ABS actuator and electric unit (control unit) power supply system</li> <li>Fuse</li> <li>Fusible link</li> <li>12V battery</li> </ul>	<ul style="list-style-type: none"> <li>Harness or connector</li> <li>CAN communication line</li> <li>ADAS control unit 2</li> <li>ABS actuator and electric unit (control unit)</li> <li>ABS actuator and electric unit (control unit) power supply system</li> <li>Fuse</li> <li>Fusible link</li> <li>12V battery</li> </ul>

## FAIL-SAFE

Normal control