

Your Ultimate Source for OEM Repair Manuals

FactoryManuals.net is a great resource for anyone who wants to save money on repairs by doing their own work. The manuals provide detailed instructions and diagrams that make it easy to understand how to fix a vehicle.

2004 MAZDA 6/Atenza Hatchback OEM Service and Repair Workshop Manual

[Go to manual page](#)

STEP	INSPECTION	RESULTS	ACTION
14	INSPECT SPILL VALVE CONTROL SOLENOID VALVE CONTROL CIRCUIT FOR SHORT TO GROUND <ul style="list-style-type: none"> • Switch the ignition off. • Disconnect the high pressure fuel pump and PCM connectors. • Inspect for continuity between high pressure fuel pump terminal A (wiring harness-side) and body ground. • Is there continuity? 	Yes	Refer to the wiring diagram and verify whether or not there is a common connector between high pressure fuel pump terminal A and PCM terminal 1D1. If there is a common connector: <ul style="list-style-type: none"> • Determine the malfunctioning part by inspecting the common connector and the terminal for corrosion, damage, or pin disconnection, and the common wiring harness for a short to ground. • Repair or replace the malfunctioning part. If there is no common connector: <ul style="list-style-type: none"> • Repair or replace the wiring harness which has a short to ground. If the malfunction remains: <ul style="list-style-type: none"> • Replace the PCM. (damage to driver in PCM) (See PCM REMOVAL/INSTALLATION [SKYACTIV-G 2.5 (WITHOUT CYLINDER DEACTIVATION)].)
		No	Replace the high pressure fuel pump. (See HIGH PRESSURE FUEL PUMP REMOVAL/INSTALLATION [SKYACTIV-G 2.5 (WITHOUT CYLINDER DEACTIVATION)] .)
15	INSPECT FUEL PRESSURE (LOW-SIDE) <ul style="list-style-type: none"> • Connect the fuel pressure gauge between fuel pump and high pressure fuel pump. • Measure the low side fuel pressure. (See FUEL LINE PRESSURE INSPECTION [SKYACTIV-G 2.5 (WITHOUT CYLINDER DEACTIVATION)].) • Is the low side fuel pressure within specification? Specification: <ul style="list-style-type: none"> • 405–485 kPa {4.13–4.94 kgf/cm², 58.8–70.3 psi} 	Yes	Go to the next step.
		No	Inspect the following: <ul style="list-style-type: none"> • Fuel line restriction • Fuel filter clogged <p>— If there is any malfunction:</p> <ul style="list-style-type: none"> • Repair or replace the malfunctioning part according to the inspection results. <p>— If there is no malfunction:</p> <ul style="list-style-type: none"> • Replace the fuel pump unit. (See FUEL PUMP UNIT REMOVAL/INSTALLATION [SKYACTIV-G 2.5 (WITHOUT CYLINDER DEACTIVATION)].)
16	INSPECT STARTING SYSTEM <ul style="list-style-type: none"> • Inspect the starting system. (See STARTER INSPECTION [SKYACTIV-G 2.5 (WITHOUT CYLINDER DEACTIVATION)].) • Does the starting system work properly? 	Yes	Go to the next step.
		No	Repair or replace the malfunctioning part according to the inspection results.
17	INSPECT ENGINE COMPRESSION <ul style="list-style-type: none"> • Measure the compression pressure for each cylinder. (See COMPRESSION INSPECTION [SKYACTIV-G 2.5 (WITHOUT CYLINDER DEACTIVATION)].) • Are compression pressures within specification? 	Yes	Go to Step 23.
		No	Go to the next step.

NO.5 ENGINE STALLS-AFTER START/AT IDLE [SKYACTIV-G 2.5 (WITHOUT CYLINDER DEACTIVATION)]

SM2897153

id0103s380110

5	ENGINE STALLS-AFTER START/AT IDLE
DESCRIPTION	<ul style="list-style-type: none">• Stalling occurs if vehicle is left idling under no load.• Stalling occurs when load (electric, A/C) is applied during idling.• Stalling occurs if the accelerator pedal is depressed from an idling condition when accelerating from a stop.

Sample

Item (definition)	Unit/Condition	Definition	Condition/Specification (Reference)
MAF	g/Sec	Mass air flow	<ul style="list-style-type: none"> Displays MAF Ignition switched ON (engine off) (MAF: 0.00 g/s {0 lb/min}): Approx. 1.69 V (ECT is 53 °C {127 °F}) Idle (after warm up) (MAF: 2.50 g/s {0.331 lb/min}): Approx. 1.89 V (ECT is 93 °C {199 °F}) Racing (engine speed is 2,000 rpm) (MAF: 3.80 g/s {0.503 lb/min}): Approx. 2.02 V (ECT is 95 °C {203 °F})
	V		
MAP	KPa {MPa}, mBar {BAR}, psi, in H2O	Manifold absolute pressure	<ul style="list-style-type: none"> Displays MAP
MAP_V	V	MAP sensor voltage	<ul style="list-style-type: none"> Ignition switched ON (engine off) (MAP:100 kPa {1.02 kgf/cm², 14.5 psi}): Approx. 4.04 V Idle (after warm up) (MAP: 35 kPa {0.36 kgf/cm², 5.1 psi}): Approx. 1.40 V Racing (engine speed is 2,000 rpm) (MAP: 26 kPa {0.27 kgf/cm², 3.8 psi}): Approx. 1.01 V
O2S11	µA	A/F sensor	<ul style="list-style-type: none"> Idle (after warm up): Approx. -39 µA Deceleration fuel cut (accelerator pedal released from engine speed of 4,000 rpm or more): Approx. 3.84 mA
O2S12	V	HO2S	<ul style="list-style-type: none"> Idle (after warm up): 0–1.0 V Deceleration fuel cut (accelerator pedal released from engine speed of 4,000 rpm or more): Approx. 0 V
RPM	RPM	Engine speed	<ul style="list-style-type: none"> Displays engine speed
SHRTFT1	%	Short term fuel trim	<ul style="list-style-type: none"> Idle (after warm up): Approx. 2.34% Racing (engine speed is 2,000 rpm): Approx. 3.9% Racing (engine speed is 4,000 rpm): Approx. 1.56%
TP_REL	%	Throttle position signal (relative value)	<ul style="list-style-type: none"> Accelerator pedal released: Approx. 12% Accelerator pedal depressed: Approx. 82%
VPWR	V	Battery positive voltage	<ul style="list-style-type: none"> Displays battery voltage
VSS	KPH, MPH	Vehicle speed	<ul style="list-style-type: none"> Displays vehicle speed

Diagnostic Procedure

STEP	INSPECTION	RESULTS	ACTION
1	VERIFY TIMING OCCURRING MALFUNCTION <ul style="list-style-type: none"> Verify the symptom. Does the malfunction symptom occur just after the engine is started? 	Yes	Perform the symptom troubleshooting “NO.4 HARD TO START/LONG CRANK/ERRATIC START/ERRATIC CRANK”. (See NO.4 HARD TO START/LONG CRANK/ERRATIC START/ERRATIC CRANK [SKYACTIV-G 2.5 (WITHOUT CYLINDER DEACTIVATION)] .)
		No	Go to the next step.
2	VERIFY IF MALFUNCTION INCLUDES ROUGH IDLING <ul style="list-style-type: none"> Verify the symptom. Does the engine idle rough? 	Yes	Perform the symptom troubleshooting “NO.8 ENGINE RUNS ROUGH/ROLLING IDLE”. (See NO.8 ENGINE RUNS ROUGH/ROLLING IDLE [SKYACTIV-G 2.5 (WITHOUT CYLINDER DEACTIVATION)] .)
		No	Go to the next step.

STEP	INSPECTION	RESULTS	ACTION
6	INSPECT MAIN RELAY CIRCUIT FOR SHORT TO GROUND <ul style="list-style-type: none"> • Switch the ignition off. • Remove the main relay. (See RELAY LOCATION.) • Inspect for continuity between the following terminals (wiring harness-side) and body ground: <ul style="list-style-type: none"> — Main relay terminal C — Main relay terminal E • Is there continuity? 	Yes	<p>Disconnect the PCM connector and inspect the wiring harness for short to ground.</p> <ul style="list-style-type: none"> • If the short to ground circuit could be detected in the wiring harness: <ul style="list-style-type: none"> — Refer to the wiring diagram and verify whether or not there is a common connector between the following terminals: <ul style="list-style-type: none"> • Main relay terminal C–PCM terminal 2B0 • Main relay terminal C–PCM terminal 2BR • Main relay terminal E–PCM terminal 2B <p>If there is a common connector:</p> <ul style="list-style-type: none"> • Determine the malfunctioning part by inspecting the common connector and the terminal for corrosion, damage, or pin disconnection, and the common wiring harness for a short to ground. • Repair or replace the malfunctioning part. <p>If there is no common connector:</p> <ul style="list-style-type: none"> • Repair or replace the wiring harness which has a short to ground. <ul style="list-style-type: none"> • If the short to ground circuit could not be detected in the wiring harness: <ul style="list-style-type: none"> — Replace the PCM (short to ground in the PCM internal circuit). (See PCM REMOVAL/INSTALLATION [SKYACTIV-G 2.5 (WITHOUT CYLINDER DEACTIVATION)].) <p>Go to Step 31.</p>
		No	Go to the next step.
7	INSPECT PCM CONNECTOR CONDITION <ul style="list-style-type: none"> • Disconnect the PCM connector. • Inspect for poor connection (such as damaged/pulled-out pins, corrosion). • Is there any malfunction? 	Yes	Repair or replace the connector and/or terminals, then go to Step 31.
		No	Go to the next step.

STEP	INSPECTION	RESULTS	ACTION
16	INSPECT FUEL PRESSURE (HIGH-SIDE) <ul style="list-style-type: none"> Start the engine and warm it up completely. Access the FUEL_PRES PID using the M-MDS at idle. (See ON-BOARD DIAGNOSTIC TEST [PCM (SKYACTIV-G 2.5 (WITHOUT CYLINDER DEACTIVATION))].) Is the FUEL_PRES PID value approx. 10 MPa {102 kgf/cm², 1,450 psi}? 	Yes	Go to Step 20.
		No	Lower than 10 MPa {102 kgf/cm ² , 1,450 psi}: <ul style="list-style-type: none"> Inspect the following: <ul style="list-style-type: none"> Fuel leakage at the fuel line and fuel injector Fuel pump <ul style="list-style-type: none"> Perform the Fuel Pump (Low-pressure Side) Operation Inspection. (See ENGINE CONTROL SYSTEM OPERATION INSPECTION [SKYACTIV-G 2.5 (WITHOUT CYLINDER DEACTIVATION)].) Fuel pressure sensor (See FUEL PRESSURE SENSOR INSPECTION [SKYACTIV-G 2.5 (WITHOUT CYLINDER DEACTIVATION)].) High pressure fuel pump (See HIGH PRESSURE FUEL PUMP INSPECTION [SKYACTIV-G 2.5 (WITHOUT CYLINDER DEACTIVATION)].) <ul style="list-style-type: none"> If there is any malfunction: <ul style="list-style-type: none"> Repair or replace the malfunctioning part according to the inspection results. If there is no malfunction: <ul style="list-style-type: none"> Go to Step 19. Higher than 10 MPa {102 kgf/cm ² , 1,450 psi}: <ul style="list-style-type: none"> Go to the next step.
17	DETERMINE IF MALFUNCTION CAUSE IS FUEL PRESSURE SENSOR OR HIGH PRESSURE FUEL PUMP <ul style="list-style-type: none"> Is the vehicle acceleration performance normal? 	Yes	Go to the next step.
		No	Go to Step 19.
18	INSPECT FUEL PRESSURE SENSOR <ul style="list-style-type: none"> Inspect the fuel pressure sensor. (See FUEL PRESSURE SENSOR INSPECTION [SKYACTIV-G 2.5 (WITHOUT CYLINDER DEACTIVATION)].) Is there any malfunction? 	Yes	Replace the fuel distributor. (See FUEL INJECTOR REMOVAL/INSTALLATION [SKYACTIV-G 2.5 (WITHOUT CYLINDER DEACTIVATION)] .)
		No	Go to Step 20.

STEP	INSPECTION	RESULTS	ACTION
30	INSPECT IF MALFUNCTION CAUSE IS PCV VALVE OR INJECTOR DRIVER (PCM INTEGRATED) <ul style="list-style-type: none"> Inspect the PCV valve. (See POSITIVE CRANKCASE VENTILATION (PCV) VALVE INSPECTION [SKYACTIV-G 2.5 (WITHOUT CYLINDER DEACTIVATION)].) Is there any malfunction? 	Yes	Replace the PCV valve. (See POSITIVE CRANKCASE VENTILATION (PCV) VALVE REMOVAL/INSTALLATION [SKYACTIV-G 2.5 (WITHOUT CYLINDER DEACTIVATION)] .)
		No	Injector driver malfunction. <ul style="list-style-type: none"> Replace the PCM. (See PCM REMOVAL/INSTALLATION [SKYACTIV-G 2.5 (WITHOUT CYLINDER DEACTIVATION)].) If the problem remains, overhaul the engine.
31	Verify the test results. <ul style="list-style-type: none"> If normal, return to the diagnostic index to service any additional symptoms. (See SYMPTOM DIAGNOSTIC INDEX [SKYACTIV-G 2.5 (WITHOUT CYLINDER DEACTIVATION)].) If the malfunction remains, inspect the related Service Bulletins and/or On-line Repair Information and perform repair or diagnosis. <ul style="list-style-type: none"> — If the vehicle is repaired, troubleshooting is completed. — If the vehicle is not repaired or additional diagnostic information is not available, reprogram the PCM if a later calibration is available. Retest. 		

6	CRANKS NORMALLY BUT WILL NOT START
POSSIBLE CAUSE	<p>Warning</p> <ul style="list-style-type: none"> • The following troubleshooting flow chart contains the fuel system diagnosis and repair procedures. Read the following warnings before performing the fuel system services: <ul style="list-style-type: none"> — Fuel vapor is hazardous. It can easily ignite, causing serious injury and damage. Always keep sparks and flames away from fuel. — Highly pressurized fuel may spray out if the fuel line is cut. Due to the following dangers occurring with a fuel spray, always complete the “Fuel Line Safety Procedure” to prevent the fuel from spraying. (See BEFORE SERVICE PRECAUTION [SKYACTIV-G 2.5 (WITHOUT CYLINDER DEACTIVATION)].) • Fuel may cause irritation if it comes in contact with skin and eyes. • If fuel ignites and causes a fire, it may lead to serious injury or death, and damage to property and facilities. — Fuel is highly flammable and dangerous. Fuel line spills and leakage can cause serious injury or death, and damage to equipment. Always refer to the “Quick Release Connector Removal/Installation (fuel system)” before performing the fuel hose installation, and execute the “Fuel Leakage Inspection” after installation. (See QUICK RELEASE CONNECTOR (FUEL SYSTEM) REMOVAL/INSTALLATION [SKYACTIV-G 2.5 (WITHOUT CYLINDER DEACTIVATION)].) (See AFTER SERVICE PRECAUTION [SKYACTIV-G 2.5 (WITHOUT CYLINDER DEACTIVATION)].) <p>Caution</p> <ul style="list-style-type: none"> • Disconnecting/connecting the quick release connector without cleaning it may possibly cause damage to the fuel pipe and quick release connector. Always clean the quick release connector joint area before disconnecting/connecting, and make sure that it is free of foreign material.

Caution

- Verify the malfunction symptom according to not only the PID value but also the symptom troubleshooting.

Related PIDs

Item (definition)	Unit/Condition	Definition	Condition/Specification (Reference)
APP1	%	APP sensor No.1	<ul style="list-style-type: none"> • Accelerator pedal released: Approx. 15 % • Accelerator pedal depressed: Approx. 90.58 %
	V		<ul style="list-style-type: none"> • Accelerator pedal released: Approx. 0.75 V • Accelerator pedal depressed: Approx. 4.52 V
APP2	%	APP sensor No.2	<ul style="list-style-type: none"> • Accelerator pedal released: Approx. 7.45 % • Accelerator pedal depressed: Approx. 45.49%
	V		<ul style="list-style-type: none"> • Accelerator pedal released: Approx. 0.38 V • Accelerator pedal depressed: Approx. 2.26 V
ECT	°C, °F	Engine coolant temperature	<ul style="list-style-type: none"> • Displays ECT
	V		<ul style="list-style-type: none"> • ECT is 20 °C {68 °F}: Approx. 3.10 V • ECT is 40 °C {104 °F}: Approx. 2.16 V • ECT is 60 °C {140 °F}: Approx. 1.40 V • ECT is 80 °C {176 °F}: Approx. 0.87 V • ECT is 100 °C {212 °F}: Approx. 0.54 V
ECT2_V	V	ECT sensor No.2 voltage	<ul style="list-style-type: none"> • ECT is 20 °C {68 °F}: Approx. 3.10 V • ECT is 40 °C {104 °F}: Approx. 2.16 V • ECT is 60 °C {140 °F}: Approx. 1.40 V • ECT is 80 °C {176 °F}: Approx. 0.87 V • ECT is 100 °C {212 °F}: Approx. 0.54 V

STEP	INSPECTION	RESULTS	ACTION
7	INSPECT PURGE CONTROL SYSTEM OPERATION <ul style="list-style-type: none"> Perform the Purge Control System Inspection. (See ENGINE CONTROL SYSTEM OPERATION INSPECTION [SKYACTIV-G 2.5 (WITHOUT CYLINDER DEACTIVATION)].) Does the purge solenoid valve work properly? 	Yes	Go to the next step.
		No	Repair or replace the malfunctioning part according to the inspection results.
8	VERIFY IF MALFUNCTION CAUSE IS MAF SENSOR SIGNAL Note <ul style="list-style-type: none"> If the inspection in Step 8 is performed, the PCM detects a DTC and performs fail-safe control. After performing the inspection, clear DTCs using the M-MDS. Switch the ignition off. Disconnect the MAF sensor/IAT sensor No.1 connector. Start the engine. Does the engine start normally? 	Yes	Clean the MAF sensor. Verify that the symptom is solved. <ul style="list-style-type: none"> If the symptom remains, inspect the MAF sensor related wiring harness and connector. <ul style="list-style-type: none"> If there is any malfunction: <ul style="list-style-type: none"> Repair or replace the malfunctioning part according to the inspection results. If there is no malfunction: <ul style="list-style-type: none"> Replace the MAF sensor/IAT sensor No.1. (See MASS AIR FLOW (MAF) SENSOR/INTAKE AIR TEMPERATURE (IAT) SENSOR NO.1 REMOVAL/INSTALLATION [SKYACTIV-G 2.5 (WITHOUT CYLINDER DEACTIVATION)].)
		No	Go to the next step.
9	INSPECT SUB RELAY <ul style="list-style-type: none"> Switch the ignition off. Remove the sub relay. Inspect the sub relay. (See RELAY INSPECTION.) Is there any malfunction? 	Yes	Replace the sub relay.
		No	Reinstall the sub relay, then go to the next step.
10	INSPECT FUEL PUMP RELAY <ul style="list-style-type: none"> Remove the fuel pump relay. Inspect the fuel pump relay. (See RELAY INSPECTION.) Is there any malfunction? 	Yes	Replace the fuel pump relay.
		No	Inspect for a short or open circuit between the following terminals: <ul style="list-style-type: none"> IG1 relay terminal C–PCM terminal 2F Battery positive terminal–PCM terminal 2BO Battery positive terminal–PCM terminal 2BR Main relay terminal C–Sub relay terminal A Sub relay terminal E–Body ground <ul style="list-style-type: none"> If there is any malfunction: <ul style="list-style-type: none"> Repair or replace the malfunctioning part according to the inspection results. If there is no malfunction: <ul style="list-style-type: none"> Reinstall the fuel pump relay, then go to the next step.

STEP	INSPECTION	RESULTS	ACTION
14	INSPECT FUEL PRESSURE (LOW-SIDE) <ul style="list-style-type: none"> • Connect the fuel pressure gauge between fuel pump and high pressure fuel pump. • Measure the low side fuel pressure. (See FUEL LINE PRESSURE INSPECTION [SKYACTIV-G 2.5 (WITHOUT CYLINDER DEACTIVATION)].) • Is the low side fuel pressure within specification? Specification: <ul style="list-style-type: none"> • 405–485 kPa {4.13–4.94 kgf/cm², 58.8–70.3 psi} 	Yes	Go to the next step.
		No	Inspect the following: <ul style="list-style-type: none"> • Fuel line restriction • Fuel filter clogged — If there is any malfunction: <ul style="list-style-type: none"> • Repair or replace the malfunctioning part according to the inspection results. — If there is no malfunction: <ul style="list-style-type: none"> • Replace the fuel pump unit. (See FUEL PUMP UNIT REMOVAL/INSTALLATION [SKYACTIV-G 2.5 (WITHOUT CYLINDER DEACTIVATION)].)
15	INSPECT FUEL INJECTOR OPERATION <ul style="list-style-type: none"> • Perform the Fuel Injector Operation Inspection. (See ENGINE CONTROL SYSTEM OPERATION INSPECTION [SKYACTIV-G 2.5 (WITHOUT CYLINDER DEACTIVATION)].) • Do the fuel injectors operate properly? 	Yes	Go to the next step.
		No	Repair or replace the malfunctioning part according to the inspection results.
16	INSPECT FUEL TANK <ul style="list-style-type: none"> • Inspect the fuel tank. (See FUEL TANK INSPECTION [SKYACTIV-G 2.5 (WITHOUT CYLINDER DEACTIVATION)].) • Is vapor occurring? 	Yes	Replace the fuel tank. (See FUEL TANK REMOVAL/INSTALLATION [SKYACTIV-G 2.5 (WITHOUT CYLINDER DEACTIVATION)] .)
		No	Go to the next step.
17	INSPECT HIGH PRESSURE FUEL PUMP <ul style="list-style-type: none"> • Inspect the high pressure fuel pump. (See HIGH PRESSURE FUEL PUMP INSPECTION [SKYACTIV-G 2.5 (WITHOUT CYLINDER DEACTIVATION)].) • Is there any malfunction? 	Yes	Replace the high pressure fuel pump. (See HIGH PRESSURE FUEL PUMP REMOVAL/INSTALLATION [SKYACTIV-G 2.5 (WITHOUT CYLINDER DEACTIVATION)] .)
		No	Go to the next step.
18	INSPECT ENGINE COMPRESSION <ul style="list-style-type: none"> • Measure the compression pressure for each cylinder. (See COMPRESSION INSPECTION [SKYACTIV-G 2.5 (WITHOUT CYLINDER DEACTIVATION)].) • Are compression pressures within specification? 	Yes	Go to Step 24.
		No	Go to the next step.
19	INSPECT ELECTRIC VARIABLE VALVE TIMING DRIVER <ul style="list-style-type: none"> • Inspect the electric variable valve timing driver. (See ELECTRIC VARIABLE VALVE TIMING MOTOR/DRIVER INSPECTION [SKYACTIV-G 2.5 (WITHOUT CYLINDER DEACTIVATION)].) • Is there any malfunction? 	Yes	Replace the electric variable valve timing motor/driver. (See ELECTRIC VARIABLE VALVE TIMING MOTOR/DRIVER REMOVAL/INSTALLATION [SKYACTIV-G 2.5 (WITHOUT CYLINDER DEACTIVATION)] .)
		No	Go to the next step.
20	INSPECT ELECTRIC VARIABLE VALVE TIMING MOTOR <ul style="list-style-type: none"> • Inspect the electric variable valve timing motor. (See ELECTRIC VARIABLE VALVE TIMING MOTOR/DRIVER INSPECTION [SKYACTIV-G 2.5 (WITHOUT CYLINDER DEACTIVATION)].) • Is there any malfunction? 	Yes	Replace the electric variable valve timing motor/driver. (See ELECTRIC VARIABLE VALVE TIMING MOTOR/DRIVER REMOVAL/INSTALLATION [SKYACTIV-G 2.5 (WITHOUT CYLINDER DEACTIVATION)] .)
		No	Go to the next step.