

# Your Ultimate Source for OEM Repair Manuals

FactoryManuals.net is a great resource for anyone who wants to save money on repairs by doing their own work. The manuals provide detailed instructions and diagrams that make it easy to understand how to fix a vehicle.

## 2004 MAZDA 6/Atenza Sedan OEM Service and Repair Workshop Manual

[Go to manual page](#)

# NO.8 ENGINE RUNS ROUGH/ROLLING IDLE [SKYACTIV-G 2.5 (WITHOUT CYLINDER DEACTIVATION)]

SM2897155

id0103s380140

8	ENGINE RUNS ROUGH/ROLLING IDLE
DESCRIPTION	<ul style="list-style-type: none"><li>• Idle speed lower than the specification.</li><li>• Idling speed unstable, increases/decreases.</li></ul>

Sample

Item (definition)	Unit/Condition	Definition	Condition/Specification (Reference)
ECT2_V	V	ECT sensor No.2 voltage	<ul style="list-style-type: none"> <li>ECT is 20 °C {68 °F}: Approx. 3.10 V</li> <li>ECT is 40 °C {104 °F}: Approx. 2.16 V</li> <li>ECT is 60 °C {140 °F}: Approx. 1.40 V</li> <li>ECT is 80 °C {176 °F}: Approx. 0.87 V</li> <li>ECT is 100 °C {212 °F}: Approx. 0.54 V</li> </ul>
FUEL_PRES	KPa {MPa}, mBar {BAR}, psi, in H2O	Fuel pressure	<ul style="list-style-type: none"> <li>Displays fuel pressure</li> </ul>
	V		Idle (ECT 80 °C {176 °F}) <ul style="list-style-type: none"> <li>Fuel pressure is 10 MPa {102 kgf/cm<sup>2</sup>, 1450 psi}: Approx. 1.4 V</li> </ul>
LOAD	%	Engine load	<ul style="list-style-type: none"> <li>Idle (after warm up): Approx. 16.07 %</li> <li>Racing (engine speed is 2,000 rpm): Approx. 13.33 %</li> <li>Racing (engine speed is 4,000 rpm): Approx. 15.29 %</li> </ul>
LONGFT1	%	Long term fuel trim	<ul style="list-style-type: none"> <li>Idle (after warm up): Approx. -3.9 %</li> <li>Racing (engine speed is 2,000 rpm): Approx. -0.78 %</li> <li>Racing (engine speed is 4,000 rpm): Approx. -0.78 %</li> </ul>
MAF	g/Sec	Mass air flow	<ul style="list-style-type: none"> <li>Displays MAF</li> </ul>
	V		<ul style="list-style-type: none"> <li>Ignition switched ON (engine off) (MAF: 0.00 g/s {0 lb/min}): Approx. 1.69 V (ECT is 53 °C {127 °F})</li> <li>Idle (after warm up) (MAF: 2.50 g/s {0.331 lb/min}): Approx. 1.89 V (ECT is 93 °C {199 °F})</li> <li>Racing (engine speed is 2,000 rpm) (MAF: 3.80 g/s {0.503 lb/min}): Approx. 2.02 V (ECT is 95 °C {203 °F})</li> </ul>
MAP	KPa {MPa}, mBar {BAR}, psi, in H2O	Manifold absolute pressure	<ul style="list-style-type: none"> <li>Displays MAP</li> </ul>
MAP_V	V	MAP sensor voltage	<ul style="list-style-type: none"> <li>Ignition switched ON (engine off) (MAP:100 kPa {1.02 kgf/cm<sup>2</sup>, 14.5 psi}): Approx. 4.04 V</li> <li>Idle (after warm up) (MAP: 35 kPa {0.36 kgf/cm<sup>2</sup>, 5.1 psi}): Approx. 1.40 V</li> <li>Racing (engine speed is 2,000 rpm) (MAP: 26 kPa {0.27 kgf/cm<sup>2</sup>, 3.8 psi}): Approx. 1.01 V</li> </ul>
O2S11	μA	A/F sensor	<ul style="list-style-type: none"> <li>Idle (after warm up): Approx. -39 μA</li> <li>Deceleration fuel cut (accelerator pedal released from engine speed of 4,000 rpm or more): Approx. 3.84 mA</li> </ul>
O2S12	V	HO2S	<ul style="list-style-type: none"> <li>Idle (after warm up): 0–1.0 V</li> <li>Deceleration fuel cut (accelerator pedal released from engine speed of 4,000 rpm or more): Approx. 0 V</li> </ul>
RPM	RPM	Engine speed	<ul style="list-style-type: none"> <li>Displays engine speed</li> </ul>
SHRTFT1	%	Short term fuel trim	<ul style="list-style-type: none"> <li>Idle (after warm up): Approx. 2.34 %</li> <li>Racing (engine speed is 2,000 rpm): Approx. 3.9 %</li> <li>Racing (engine speed is 4,000 rpm): Approx. 1.56 %</li> </ul>
TP_REL	%	Throttle position signal (relative value)	<ul style="list-style-type: none"> <li>Accelerator pedal released: Approx. 12 %</li> <li>Accelerator pedal depressed: Approx. 82 %</li> </ul>
VSS	KPH, MPH	Vehicle speed	<ul style="list-style-type: none"> <li>Displays vehicle speed</li> </ul>

## Diagnostic Procedure

STEP	INSPECTION	RESULTS	ACTION
1	<b>VERIFY IF MALFUNCTION INCLUDES HARD ENGINE STARTING</b> <ul style="list-style-type: none"> <li>Verify the vehicle engine condition.</li> <li>Can idling be maintained?</li> </ul>	Yes	Go to the next step.
		No	Perform the symptom troubleshooting “NO.5 ENGINE STALLS-AFTER START/AT IDLE”. (See <b>NO.5 ENGINE STALLS-AFTER START/AT IDLE [SKYACTIV-G 2.5 (WITHOUT CYLINDER DEACTIVATION)].</b> )

STEP	INSPECTION	RESULTS	ACTION
6	<b>INSPECT DRIVE-BY-WIRE CONTROL SYSTEM OPERATION</b> <ul style="list-style-type: none"> <li>Perform the Electronic Control Throttle Operation Inspection. (See <b>ENGINE CONTROL SYSTEM OPERATION INSPECTION [SKYACTIV-G 2.5 (WITHOUT CYLINDER DEACTIVATION)]</b>.)</li> <li>Does the drive-by-wire control system work properly?</li> </ul>	Yes	Visually inspect the throttle body (damage/scratching). <ul style="list-style-type: none"> <li>If there is any malfunction:               <ul style="list-style-type: none"> <li>Repair or replace the malfunctioning part according to the inspection results.</li> </ul> </li> <li>If there is no malfunction:               <ul style="list-style-type: none"> <li>Go to the next step.</li> </ul> </li> </ul>
		No	Repair or replace the malfunctioning part according to the inspection results.
7	<b>INSPECT FUEL INJECTOR OPERATION</b> <ul style="list-style-type: none"> <li>Perform the Fuel Injector Operation Inspection. (See <b>ENGINE CONTROL SYSTEM OPERATION INSPECTION [SKYACTIV-G 2.5 (WITHOUT CYLINDER DEACTIVATION)]</b>.)</li> <li>Do the fuel injectors operate properly?</li> </ul>	Yes	Go to the next step.
		No	Repair or replace the malfunctioning part according to the inspection results.
8	<b>INSPECT PURGE CONTROL SYSTEM OPERATION</b> <ul style="list-style-type: none"> <li>Perform the Purge Control System Inspection. (See <b>ENGINE CONTROL SYSTEM OPERATION INSPECTION [SKYACTIV-G 2.5 (WITHOUT CYLINDER DEACTIVATION)]</b>.)</li> <li>Does the purge solenoid valve work properly?</li> </ul>	Yes	Go to the next step.
		No	Repair or replace the malfunctioning part according to the inspection results.
9	<b>INSPECT RELATED PART CONDITION</b> <ul style="list-style-type: none"> <li>Inspect the following:               <ul style="list-style-type: none"> <li>Fuel quality (proper octane, contamination, winter/summer blend)</li> <li>Intake-air system restriction or leakage</li> <li>Electrical connectors connection</li> <li>Fuel leakage in fuel system</li> <li>Vacuum leakage</li> <li>Engine oil viscosity</li> <li>CKP sensor, intake CMP sensor and exhaust CMP sensor</li> </ul> </li> <li>Installation condition (See <b>CRANKSHAFT POSITION (CKP) SENSOR REMOVAL/INSTALLATION [SKYACTIV-G 2.5 (WITHOUT CYLINDER DEACTIVATION)]</b>.) (See <b>CAMSHAFT POSITION (CMP) SENSOR REMOVAL/INSTALLATION [SKYACTIV-G 2.5 (WITHOUT CYLINDER DEACTIVATION)]</b>.)</li> <li>Damaged trigger wheel, intake camshaft and exhaust camshaft</li> <li>Is there any malfunction?</li> </ul>	Yes	Service if necessary. <ul style="list-style-type: none"> <li>Repeat this step.</li> </ul>
		No	Go to the next step.

STEP	INSPECTION	RESULTS	ACTION
17	<b>INSPECT ELECTRIC VARIABLE VALVE TIMING MOTOR</b> • Inspect the electric variable valve timing motor. (See <b>ELECTRIC VARIABLE VALVE TIMING MOTOR/DRIVER INSPECTION [SKYACTIV-G 2.5 (WITHOUT CYLINDER DEACTIVATION)]</b> .) • Is there any malfunction?	Yes	Replace the electric variable valve timing motor/driver. (See <b>ELECTRIC VARIABLE VALVE TIMING MOTOR/DRIVER REMOVAL/INSTALLATION [SKYACTIV-G 2.5 (WITHOUT CYLINDER DEACTIVATION)]</b> .)
		No	Go to the next step.
18	<b>INSPECT ELECTRIC VARIABLE VALVE TIMING ACTUATOR</b> • Inspect the electric variable valve timing actuator. (See <b>ELECTRIC VARIABLE VALVE TIMING ACTUATOR INSPECTION [SKYACTIV-G 2.5 (WITHOUT CYLINDER DEACTIVATION)]</b> .) • Is there any malfunction?	Yes	Replace the electric variable valve timing actuator. (See <b>ELECTRIC VARIABLE VALVE TIMING ACTUATOR, HYDRAULIC VARIABLE VALVE TIMING ACTUATOR REMOVAL/INSTALLATION [SKYACTIV-G 2.5 (WITHOUT CYLINDER DEACTIVATION)]</b> .)
		No	Go to the next step.
19	<b>INSPECT HYDRAULIC VARIABLE VALVE TIMING CONTROL SYSTEM OPERATION</b> • Perform the Hydraulic Variable Valve Timing Control System Operation Inspection. (See <b>ENGINE CONTROL SYSTEM OPERATION INSPECTION [SKYACTIV-G 2.5 (WITHOUT CYLINDER DEACTIVATION)]</b> .) • Is there any malfunction?	Yes	Repair or replace the malfunctioning part according to the inspection results.
		No	Go to the next step.
20	<b>INSPECT FOR MALFUNCTION DUE TO DEVIATED VALVE TIMING</b> • Inspect the valve timing (timing chain installation condition). (See <b>TIMING CHAIN REMOVAL/INSTALLATION [SKYACTIV-G 2.5 (WITHOUT CYLINDER DEACTIVATION)]</b> .) • Is the valve timing normal?	Yes	Inspect for the following engine internal parts: • Cylinder • Piston ring • Intake valve • Exhaust valve • Such as cylinder head gasket  — If there is any malfunction:  • Repair or replace the malfunctioning part according to the inspection results.
		No	Adjust the valve timing to the correct timing.
21	<b>INSPECT IGNITION SYSTEM OPERATION</b> • Perform the Spark Test. (See <b>ENGINE CONTROL SYSTEM OPERATION INSPECTION [SKYACTIV-G 2.5 (WITHOUT CYLINDER DEACTIVATION)]</b> .) • Is a strong blue spark visible at each cylinder?	Yes	Go to the next step.
		No	Repair or replace the malfunctioning part according to the inspection results.
22	<b>INSPECT EXHAUST SYSTEM FOR RESTRICTION</b> • Inspect for restriction in the exhaust system and the TWC. • Is there any restriction?	Yes	Repair or replace the malfunctioning part according to the inspection results.
		No	Go to the next step.
23	<b>INSPECT IF MALFUNCTION CAUSE IS PCV VALVE OR INJECTOR DRIVER (PCM INTEGRATED)</b> • Inspect the PCV valve. (See <b>POSITIVE CRANKCASE VENTILATION (PCV) VALVE INSPECTION [SKYACTIV-G 2.5 (WITHOUT CYLINDER DEACTIVATION)]</b> .) • Is there any malfunction?	Yes	Replace the PCV valve. (See <b>POSITIVE CRANKCASE VENTILATION (PCV) VALVE REMOVAL/INSTALLATION [SKYACTIV-G 2.5 (WITHOUT CYLINDER DEACTIVATION)]</b> .)
		No	Injector driver malfunction. • Replace the PCM. (See <b>PCM REMOVAL/INSTALLATION [SKYACTIV-G 2.5 (WITHOUT CYLINDER DEACTIVATION)]</b> .) If the problem remains, overhaul the engine.

Item (definition)	Unit/Condition	Definition	Condition/Specification (Reference)
AC_REQ	Off/On	A/C request signal	<ul style="list-style-type: none"> <li>A/C switch off: Off</li> <li>A/C switch on: On</li> </ul>
APP1	%	APP sensor No.1	<ul style="list-style-type: none"> <li>Accelerator pedal released: Approx. 15%</li> <li>Accelerator pedal depressed: Approx. 90.58%</li> </ul>
	V		<ul style="list-style-type: none"> <li>Accelerator pedal released: Approx. 0.75 V</li> <li>Accelerator pedal depressed: Approx. 4.52 V</li> </ul>
APP2	%	APP sensor No.2	<ul style="list-style-type: none"> <li>Accelerator pedal released: Approx. 7.45%</li> <li>Accelerator pedal depressed: Approx. 45.49%</li> </ul>
	V		<ul style="list-style-type: none"> <li>Accelerator pedal released: Approx. 0.38 V</li> <li>Accelerator pedal depressed: Approx. 2.26 V</li> </ul>
ECT	°C, °F	Engine coolant temperature	<ul style="list-style-type: none"> <li>Displays ECT</li> </ul>
	V		<ul style="list-style-type: none"> <li>ECT is 20 °C {68 °F}: Approx. 3.10 V</li> <li>ECT is 40 °C {104 °F}: Approx. 2.16 V</li> <li>ECT is 60 °C {140 °F}: Approx. 1.40 V</li> <li>ECT is 80 °C {176 °F}: Approx. 0.87 V</li> <li>ECT is 100 °C {212 °F}: Approx. 0.54 V</li> </ul>
FUEL_PRES	KPa {MPa}, mBar {BAR}, psi, in H2O	Fuel pressure input from fuel pressure sensor	<ul style="list-style-type: none"> <li>Displays fuel pressure</li> </ul>
	V	Fuel pressure sensor voltage	<ul style="list-style-type: none"> <li>Idle (ECT 80 °C {176 °F}) — Fuel pressure is 10 MPa {102 kgf/cm<sup>2</sup>, 1450 psi}: Approx. 1.4 V</li> </ul>
LOAD	%	Engine load	<ul style="list-style-type: none"> <li>Idle (after warm up): Approx. 16.07%</li> <li>Racing (engine speed is 2,000 rpm): Approx. 13.33%</li> <li>Racing (engine speed is 4,000 rpm): Approx. 15.29%</li> </ul>
LONGFT1	%	Long term fuel trim	<ul style="list-style-type: none"> <li>Idle (after warm up): Approx. -3.9%</li> <li>Racing (engine speed is 2,000 rpm): Approx. -0.78%</li> <li>Racing (engine speed is 4,000 rpm): Approx. -0.78%</li> </ul>
O2S11	μA	A/F sensor	<ul style="list-style-type: none"> <li>Idle (after warm up): Approx. -39 μA</li> <li>Deceleration fuel cut (accelerator pedal released from engine speed of 4,000 rpm or more): Approx. 3.84 mA</li> </ul>
O2S12	V	HO2S	<ul style="list-style-type: none"> <li>Idle (after warm up): 0–1.0 V</li> <li>Deceleration fuel cut (accelerator pedal released from engine speed of 4,000 rpm or more): Approx. 0 V</li> </ul>
RPM	RPM	Engine speed	<ul style="list-style-type: none"> <li>Displays engine speed</li> </ul>
SHRTFT1	%	Short term fuel trim	<ul style="list-style-type: none"> <li>Idle (after warm up): Approx. 2.34%</li> <li>Racing (engine speed is 2,000 rpm): Approx. 3.9%</li> <li>Racing (engine speed is 4,000 rpm): Approx. 1.56%</li> </ul>
TP_REL	%	Throttle position signal (relative value)	<ul style="list-style-type: none"> <li>Accelerator pedal released: Approx. 12%</li> <li>Accelerator pedal depressed: Approx. 82%</li> </ul>
VSS	KPH, MPH	Vehicle speed	<ul style="list-style-type: none"> <li>Displays vehicle speed</li> </ul>

## Diagnostic Procedure

NO.10 LOW IDLE/STALLS DURING DECELERATION [SKYACTIV-G 2.5 (WITHOUT CYLINDER DEACTIVATION)]

SM2897157

id0103s380160

10	LOW IDLE/STALLS DURING DECELERATION
DESCRIPTION	<ul style="list-style-type: none"><li>• Engine speed decreases when the accelerator pedal is released.</li><li>• Stalls during deceleration with the accelerator pedal fully released.</li><li>• When the accelerator pedal is fully released, vehicle stalls directly after vehicle stops.</li></ul>

Item (definition)	Unit/Condition	Definition	Condition/Specification (Reference)
ECT	°C, °F	Engine coolant temperature	• Displays ECT
	V		• ECT is 20 °C {68 °F}: Approx. 3.10 V • ECT is 40 °C {104 °F}: Approx. 2.16 V • ECT is 60 °C {140 °F}: Approx. 1.40 V • ECT is 80 °C {176 °F}: Approx. 0.87 V • ECT is 100 °C {212 °F}: Approx. 0.54 V
ECT2_V	V	ECT sensor No.2 voltage	• ECT is 20 °C {68 °F}: Approx. 3.10 V • ECT is 40 °C {104 °F}: Approx. 2.16 V • ECT is 60 °C {140 °F}: Approx. 1.40 V • ECT is 80 °C {176 °F}: Approx. 0.87 V • ECT is 100 °C {212 °F}: Approx. 0.54 V
FUEL_PRES	KPa {MPA}, mBar {BAR}, psi, in H2O	Fuel pressure	• Displays fuel pressure
	V		Idle (ECT 80 °C {176 °F}) • Fuel pressure is 10 MPa {102 kgf/cm <sup>2</sup> , 1450 psi}: Approx. 1.4 V
LOAD	%	Engine load	• Idle (after warm up): Approx. 16.07 % • Racing (engine speed is 2,000 rpm): Approx. 13.33 % • Racing (engine speed is 4,000 rpm): Approx. 15.29 %
LONGFT1	%	Long term fuel trim	• Idle (after warm up): Approx. -3.9 % • Racing (engine speed is 2,000 rpm): Approx. -0.78 % • Racing (engine speed is 4,000 rpm): Approx. -0.78 %
MAF	g/Sec	Mass air flow	• Displays MAF
	V		• Ignition switched ON (engine off) (MAF: 0.00 g/s {0 lb/min}): Approx. 1.69 V (ECT is 53 °C {127 °F}) • Idle (after warm up) (MAF: 2.50 g/s {0.331 lb/min}): Approx. 1.89 V (ECT is 93 °C {199 °F}) • Racing (engine speed is 2,000 rpm) (MAF: 3.80 g/s {0.503 lb/min}): Approx. 2.02 V (ECT is 95 °C {203 °F})
MAP	KPa {MPA}, mBar {BAR}, psi, in H2O	Manifold absolute pressure	• Displays MAP
MAP_V	V	MAP sensor voltage	• Ignition switched ON (engine off) (MAP:100 kPa {1.02 kgf/cm <sup>2</sup> , 14.5 psi}): Approx. 4.04 V • Idle (after warm up) (MAP: 35 kPa {0.36 kgf/cm <sup>2</sup> , 5.1 psi}): Approx. 1.40 V • Racing (engine speed is 2,000 rpm) (MAP: 26 kPa {0.27 kgf/cm <sup>2</sup> , 3.8 psi}): Approx. 1.01 V
O2S11	µA	A/F sensor	• Idle (after warm up): Approx. -39 µA • Deceleration fuel cut (accelerator pedal released from engine speed of 4,000 rpm or more): Approx. 3.84 mA
O2S12	V	HO2S	• Idle (after warm up): 0–1.0 V • Deceleration fuel cut (accelerator pedal released from engine speed of 4,000 rpm or more): Approx. 0 V
RPM	RPM	Engine speed	• Displays engine speed
SHRTFT1	%	Short term fuel trim	• Idle (after warm up): Approx. 2.34 % • Racing (engine speed is 2,000 rpm): Approx. 3.9 % • Racing (engine speed is 4,000 rpm): Approx. 1.56 %
TP_REL	%	Throttle position signal (relative value)	• Accelerator pedal released: Approx. 12 % • Accelerator pedal depressed: Approx. 82 %
VSS	KPH, MPH	Vehicle speed	• Displays vehicle speed

## Diagnostic Procedure



STEP	INSPECTION	RESULTS	ACTION
5	<b>DETERMINE IF MALFUNCTION CAUSE IS A/C REQUEST SIGNAL OR OTHER</b> <ul style="list-style-type: none"> <li>• Access the AC_REQ PID using the M-MDS. (See <b>ON-BOARD DIAGNOSTIC TEST [PCM (SKYACTIV-G 2.5 (WITHOUT CYLINDER DEACTIVATION))]</b>.)</li> <li>• Monitor the AC_REQ PID while turning on and off the air conditioner using the switch on the control panel.</li> <li>• Does the AC_REQ PID value change from on to off according to switch control panel?</li> </ul>	Yes	Go to the next step.
		No	If the AC_REQ PID is always ON: <ul style="list-style-type: none"> <li>• Perform the symptom troubleshooting “A/C IS ALWAYS ON OR A/C COMPRESSOR RUNS CONTINUOUSLY”. (See <b>A/C IS ALWAYS ON OR A/C COMPRESSOR RUNS CONTINUOUSLY [FULL-AUTO AIR CONDITIONER]</b>.) (See <b>A/C IS ALWAYS ON OR A/C COMPRESSOR RUNS CONTINUOUSLY [MANUAL AIR CONDITIONER]</b>.)</li> </ul> If the AC_REQ PID is always OFF: <ul style="list-style-type: none"> <li>• Perform the symptom troubleshooting “A/C DOES NOT WORK SUFFICIENTLY”. (See <b>A/C DOES NOT WORK SUFFICIENTLY [FULL-AUTO AIR CONDITIONER]</b>.) (See <b>A/C DOES NOT WORK SUFFICIENTLY [MANUAL AIR CONDITIONER]</b>.)</li> </ul>
6	<b>DETERMINE IF MALFUNCTION CAUSE IS DRIVE-BY-WIRE CONTROL SYSTEM OR OTHER</b> <ul style="list-style-type: none"> <li>• Will the engine run smoothly at part throttle?</li> </ul>	Yes	Go to Step 8.
		No	Go to the next step.
7	<b>INSPECT DRIVE-BY-WIRE CONTROL SYSTEM OPERATION</b> <ul style="list-style-type: none"> <li>• Perform the Electronic Control Throttle Operation Inspection. (See <b>ENGINE CONTROL SYSTEM OPERATION INSPECTION [SKYACTIV-G 2.5 (WITHOUT CYLINDER DEACTIVATION)]</b>.)</li> <li>• Does the drive-by-wire control system work properly?</li> </ul>	Yes	Visually inspect the throttle body (damage/scratching). <ul style="list-style-type: none"> <li>• If there is any malfunction:               <ul style="list-style-type: none"> <li>— Repair or replace the malfunctioning part according to the inspection results.</li> </ul> </li> <li>• If there is no malfunction:               <ul style="list-style-type: none"> <li>— Go to the next step.</li> </ul> </li> </ul>
		No	Repair or replace the malfunctioning part according to the inspection results.
8	<b>INSPECT FUEL INJECTOR OPERATION</b> <ul style="list-style-type: none"> <li>• Perform the Fuel Injector Operation Inspection. (See <b>ENGINE CONTROL SYSTEM OPERATION INSPECTION [SKYACTIV-G 2.5 (WITHOUT CYLINDER DEACTIVATION)]</b>.)</li> <li>• Do the fuel injectors operate properly?</li> </ul>	Yes	Go to the next step.
		No	Repair or replace the malfunctioning part according to the inspection results.
9	<b>INSPECT PURGE CONTROL SYSTEM OPERATION</b> <ul style="list-style-type: none"> <li>• Perform the Purge Control System Inspection. (See <b>ENGINE CONTROL SYSTEM OPERATION INSPECTION [SKYACTIV-G 2.5 (WITHOUT CYLINDER DEACTIVATION)]</b>.)</li> <li>• Does the purge solenoid valve work properly?</li> </ul>	Yes	Go to the next step.
		No	Repair or replace the malfunctioning part according to the inspection results.

STEP	INSPECTION	RESULTS	ACTION
14	<b>INSPECT SPILL VALVE CONTROL SOLENOID VALVE CONTROL CIRCUIT FOR SHORT TO GROUND</b> <ul style="list-style-type: none"> <li>• Switch the ignition off.</li> <li>• Disconnect the high pressure fuel pump and PCM connectors.</li> <li>• Inspect for continuity between high pressure fuel pump terminal A (wiring harness-side) and body ground.</li> <li>• Is there continuity?</li> </ul>	Yes	Refer to the wiring diagram and verify whether or not there is a common connector between high pressure fuel pump terminal A and PCM terminal 1DI. <b>If there is a common connector:</b> <ul style="list-style-type: none"> <li>• Determine the malfunctioning part by inspecting the common connector and the terminal for corrosion, damage, or pin disconnection, and the common wiring harness for a short to ground.</li> <li>• Repair or replace the malfunctioning part.</li> </ul> <b>If there is no common connector:</b> <ul style="list-style-type: none"> <li>• Repair or replace the wiring harness which has a short to ground.</li> </ul> If the malfunction remains: <ul style="list-style-type: none"> <li>• Replace the PCM. (damage to driver in PCM) (See <b>PCM REMOVAL/INSTALLATION [SKYACTIV-G 2.5 (WITHOUT CYLINDER DEACTIVATION)]</b>.)</li> </ul>
		No	Replace the high pressure fuel pump. (See <b>HIGH PRESSURE FUEL PUMP REMOVAL/INSTALLATION [SKYACTIV-G 2.5 (WITHOUT CYLINDER DEACTIVATION)]</b> .)
15	<b>INSPECT FUEL PRESSURE (LOW-SIDE)</b> <ul style="list-style-type: none"> <li>• Connect the fuel pressure gauge between fuel pump and high pressure fuel pump.</li> <li>• Measure the low side fuel pressure. (See <b>FUEL LINE PRESSURE INSPECTION [SKYACTIV-G 2.5 (WITHOUT CYLINDER DEACTIVATION)]</b>.)</li> <li>• Is the low side fuel pressure within specification?</li> </ul> <b>Specification:</b> <ul style="list-style-type: none"> <li>• 405–485 kPa {4.13–4.94 kgf/cm<sup>2</sup>, 58.8–70.3 psi}</li> </ul>	Yes	Go to the next step.
		No	Inspect the following: <ul style="list-style-type: none"> <li>• Fuel line restriction</li> <li>• Fuel filter clogged</li> </ul> — If there is any malfunction: <ul style="list-style-type: none"> <li>• Repair or replace the malfunctioning part according to the inspection results.</li> </ul> — If there is no malfunction: <ul style="list-style-type: none"> <li>• Replace the fuel pump unit. (See <b>FUEL PUMP UNIT REMOVAL/INSTALLATION [SKYACTIV-G 2.5 (WITHOUT CYLINDER DEACTIVATION)]</b>.)</li> </ul>
16	<b>VERIFY ATX DTC</b> <ul style="list-style-type: none"> <li>• Retrieve TCM DTCs using the M-MDS. (See <b>ON-BOARD DIAGNOSTIC TEST MODE [TCM (FW6A-EL, FW6AX-EL)]</b>.)</li> <li>• Are any DTCs present?</li> </ul>	Yes	Go to the applicable DTC inspection. (See <b>ON-BOARD DIAGNOSTIC SYSTEM DTC TABLE [TCM (FW6A-EL, FW6AX-EL)]</b> .)
		No	Go to the next step.
17	<b>INSPECT ENGINE COMPRESSION</b> <ul style="list-style-type: none"> <li>• Measure the compression pressure for each cylinder. (See <b>COMPRESSION INSPECTION [SKYACTIV-G 2.5 (WITHOUT CYLINDER DEACTIVATION)]</b>.)</li> <li>• Are compression pressures within specification?</li> </ul>	Yes	Go to Step 23.
		No	Go to the next step.
18	<b>INSPECT ELECTRIC VARIABLE VALVE TIMING DRIVER</b> <ul style="list-style-type: none"> <li>• Inspect the electric variable valve timing driver. (See <b>ELECTRIC VARIABLE VALVE TIMING MOTOR/DRIVER INSPECTION [SKYACTIV-G 2.5 (WITHOUT CYLINDER DEACTIVATION)]</b>.)</li> <li>• Is there any malfunction?</li> </ul>	Yes	Replace the electric variable valve timing motor/driver. (See <b>ELECTRIC VARIABLE VALVE TIMING MOTOR/DRIVER REMOVAL/INSTALLATION [SKYACTIV-G 2.5 (WITHOUT CYLINDER DEACTIVATION)]</b> .)
		No	Go to the next step.