


Your Ultimate Source for OEM Repair Manuals

FactoryManuals.net is a great resource for anyone who wants to save money on repairs by doing their own work. The manuals provide detailed instructions and diagrams that make it easy to understand how to fix a vehicle.

2006 TOYOTA Sienna OEM Service and Repair Workshop Manual

[Go to manual page](#)



(j) Tighten the screws (2) from the set of special tools 2 456 372.

SST: 09200-WA700


Torque:

8.0 N·m {82 kgf·cm, 71 in·lbf}

(k) Position the test gauge (2) from the set of special tools 2 358 122 between the intake camshaft sub-assembly and the basic carrier (1) from the set of special tools 2 456 372.

SST: 09200-WA380

SST: 09200-WA700



(l) Position the test gauge (3) from the set of special tools 2 358 122 between the exhaust camshaft sub-assembly and the basic carrier (1) from the set of special tools 2 456 372.

SST: 09200-WA380


SST: 09200-WA700

(m) Tighten screws (arrows).

Torque:


8.0 N·m {82 kgf·cm, 71 in·lbf}

(n) Guide out and remove sealing cap (1) on oil pan cover (2).



(b) Type B:


(1) Replace the cylinder head cover gasket as shown in the illustration.




(c) Ensure that the cylinder head cover sub-assembly (1) is installed in the marked area correctly on the fuel pump bracket (2).

NOTICE:

The cylinder head cover sub-assembly (1) must not touch the high pressure pump bracket (2) in the marked area.



(d) Position cylinder head cover sub-assembly.




(m) Correctly route the engine wiring harness (3) and secure it.

(n) Connect the ventilation hose (2).

(o) Connect both connectors (1).

(p) Secure the positive battery cable (2) in the marked area.



(q) Attach both oxygen sensor cables (1) in the highlighted areas.

13. INSTALL FUEL INJECTOR ASSEMBLY

Click here [INFO](#)

14. INSTALL FUEL (ENGINE ROOM SIDE) PUMP ASSEMBLY

Click here [INFO](#)

15. INSTALL NO. 2 FUEL PIPE SUB-ASSEMBLY

Click here [INFO](#)

16. INSTALL NO. 1 FUEL PIPE SUB-ASSEMBLY

Click here [INFO](#)

17. INSTALL SPARK PLUG

Click here [INFO](#)

18. INSTALL CAM TIMING OIL CONTROL SOLENOID ASSEMBLY

Click here [INFO](#)

HINT:

Use the same procedure as for the LH side.

31. INSTALL NO. 1 ENGINE UNDER COVER ASSEMBLY

Click here [INFO](#)

32. INSTALL NO. 2 AIR CLEANER HOSE

Click here [INFO](#)

33. INSTALL NO. 2 CYLINDER BLOCK SIDE COVER

- (a) Feed in No. 2 cylinder block side cover.
- (b) Install the clip.
- (c) Tighten down T25 screw.

Torque:

8.0 N·m {82 kgf·cm, 71 in·lbf}

34. INSTALL NO. 1 ENGINE COVER SUB-ASSEMBLY

Click here [INFO](#)

35. CONNECT CABLE TO NEGATIVE BATTERY TERMINAL

Click here [INFO](#)

36. ADD ENGINE COOLANT (for Low Temperature)

Click here [INFO](#)

37. ADD ENGINE OIL

Click here [INFO](#)

38. INSTALL OIL FILLER CAP ASSEMBLY

Click here [INFO](#)

39. INSPECT FOR COOLANT LEAK (for Low Temperature)

Click here [INFO](#)

40. CHECK ENGINE OIL LEVEL

Click here [INFO](#)

41. REMOVE AND INSTALL HOOD SUPPORT ASSEMBLY

Click here [INFO](#)

