

Your Ultimate Source for OEM Repair Manuals

FactoryManuals.net is a great resource for anyone who wants to save money on repairs by doing their own work. The manuals provide detailed instructions and diagrams that make it easy to understand how to fix a vehicle.

2007 FORD Focus ST 3 Doors OEM Service and Repair Workshop Manual

[Go to manual page](#)

Yes	<p>CHECK OASIS (Online Automotive Service Information System) for any applicable service articles: TSB (Technical Service Bulletin) , GSB (General Service Bulletin) , SSM (special service message) or FSA (Field Service Action) . If a service article exists for this concern, DISCONTINUE this test and FOLLOW the service article instructions.</p> <p>If no service articles exist for this concern, INSTALL a new VDM (vehicle dynamics control module) module.</p> <p>REFER to: Vehicle Dynamics Control Module (VDM) (204-05 Vehicle Dynamic Suspension, Removal and Installation).</p>
No	<p>The system is operating correctly at this time. The concern may have been caused by a loose or corroded connector. ADDRESS the root cause of any connector or pin issues.</p>

PINPOINT TEST G : RIGHT REAR DAMPER SOLENOID ELECTRICAL FAULTS

Refer to Wiring Diagrams Cell 41 for schematic and connector information.

Normal Operation and Fault Conditions

The VDM (vehicle dynamics control module) sends a variable voltage to the damper solenoids based on sensor input and FD-CAN (Flexible Data Rate Controller Area Network) messages. The VDM (vehicle dynamics control module) continually monitors the damper solenoid circuits and sets a DTC (diagnostic trouble code) when a circuit fault is detected. A shorted or open damper solenoid also causes the VDM (vehicle dynamics control module) to set a DTC (diagnostic trouble code) . After setting the DTC (diagnostic trouble code) the VDM (vehicle dynamics control module) deactivates the dynamic suspension system resulting in a firm/harsh suspension feel and send a message to the IPC (instrument panel cluster) to display a dynamic suspension system warning message.

REFER to: [Vehicle Dynamic Suspension](#) (204-05 Vehicle Dynamic Suspension) .

DTC Fault Trigger Conditions

DTC (diagnostic trouble code)	Description	Fault Trigger Condition
VDM (vehicle dynamics control	Right Rear Damper Solenoid: Circuit	This DTC (diagnostic trouble code) sets in continuous memory when the VDM (vehicle dynamics control module)

- Make sure the valve solenoid electrical connector is free from any corrosion or other contaminants.

NOTICE

Use the correct probe adapter(s) when making measurements. Failure to use the correct probe adapter(s) may cause damage to the connector.

G1 CHECK THE VDM (VEHICLE DYNAMICS CONTROL MODULE) DIAGNOSTIC TROUBLE CODES (DTCS)

- Ignition ON.
- Using a diagnostic scan tool, carry out the VDM (vehicle dynamics control module) self-test.

Is DTC (diagnostic trouble code) C110F:11 present?

Yes	GO to G2
------------	--------------------------

No	GO to G3
-----------	--------------------------

G2 CHECK THE RH (RIGHT-HAND) REAR DAMPER SOLENOID CIRCUITS FOR A SHORT TO GROUND

- Ignition OFF.
- Disconnect VDM (vehicle dynamics control module) C4396 .
- Disconnect RH (right-hand) rear damper solenoid C3656 .
- Disconnect RH (right-hand) rear damper solenoid C372 Raptor .
- Measure:

Positive Lead	Measurement / Action	Negative Lead
C4396-G1	Ω	Ground
C4396-H1	Ω	Ground

Are the resistances greater than 10,000 ohms?

C4396-G1	Ω	C3656-1
C4396-H1	Ω	C3656-2

Raptor

Positive Lead	Measurement / Action	Negative Lead
C4396-G1	Ω	C372-1
C4396-H1	Ω	C372-2

Are the resistances less than 3 ohms?

Yes	GO to G5
------------	--------------------------

No	REPAIR the affected circuit.
-----------	------------------------------

G5 CHECK THE RH (RIGHT-HAND) REAR DAMPER SOLENOID CIRCUITS FOR A SHORT TOGETHER

- Measure:

Positive Lead	Measurement / Action	Negative Lead
C3656-1	Ω	C3656-2

Raptor

REFER to: [Shock Absorber Solenoid - Raptor](#)

(204-02 Rear Suspension, Removal and Installation).

REFER to: [Shock Absorber and Spring Assembly - Vehicles With: Dynamic Suspension](#)

(204-01B Front Suspension - LHD 4WD, Removal and Installation).

G7 VERIFY ALL WIRING CONNECTIONS

- Disconnect VDM (vehicle dynamics control module) C4396 (if not previously disconnected).
- Disconnect damper solenoid valve electrical connector C3656 (if not previously disconnected).
- Disconnect damper solenoid valve electrical connector C372 Raptor (if not previously disconnected).
- Using a good light source, inspect all disconnected electrical connectors for the following:
 - corrosion - install new connector or terminal and clean the module pins
 - damaged or bent pins - install new terminals or pins
 - pushed-out pins - install new pins as necessary
 - spread terminals - install new terminals as necessary

Are the connectors free of corrosion, damaged pins, bent pins, pushed-out pins and spread terminals?

Yes

GO to [G8](#)

No

REPAIR the connector or terminals.

Refer to Wiring Diagrams Cell 5 for schematic and connector information.

G8 CHECK FOR CORRECT VDM (VEHICLE DYNAMICS CONTROL MODULE) OPERATION

- Connect damper solenoid valve electrical connector C3656. Make sure it seats and latches correctly.
- Connect damper solenoid valve electrical connector C372 Raptor. Make sure it seats and latches correctly.
- Connect VDM (vehicle dynamics control module) C4396. Make sure they seat and latch correctly.
- Operate the system and determine if the concern is still present.

Is the concern still present?

Yes

CHECK OASIS (Online Automotive Service Information System) for any applicable service articles: TSB (Technical Service Bulletin) , GSB (General Service Bulletin) , SSM (special service message) or FSA (Field Service Action) . If a service article exists for this concern, DISCONTINUE this test and FOLLOW the service article instructions.

If no service articles exist for this concern, INSTALL a new VDM (vehicle dynamics control module)

VDM (vehicle dynamics control module) U200D:11	Control Module Output Power A: Circuit Short To Ground	Sets in continuous memory when the VDM (vehicle dynamics control module) detects if front height sensor supply voltage is less than 4.7 volts for 250 milliseconds.
VDM (vehicle dynamics control module) U200D:12	Control Module Output Power A: Circuit Short To Battery	Sets in continuous memory when the VDM (vehicle dynamics control module) detects if front height sensor supply voltage is greater than 5.2 volts for 250 milliseconds.

Possible Sources

- Wiring, terminals or connectors
- Height sensor
- VDM (vehicle dynamics control module)

Visual Inspection and Pre-checks

- Make sure the height sensor harness is routed correctly and is undamaged.
- Make sure the height sensor electrical connector is free from any corrosion or other contaminants.
- Make sure the height sensor brackets are not damaged.

NOTICE

Use the correct probe adapter(s) when making measurements. Failure to use the correct probe adapter(s) may cause damage to the connector.

H1 CHECK THE VDM (VEHICLE DYNAMICS CONTROL MODULE) DIAGNOSTIC TROUBLE CODES (DTCS)

If the connector is OK, REPAIR the affected circuit.

No GO to [H5](#)

H3 CHECK THE LH (LEFT-HAND) FRONT HEIGHT SENSOR CIRCUITS FOR A SHORT TO GROUND

- Ignition OFF.
- Disconnect VDM (vehicle dynamics control module) C4396 .
- Disconnect LH (left-hand) front height sensor C1153 .
- Measure:

Positive Lead	Measurement / Action	Negative Lead
C1153-1	Ω	Ground
C1153-2	Ω	Ground
C1153-3	Ω	Ground

Are the resistance greater than 10,000 ohms?

Yes GO to [H4](#)

No

INSPECT the height sensor connector for corrosion, pushed out pins, bent pins and spread terminals. REPAIR as necessary.
If the connector is OK, REPAIR the affected circuit.

H4 CHECK THE LH (LEFT-HAND) FRONT HEIGHT SENSOR CIRCUITS FOR AN OPEN

- Measure:

C1153-2

Ω

C1153-3

Are the resistances greater than 10,000 ohms?

Yes

INSTALL a new height sensor.
REFER to: [Front Suspension Height Sensor](#)
(204-05 Vehicle Dynamic Suspension, Removal and Installation).
If the concern is still present after height sensor replacement, GO to [H6](#)

No

INSPECT the height sensor connector for corrosion, pushed out pins, bent pins and spread terminals. REPAIR as necessary.
If the connector is OK, REPAIR the affected circuit.

H6 VERIFY ALL WIRING CONNECTIONS

- Ignition OFF.
- Disconnect all VDM (vehicle dynamics control module) connectors.
- Using a good light source, inspect all disconnected electrical connectors for the following:
 - corrosion - install new connector or terminal and clean the module pins
 - damaged or bent pins - install new terminals or pins
 - pushed-out pins - install new pins as necessary
 - spread terminals - install new terminals as necessary

Are the connectors free of corrosion, damaged pins, bent pins, pushed-out pins and spread terminals?

Yes

GO to [H7](#)

No

REPAIR the connector or terminals.
Refer to Wiring Diagrams Cell 5 for schematic and connector information.

H7 CHECK FOR CORRECT VDM (VEHICLE DYNAMICS CONTROL MODULE) OPERATION

- Connect LH (left-hand) front height sensor C1153. Make sure they seat and latch correctly.

VDM (vehicle dynamics control module) C1A04:11	Right Front Height Sensor: Circuit Short To Ground	Sets in continuous memory when the VDM (vehicle dynamics control module) detects height sensor voltage less than 4% of supply (nominally 5V) for greater than 250 milliseconds on the right front height sensor signal circuit.
VDM (vehicle dynamics control module) C1A04:12	Right Front Height Sensor: Circuit Short To Battery	Sets in continuous memory when the VDM (vehicle dynamics control module) detects height sensor voltage greater than 96% of supply (nominally 5V) for greater than 250 milliseconds on the right front height sensor signal circuit.
VDM (vehicle dynamics control module) U200D:11	Control Module Output Power A: Circuit Short To Ground	Sets in continuous memory when the VDM (vehicle dynamics control module) detects if front height sensor supply voltage is less than 4.7 volts for 250 milliseconds.
VDM (vehicle dynamics control module) U200D:12	Control Module Output Power A: Circuit Short To Battery	Sets in continuous memory when the VDM (vehicle dynamics control module) detects if front height sensor supply voltage is greater than 5.2 volts for 250 milliseconds.

Possible Sources

- Wiring, terminals or connectors
- Height sensor
- VDM (vehicle dynamics control module)

Visual Inspection and Pre-checks

- Make sure the height sensor harness is routed correctly and is undamaged.
- Make sure the height sensor electrical connector is free from any corrosion or other contaminants.
- Make sure the height sensor brackets are not damaged.

NOTICE

Use the correct probe adapter(s) when making measurements. Failure to use the correct probe adapter(s) may cause damage to the connector.

I1 CHECK THE VDM (VEHICLE DYNAMICS CONTROL MODULE) DIAGNOSTIC TROUBLE CODES (DTCS)

- Ignition ON.

NOTE

No	GO to I5
----	--------------------------

I3 CHECK THE RH (RIGHT-HAND) FRONT HEIGHT SENSOR CIRCUITS FOR A SHORT TO GROUND

- Ignition OFF.
- Disconnect VDM (vehicle dynamics control module) C4396 .
- Disconnect RH (right-hand) front height sensor C1151 .
- Measure:

Positive Lead	Measurement / Action	Negative Lead
C1151-1	Ω	Ground
C1151-2	Ω	Ground
C1151-3	Ω	Ground

Are the resistance greater than 10,000 ohms?

Yes	GO to I4
-----	--------------------------

No	INSPECT the height sensor connector for corrosion, pushed out pins, bent pins and spread terminals. REPAIR as necessary. If the connector is OK, REPAIR the affected circuit.
----	--

I4 CHECK THE RH (RIGHT-HAND) FRONT HEIGHT SENSOR CIRCUITS FOR AN OPEN

- Measure:

Positive Lead	Measurement / Action	Negative Lead
---------------	----------------------	---------------