

Your Ultimate Source for OEM Repair Manuals

FactoryManuals.net is a great resource for anyone who wants to save money on repairs by doing their own work. The manuals provide detailed instructions and diagrams that make it easy to understand how to fix a vehicle.

2008 CHEVROLET Traverse OEM Service and Repair Workshop Manual

[Go to manual page](#)

7. Ignition » On / Vehicle » In Service Mode

8. Verify the scan tool parameter:Transmission ISS=250 to 280 RPM

- **If not between 250 and 280 RPM**

1. Ignition/Vehicle » Off

2. Disconnect the electrical connector:K71 Transmission Control Module

3. Ignition » On / Vehicle » In Service Mode

4. Test for less than 1 V between the test points:Signal circuit terminal 26@Component harness&Ground

- If 1 V or greater » Repair the short to voltage on the circuit.
- If less than 1 V

5. Ignition/Vehicle » Off

6. Test for infinite resistance between the test points:Signal circuit terminal 26@Component harness&Ground

- If less than infinite resistance » Repair the short to ground on the circuit.
- If infinite resistance

7. Test for less than 2 Ω between the test points:Signal circuit terminal 26@Component harness&Terminal 15@Control module harness

- If 2 Ω or greater » Repair the open/high resistance in the circuit.
- If less than 2 Ω » Replace the component:K71 Transmission Control Module

- **If between 250 and 280 RPM**

9. Ignition/Vehicle » Off

10. Connect the electrical connector:X175@T12 Automatic Transmission Assembly

11. Remove the component:Control Valve Body

12. Disconnect the appropriate electrical connector:B14C Transmission Input Shaft Speed Sensor

13. Ignition » On / Vehicle » In Service Mode

14. Test for 8.5 to 9.5 V between the test points:9 V Reference circuitComponent terminal 4&Ground

- **If not between 8.5 and 9.5 V**

- For control module replacement, programming, and setup refer to: [Control Module References](#)

Additional Procedures

[Transmission Service Fast Learn Procedure](#)—Perform only when the component/system is serviced.

Sample

Typical Scan Tool Data

9V Reference 1 Circuit Status

Circuit	Short to Ground	Open	Short to Voltage
Operating Conditions: Ignition=On Parameter Normal Range: OKorNot Run			
9 V Reference1	Malfunction	Malfunction	Malfunction

Transmission OSS

Circuit	Short to Ground	Open	Short to Voltage
Operating Conditions: Engine=Running Parameter Normal Range: 500 to 7,500 RPM			
Signal	0 RPM	0 RPM	—

Circuit/System Description

- [Electronic Component Description](#)
- [Transmission Component and System Description](#)
- [Transmission General Description](#)

Circuit	Description
9 V Reference1	Regulated voltage supplied by the control module.
Signal	The sensor produces a frequency modulated signal.

Component	Description
B14A Transmission	The sensor contains a hall-effect sensor and additional electronics that processes the signal. It detects the change of strength of the magnetic field caused by the reluctor ring.

- Ignition Voltage=Greater than 9 V
- Transmission Gear=Reverse or Drive
- Transmission OSS=Greater than 105 RPM

Frequency the DTC runs=Continuously—After the running conditions are met

P077C, P077D

- { P077C } DTC P077D = Not set
- { P077D } DTC P077C = Not set
- Battery Voltage=Greater than 9 V

Frequency the DTC runs=Continuously—After the running conditions are met

Conditions for Setting the DTC

P0722

Transmission OSS=Less than 30 RPM—For greater than 5 s

P0723

Transmission OSS=Decreases greater than 1000 RPM—For greater than 1 s

P077C

Transmission OSS=Less than 0.25 V—For greater than 1 s

P077D

Transmission OSS=Greater than 4.75 V—For greater than 1 s

Actions Taken When the DTC Sets

DTCs listed in the DTC Descriptor category=Type A DTC

- Autostart/Autostop=Disabled—If equipped
- Default shift pattern=Enabled
- Grade braking=Disabled
- Manual Shift Control=Disabled
- Neutral Idle Mode=Disabled