

# Your Ultimate Source for OEM Repair Manuals

FactoryManuals.net is a great resource for anyone who wants to save money on repairs by doing their own work. The manuals provide detailed instructions and diagrams that make it easy to understand how to fix a vehicle.

## 2008 MAZDA 2 OEM Service and Repair Workshop Manual

[Go to manual page](#)

### Warning


- Highly pressurized fuel may spray out if the fuel line is cut. Due to the following dangers occurring with a fuel spray, always complete the "Fuel Line Safety Procedure" to prevent the fuel from spraying.
  - Fuel may cause irritation if it comes in contact with skin and eyes.
  - If fuel ignites and causes a fire, it may lead to serious injury or death, and damage to property and facilities.
- A person charged with static electricity could cause a fire or explosion, resulting in death or serious injury. Before performing work on the fuel system, discharge static electricity by touching the vehicle body.

## Fuel Siphoning Procedure Using Fuel Pump

### Caution

- Disconnecting/connecting the quick release connector without cleaning it may possibly cause damage to the fuel pipe and quick release connector. Always clean the quick release connector joint area before disconnecting/connecting using cloth or soft brush, and make sure that it is free of foreign material.

1. Complete the "BEFORE SERVICE PRECAUTION". (See [BEFORE SERVICE PRECAUTION \[SKYACTIV-G 2.5 \(WITHOUT CYLINDER DEACTIVATION\)\]](#).)
2. Disconnect the negative battery terminal. (See [NEGATIVE BATTERY TERMINAL DISCONNECTION/CONNECTION](#).)
3. Disconnect the quick release connector as shown in the figure. (See [QUICK RELEASE CONNECTOR \(FUEL SYSTEM\) REMOVAL/INSTALLATION \[SKYACTIV-G 2.5 \(WITHOUT CYLINDER DEACTIVATION\)\]](#).)



ac5uuw00000404

6.Remove the hose using a rag.

Sample

# FUEL PUMP CONTROL MODULE INSPECTION [SKYACTIV-G 2.5 (WITHOUT CYLINDER DEACTIVATION)]

SM2897475


id0114s117510

1. Connect the M-MDS to the DLC-2.
2. Switch the ignition ON (engine off).
3. Perform the KOEO self-test. (See [KOEO/KOER SELF TEST \[PCM \(SKYACTIV-G 2.5 \(WITHOUT CYLINDER DEACTIVATION\)\)\]](#).)
4. Verify that a fuel pump control module related DTC is detected. (See [ON-BOARD DIAGNOSTIC TEST \[PCM \(SKYACTIV-G 2.5 \(WITHOUT CYLINDER DEACTIVATION\)\)\]](#).)
  - If DTCs are detected, repair the malfunctioning part according to the applicable DTC troubleshooting. (See [DTC TABLE \[PCM \(SKYACTIV-G 2.5 \(WITHOUT CYLINDER DEACTIVATION\)\)\]](#).)
  - If a DTC is not detected, go to the next step.
5. Inspect the following:
  - Fuel pump control module damage
  - Fuel pump control module connector damage or corrosion
    - If there is any malfunction, repair or replace the malfunctioning part.



8	Joint hose (See <b>FUEL TANK REMOVAL/INSTALLATION [SKYACTIV-G 2.5 (WITHOUT CYLINDER DEACTIVATION)]</b> .)
9	Non-return valve (See <b>NON-RETURN VALVE INSPECTION [SKYACTIV-G 2.5 (WITHOUT CYLINDER DEACTIVATION)]</b> .)
10	Fuel pump control module (See <b>FUEL PUMP CONTROL MODULE REMOVAL/INSTALLATION [SKYACTIV-G 2.5 (WITHOUT CYLINDER DEACTIVATION)]</b> .) (See <b>FUEL PUMP CONTROL MODULE INSPECTION [SKYACTIV-G 2.5 (WITHOUT CYLINDER DEACTIVATION)]</b> .)

## AWD



1	Fuel tank (See <b>FUEL TANK REMOVAL/INSTALLATION [SKYACTIV-G 2.5 (WITHOUT CYLINDER DEACTIVATION)]</b> .) (See <b>FUEL TANK INSPECTION [SKYACTIV-G 2.5 (WITHOUT CYLINDER DEACTIVATION)]</b> .)
2	Quick release connector (See <b>QUICK RELEASE CONNECTOR (FUEL SYSTEM) REMOVAL/INSTALLATION [SKYACTIV-G 2.5 (WITHOUT CYLINDER DEACTIVATION)]</b> .)
3	Fuel pump unit (See <b>FUEL PUMP UNIT REMOVAL/INSTALLATION [SKYACTIV-G 2.5 (WITHOUT CYLINDER DEACTIVATION)]</b> .) (See <b>FUEL PUMP UNIT DISASSEMBLY/ASSEMBLY [SKYACTIV-G 2.5 (WITHOUT CYLINDER DEACTIVATION)]</b> .) (See <b>FUEL PUMP UNIT INSPECTION [SKYACTIV-G 2.5 (WITHOUT CYLINDER DEACTIVATION)]</b> .)
4	Fuel filter (high-pressure) (See <b>FUEL FILTER (HIGH-PRESSURE) REMOVAL/INSTALLATION [SKYACTIV-G 2.5 (WITHOUT CYLINDER DEACTIVATION)]</b> .)
5	Breather hose (See <b>FUEL TANK REMOVAL/INSTALLATION [SKYACTIV-G 2.5 (WITHOUT CYLINDER DEACTIVATION)]</b> .)
6	Breather pipe (See <b>FUEL TANK REMOVAL/INSTALLATION [SKYACTIV-G 2.5 (WITHOUT CYLINDER DEACTIVATION)]</b> .)
7	Fuel-filler pipe (See <b>FUEL-FILLER PIPE REMOVAL/INSTALLATION [SKYACTIV-G 2.5 (WITHOUT CYLINDER DEACTIVATION)]</b> .)
8	Joint hose (See <b>FUEL TANK REMOVAL/INSTALLATION [SKYACTIV-G 2.5 (WITHOUT CYLINDER DEACTIVATION)]</b> .)
9	Non-return valve (See <b>NON-RETURN VALVE INSPECTION [SKYACTIV-G 2.5 (WITHOUT CYLINDER DEACTIVATION)]</b> .)

# FUEL LINE PRESSURE INSPECTION [SKYACTIV-G 2.5 (WITHOUT CYLINDER DEACTIVATION)]


SM2897477

id0114s180050

## Special Service Tool (SST)

1: 49 N013 1A0D  
2: -

Fuel pressure gauge set



## Warning

- Fuel line spills and leakage from the pressurized fuel system are dangerous. Fuel can ignite and cause serious injury or death and damage. To prevent this, complete the following inspection with the engine stopped.
- Highly pressurized fuel may spray out if the fuel line is cut. Due to the following dangers occurring with a fuel spray, always complete the "Fuel Line Safety Procedure" to prevent the fuel from spraying.
  - Fuel may cause irritation if it comes in contact with skin and eyes.
  - If fuel ignites and causes a fire, it may lead to serious injury or death, and damage to property and facilities.
- A person charged with static electricity could cause a fire or explosion, resulting in death or serious injury. Before performing work on the fuel system, discharge static electricity by touching the vehicle body.

## Caution

- Disconnecting/connecting the quick release connector without cleaning it may possibly cause damage to the fuel pipe and quick release connector. Always clean the quick release connector joint area before disconnecting/connecting using cloth or soft brush, and make sure that it is free of foreign material.

1. Complete the "BEFORE SERVICE PRECAUTION". (See **BEFORE SERVICE PRECAUTION [SKYACTIV-G 2.5 (WITHOUT CYLINDER DEACTIVATION)]**.)

2. Disconnect the negative battery terminal. (See **NEGATIVE BATTERY TERMINAL DISCONNECTION/CONNECTION**.)

3. Disconnect the quick release connector as shown in the figure. (See **QUICK RELEASE CONNECTOR (FUEL SYSTEM) REMOVAL/INSTALLATION [SKYACTIV-G 2.5 (WITHOUT CYLINDER DEACTIVATION)]**.)

— Fuel line leakage

#### Fuel hold pressure

230 kPa {2.35 kgf/cm<sup>2</sup>, 33.4 psi} or more

13. Complete the "BEFORE SERVICE PRECAUTION". (See **BEFORE SERVICE PRECAUTION [SKYACTIV-G 2.5 (WITHOUT CYLINDER DEACTIVATION)]**.)

14. Disconnect the SST.

15. Connect the quick release connector. (See **QUICK RELEASE CONNECTOR (FUEL SYSTEM) REMOVAL/INSTALLATION [SKYACTIV-G 2.5 (WITHOUT CYLINDER DEACTIVATION)]**.)

16. Complete the "AFTER SERVICE PRECAUTION". (See **AFTER SERVICE PRECAUTION [SKYACTIV-G 2.5 (WITHOUT CYLINDER DEACTIVATION)]**.)

# SUCTION CONTROL VALVE INSPECTION [SKYACTIV-D 2.2]

SM2897496


id0114z708780

## Caution

- The supply pump is sealed to maintain the function. Therefore, SSTs and tester are required to disassemble the supply pump securely.
- If a malfunction in the supply pump is verified, place a repair order with the DENSO, Ltd. services network (supply pump manufacturer), and do not disassemble the supply pump yourself.

## Resistance inspection

1. Disconnect the negative battery terminal. (See [NEGATIVE BATTERY TERMINAL DISCONNECTION/CONNECTION.](#))
2. Disconnect suction control valve connector.
3. Measure the resistance between the suction control valve terminals.



ac5wzw00009763

## Suction control valve resistance (specification)

Approx. 2.1 ohms [20 °C {68 °F}]

- If not within the specification, place a repair order with the DENSO, Ltd. services network.

# FUEL CHECK VALVE INSPECTION [SKYACTIV-D 2.2]

SM2897503

id0114z770600

- The fuel check valve cannot be inspected as a single unit.

Sample

# LOWER CASE REMOVAL/INSTALLATION [SKYACTIV-D 2.2]

SM2897501

id0114z726630

## Replacement Part

Fuel main hose	Fuel return hose No.1	Fuel return hose No.2
Quantity: 1	Quantity: 1	Quantity: 1
Location of use: Lower Case	Location of use: Lower Case	Location of use: Lower Case
Fuel return hose No.3	Fuel return hose No.4	
Quantity: 1	Quantity: 1	-
Location of use: Lower Case	Location of use: Lower Case	

## Warning

- Highly pressurized fuel may spray out if the fuel line is cut. Due to the following dangers occurring with a fuel spray, always complete the “Fuel Line Safety Procedure” to prevent the fuel from spraying.
  - Fuel may cause irritation if it comes in contact with skin and eyes.
  - If fuel ignites and causes a fire, it may lead to serious injury or death, and damage to property and facilities.
- A person charged with static electricity could cause a fire or explosion, resulting in death or serious injury. Before draining fuel, make sure to discharge static electricity by touching the vehicle body.

## Caution

- If parts are exposed to the fuel, their function may be decreased or a fire may occur. Spread a rag to absorb any leaked fuel.
- If fuel does not pass through the fuel filter, it could cause a fuel system malfunction. Therefore, do not install the fuel hoses (main and return side) in reverse. When installing the fuel hose, always refer to the “AFTER SERVICE PRECAUTION” and perform the “Fuel Hose Installation Procedure”.

- 1.Disconnect the negative battery terminal. (See [NEGATIVE BATTERY TERMINAL DISCONNECTION/CONNECTION.](#))
- 2.Perform the “Fuel Line Safety Procedure” referring to the “BEFORE SERVICE PRECAUTION”. (See [BEFORE SERVICE PRECAUTION \[SKYACTIV-D 2.2\].](#))
- 3.Remove the engine cover. (See [ENGINE COVER REMOVAL/INSTALLATION \[SKYACTIV-D 2.2\].](#))
- 4.Disconnect the fuel feed pipe (lower case side). (See [SUPPLY PUMP REMOVAL/INSTALLATION \[SKYACTIV-D 2.2\].](#))
- 5.Remove the fuel return pipe (fuel injector side) and cover. (See [FUEL INJECTOR REMOVAL/INSTALLATION \[SKYACTIV-D 2.2\].](#))
- 6.Remove in the order shown in the figure.