

# Your Ultimate Source for OEM Repair Manuals

FactoryManuals.net is a great resource for anyone who wants to save money on repairs by doing their own work. The manuals provide detailed instructions and diagrams that make it easy to understand how to fix a vehicle.

## 2010 FORD Edge OEM Service and Repair Workshop Manual

[Go to manual page](#)

		area network 3)	<ul style="list-style-type: none"> <li>• IPC (instrument panel cluster)</li> </ul>
Input controller interface button data	SCCM (steering column control module)	HS-CAN2 (high-speed controller area network 2)	<ul style="list-style-type: none"> <li>• GWM (gateway module A)</li> </ul>
Input controller interface button data	GWM (gateway module A)	HS-CAN3 (high-speed controller area network 3)	<ul style="list-style-type: none"> <li>• APIM (SYNC module)</li> <li>• IPC (instrument panel cluster)</li> </ul>
IPC (instrument panel cluster) chime request	IPC (instrument panel cluster)	HS-CAN3 (high-speed controller area network 3)	<ul style="list-style-type: none"> <li>• ACM (audio front control module)</li> <li>• APIM (SYNC module)</li> <li>• DSP (audio digital signal processing module)</li> <li>• GWM (gateway module A)</li> </ul>
IPC (instrument panel cluster) chime request	GWM (gateway module A)	FD-CAN (Flexible Data Rate Controller Area Network)	<ul style="list-style-type: none"> <li>• IPMA (image processing module A)</li> </ul>
Lane keep assist hands off	PSCM (power steering control module)	FD-CAN (Flexible Data Rate Controller Area Network)	<ul style="list-style-type: none"> <li>• ABS (anti-lock brake system) module</li> <li>• IPMA (image processing module A)</li> <li>• GWM (gateway module A)</li> </ul>
Lane keep assist hands off	GWM (gateway module A)	HS-CAN3 (high-speed controller area network 3)	<ul style="list-style-type: none"> <li>• IPC (instrument panel cluster)</li> </ul>

			<ul style="list-style-type: none"> <li>• SCMH (passenger multi-contour seat module)</li> </ul>
Lock system message request	GWM (gateway module A)	MS-CAN (medium speed-controller area network) 2	<ul style="list-style-type: none"> <li>• RGTM (rear gate trunk module)</li> </ul>
Manual mirror override	DDM (driver door module)	MS-CAN (medium speed-controller area network) 1	<ul style="list-style-type: none"> <li>• DSM (driver front seat module)</li> </ul>
Memory recall source	BCM (body control module)	HS-CAN1 (high-speed controller area network 1)	<ul style="list-style-type: none"> <li>• GWM (gateway module A)</li> </ul>
Memory recall source	GWM (gateway module A)	FD-CAN (Flexible Data Rate Controller Area Network)	<ul style="list-style-type: none"> <li>• ABS (anti-lock brake system) module</li> <li>• IPMA (image processing module A)</li> </ul>
Memory recall source	GWM (gateway module A)	MS-CAN (medium speed-controller area network) 1	<ul style="list-style-type: none"> <li>• DDM (driver door module)</li> <li>• DSM (driver front seat module)</li> <li>• HVAC (heating, ventilation and air conditioning) module</li> <li>• PDM (passenger door module)</li> <li>• SCMG (driver multi-contour seat module)</li> </ul>

Message center display	GWM (gateway module A)	MS-CAN (medium speed-controller area network) 1	<ul style="list-style-type: none"> <li>• DDM (driver door module)</li> <li>• DSM (driver front seat module)</li> <li>• HVAC (heating, ventilation and air conditioning) module</li> <li>• PDM (passenger door module)</li> </ul>
Multi-contour seat massage settings - driver	SCMG (driver multi-contour seat module)	MS-CAN (medium speed-controller area network) 1	<ul style="list-style-type: none"> <li>• GWM (gateway module A)</li> </ul>
Multi-contour seat massage settings - driver	GWM (gateway module A)	HS-CAN3 (high-speed controller area network 3)	<ul style="list-style-type: none"> <li>• APIM (SYNC module)</li> </ul>
Multi-contour seat massage settings - passenger	SCMH (passenger multi-contour seat module)	MS-CAN (medium speed-controller area network) 1	<ul style="list-style-type: none"> <li>• GWM (gateway module A)</li> </ul>
Multi-contour seat massage settings - passenger	GWM (gateway module A)	HS-CAN3 (high-speed controller area network 3)	<ul style="list-style-type: none"> <li>• APIM (SYNC module)</li> </ul>
Multi-contour seat passenger status	SCMH (passenger multi-contour seat module)	MS-CAN (medium speed-controller)	<ul style="list-style-type: none"> <li>• GWM (gateway module A)</li> </ul>

OCS (occupant classification system) fault status	OCS (occupant classification system) module	HS-CAN2 (high-speed controller area network 2)	<ul style="list-style-type: none"> <li>RCM (restraints control module)</li> </ul>
OCS (occupant classification system) serial number	OCS (occupant classification system) module	HS-CAN2 (high-speed controller area network 2)	<ul style="list-style-type: none"> <li>RCM (restraints control module)</li> </ul>
OTA (Over-The-Air Programming) data push function - ABS (anti-lock brake system) module to GWM (gateway module A)	ABS (anti-lock brake system) module	FD-CAN (Flexible Data Rate Controller Area Network)	<ul style="list-style-type: none"> <li>GWM (gateway module A)</li> </ul>
OTA (Over-The-Air Programming) data push function - GWM (gateway module A) to ABS (anti-lock brake system) module	GWM (gateway module A)	FD-CAN (Flexible Data Rate Controller Area Network)	<ul style="list-style-type: none"> <li>ABS (anti-lock brake system) module</li> </ul>
OTA (Over-The-Air Programming) data push function - CCM (cruise control module) to GWM (gateway module A)	IPMA (image processing module A)	FD-CAN (Flexible Data Rate Controller Area Network)	<ul style="list-style-type: none"> <li>GWM (gateway module A)</li> </ul>
OTA (Over-The-Air Programming) data push function - GWM (gateway module A) to CCM (cruise control module)	GWM (gateway module A)	FD-CAN (Flexible Data Rate Controller Area Network)	<ul style="list-style-type: none"> <li>IPMA (image processing module A)</li> </ul>

		Area Network)	
OTA (Over-The-Air Programming) data push function - SODCMC (Side Obstacle Detection Control Module C) to GWM (gateway module A)	IPMA (image processing module A)	FD-CAN (Flexible Data Rate Controller Area Network)	<ul style="list-style-type: none"> <li>GWM (gateway module A)</li> </ul>
OTA (Over-The-Air Programming) data push function - GWM (gateway module A) to SODCMC (Side Obstacle Detection Control Module C)	GWM (gateway module A)	FD-CAN (Flexible Data Rate Controller Area Network)	<ul style="list-style-type: none"> <li>IPMA (image processing module A)</li> </ul>
OTA (Over-The-Air Programming) data push function - SODCMD (Side Obstacle Detection Control Module D) to GWM (gateway module A)	IPMA (image processing module A)	FD-CAN (Flexible Data Rate Controller Area Network)	<ul style="list-style-type: none"> <li>GWM (gateway module A)</li> </ul>
OTA (Over-The-Air Programming) data push function - GWM (gateway module A) to SODCMD (Side Obstacle Detection Control Module D)	GWM (gateway module A)	FD-CAN (Flexible Data Rate Controller Area Network)	<ul style="list-style-type: none"> <li>IPMA (image processing module A)</li> </ul>
OTA (Over-The-Air Programming) data push function - SODL (side obstacle detection control module LH) to GWM (gateway module A)	IPMA (image processing module A)	FD-CAN (Flexible Data Rate Controller Area Network)	<ul style="list-style-type: none"> <li>GWM (gateway module A)</li> </ul>
OTA (Over-The-Air Programming) data push function - GWM (gateway	GWM (gateway module A)	FD-CAN (Flexible Data Rate	<ul style="list-style-type: none"> <li>IPMA (image processing module A)</li> </ul>

OTA (Over-The-Air Programming) physical data - GWM (gateway module A) to ABS (anti-lock brake system) module	GWM (gateway module A)	FD-CAN (Flexible Data Rate Controller Area Network)	<ul style="list-style-type: none"> <li>• ABS (anti-lock brake system) module</li> </ul>
OTA (Over-The-Air Programming) physical data - CCM (cruise control module) to GWM (gateway module A)	IPMA (image processing module A)	FD-CAN (Flexible Data Rate Controller Area Network)	<ul style="list-style-type: none"> <li>• GWM (gateway module A)</li> </ul>
OTA (Over-The-Air Programming) physical data - GWM (gateway module A) to CCM (cruise control module)	GWM (gateway module A)	FD-CAN (Flexible Data Rate Controller Area Network)	<ul style="list-style-type: none"> <li>• IPMA (image processing module A)</li> </ul>
OTA (Over-The-Air Programming) physical data - CMR (Camera Module - Rear) to GWM (gateway module A)	CMR (Camera Module - Rear)	FD-CAN (Flexible Data Rate Controller Area Network)	<ul style="list-style-type: none"> <li>• GWM (gateway module A)</li> </ul>
OTA (Over-The-Air Programming) physical data - GWM (gateway module A) to CMR (Camera Module - Rear)	GWM (gateway module A)	FD-CAN (Flexible Data Rate Controller Area Network)	<ul style="list-style-type: none"> <li>• CMR (Camera Module - Rear)</li> </ul>
OTA (Over-The-Air Programming) physical data - IPMA (image processing module A) to GWM (gateway module A)	IPMA (image processing module A)	FD-CAN (Flexible Data Rate Controller Area Network)	<ul style="list-style-type: none"> <li>• GWM (gateway module A)</li> </ul>

Detection Control Module C) to GWM (gateway module A)		Controller Area Network)	
OTA (Over-The-Air Programming) physical data - GWM (gateway module A) to SODCMC (Side Obstacle Detection Control Module C)	GWM (gateway module A)	FD-CAN (Flexible Data Rate Controller Area Network)	<ul style="list-style-type: none"> <li>IPMA (image processing module A)</li> </ul>
OTA (Over-The-Air Programming) physical data - SODCMD (Side Obstacle Detection Control Module D) to GWM (gateway module A)	IPMA (image processing module A)	FD-CAN (Flexible Data Rate Controller Area Network)	<ul style="list-style-type: none"> <li>GWM (gateway module A)</li> </ul>
OTA (Over-The-Air Programming) physical data - GWM (gateway module A) to SODCMD (Side Obstacle Detection Control Module D)	GWM (gateway module A)	FD-CAN (Flexible Data Rate Controller Area Network)	<ul style="list-style-type: none"> <li>IPMA (image processing module A)</li> </ul>
OTA (Over-The-Air Programming) physical data - SODL (side obstacle detection control module LH) to GWM (gateway module A)	IPMA (image processing module A)	FD-CAN (Flexible Data Rate Controller Area Network)	<ul style="list-style-type: none"> <li>GWM (gateway module A)</li> </ul>
OTA (Over-The-Air Programming) physical data - GWM (gateway module A) to SODL (side obstacle detection control module LH)	GWM (gateway module A)	FD-CAN (Flexible Data Rate Controller Area Network)	<ul style="list-style-type: none"> <li>IPMA (image processing module A)</li> </ul>
OTA (Over-The-Air Programming) physical data -	IPMA (image processing module A)	FD-CAN (Flexible Data	<ul style="list-style-type: none"> <li>GWM (gateway module A)</li> </ul>



		area network 3)	
Outside air temperature	GWM (gateway module A)	MS-CAN (medium speed-controller area network) 2	<ul style="list-style-type: none"> <li>• RGTM (rear gate trunk module)</li> </ul>
Park lock control status	BCM (body control module)	HS-CAN1 (high-speed controller area network 1)	<ul style="list-style-type: none"> <li>• ACCM (air conditioning control module)</li> <li>• ACCMB (Air Conditioning Compressor Control Module B)</li> <li>• BECM (battery energy control module)</li> <li>• DCDC (direct current/direct current converter control module)</li> <li>• OBCC (Off-Board Charger Controller)</li> <li>• SOBDM (secondary on-board diagnostic control module A) (Battery Charging Control Module [BCCM])</li> <li>• SOBDMB (Secondary On-Board Diagnostic Control Module B (SOBDMB)) (All Wheel Drive Control [AWDC])</li> <li>• GWM (gateway module A)</li> </ul>
Park lock control status	GWM (gateway module A)	FD-CAN (Flexible Data Rate Controller)	<ul style="list-style-type: none"> <li>• ABS (anti-lock brake system) module</li> <li>• CMR (Camera Module - Rear)</li> </ul>

		controller area network 2	
PATS (passive anti-theft system) control command	BCM (body control module)	HS-CAN1 (high-speed controller area network 1)	<ul style="list-style-type: none"> <li>• GWM (gateway module A)</li> </ul>
PATS (passive anti-theft system) control command	GWM (gateway module A)	FD-CAN (Flexible Data Rate Controller Area Network)	<ul style="list-style-type: none"> <li>• PCM (powertrain control module)</li> </ul>
PATS (passive anti-theft system) start request target command	PCM (powertrain control module)	FD-CAN (Flexible Data Rate Controller Area Network)	<ul style="list-style-type: none"> <li>• ABS (anti-lock brake system) module</li> <li>• GWM (gateway module A)</li> </ul>
PATS (passive anti-theft system) start request target command	GWM (gateway module A)	HS-CAN1 (high-speed controller area network 1)	<ul style="list-style-type: none"> <li>• BCM (body control module)</li> </ul>
Power running board status	DSM (driver front seat module) / RBM (running board control module)	MS-CAN (medium speed-controller area network) 1	<ul style="list-style-type: none"> <li>• GWM (gateway module A)</li> </ul>
Power running board status	GWM (gateway module A)	HS-CAN3 (high-speed controller)	<ul style="list-style-type: none"> <li>• APIM (SYNC module)</li> <li>• IPC (instrument panel cluster)</li> </ul>