

# Your Ultimate Source for OEM Repair Manuals

FactoryManuals.net is a great resource for anyone who wants to save money on repairs by doing their own work. The manuals provide detailed instructions and diagrams that make it easy to understand how to fix a vehicle.

## **2010 MAZDA 3 MPS / MAZDASPEED3 OEM Service and Repair Workshop Manual**

[Go to manual page](#)

Terminal	Signal	Connected to	Test condition	Voltage (V)	inspection item
1H	A/F (+)	A/F sensor	Idle (after warm up)	Approx. 2.18	• A/F sensor • Related wiring harness
1I	A/F (–)	A/F sensor	Idle (after warm up)	Approx. 1.735	• A/F sensor • Related wiring harness
1J	Constant voltage (Vref)	CKP sensor	Switch the ignition ON (engine off)	Approx. 5.03	• Related wiring harness
1K	Constant voltage (Vref)	CMP sensor	Switch the ignition ON (engine off)	Approx. 5.03	• Related wiring harness
1L	GND	Engine oil level sensor	Switch ignition ON (engine off)	Below 1.0	• Related wiring harness
1M	Constant voltage (Vref)	Fuel pressure sensor (in fuel injector No.1)	Switch ignition ON (engine off)	Approx. 5.03	• Related wiring harness
1N	Constant voltage (Vref)	Fuel pressure sensor (in fuel injector No.4)	Switch ignition ON (engine off)	Approx. 5.03	• Related wiring harness
1O	–	–	–	–	–
1P	LIN	Fuel temperature sensor (in fuel injector No.3)	Because this terminal is for communication, integrity determination using terminal voltage inspection is not possible.		• Related wiring harness
1Q	–	–	–	–	–
1R	GND	Fuel pressure sensor (in fuel injector No.1)	Switch ignition ON (engine off)	Below 1.0	• Related wiring harness
1S	GND	Fuel pressure sensor (in fuel injector No.4)	Switch ignition ON (engine off)	Below 1.0	• Related wiring harness
1T	LIN	Fuel temperature sensor (in fuel injector No.1)	Because this terminal is for communication, integrity determination using terminal voltage inspection is not possible.		• Related wiring harness
1U	LIN	Fuel temperature sensor (in fuel injector No.4)	Because this terminal is for communication, integrity determination using terminal voltage inspection is not possible.		• Related wiring harness
1V	LIN	Fuel temperature sensor (in fuel injector No.2)	Because this terminal is for communication, integrity determination using terminal voltage inspection is not possible.		• Related wiring harness
1W	–	–	–	–	–
1X	GND	ECT sensor No.2	Switch the ignition ON (engine off)	Below 1.0	• Related wiring harness
1Y	CAN_2L	CAN system related modules	Because this terminal is for CAN, good/no good judgment by terminal voltage is not possible.		• Related wiring harness
1Z	Exhaust gas pressure	Exhaust gas pressure sensor No.2	Switch the ignition ON (engine off)	Approx. 0.525	• Exhaust gas pressure sensor No.2 • Related wiring harness
			Idle (after warm up)	Approx. 0.57	
1AA	GND	Sensor shield	Switch the ignition ON (engine off)	Below 1.0	• Related wiring harness
1AB	EGR temperature	EGR temperature sensor	Switch the ignition ON (engine off)	Approx. 5.03	• EGR temperature sensor • Related wiring harness
1AC	GND	Exhaust gas temperature sensor No.1	Switch the ignition ON (engine off)	Below 1.0	• Related wiring harness


Terminal	Signal	Connected to	Test condition	Voltage (V)	inspection item
1BS	GND	Exhaust gas temperature sensor No.3	Under any condition	Below 1.0	• Related wiring harness
1BT	—	—	—	—	—
1BU	—	—	—	—	—
1BV	Constant voltage (Vref)	Fuel pressure sensor (in fuel injector No.3)	Switch the ignition ON (engine off)	Approx. 5.03	• Related wiring harness
1BW	Exhaust gas temperature	Exhaust gas temperature sensor No.3	Switch the ignition ON (engine off)	Approx. 5.03	• Exhaust gas temperature sensor No.3 • Related wiring harness
1BX	Constant voltage (Vref)	Fuel pressure sensor (in fuel injector No.2)	Switch the ignition ON (engine off)	Approx. 5.03	• Related wiring harness
1BY	Suction control valve	Suction control valve	Switch the ignition ON (engine off)	Below 1.0	• Suction control valve • Related wiring harness
			(See <b>Suction control valve signal.</b> )		
1BZ	GND	GND	Switch the ignition ON (engine off)	Below 1.0	• Related wiring harness
1CA	Exhaust gas temperature	Exhaust gas temperature sensor No.2	Switch the ignition ON (engine off)	Approx. 5.03	• Exhaust gas temperature sensor No.2 • Related wiring harness
1CB	GND	Exhaust gas temperature sensor No.2	Switch the ignition ON (engine off)	Below 1.0	• Related wiring harness
1CC	Suction control valve	Suction control valve	Switch the ignition ON (engine off)	Below 1.0	• Suction control valve • Related wiring harness
			(See <b>Suction control valve signal.</b> )		
1CD	GND	GND	Switch the ignition ON (engine off)	Below 1.0	• Related wiring harness
1CE	Exhaust gas pressure	Exhaust gas pressure sensor No.1	Switch the ignition ON (engine off)	Approx. 0.957	• Exhaust gas pressure sensor No.1 • Related wiring harness
			Idle (after warm up)	0.975–1.230	
1CF	GND	Exhaust gas pressure sensor No.1	Switch the ignition ON (engine off)	Below 1.0	• Related wiring harness
1CG	A/F sensor heater control	A/F sensor heater	(See <b>A/F sensor heater control signal.</b> )		• A/F sensor heater • Related wiring harness
1CH	Engine oil control	Engine oil solenoid valve	(See <b>Engine oil control signal.</b> )		• Engine oil solenoid valve • Related wiring harness
1CI	Exhaust gas temperature	Exhaust gas temperature sensor No.1	Switch the ignition ON (engine off)	Approx. 4.94	• Exhaust gas temperature sensor No.1 • Related wiring harness
1CJ	Constant voltage (Vref)	Exhaust gas pressure sensor No.1	Switch the ignition ON (engine off)	Approx. 5.03	• Related wiring harness

Terminal	Signal	Connected to	Test condition	Voltage (V)	inspection item
1DX	GND	Sensor shield	Switch the ignition ON (engine off)	Below 1.0	• Related wiring harness
1DY	—	—	—	—	—
1DZ	GND	Exhaust gas temperature sensor No.5	Switch the ignition ON (engine off)	Below 1.0	• Related wiring harness
1EA	Fuel injection control (+)	Fuel injector No.1	(See <b>Fuel injection control (+) signal.</b> )		• Fuel injector No.1 • Related wiring harness
1EB	GND	Sensor shield	Switch the ignition ON (engine off)	Below 1.0	• Related wiring harness
1EC	—	—	—	—	—
1ED	—	—	—	—	—
1EE	Fuel injection control (–)	Fuel injector No.1	(See <b>Fuel injection control (–) signal.</b> )		• Fuel injector No.1 • Related wiring harness
1EF	Fuel injection control (–)	Fuel injector No.4	(See <b>Fuel injection control (–) signal.</b> )		• Fuel injector No.4 • Related wiring harness
1EG	—	—	—	—	—
1EH	—	—	—	—	—
1EI	Generator field coil control	Generator	(See <b>Generator field coil control signal.</b> )		• Generator • Related wiring harness
1EJ	—	—	—	—	—
2A	—	—	—	—	—
2B	—	—	—	—	—
2C	Blow-by heater relay	Blow-by heater relay	Switch the ignition ON (engine off)	B+	• Blow-by heater relay
			Idle (after warm up)	B+	• Related wiring harness
2D	Blow-by heater relay	Blow-by heater relay	Switch the ignition ON (engine off)	Below 1.0	• Blow-by heater relay
			Idle (after warm up)	Below 1.0	• Related wiring harness
2E	Check connector	Check connector	Switch the ignition ON (engine off)	B+	• Check connector • Related wiring harness
2F	Sedimentor	Sedimentor switch	Switch the ignition ON (engine off)	B+	• Sedimentor switch • Related wiring harness
2G	LIN	Glow control module, engine oil level sensor	Because this terminal is for CAN, good/no good judgment by terminal voltage is not possible.		• Glow control module • Engine oil level sensor • Related wiring harness
2H	Ignition (IG1)	IG1 relay	Switch the ignition ON (engine off)	B+	• IG1 relay • Related wiring harness
2I	—	—	—	—	—
2J	—	—	—	—	—

Terminal	Signal	Connected to	Test condition		Voltage (V)	inspection item
2BE	A/C cut-off control	A/C relay	A/C relay OFF		B+	<ul style="list-style-type: none"> <li>• A/C relay</li> <li>• Related wiring harness</li> </ul>
			A/C relay ON		Below 1.0	
2BF	Starter cut-off control	Starter relay, start stop unit	Switch the ignition ON (engine off)	Selector lever position is not P or N position	R position: B+	<ul style="list-style-type: none"> <li>• Starter relay</li> <li>• Start stop unit</li> <li>• Related wiring harness</li> </ul>
				Selector lever position is P or N position	D position: B+	
					M position: B+	
					P position: B+	
					N position: B+	
2BG	Fan control	Fan control module No.1	Switch the ignition ON (engine off)		Below 1.0	<ul style="list-style-type: none"> <li>• Fan control module No.1</li> <li>• Related wiring harness</li> </ul>
2BH	Refrigerant pressure	Refrigerant pressure sensor	Switch the ignition ON (engine off)	A/C switch off	Approx. 0.771	<ul style="list-style-type: none"> <li>• Refrigerant pressure sensor</li> <li>• Related wiring harness</li> </ul>
			Idle (after warm up) or switch the ignition ON (engine off)		Approx. 1.23	

## Inspection Using An Oscilloscope (Reference)

### CMP (G+) signal



#### PCM terminals

- 1A(+)-body ground(-)

#### Oscilloscope setting

- 1 V/DIV (Y), 20 ms/DIV (X), DC range

#### Vehicle condition

- Idle (after warm up)

### Intake shutter valve (ISV-) signal


#### Oscilloscope setting

- 5 V/DIV (Y), 20 ms/DIV (X), DC range

#### Vehicle condition

- Idle (after warm up)

#### Engine oil control signal



#### PCM terminals

- 1CH(+)-body ground(-)


#### Oscilloscope setting

- 5 V/DIV (Y), 1 ms/DIV (X), DC range

#### Vehicle condition

- Idle (after warm up)

#### Wastegate solenoid valve signal



#### PCM terminals


- 1CL(+)-body ground(-)

#### Oscilloscope setting

- 5 V/DIV (Y), 5 ms/DIV (X), DC range

#### Vehicle condition

- Idle (after warm up)



#### PCM terminals

- 1E(+)-body ground(-)


#### Oscilloscope setting

- 3 V/DIV (Y), 1 ms/DIV (X), DC range

#### Vehicle condition

- Idle (after warm up)

### Generator field coil control signal



#### PCM terminals

- 1E(+)-body ground(-)

#### Oscilloscope setting

- 500 mV/DIV (Y), 1 ms/DIV (X), DC range

#### Vehicle condition

- Idle (after warm up)

## Using The M-MDS

#### Note

- PIDs for the following parts are not available on this model. Go to the appropriate part inspection page.
  - CMP sensor (See **CAMSHAFT POSITION (CMP) SENSOR INSPECTION [SKYACTIV-D 2.2].**)
  - Main relay (See **RELAY INSPECTION.**)

1. Connect the M-MDS to the DLC-2.

Item (definition)	Unit/Condition	Definition	Condition/Specification (Reference)
DEF_TYPE	–	DEF type	• Displays the DEF type.
DET_CNT_L1	–	Number of times DPF regeneration interval (5 g/l accumulation point) is 39–69 km	• Number of times DPF regeneration interval (5 g/l accumulation point) is 39–69 km
DET_CNT_L2	–	Number of times DPF regeneration interval (5 g/l accumulation point) is 70–99 km	• Number of times DPF regeneration interval (5 g/l accumulation point) is 70–99 km
DNS_F_WF	km, ft, mi	Distance to next service for water in fuel	• Displays the distance to next service for water in fuel.
DPF_DIS_1	Displays in the Mazda Modular Diagnostic System (M-MDS) but it does not operate.		
DPF_DIS_2			
DPF_DIS_3			
DPF_DIS_4			
DPF_DIS_5			
DPF_DIS_6			
DPF_DIS_7			
DPF_DIS_8			
DPF_DIS_9			
DPF_DIS_10			
DPF_LMP	Off/On	Diesel particulate filter indicator light	• Diesel particulate filter indicator light not illuminate: Off • Diesel particulate filter indicator light illuminate: On
DPF_LMP_CNT	–	Number of times diesel particulate filter indicator light illuminates	• Displays the number of times diesel particulate filter indicator light illuminates.
DPF_REG_CNT	–	Diesel particulate filter regeneration count	• Displays the diesel particulate filter regeneration count.
DPS_RGN_ST	–	Diesel particulate filter regen status	• Displays the diesel particulate filter regen status.
DV_RGT_CSPT_10K	Displays in the Mazda Modular Diagnostic System (M-MDS) but it does not operate.		
DV_RGT_CSPT_20K			
DV_RGT_CSPT_30K			
DV_RGT_CSPT_40K			
DV_RGT_CSPT_ACT			
EG_FRC_PRS_TRQ	%	Engine friction-percent torque	• Displays the engine friction-percent torque.
EGR_LRN	V	EGR valve learning value (closed condition)	• Displays the EGR valve fully-closed learning value.
EGR_VVT_MN_CP	Displays in the Mazda Modular Diagnostic System (M-MDS) but it does not operate.		
EGR_VVT_MNT			
EGRB_DC_POS	%	EGR cooler bypass valve	• Displays the EGR cooler bypass valve position.
EGRP	%	EGR valve	• Displays the EGR valve position.
EGRP_ACT	%	EGR valve actual opening angle	<b>ECT: above 70 °C {158 °F}</b> • idle: 0 % (after 20–30 s have elapsed since start the engine) • Racing (engine speed 2,000 rpm): Approx. 60 %
EGRT	°C, °F	EGR gas temperature	• Displays the EGR gas temperature.
EGT_B1S5	°C, °F	Exhaust gas temperature (No.5)	• Displays the exhaust gas temperature.



Item (definition)	Unit/Condition	Definition	Condition/Specification (Reference)
GPC_DUTY	%	Glow plug coil duty cycle	<ul style="list-style-type: none"> <li>Switch the ignition ON (engine off): 0 %</li> <li><b>Idle</b></li> <li>ECT is 36 °C {86 °F}: Approx. 51 %</li> <li>After a certain period has elapsed from when ECT exceeds 40 °C {104 °F}: 0 %</li> </ul>
GPL_OP_ST	Displays in the Mazda Modular Diagnostic System (M-MDS) but it does not operate.		
GPL_ST_SUP			
HPEGR_DSD			
HT_NOX_SRC_MN			
HTR11	%	A/F sensor heater control	<ul style="list-style-type: none"> <li>Switch the ignition ON (engine off): 0 %</li> <li>idle: Approx. 10.49 %</li> <li>Racing (engine speed above 4,000 rpm): Approx. 50 %</li> </ul>
IAT_B1S1	°C, °F	Intake air temperature (No.1)	Displays the intake air temperature (No.1).
IAT_B1S2	°C, °F	Intake air temperature (No.2)	Displays the intake air temperature (No.2).
IAT13	°C, °F	Intake air temperature (No.3)	Displays the intake air temperature (No.3).
ICP1	KPa {MPa}, mBar {BAR}, psi, in H2O	Fuel pressure sensor (built into fuel injector No.1)	Displays the fuel pressure sensor (built into fuel injector No.1).
ICP2	KPa {MPa}, mBar {BAR}, psi, in H2O	Fuel pressure sensor (built into fuel injector No.2)	Displays the fuel pressure sensor (built into fuel injector No.2).
ICP3	KPa {MPa}, mBar {BAR}, psi, in H2O	Fuel pressure sensor (built into fuel injector No.3)	Displays the fuel pressure sensor (built into fuel injector No.3).
ICP4	KPa {MPa}, mBar {BAR}, psi, in H2O	Fuel pressure sensor (built into fuel injector No.4)	Displays the fuel pressure sensor (built into fuel injector No.4).
IDC_SYS_ACT	Displays in the Mazda Modular Diagnostic System (M-MDS) but it does not operate.		
IFT1	KPa {MPa}, mBar {BAR}, psi, in H2O	Fuel temperature sensor (built into fuel injector No.1)	Displays the fuel temperature sensor (built into fuel injector No.1).
IFT2	KPa {MPa}, mBar {BAR}, psi, in H2O	Fuel temperature sensor (built into fuel injector No.2)	Displays the fuel temperature sensor (built into fuel injector No.2).
IFT3	KPa {MPa}, mBar {BAR}, psi, in H2O	Fuel temperature sensor (built into fuel injector No.3)	Displays the fuel temperature sensor (built into fuel injector No.3).
IFT4	KPa {MPa}, mBar {BAR}, psi, in H2O	Fuel temperature sensor (built into fuel injector No.4)	Displays the fuel temperature sensor (built into fuel injector No.4).
INCR_RGT_10K	Displays in the Mazda Modular Diagnostic System (M-MDS) but it does not operate.		
INCR_RGT_20K			
INCR_RGT_30K			
INCR_RGT_40K			
INCR_RGT_ACT			
INGEAR	Off/On	Gears are engaged	<ul style="list-style-type: none"> <li>Selector lever at R, D or M position: ON</li> <li>Selector lever at P or N position: OFF</li> </ul>
INJ1_CMP	–(mm <sup>3</sup> /Stroke)	Fuel injector No.1 correction value	<ul style="list-style-type: none"> <li>Switch the ignition ON (engine off): Approx. –0.2</li> <li>idle: Approx. –0.03</li> <li>Racing (engine speed above 4,000 rpm): 0</li> </ul>
INJ2_CMP	–(mm <sup>3</sup> /Stroke)	Fuel injector No.2 correction value	<ul style="list-style-type: none"> <li>Switch the ignition ON (engine off): Approx. 0.27</li> <li>idle: Approx. –0.06</li> <li>Racing (engine speed above 4,000 rpm): 0</li> </ul>
INJ3_CMP	–(mm <sup>3</sup> /Stroke)	Fuel injector No.3 correction value	<ul style="list-style-type: none"> <li>Switch the ignition ON (engine off): Approx. 0.01</li> <li>idle: Approx. 0.03</li> <li>Racing (engine speed above 4,000 rpm): 0</li> </ul>
INJ4_CMP	–(mm <sup>3</sup> /Stroke)	Fuel injector No.4 correction value	<ul style="list-style-type: none"> <li>Switch the ignition ON (engine off): Approx. –0.01</li> <li>idle: Approx. 0.03</li> <li>Racing (engine speed above 4,000 rpm): 0</li> </ul>

Item (definition)	Unit/Condition	Definition	Condition/Specification (Reference)
PRS_TRQ_DEM	%	Driver's demand engine-percent torque	• Displays the driver's demand engine-percent torque
RE_LIFE	%	Remaining life	• Displays the remaining life
RE_MILA	km, ft, mi	Remaining milage	• Displays the remaining milage
REG_DIS	km, ft, mi	Distance since last diesel particulate filter regeneration	• Displays the distance since last diesel particulate filter regeneration.
REGVP	mm	Regulating valve actuator position sensor	• idle: Approx. 19.02 mm • Racing (engine speed approx 3,500 rpm): Approx. 12.15 mm
REGVP_DSD	mm	Regulating valve actuator position desired value	• Displays the Regulating valve actuator position desired value
REL_THR_APOS	%	Relative throttle A position	• Displays the relative throttle A position
REV_SW	Off/On	Reverse position determination	• Displays the reverse position.
RGT_LV_T_LO_10K	Displays in the Mazda Modular Diagnostic System (M-MDS) but it does not operate.		
RGT_LV_T_LO_20K			
RGT_LV_T_LO_30K			
RGT_LV_T_LO_40K			
RGT_LV_T_LO_ACT			
RLF_DIST	%	Remaining life (distance)	• Displays the remaining life (distance)
RLF_PERIOD	%	Remaining life (period)	• Displays the remaining life (period)
RLF_RESOT	%	Remaining life (remaining soot)	• Displays the remaining life (remaining soot)
RLF_TBNUM	%	Remaining life (total base number)	• Displays the remaining life (total base number)
RPM	RPM	Engine speed	• Displays the engine speed.
SDARS_BSPR_CP	Displays in the Mazda Modular Diagnostic System (M-MDS) but it does not operate.		
SDARS_BSTPRE			
SED_SW	Off/On	Sedimentor switch	• There is no water in sedimentor: Off • There is water in sedimentor: On
T_ENG_RT	hh:mm:ss	Total engine run time	• Displays the total engine run time
TCA_CINP	KPa, Bar, psi	Manifold absolute pressure (No.1)	• idle: Approx. 104 kPa {1.06 kgf/cm <sup>2</sup> , 15.1 psi} • Racing (engine speed above 4,000 rpm): Approx. 152 kPa {1.54 kgf/cm <sup>2</sup> , 22.0 psi} • Racing (engine speed above 5,000 rpm): Approx. 176 kPa {1.79 kgf/cm <sup>2</sup> , 25.5 psi}
TFIQ_AFL_SM	–	Target fuel injection quantity after limitation for smoke	• Displays the target fuel injection quantity after limitation for smoke.
TIM_CLR_DTC	–	Time since DTCs cleared (min)	• Displays time since DTCs cleared (min)
TIRT	hh:mm:ss	Total idle run time	• Displays total idle run time
TIRT_SUP	–	Total idle run time supported	• Displays total idle run time supported
VEH_FEL_RATE	g/sec	Vehicle fuel rate	• Displays the vehicle fuel rate
VGT_CMODE	–	Turbocharger Control Mode	• Displays total run time with PTO active supported
VPWR	V	Battery positive voltage	• Switch the ignition ON (engine off): Approx. 12.78 V • idle: Approx. 13.78 V
VSS	KPH, MPH	Vehicle speed	• Displays the vehicle speed.
WGV	Displays in the Mazda Modular Diagnostic System (M-MDS) but it does not operate.		