


Your Ultimate Source for OEM Repair Manuals

FactoryManuals.net is a great resource for anyone who wants to save money on repairs by doing their own work. The manuals provide detailed instructions and diagrams that make it easy to understand how to fix a vehicle.

2010 MAZDA 5 / Premacy OEM Service and Repair Workshop Manual


[Go to manual page](#)

2	MAP sensor No.2 (See MANIFOLD ABSOLUTE PRESSURE (MAP) SENSOR REMOVAL/INSTALLATION [SKYACTIV-D 2.2].) (See MANIFOLD ABSOLUTE PRESSURE (MAP) SENSOR INSPECTION [SKYACTIV-D 2.2].)
3	ECT sensor No.1 (See ENGINE COOLANT TEMPERATURE (ECT) SENSOR REMOVAL/INSTALLATION [SKYACTIV-D 2.2].) (See ENGINE COOLANT TEMPERATURE (ECT) SENSOR INSPECTION [SKYACTIV-D 2.2].)
4	IAT sensor No.3 (See INTAKE AIR TEMPERATURE (IAT) SENSOR NO.3 REMOVAL/INSTALLATION [SKYACTIV-D 2.2].) (See INTAKE AIR TEMPERATURE (IAT) SENSOR INSPECTION [SKYACTIV-D 2.2].)
5	Fuel pressure sensor / Fuel temperature sensor (See FUEL PRESSURE SENSOR REMOVAL/INSTALLATION [SKYACTIV-D 2.2].) (See FUEL PRESSURE SENSOR INSPECTION [SKYACTIV-D 2.2].) (See FUEL TEMPERATURE SENSOR REMOVAL/INSTALLATION [SKYACTIV-D 2.2].) (See FUEL TEMPERATURE SENSOR INSPECTION [SKYACTIV-D 2.2].)
6	Exhaust gas pressure sensor No.2 (See EXHAUST GAS PRESSURE SENSOR REMOVAL/INSTALLATION [SKYACTIV-D 2.2].) (See EXHAUST GAS PRESSURE SENSOR INSPECTION [SKYACTIV-D 2.2].)
7	Exhaust gas pressure sensor No.1 (See EXHAUST GAS PRESSURE SENSOR REMOVAL/INSTALLATION [SKYACTIV-D 2.2].) (See EXHAUST GAS PRESSURE SENSOR INSPECTION [SKYACTIV-D 2.2].)
8	CMP sensor (See CAMSHAFT POSITION (CMP) SENSOR REMOVAL/INSTALLATION [SKYACTIV-D 2.2].) (See CAMSHAFT POSITION (CMP) SENSOR INSPECTION [SKYACTIV-D 2.2].)
9	A/F sensor (See AIR FUEL RATIO (A/F) SENSOR REMOVAL/INSTALLATION [SKYACTIV-D 2.2].) (See AIR FUEL RATIO (A/F) SENSOR INSPECTION [SKYACTIV-D 2.2].)
10	Blow-by heater (See BLOW-BY HEATER INSPECTION [SKYACTIV-D 2.2].)
11	Exhaust gas temperature sensor No.1 (See EXHAUST GAS TEMPERATURE SENSOR REMOVAL/INSTALLATION [SKYACTIV-D 2.2].) (See EXHAUST GAS TEMPERATURE SENSOR INSPECTION [SKYACTIV-D 2.2].)
12	MAP sensor No.1 (See MANIFOLD ABSOLUTE PRESSURE (MAP) SENSOR REMOVAL/INSTALLATION [SKYACTIV-D 2.2].) (See MANIFOLD ABSOLUTE PRESSURE (MAP) SENSOR INSPECTION [SKYACTIV-D 2.2].)
13	Boost air temperature sensor (See BOOST AIR TEMPERATURE SENSOR REMOVAL/INSTALLATION [SKYACTIV-D 2.2].) (See BOOST AIR TEMPERATURE SENSOR INSPECTION [SKYACTIV-D 2.2].)
14	ECT sensor No.2 (See ENGINE COOLANT TEMPERATURE (ECT) SENSOR REMOVAL/INSTALLATION [SKYACTIV-D 2.2].) (See ENGINE COOLANT TEMPERATURE (ECT) SENSOR INSPECTION [SKYACTIV-D 2.2].)
15	Intake shutter valve position sensor (See INTAKE SHUTTER VALVE POSITION SENSOR REMOVAL/INSTALLATION [SKYACTIV-D 2.2].) (See INTAKE SHUTTER VALVE POSITION SENSOR INSPECTION [SKYACTIV-D 2.2].)
16	EGR temperature sensor (See EGR TEMPERATURE SENSOR REMOVAL/INSTALLATION [SKYACTIV-D 2.2].) (See EGR TEMPERATURE SENSOR INSPECTION [SKYACTIV-D 2.2].)
17	IAT sensor No.2 (See INTAKE AIR TEMPERATURE (IAT) SENSOR NO.2 REMOVAL/INSTALLATION [SKYACTIV-D 2.2].) (See INTAKE AIR TEMPERATURE (IAT) SENSOR INSPECTION [SKYACTIV-D 2.2].)
18	Engine oil temperature sensor/Engine oil pressure sensor (See ENGINE OIL TEMPERATURE SENSOR/ENGINE OIL PRESSURE SENSOR REMOVAL/INSTALLATION [SKYACTIV-D 2.2].) (See ENGINE OIL TEMPERATURE SENSOR INSPECTION [SKYACTIV-D 2.2].) (See ENGINE OIL PRESSURE SENSOR INSPECTION [SKYACTIV-D 2.2].)
19	EGR cooler bypass valve position sensor (See EGR COOLER BYPASS VALVE POSITION SENSOR REMOVAL/INSTALLATION [SKYACTIV-D 2.2].) (See EGR COOLER BYPASS VALVE POSITION SENSOR INSPECTION [SKYACTIV-D 2.2].)
20	MAF sensor/IAT sensor No.1 (See MASS AIR FLOW (MAF) SENSOR/INTAKE AIR TEMPERATURE (IAT) SENSOR NO.1 REMOVAL/INSTALLATION [SKYACTIV-D 2.2].) (See MASS AIR FLOW (MAF) SENSOR INSPECTION [SKYACTIV-D 2.2].) (See INTAKE AIR TEMPERATURE (IAT) SENSOR INSPECTION [SKYACTIV-D 2.2].)




ac5uuw00008550

1	Exhaust gas temperature sensor No.2 (See EXHAUST GAS TEMPERATURE SENSOR REMOVAL/INSTALLATION [SKYACTIV-D 2.2].) (See EXHAUST GAS TEMPERATURE SENSOR INSPECTION [SKYACTIV-D 2.2].)
2	CKP sensor (See CRANKSHAFT POSITION (CKP) SENSOR REMOVAL/INSTALLATION [SKYACTIV-D 2.2].) (See CRANKSHAFT POSITION (CKP) SENSOR INSPECTION [SKYACTIV-D 2.2].)
3	Engine oil level sensor (See ENGINE OIL LEVEL SENSOR REMOVAL/INSTALLATION [SKYACTIV-D 2.2].) (See ENGINE OIL LEVEL SENSOR INSPECTION [SKYACTIV-D 2.2].)




(2) Pull out the connector lock in the direction of the arrow.




(3) Disconnect the connector. (See [MAP sensor No.1 connector connection note.](#))


8. Remove the clip from the bracket.



9. Remove the bolts from the bracket.



4. Set the wiring harness aside. (See [Protector installation note](#).)



5. Disconnect the MAP sensor No.2 connector.


6. Remove the MAP sensor No.2.

INTAKE AIR TEMPERATURE (IAT) SENSOR NO.2 REMOVAL/INSTALLATION [SKYACTIV-D 2.2]


SM2897879

id0140z780630

1. Disconnect the negative battery terminal. (See [NEGATIVE BATTERY TERMINAL DISCONNECTION/CONNECTION.](#))
2. Remove the front bumper. (See [FRONT BUMPER REMOVAL/INSTALLATION.](#))
3. Remove the bolt.



4. Remove the charge air cooler duct (LH).
5. Disconnect the IAT sensor No.2 connector.



6. Remove the clip from the bracket.

FUEL TEMPERATURE SENSOR REMOVAL/INSTALLATION [SKYACTIV-D 2.2]

SM2897881

id0140z780650

Note

- The fuel temperature sensor cannot be removed as a single unit. When replacing the fuel temperature sensor, replace it together with the fuel injector as a single unit.

1.Remove the fuel injector. (See [FUEL INJECTOR REMOVAL/INSTALLATION \[SKYACTIV-D 2.2\]](#).)

Sample

MASS AIR FLOW (MAF) SENSOR DATA RESET [SKYACTIV-D 2.2]

SM2897884

id0140z781010

1.Connect the M-MDS to the DLC-2.

2.After the vehicle is identified, select the following item from the initial screen of the M-MDS.

(1)Select the "Powertrain".

3.Then, select the items from the screen menu in the following order.

(1)Select the "Data Reset".

(2)Select the "MAF sensor".

4.Perform the procedure according to the directions on the screen.

DOSING CONTROL UNIT INSPECTION [SKYACTIV-D 2.2]

SM2897887


id0140z782410

Without Using The M-MDS

Note

- The dosing control unit terminal voltage can vary with the conditions when measuring and changes due to aged deterioration on the vehicle, causing false diagnosis. Therefore determine comprehensively where the malfunction occurs among the input systems, output systems, and the dosing control unit.

Terminal voltage table (Reference)



Terminal	Signal	Connected to	Test condition	Voltage (V)	inspection item
A	Battery voltage	SCR relay No.2	Switch the ignition ON (engine off)	B+	• SCR relay No.2 • Related wiring harness
B	Battery voltage	SCR relay No.1, No.2	Switch the ignition ON (engine off)	B+	• SCR relay No.1, No.2 • Related wiring harness
C	Battery voltage	SCR relay No.1, No.2	Switch the ignition ON (engine off)	B+	• SCR relay No.1, No.2 • Related wiring harness
D	Urea tank heater control	Urea tank heater	Urea tank heater operating	B+	• Urea tank heater • Related wiring harness
			Urea tank heater not operating	Below 1.0	
E	GND	GND	Under any condition	Below 1.0	• Related wiring harness
F	Urea hose heater control	Urea hose heater	Urea hose heater operating	B+	• Urea hose heater • Related wiring harness
			Urea hose heater not operating	Below 1.0	
G	—	—	—	—	—
H	DEF pump control (GND)	DEF pump (pumping side)	Depend on engine load	Below 1.0	• DEF pump • Related wiring harness

Terminal	Signal	Connected to	Test condition	Voltage (V)	inspection item
CE	—	—	—	—	—
CF	—	—	—	—	—
CG	—	—	—	—	—
CH	—	—	—	—	—
CI	—	—	—	—	—
CJ	—	—	—	—	—
CK	—	—	—	—	—
CL	—	—	—	—	—
CM	—	—	—	—	—
CN	DEF pump control (GND)	DEF pump (siphoning side)	Depend on engine load	Below 1.0	• DEF pump • Related wiring harness
CO	—	—	—	—	—
CP	—	—	—	—	—

Using The M-MDS

Caution

- The dosing control unit terminal voltage vary with change in measuring conditions and vehicle conditions. Always carry out a total inspection of the input systems, output systems, and dosing control unit to determine the cause of trouble. Otherwise, diagnosis will be incorrect.

1.Connect the M-MDS to the DLC-2.

2.Switch the ignition ON (engine off).

3.Measure the PID value.

- If PID value is not within the specification, follow the instructions in Action column.

Simulation item table

—: Not applicable

Item (definition)	Unit/Condition	Definition	Operation condition
HTR_LINE	Off/On	Urea Pressure Line Heater	• Under the following conditions: — Ignition switched ON (engine off) — Idle
HTR_TANK	Off/On	Urea tank heater	• Under the following conditions: — Ignition switched ON (engine off) — Idle
RDC_PMP_DC_CM	—	DEF pump duty cycle	• Under the following conditions: — Ignition switched ON (engine off) — Idle