

Your Ultimate Source for OEM Repair Manuals

FactoryManuals.net is a great resource for anyone who wants to save money on repairs by doing their own work. The manuals provide detailed instructions and diagrams that make it easy to understand how to fix a vehicle.

2011 MAZDA 3 / Axela Sedan OEM Service and Repair Workshop Manual


[Go to manual page](#)

REAR LATERAL LINK REMOVAL/INSTALLATION

SM2897970


id02140080120

- 1.Remove the wheel and tire. (See [WHEEL AND TIRE REMOVAL/INSTALLATION.](#))
- 2.Remove the protector. (With protector)



ac5uuw00006492

- 3.Disconnect the rear stabilizer control link from the rear lower arm.



ac5uuw00006493


- 4.Remove in the order indicated in the table.
- 5.Install in the reverse order of removal. (See [Suspension Links Installation Note.](#))
- 6.When replacing the rear lateral link, inspect the wheel alignment and adjust it if necessary. (See [REAR WHEEL ALIGNMENT.](#))

REAR SHOCK ABSORBER REMOVAL/INSTALLATION

SM2897971

id02140080130

- 1.Remove the wheel and tire. (See [WHEEL AND TIRE REMOVAL/INSTALLATION](#).)
- 2.Remove in the order indicated in the table.
- 3.Install in the reverse order of removal. (See [Suspension Link Installation Note](#).)



| | |
|---|--|
| 1 | Rear shock absorber upper nut (See Rear Shock Absorber Upper Nut Removal Note .) (See Rear Shock Absorber Upper Nut Installation Note .) |
|---|--|

Caution

- Assemble the gasket to the correct position. If the rear shock absorber is installed with the gasket deviated or with a gap, it could cause deterioration or abnormal noise of the rear shock absorber, or cause water to penetrate into the cabin.

3. Install the rear shock absorber.



Sample

REAR SHOCK ABSORBER DISASSEMBLY/ASSEMBLY

SM2897974

id02140090000

Special service tool (SST)

| | | | |
|--------------------------|---|--------------------------------|---|
| 49 G027 006 Installer |  | 49 H027 002 Bearing remover |  |
|--------------------------|---|--------------------------------|---|

Replacement part

| |
|--------------------------------------|
| Piston rod nut |
| Quantity: 1 |
| Location of use: Rear shock absorber |

Oil and Chemical Type

| |
|-----------------------------------|
| Rubber grease |
| Type: NIPPON GREASE RUBBER GREASE |


- 1.Remove the rear shock absorber. (See [REAR SHOCK ABSORBER REMOVAL/INSTALLATION.](#))
- 2.Remove in the order indicated in the table.
- 3.Install in the reverse order of removal.

Standard

349.9–356.9 mm {13.78–14.05 in}

Dust Boot Installation Note

1. Assemble the dust boot to position A shown in the figure.




Standard

A: $0^\circ \pm 6.5^\circ$

Piston Rod Nut Installation Note

1. Install the offset box-end wrench to the torque wrench as shown in the figure, set it on the piston rod nut, and measure dimensions A and L shown in the figure.



2. Tighten the piston rod nut after calculating the tightening torque using the following formula.

Suspension

| Item | | Specification |
|--|--|--|
| Front lower arm ball joint stud starting torque | | 17 N·m {1.7 kgf·m, 12 ft·lbf} max. |
| Front lower arm ball joint stud rotational torque | | 3.2 N·m {33 kgf·cm, 28 in·lbf} max. |
| Front stabilizer control link ball joint starting torque | | 0.8–3.5 N·m {8.2–35 kgf·cm, 7.1–30 in·lbf} |
| Rear stabilizer control link ball joint starting torque | | 0.8–3.5 N·m {8.2–35 kgf·cm, 7.1–30 in·lbf} |

Standard tire and wheel (US, Canada and Israel)

| Item | | | Specification | |
|----------------|---------------------------------|-----------------------|---|---|
| Wheel | Size | | 17 × 7J | 19 × 7J |
| | Inset | (mm {IN}) | 45 {1.8} | |
| | Pitch circle diameter | (mm {IN}) | 114.3 {4.50} | |
| | Material | | Aluminum alloy | |
| Tire | Size | | P225/65R17 100H | P225/55R19 99V |
| | Air pressure (kPa {PSI}) | Front | 230 {34} | 240 {35} |
| | | Rear | 230 {34} ^{*4} | 240 {35} ^{*4} |
| | Remaining tread | (mm {IN}) | 1.6 {0.063} min. | |
| Wheel and tire | Lug nut tightening torque | (N·m {kgf·m, ft·lbf}) | 108–147 {12–14, 80–108} | |
| | Wheel and tire runout (mm {IN}) | Radial direction | 1.5 {0.059} max. | |
| | | Lateral direction | 2.0 {0.079} max. | |
| | Wheel imbalance | (g {OZ}) | Adhesive-type ^{*1} : 13 {0.46} max. Knock-type ^{*2} ^{*3} : 8 {0.3} max. | Adhesive-type ^{*1} : 12 {0.42} max. Knock-type ^{*2} ^{*3} : 7 {0.2} max. |

^{*1}:Do not install four or more weights. Do not affix the weights such that they are parallel to each other or overlapping. The total weight of all the weights is 160 g {5.64 oz} or less.

^{*2}:Do not install three or more weights. One weight is 60 g {2.1 oz} or less and two weights are 100 g {3.53 oz} or less.

^{*3}:If a weight of 125 g {4.41 oz} is to be added, divide the weight into two pieces and affix.

^{*4}:When towing a trailer, make sure that the tire pressures of the rear tires are at least 20 kPa (0.2 bar, 2.9 psi) higher than the recommended tire pressures indicated on the tire pressure chart on the driver's door frame.

Standard tire and wheel (Except US, Canada and Israel)

| Item | | | | Specification | |
|-------|-----------------------------------|-------|-----------------|-------------------------------|-------------------------------|
| Wheel | Size | | | 17 × 7J | 19 × 7J |
| | Inset | | (mm {IN}) | 45 {1.8} | |
| | Pitch circle diameter | | (mm {IN}) | 114.3 {4.50} | |
| | Material | | | Aluminum alloy | |
| Tire | Size | | | 225/65R17 102V | 225/55R19 99V |
| | Air pressure (kPa {bar <psi>}) | Front | Up to 3 persons | 230 {2.3, <33>} | 250 {2.5, <36>} |
| | | | Full load | 260 {2.6, <38>} | 260 {2.6, <38>} |
| | | Rear | Up to 3 persons | 230 {2.3, <33>} ^{*4} | 250 {2.5, <36>} ^{*4} |
| | | | Full load | 280 {2.8, <41>} ^{*4} | 290 {2.9, <42>} ^{*4} |
| | Remaining tread | | (mm {IN}) | 1.6 {0.063} min. | |

| Snapshot data item | Unit | | Data contents | Data read/use method | Corresponding data monitor items |
|--------------------|--|-------|---|--|----------------------------------|
| IC_VPWR | V | | Instrument cluster power supply voltage | <ul style="list-style-type: none"> The AWD control module constantly receives the power supply voltage value of the instrument cluster sent via CAN signal from the instrument cluster. If a DTC is detected, the AWD control module records the power supply voltage of the instrument cluster when the DTC was detected, and it is displayed in the M-MDS. | VPWR ^{*1} |
| IG-ON_TIMER | hh:mm:ss ^{*2} | | <p>Elapsed time since ignition was switched ON (engine off or on)</p> <p>Note</p> <ul style="list-style-type: none"> The instrument cluster records the elapsed time since the ignition was switched ON (engine off or on). | <ul style="list-style-type: none"> The AWD control module constantly receives the elapsed time since the ignition was switched ON (engine off or on) sent via CAN signal from the instrument cluster. If a DTC is detected, the AWD control module records the elapsed time since the ignition was switched ON (engine off or on) when the DTC was detected, and it is displayed in the M-MDS. | – |
| PWR_MODE_KEY | Key Out/ Key Recently Out/ Key Approved(Position 0)/ Post Accessory (Position 0)/ Accessory (Position 1)/ Post Ignition (Position 1)/ Ignition On (Position 2)/ Running (Position 2)/ Running - Starting In Progress (Position 2)/ Crank (Position 3) | | <ul style="list-style-type: none"> Key Out: Ignition switched off Key Recently Out (Position 0): Elapsed time within 3 s since ignition was switched off Accessory (Position 1): Ignition is switched to ACC Post Ignition (Position 2): Elapsed time within 3 s since ignition was switched ON (engine off or on) Ignition On (Position 2): Ignition switched ON (engine off) Running (Position 2): Ignition switched ON (engine on) Running - Starting: Cranking condition | <ul style="list-style-type: none"> The AWD control module constantly receives the ignition switch status sent via CAN signal from the instrument cluster. If a DTC is detected, the AWD control module records the ignition switch status when the DTC was detected, and it is displayed in the M-MDS. | – |
| TOTAL_DIST | km | Miles | Accumulated total traveled distance from completion of vehicle until AWD control module detects DTC (Odometer value in instrument cluster) | <p>The total traveled distance from which the AWD control module detects DTCs to the present can be calculated by performing the following procedure.</p> <ol style="list-style-type: none"> Verify the odometer value in the instrument cluster. Verify the snapshot data item TOTAL_DIST. Subtract 2 from 1. | – |

DTC TABLE [AWD CONTROL MODULE]

SM2897978

id0302d313040

×: Applicable –: Not applicable


| DTC | AWD warning light illumination status | Diagnosis system component | Fail-safe | Drive cycle | Self test type*1 | Memory function | Page |
|----------|---------------------------------------|---|-----------|-------------|------------------|-----------------|---|
| M-MDS | | | | | | | |
| P164D:00 | Illuminated | Configuration data not recorded | × | – | C | × | (See DTC P164D:00 [AWD CONTROL MODULE].) |
| P182F:00 | Flashed | Excessive load detected on AWD part | × | – | C | × | (See DTC P182F:00 [AWD CONTROL MODULE].) |
| P187B:00 | Illuminated | A tire diameter is outside of the allowable range | × | – | C | × | (See DTC P187B:00 [AWD CONTROL MODULE].) |
| P1886:00 | Illuminated | Configuration data not recorded | × | – | C | × | (See DTC P1886:00 [AWD CONTROL MODULE].) |
| P1887:11 | Illuminated | AWD solenoid circuit | × | – | C | × | (See DTC P1887:11/P1887:12/P1887:13/P1887:14 [AWD CONTROL MODULE].) |
| P1887:12 | Illuminated | AWD solenoid circuit | × | – | C | × | |
| P1887:13 | Illuminated | AWD solenoid circuit | × | – | C | × | |
| P1887:14 | Illuminated | AWD solenoid circuit | × | – | C | × | |
| P1888:11 | Illuminated | Differential oil temperature sensor circuit | × | – | C | × | (See DTC P1888:11/P1888:15 [AWD CONTROL MODULE].) |
| P1888:15 | Illuminated | Differential oil temperature sensor circuit | × | – | C | × | |
| P188A:00 | Flashed | Differential oil temperature is out of range | × | – | C | × | (See DTC P188A:00 [AWD CONTROL MODULE].) |
| U0001:88 | – | CAN system Communication error | × | – | C | × | (See DTC U0001:88/U0100:00/U0101:00/U0121:00 [AWD CONTROL MODULE].) |
| U0100:00 | – | Communication error to PCM | × | – | C | × | |
| U0101:00 | – | Communication error to TCM | × | – | C | × | |
| U0121:00 | – | Communication error to DSC HU/CM | × | – | C | × | |
| U0401:68 | – | Abnormal message from PCM | × | – | C | × | (See DTC U0401:68 [AWD CONTROL MODULE].) |

*1:(See **CONTROLLER AREA NETWORK (CAN) MALFUNCTION DIAGNOSIS FLOW [TYPE-A (SKYACTIV-G 2.5)]**.) (See **CONTROLLER AREA NETWORK (CAN) MALFUNCTION DIAGNOSIS FLOW [TYPE-A (SKYACTIV-G 2.5T, SKYACTIV-D 2.2)]**.) (See **CONTROLLER AREA NETWORK (CAN) MALFUNCTION DIAGNOSIS FLOW [TYPE-B]**.)

Action for Non-repeatable Malfunction

• If the malfunction does not recur, verify the malfunction cause by performing the following actions:

- Based on the repair order form, attempt to drive the vehicle or perform tests to replicate the malfunction, record the data at that time, and detect the malfunction cause.
- Shake the wiring harness or connector of the electrical component which is suspected to be the cause of the malfunction, and inspect for occurrence of any malfunction or DTCs.




aaxjjw00007274

- Inspect the female terminals on the connector of the electric component which is suspected to be the cause of the malfunction for poor connection. (See **ELECTRICAL SYSTEM**.)

Note

- Tool used (Reference): terminal test kit (49US-15-KIT)



ac5uuw00007975