

Your Ultimate Source for OEM Repair Manuals

FactoryManuals.net is a great resource for anyone who wants to save money on repairs by doing their own work. The manuals provide detailed instructions and diagrams that make it easy to understand how to fix a vehicle.

2011 MAZDA 3 MPS / MAZDASPEED3 OEM Service and Repair Workshop Manual

[Go to manual page](#)

PID name (definition)	Unit/Condition	Operation condition (reference)	Action
WARN_LAMP	OFF/ON/Blinking	• Displays the warning light state	Inspect the AWD control module. (See AWD CONTROL MODULE INSPECTION.)
WSPD_LF	KPH, MPH	• Vehicle stopped: 0 KPH, 0 MPH • Vehicle running: Vehicle speed	Inspect the front ABS wheel-speed sensor. (See FRONT ABS WHEEL-SPEED SENSOR INSPECTION.)
WSPD_LR			Inspect the rear ABS wheel-speed sensor. (See REAR ABS WHEEL-SPEED SENSOR INSPECTION [AWD].)
WSPD_RF			Inspect the front ABS wheel-speed sensor. (See FRONT ABS WHEEL-SPEED SENSOR INSPECTION.)
WSPD_RR			Inspect the rear ABS wheel-speed sensor. (See REAR ABS WHEEL-SPEED SENSOR INSPECTION [AWD].)

Sample

DTC P164D:00 [AWD CONTROL MODULE]

SM2897984

id0302d320010

DTC P164D:00	Configuration data not recorded
DETECTION CONDITION	• AWD control module detects coupling component calibration data error
FAIL-SAFE FUNCTION	• AWD operates by the specified data. • AWD warning light: Illuminated
POSSIBLE CAUSE	• Module configuration procedure is not done properly
SYSTEM WIRING DIAGRAM	Not applicable

Diagnostic procedure

Step	Inspection	Results	Action
1	COUPLING COMPONENT CALIBRATION DATA WRITING • Write the coupling component calibration data. (See COUPLING COMPONENT CALIBRATION DATA WRITING .) • Clear the DTCs from the memory. (See CLEARING DTC [AWD CONTROL MODULE] .) • Using the M-MDS, perform the AWD control module DTC inspection. (See DTC INSPECTION [AWD CONTROL MODULE] .) • Is the same Pending DTC present?	–	Go to the next step.
2	VERIFY THAT THE SAME DTC IS NOT PRESENT • Clear the DTCs from the memory. (See CLEARING DTC [AWD CONTROL MODULE] .) • Using the M-MDS, perform the AWD control module DTC inspection. (See DTC INSPECTION [AWD CONTROL MODULE] .) • Is the same Pending DTC present?	Yes	Replace the AWD control module. (See AWD CONTROL MODULE REMOVAL/INSTALLATION .)
		No	Go to the next step.
3	VERIFY THAT NO OTHER DTCs ARE PRESENT • Are any other DTCs output?	Yes	Go to the applicable DTC inspection. (See DTC TABLE [AWD CONTROL MODULE] .)
		No	DTC troubleshooting completed.

DTC P187B:00 [AWD CONTROL MODULE]

SM2897986

id0302d320030

DTC P187B:00	A tire diameter is outside of the allowable range
DETECTION CONDITION	• AWD control module detects a tire diameter is outside of the allowable range
FAIL-SAFE FUNCTION	• Control disabled. • AWD warning light: Illuminated
POSSIBLE CAUSE	• Detects a tire diameter which is outside of the allowable range to switch to 2WD and protect the system. • Flat tire • Wrong tire pressure
SYSTEM WIRING DIAGRAM	Not applicable

Diagnostic procedure

Step	Inspection	Results	Action
1	INSPECT A TIRE DIAMETER • Is the tire diameter as specified?	Yes	Go to the next step.
		No	Replace with specified tire.
2	VERIFY THAT THE SAME DTC IS NOT PRESENT • Clear the DTCs from the memory. (See CLEARING DTC [AWD CONTROL MODULE].) • Drive the vehicle in a straight line at 10 km/h or more for 10 s or more. • Using the M-MDS, perform the AWD control module DTC inspection. (See DTC INSPECTION [AWD CONTROL MODULE].) • Is the same Pending DTC present?	Yes	Replace the AWD control module. (See AWD CONTROL MODULE REMOVAL/INSTALLATION.)
		No	Go to the next step.
3	VERIFY THAT NO OTHER DTCS ARE PRESENT • Are any other DTCs output?	Yes	Go to the applicable DTC inspection. (See DTC TABLE [AWD CONTROL MODULE].)
		No	DTC troubleshooting completed.

DTC P1887:11/P1887:12/P1887:13/P1887:14 [AWD CONTROL MODULE]

SM2897988

id0302d320050

DTC P1887:11	AWD solenoid circuit
DTC P1887:12	
DTC P1887:13	
DTC P1887:14	
DETECTION CONDITION	<ul style="list-style-type: none">• P1887:11<ul style="list-style-type: none">— Short circuit to ground is detected in AWD solenoid circuit• P1887:12<ul style="list-style-type: none">— Short to battery is detected in AWD solenoid circuit• P1887:13<ul style="list-style-type: none">— Open circuit is detected in AWD solenoid circuit• P1887:14<ul style="list-style-type: none">— Open circuit or short to ground is detected in power supply circuit
FAIL-SAFE FUNCTION	<ul style="list-style-type: none">• Control disabled.• AWD warning light: Illuminated
POSSIBLE CAUSE	<ul style="list-style-type: none">• AWD solenoid malfunction• Open circuit or short to ground between AWD control module terminal O and AWD solenoid terminal A• Open circuit or short to ground between AWD control module terminal P and AWD solenoid terminal B• Open circuit or short to ground in harness between battery and AWD control module terminal K• Open circuit between AWD control module terminal N and body ground• Open or short circuit in AWD control module internal circuit• AT 15 A fuse malfunction• AWD control module malfunction• Poor connection of connectors (female terminals)

Step	Inspection	Results	Action
7	INSPECT AWD CONTROL MODULE POWER SUPPLY CIRCUIT FOR OPEN CIRCUIT OR SHORT TO GROUND <ul style="list-style-type: none"> • Verify that the AWD solenoid and AWD control module connectors are disconnected. • Measure the voltage between AWD control module terminal K (wiring harness-side) and body ground. • Is the voltage B+? 	Yes	Replace the AWD control module, then go to Step 9. (See AWD CONTROL MODULE REMOVAL/INSTALLATION.)
		No	Go to the next step.
8	INSPECT FUSE CONDITION <ul style="list-style-type: none"> • Is the AT 15 A fuse normal? 	Yes	Go to the next step.
		No	<ul style="list-style-type: none"> • If the fuse is blown: <ul style="list-style-type: none"> — Refer to the wiring diagram and verify whether or not there is a common connector between fuse and AWD control module terminal K. • If there is a common connector: <ul style="list-style-type: none"> • Determine the malfunctioning part by inspecting the common connector and the terminal for corrosion, damage, or pin disconnection, and the common wiring harness for a short to ground. • Repair or replace the malfunctioning part. • If there is no common connector: <ul style="list-style-type: none"> • Repair or replace the wiring harness which has a short to ground. • Replace the fuse. • If the fuse is damaged: <ul style="list-style-type: none"> — Replace the fuse. Go to the next step.
9	VERIFY DTC TROUBLESHOOTING COMPLETED <ul style="list-style-type: none"> • Using the M-MDS, clear the DTC from the AWD control module. (See CLEARING DTC [AWD CONTROL MODULE].) • Drive the vehicle. • Using the M-MDS, perform the AWD control module DTC inspection. (See DTC INSPECTION [AWD CONTROL MODULE].) • Is the same Pending DTC present? 	Yes	Replace the AWD control module, then go to the next step. (See AWD CONTROL MODULE REMOVAL/INSTALLATION.)
		No	Go to the next step.
10	VERIFY NO DTC IS PRESENT <ul style="list-style-type: none"> • Are any DTCs present? 	Yes	Go to the applicable DTC inspection. (See DTC TABLE [AWD CONTROL MODULE].)
		No	DTC troubleshooting completed.

Step	Inspection	Results	Action
5	INSPECT DIFFERENTIAL OIL TEMPERATURE SENSOR GROUND CIRCUIT FOR OPEN CIRCUIT <ul style="list-style-type: none"> • Verify that the differential oil temperature sensor and AWD control module connectors are disconnected. • Inspect for continuity between AWD control module terminal C (wiring harness-side) and differential oil temperature sensor terminal B (wiring harness-side). • Is there continuity? 	Yes	Go to the next step.
		No	Refer to the wiring diagram and verify whether or not there is a common connector between AWD control module terminal C and differential oil temperature sensor terminal B. If there is a common connector: <ul style="list-style-type: none"> • Determine the malfunctioning part by inspecting the common connector and the terminal for corrosion, damage, or pin disconnection, and the common wiring harness for an open circuit. • Repair or replace the malfunctioning part. If there is no common connector: <ul style="list-style-type: none"> • Repair or replace the wiring harness which has an open circuit. Go to Step 7.
6	INSPECT DIFFERENTIAL OIL TEMPERATURE SENSOR GROUND CIRCUIT FOR SHORT TO POWER SUPPLY <ul style="list-style-type: none"> • Verify that the differential oil temperature sensor and AWD control module connectors are disconnected. • Measure the voltage between AWD control module terminal C (wiring harness-side) and body ground. • Is the voltage B+? 	Yes	Refer to the wiring diagram and verify whether or not there is a common connector between AWD control module terminal C and differential oil temperature sensor terminal B. If there is a common connector: <ul style="list-style-type: none"> • Determine the malfunctioning part by inspecting the common connector and the terminal for corrosion, damage, or pin disconnection, and the common wiring harness for a short to power supply. • Repair or replace the malfunctioning part. If there is no common connector: <ul style="list-style-type: none"> • Repair or replace the wiring harness which has a short to power supply. Go to the next step.
		No	Go to next step.
7	VERIFY DTC TROUBLESHOOTING COMPLETED <ul style="list-style-type: none"> • Using the M-MDS, clear the DTC from the AWD control module. (See CLEARING DTC [AWD CONTROL MODULE].) • Drive the vehicle. • Using the M-MDS, perform the AWD control module DTC inspection. (See DTC INSPECTION [AWD CONTROL MODULE].) • Is the same Pending DTC present? 	Yes	Replace the AWD control module, then go to the next step. (See AWD CONTROL MODULE REMOVAL/INSTALLATION.)
		No	Go to the next step.
8	VERIFY NO DTC IS PRESENT <ul style="list-style-type: none"> • Are any DTCs present? 	Yes	Go to the applicable DTC inspection. (See DTC TABLE [AWD CONTROL MODULE].)
		No	DTC troubleshooting completed.

DTC U0401:68 [AWD CONTROL MODULE]

SM2897992

id0302d320120

DTC U0401:68	Abnormal message from PCM
DETECTION CONDITION	• Correct data cannot be received from PCM
FAIL-SAFE FUNCTION	• Control disabled.
POSSIBLE CAUSE	• PCM malfunction • AWD control module malfunction
SYSTEM WIRING DIAGRAM	Not applicable

Diagnostic procedure

Step	Inspection	Results	Action
1	INSPECT FOR PCM MALFUNCTION <ul style="list-style-type: none">• Switch the ignition to off.• Using the M-MDS, perform the DTC inspection for the PCM. (See ON-BOARD DIAGNOSTIC TEST [PCM (SKYACTIV-G 2.5 (WITHOUT CYLINDER DEACTIVATION))].) (See ON-BOARD DIAGNOSTIC TEST [PCM (SKYACTIV-G 2.5 (WITH CYLINDER DEACTIVATION))].) (See ON-BOARD DIAGNOSTIC TEST [PCM (SKYACTIV-D 2.2)].) (See ON-BOARD DIAGNOSTIC TEST [PCM (SKYACTIV-G 2.5T)].)• Are any DTCs detected?	Yes	Go to applicable DTC inspection. (See DTC TABLE [PCM (SKYACTIV-G 2.5 (WITHOUT CYLINDER DEACTIVATION))] .) (See DTC TABLE [PCM (SKYACTIV-G 2.5 (WITH CYLINDER DEACTIVATION))] .) (See DTC TABLE [PCM (SKYACTIV-D 2.2)] .) (See DTC TABLE [PCM (SKYACTIV-G 2.5T)] .)
		No	Go to the next step.
2	VERIFY THAT THE SAME DTC IS NOT PRESENT <ul style="list-style-type: none">• Clear the DTCs from the memory. (See CLEARING DTC [AWD CONTROL MODULE].)• Using the M-MDS, perform the AWD control module DTC inspection. (See DTC INSPECTION [AWD CONTROL MODULE].)• Are the same DTCs present?	Yes	Replace the AWD control module. (See AWD CONTROL MODULE REMOVAL/INSTALLATION .)
		No	Go to the next step.
3	VERIFY THAT NO OTHER DTCS ARE PRESENT <ul style="list-style-type: none">• Are any other DTCs output?	Yes	Go to the applicable DTC inspection. (See DTC TABLE [AWD CONTROL MODULE] .)
		No	DTC troubleshooting completed.

DTC U0415:68 [AWD CONTROL MODULE]

SM2897994

id0302d320140

DTC U0415:68	Abnormal message from DSC HU/CM
DETECTION CONDITION	• Correct data cannot be received from DSC HU/CM
FAIL-SAFE FUNCTION	• Control disabled.
POSSIBLE CAUSE	• DSC HU/CM malfunction • AWD control module malfunction
SYSTEM WIRING DIAGRAM	Not applicable

Diagnostic procedure


Step	Inspection	Results	Action
1	INSPECT FOR DSC HU/CM MALFUNCTION <ul style="list-style-type: none">• Switch the ignition to off.• Using the M-MDS, perform the DTC inspection for the DSC HU/CM. (See DTC INSPECTION [DSC HU/CM].)• Are any DTCs detected?	Yes	Go to applicable DTC inspection. (See DTC TABLE [DSC HU/CM].)
		No	Go to the next step.
2	VERIFY THAT THE SAME DTC IS NOT PRESENT <ul style="list-style-type: none">• Clear the DTCs from the memory. (See CLEARING DTC [AWD CONTROL MODULE].)• Using the M-MDS, perform the AWD control module DTC inspection. (See DTC INSPECTION [AWD CONTROL MODULE].)• Are the same DTCs present?	Yes	Repeat the inspection from Step1. If the malfunction recurs, replace the DSC HU/CM, then go to the next step. (See DSC HU/CM REMOVAL/INSTALLATION [SKYACTIV-G 2.5 (WITH CYLINDER DEACTIVATION)].) (See DSC HU/CM REMOVAL/INSTALLATION [SKYACTIV-G 2.5 (WITH CYLINDER DEACTIVATION)].) (See DSC HU/CM REMOVAL/INSTALLATION [SKYACTIV-D 2.2].) (See DSC HU/CM REMOVAL/INSTALLATION [SKYACTIV-G 2.5T].)
		No	Go to the next step.
3	VERIFY THAT NO OTHER DTCS ARE PRESENT <ul style="list-style-type: none">• Are any other DTCs output?	Yes	Go to the applicable DTC inspection. (See DTC TABLE [AWD CONTROL MODULE].)
		No	DTC troubleshooting completed.

*1:(See **CONTROLLER AREA NETWORK (CAN) MALFUNCTION DIAGNOSIS FLOW [TYPE-A (SKYACTIV-G 2.5)]**.) (See **CONTROLLER AREA NETWORK (CAN) MALFUNCTION DIAGNOSIS FLOW [TYPE-A (SKYACTIV-G 2.5T, SKYACTIV-D 2.2)]**.) (See **CONTROLLER AREA NETWORK (CAN) MALFUNCTION DIAGNOSIS FLOW [TYPE-B]**.)

Action for Non-repeatable Malfunction

• If the malfunction does not recur, verify the malfunction cause by performing the following actions:

- Based on the repair order form, attempt to drive the vehicle or perform tests to replicate the malfunction, record the data at that time, and detect the malfunction cause.
- Shake the wiring harness or connector of the electrical component which is suspected to be the cause of the malfunction, and inspect for occurrence of any malfunction or DTCs.



- Inspect the female terminals on the connector of the electric component which is suspected to be the cause of the malfunction for poor connection. (See **ELECTRICAL SYSTEM**.)

Note

- Tool used (Reference): terminal test kit (49US-15-KIT)

