

Your Ultimate Source for OEM Repair Manuals

FactoryManuals.net is a great resource for anyone who wants to save money on repairs by doing their own work. The manuals provide detailed instructions and diagrams that make it easy to understand how to fix a vehicle.

2011 MAZDA CX-9 OEM Service and Repair Workshop Manual

[Go to manual page](#)

DIFFERENTIAL OIL TEMPERATURE SENSOR REMOVAL/INSTALLATION


SM2898043

id03190080080

Warning

- Hot differential oil may cause severe burns. Do not perform maintenance while differential oil is hot.

1. Disconnect the negative battery terminal. (See [NEGATIVE BATTERY TERMINAL DISCONNECTION/CONNECTION.](#))
2. Disconnect the differential oil temperature sensor connector.
3. Remove the differential oil temperature sensor.



ac5uuw00000322

4. Install the differential oil temperature sensor.

Tightening torque

13–17 N·m {133–173 kgf·cm, 116–150 in·lbf}

5. Connect the differential oil temperature sensor connector.
6. Connect the negative battery terminal. (See [NEGATIVE BATTERY TERMINAL DISCONNECTION/CONNECTION.](#))

DRIVELINE/AXLE TECHNICAL DATA

SM2898046

id03500080010

Item		Specification
Front wheel bearing maximum play		0.05 mm {0.002 in}
Rear wheel bearing maximum play		0.05 mm {0.002 in}
Front drive shaft (tripod joint) full length (standard) (SKYACTIV-G 2.5 (Without cylinder deactivation))		LH: 672.5–682.5 mm {26.48–26.87 in} RH: 1036.4–1046.4 mm {40.804–41.196 in}
Front drive shaft (tripod joint) full length (standard) (SKYACTIV-G 2.5 (With cylinder deactivation))		LH: 663.5–673.5 mm {26.13–26.51 in} RH: 1045.5–1055.5 mm {41.162–41.555 in}
Front drive shaft (tripod joint) full length (standard) (SKYACTIV-G 2.5T, SKYACTIV-D 2.2)		LH: 661.8–671.8 mm {26.06–26.44in} RH: 1043.3–1053.3 mm {41.075–41.468 in}
Rear drive shaft standard length		LH: 834.7–844.7 mm {32.87–33.25 in} RH: 873.2–883.2 mm {34.38–34.77 in}
Rear differential oil	Type	MAZDA LONG LIFE HYPOID GEAR OIL SG1
	Capacity (approx. quantity)	0.35 L {0.37 US qt, 0.31 Imp qt}
Rear differential backlash of pinion gear and side gear		0.1 mm {0.004 in} or less
Rear differential drive pinion preload		0.2–0.5 N·m {2.1–5.0 kgf·cm, 1.8–4.4 in-lbf}
Rear differential backlash of drive pinion and ring gear		Standard: 0.09–0.14 mm {0.004–0.005 in} Minimum: 0.05 mm {0.002 in} or more Variance: 0.07 mm {0.003 in} or less
Propeller shaft maximum runout		0.8 mm {0.031 in}
Propeller shaft rotation torque		0.3–1.4 N·m {3.1–14.0 kgf·cm, 2.7–12.0 in-lbf}
Transfer oil	Type	MAZDA LONG LIFE HYPOID GEAR OIL SG1
	Capacity (approx. quantity)	0.45 L {0.48 US qt, 0.40 Imp qt}

Step	Inspection	Results	Action
4	INSPECT ELECTRIC PARKING BRAKE MOTOR GEAR UNIT (LH) CIRCUIT FOR OPEN CIRCUIT <ul style="list-style-type: none"> • Verify that the electric parking brake motor gear unit (LH) and electric parking brake control module connectors are disconnected. • Inspect for continuity between the following terminals (wiring harness-side): <ul style="list-style-type: none"> — Electric parking brake motor gear unit (LH) terminal A–Electric parking brake control module terminal 1U — Electric parking brake motor gear unit (LH) terminal B–Electric parking brake control module terminal 1Z • Is there continuity? 	Yes	Go to the next step.
		No	Refer to the wiring diagram and verify whether or not there is a common connector between the following terminals: <ul style="list-style-type: none"> • Electric parking brake motor gear unit (LH) terminal A–Electric parking brake control module terminal 1U • Electric parking brake motor gear unit (LH) terminal B–Electric parking brake control module terminal 1Z If there is a common connector: <ul style="list-style-type: none"> • Determine the malfunctioning part by inspecting the common connector and the terminal for corrosion, damage, or pin disconnection, and the common wiring harness for an open circuit. • Repair or replace the malfunctioning part. If there is no common connector: <ul style="list-style-type: none"> • Repair or replace the wiring harness which has an open circuit. Go to Step 7.
5	INSPECT REAR BRAKE CALIPER (LH) PISTON FOR STICKING <ul style="list-style-type: none"> • Verify the condition of the rear brake caliper (LH) piston. • Is the rear brake caliper (LH) piston stuck? 	Yes	Repair the piston for sticking. (See REAR BRAKE CALIPER DISASSEMBLY/ASSEMBLY .) Go to Step 7.
		No	Go to the next step.
6	VERIFY IF MALFUNCTIONING LOCATION IS ELECTRIC PARKING BRAKE MOTOR GEAR UNIT (LH) DEPENDING ON REPEATABILITY <ul style="list-style-type: none"> • Always reconnect all disconnected connectors. • Connect the negative battery terminal. (See NEGATIVE BATTERY TERMINAL DISCONNECTION/CONNECTION.) • Clear the DTC for the electric parking brake control module using the M-MDS. (See CLEARING DTC [ELECTRIC PARKING BRAKE CONTROL MODULE].) • Perform the following procedure 3 times or more. <ul style="list-style-type: none"> — Pull up the electric parking brake switch to operate the electric parking brake. — Press down the electric parking brake switch to release the electric parking brake. • Retrieve the electric parking brake control module DTCs using the M-MDS. (See DTC INSPECTION [ELECTRIC PARKING BRAKE CONTROL MODULE].) • Is the same DTC displayed? 	Yes	Replace the electric parking brake motor gear unit (LH), then go to the next step. (See ELECTRIC PARKING BRAKE MOTOR GEAR UNIT REMOVAL/INSTALLATION .)
		No	Go to Step 8.


Step	Inspection	Results	Action
1	VERIFY OTHER ELECTRIC PARKING BRAKE CONTROL MODULE DTCs <ul style="list-style-type: none"> • Clear the DTC for the electric parking brake control module using the M-MDS. (See CLEARING DTC [ELECTRIC PARKING BRAKE CONTROL MODULE].) • Perform the following procedure 3 times or more. <ul style="list-style-type: none"> — Pull up the electric parking brake switch to operate the electric parking brake. — Press down the electric parking brake switch to release the electric parking brake. • Retrieve the electric parking brake control module DTCs using the M-MDS. (See DTC INSPECTION [ELECTRIC PARKING BRAKE CONTROL MODULE].) • Are any DTCs other than DTC C2006:74 displayed? 	Yes	<p>If a procedure which verifies other DTCs is included in the diagnostic procedure of the displayed DTC:</p> <ul style="list-style-type: none"> • Go to the next step. <p>If a procedure which verifies other DTCs is not included in the diagnostic procedure of the displayed DTC:</p> <ul style="list-style-type: none"> • Repair or replace the malfunctioning part according to the applicable DTC troubleshooting. (See DTC TABLE [ELECTRIC PARKING BRAKE CONTROL MODULE].)
		No	Go to the next step.
2	INSPECT ELECTRIC PARKING BRAKE MOTOR GEAR UNIT (LH) CONNECTOR CONDITION <ul style="list-style-type: none"> • Switch the ignition off. • Disconnect the negative battery terminal. (See NEGATIVE BATTERY TERMINAL DISCONNECTION/CONNECTION.) • Disconnect the electric parking brake motor gear unit (LH) connector. • Inspect the connector engagement and connection condition and inspect the terminals for damage, deformation, corrosion, or disconnection. • Is the connector normal? 	Yes	Go to the next step.
		No	Repair or replace the connector, then go to Step 7.
3	INSPECT ELECTRIC PARKING BRAKE CONTROL MODULE CONNECTOR CONDITION <ul style="list-style-type: none"> • Disconnect the electric parking brake control module connector. • Inspect the connector engagement and connection condition and inspect the terminals for damage, deformation, corrosion, or disconnection. • Is the connector normal? 	Yes	Go to the next step.
		No	Repair or replace the connector, then go to Step 7.

DTC C2005:74 [ELECTRIC PARKING BRAKE CONTROL MODULE]

SM2898061

id04023425200

Description	Electric parking brake motor gear unit (RH) power transmission impossible (spin)
Detection condition	<ul style="list-style-type: none">• Electric parking brake control module detects an electric parking brake motor gear unit (RH) power transmission impossible (spin).
Fail-safe	Not applicable
Possible cause	<ul style="list-style-type: none">• Electric parking brake motor gear unit (RH) connector or terminal malfunction• Electric parking brake control module connector or terminal malfunction• Open circuit in wiring harness between the following terminals:<ul style="list-style-type: none">— Electric parking brake motor gear unit (RH) terminal A–Electric parking brake control module terminal 1P— Electric parking brake motor gear unit (RH) terminal B–Electric parking brake control module terminal 1M• Rear brake caliper (RH) piston stuck• Spindle in electric parking brake motor gear unit (RH) is stuck• Electric parking brake motor gear unit (RH) malfunction• Electric parking brake control module malfunction



Diagnostic Procedure

Step	Inspection	Results	Action
7	VERIFY THAT REPAIRS HAVE BEEN COMPLETED <ul style="list-style-type: none"> • Always reconnect all disconnected connectors. • Connect the negative battery terminal. (See NEGATIVE BATTERY TERMINAL DISCONNECTION/CONNECTION.) • Clear the DTC for the electric parking brake control module using the M-MDS. (See CLEARING DTC [ELECTRIC PARKING BRAKE CONTROL MODULE].) • Perform the following procedure 3 times or more. <ul style="list-style-type: none"> — Pull up the electric parking brake switch to operate the electric parking brake. — Press down the electric parking brake switch to release the electric parking brake. • Retrieve the electric parking brake control module DTCs using the M-MDS. (See DTC INSPECTION [ELECTRIC PARKING BRAKE CONTROL MODULE].) • Is the same DTC displayed? 	Yes	Repeat the inspection from Step 1. <ul style="list-style-type: none"> • If the malfunction recurs, replace the electric parking brake control module. (See ELECTRIC PARKING BRAKE CONTROL MODULE REMOVAL/INSTALLATION.) Go to the next step.
		No	Go to the next step.
8	VERIFY IF OTHER DTCs DISPLAYED <ul style="list-style-type: none"> • Are any other DTCs displayed? 	Yes	Repair or replace the malfunctioning part according to the applicable DTC troubleshooting. (See DTC TABLE [ELECTRIC PARKING BRAKE CONTROL MODULE] .)
		No	DTC troubleshooting completed.

Step	Inspection	Results	Action
4	INSPECT ELECTRIC PARKING BRAKE MOTOR GEAR UNIT (RH) CIRCUIT FOR OPEN CIRCUIT <ul style="list-style-type: none"> • Verify that the electric parking brake motor gear unit (RH) and electric parking brake control module connectors are disconnected. • Inspect for continuity between the following terminals (wiring harness-side): <ul style="list-style-type: none"> — Electric parking brake motor gear unit (RH) terminal A–Electric parking brake control module terminal 1P — Electric parking brake motor gear unit (RH) terminal B–Electric parking brake control module terminal 1M • Is there continuity? 	Yes	Go to the next step.
		No	Refer to the wiring diagram and verify whether or not there is a common connector between the following terminals: <ul style="list-style-type: none"> • Electric parking brake motor gear unit (RH) terminal A–Electric parking brake control module terminal 1P • Electric parking brake motor gear unit (RH) terminal B–Electric parking brake control module terminal 1M If there is a common connector: <ul style="list-style-type: none"> • Determine the malfunctioning part by inspecting the common connector and the terminal for corrosion, damage, or pin disconnection, and the common wiring harness for an open circuit. • Repair or replace the malfunctioning part. If there is no common connector: <ul style="list-style-type: none"> • Repair or replace the wiring harness which has an open circuit. Go to Step 7.
5	INSPECT REAR BRAKE CALIPER (RH) PISTON FOR STICKING <ul style="list-style-type: none"> • Verify the condition of the rear brake caliper (RH) piston. • Is the rear brake caliper (RH) piston stuck? 	Yes	Repair the piston for sticking. (See REAR BRAKE CALIPER DISASSEMBLY/ASSEMBLY .) Go to Step 7.
		No	Go to the next step.
6	VERIFY IF MALFUNCTIONING LOCATION IS ELECTRIC PARKING BRAKE MOTOR GEAR UNIT (RH) DEPENDING ON REPEATABILITY <ul style="list-style-type: none"> • Always reconnect all disconnected connectors. • Connect the negative battery terminal. (See NEGATIVE BATTERY TERMINAL DISCONNECTION/CONNECTION.) • Clear the DTC for the electric parking brake control module using the M-MDS. (See CLEARING DTC [ELECTRIC PARKING BRAKE CONTROL MODULE].) • Perform the following procedure 3 times or more. <ul style="list-style-type: none"> — Pull up the electric parking brake switch to operate the electric parking brake. — Press down the electric parking brake switch to release the electric parking brake. • Retrieve the electric parking brake control module DTCs using the M-MDS. (See DTC INSPECTION [ELECTRIC PARKING BRAKE CONTROL MODULE].) • Is the same DTC displayed? 	Yes	Replace the electric parking brake motor gear unit (RH), then go to the next step. (See ELECTRIC PARKING BRAKE MOTOR GEAR UNIT REMOVAL/INSTALLATION .)
		No	Go to Step 8.

Step	Inspection	Results	Action
1	INSPECT ELECTRIC PARKING BRAKE MOTOR GEAR UNIT (LH) CONNECTOR CONDITION <ul style="list-style-type: none"> • Switch the ignition off. • Disconnect the negative battery terminal. (See NEGATIVE BATTERY TERMINAL DISCONNECTION/CONNECTION.) • Disconnect the electric parking brake motor gear unit (LH) connector. • Inspect the connector engagement and connection condition and inspect the terminals for damage, deformation, corrosion, or disconnection. • Is the connector normal? 	Yes	Go to the next step.
		No	Repair or replace the connector, then go to Step 6.
2	INSPECT ELECTRIC PARKING BRAKE CONTROL MODULE CONNECTOR CONDITION <ul style="list-style-type: none"> • Disconnect the electric parking brake control module connector. • Inspect the connector engagement and connection condition and inspect the terminals for damage, deformation, corrosion, or disconnection. • Is the connector normal? 	Yes	Go to the next step.
		No	Repair or replace the connector, then go to Step 6.
3	INSPECT ELECTRIC PARKING BRAKE MOTOR GEAR UNIT (LH) CIRCUIT FOR OPEN CIRCUIT <ul style="list-style-type: none"> • Verify that the electric parking brake motor gear unit (LH) and electric parking brake control module connectors are disconnected. • Inspect for continuity between the following terminals (wiring harness-side): <ul style="list-style-type: none"> — Electric parking brake motor gear unit (LH) terminal A–Electric parking brake control module terminal 1U — Electric parking brake motor gear unit (LH) terminal B–Electric parking brake control module terminal 1Z • Is there continuity? 	Yes	Go to the next step.
		No	Refer to the wiring diagram and verify whether or not there is a common connector between the following terminals: <ul style="list-style-type: none"> • Electric parking brake motor gear unit (LH) terminal A–Electric parking brake control module terminal 1U • Electric parking brake motor gear unit (LH) terminal B–Electric parking brake control module terminal 1Z If there is a common connector: <ul style="list-style-type: none"> • Determine the malfunctioning part by inspecting the common connector and the terminal for corrosion, damage, or pin disconnection, and the common wiring harness for an open circuit. • Repair or replace the malfunctioning part. If there is no common connector: <ul style="list-style-type: none"> • Repair or replace the wiring harness which has an open circuit. Go to Step 6.
4	INSPECT REAR BRAKE CALIPER (LH) PISTON FOR STICKING <ul style="list-style-type: none"> • Verify the condition of the rear brake caliper (LH) piston. • Is the rear brake caliper (LH) piston stuck? 	Yes	Repair the piston for sticking. (See REAR BRAKE CALIPER DISASSEMBLY/ASSEMBLY.) Go to Step 6.
		No	Go to the next step.

Step	Inspection	Results	Action
1	INSPECT ELECTRIC PARKING BRAKE MOTOR GEAR UNIT (RH) CONNECTOR CONDITION <ul style="list-style-type: none"> • Switch the ignition off. • Disconnect the negative battery terminal. (See NEGATIVE BATTERY TERMINAL DISCONNECTION/CONNECTION.) • Disconnect the electric parking brake motor gear unit (RH) connector. • Inspect the connector engagement and connection condition and inspect the terminals for damage, deformation, corrosion, or disconnection. • Is the connector normal? 	Yes	Go to the next step.
		No	Repair or replace the connector, then go to Step 6.
2	INSPECT ELECTRIC PARKING BRAKE CONTROL MODULE CONNECTOR CONDITION <ul style="list-style-type: none"> • Disconnect the electric parking brake control module connector. • Inspect the connector engagement and connection condition and inspect the terminals for damage, deformation, corrosion, or disconnection. • Is the connector normal? 	Yes	Go to the next step.
		No	Repair or replace the connector, then go to Step 6.
3	INSPECT ELECTRIC PARKING BRAKE MOTOR GEAR UNIT (RH) CIRCUIT FOR OPEN CIRCUIT <ul style="list-style-type: none"> • Verify that the electric parking brake motor gear unit (RH) and electric parking brake control module connectors are disconnected. • Inspect for continuity between the following terminals (wiring harness-side): <ul style="list-style-type: none"> — Electric parking brake motor gear unit (RH) terminal A–Electric parking brake control module terminal 1P — Electric parking brake motor gear unit (RH) terminal B–Electric parking brake control module terminal 1M • Is there continuity? 	Yes	Go to the next step.
		No	Refer to the wiring diagram and verify whether or not there is a common connector between the following terminals: <ul style="list-style-type: none"> • Electric parking brake motor gear unit (RH) terminal A–Electric parking brake control module terminal 1P • Electric parking brake motor gear unit (RH) terminal B–Electric parking brake control module terminal 1M If there is a common connector: <ul style="list-style-type: none"> • Determine the malfunctioning part by inspecting the common connector and the terminal for corrosion, damage, or pin disconnection, and the common wiring harness for an open circuit. • Repair or replace the malfunctioning part. If there is no common connector: <ul style="list-style-type: none"> • Repair or replace the wiring harness which has an open circuit. Go to Step 6.
4	INSPECT REAR BRAKE CALIPER (RH) PISTON FOR STICKING <ul style="list-style-type: none"> • Verify the condition of the rear brake caliper (RH) piston. • Is the rear brake caliper (RH) piston stuck? 	Yes	Repair the piston for sticking. (See REAR BRAKE CALIPER DISASSEMBLY/ASSEMBLY.) Go to Step 6.
		No	Go to the next step.