

Your Ultimate Source for OEM Repair Manuals

FactoryManuals.net is a great resource for anyone who wants to save money on repairs by doing their own work. The manuals provide detailed instructions and diagrams that make it easy to understand how to fix a vehicle.

2011 MAZDA MX-5 / Miata OEM Service and Repair Workshop Manual

[Go to manual page](#)

DTC U3001:04 [ELECTRIC PARKING BRAKE CONTROL MODULE]

SM2898090

id04023425580

Description	Electric parking brake control module internal malfunction
Detection condition	• Malfunction in the electric parking brake control module is detected.
Fail-safe	Not applicable
Possible cause	• Electric parking brake control module malfunction
System wiring diagram	Not applicable

Diagnostic Procedure

Step	Inspection	Results	Action
1	VERIFY IF THE ELECTRIC PARKING BRAKE WARNING LIGHT IS TURNED ON <ul style="list-style-type: none">• Verify if the electric parking brake warning light is turned on.• Is the electric parking brake warning light turned on?	Yes	Go to the next step.
		No	Replace the electric parking brake control module, then go to the next step. (See ELECTRIC PARKING BRAKE CONTROL MODULE REMOVAL/INSTALLATION.)
2	VERIFY IF MALFUNCTIONING LOCATION IS ELECTRIC PARKING BRAKE CONTROL MODULE DEPENDING ON REPEATABILITY <ul style="list-style-type: none">• Clear the DTC for the electric parking brake control module using the M-MDS. (See CLEARING DTC [ELECTRIC PARKING BRAKE CONTROL MODULE].)• Perform the following procedure 3 times or more.<ul style="list-style-type: none">— Pull up the electric parking brake switch to operate the electric parking brake.— Press down the electric parking brake switch to release the electric parking brake.• Retrieve the electric parking brake control module DTCs using the M-MDS. (See DTC INSPECTION [ELECTRIC PARKING BRAKE CONTROL MODULE].)• Is the same DTC displayed?	Yes	Replace the electric parking brake control module, then go to the next step. (See ELECTRIC PARKING BRAKE CONTROL MODULE REMOVAL/INSTALLATION.)
		No	Go to the next step.
3	VERIFY IF OTHER DTCs DISPLAYED <ul style="list-style-type: none">• Are any other DTCs displayed?	Yes	Repair or replace the malfunctioning part according to the applicable DTC troubleshooting. (See DTC TABLE [ELECTRIC PARKING BRAKE CONTROL MODULE].)
		No	DTC troubleshooting completed.

Step	Inspection	Results	Action
5	VERIFY ELECTRIC PARKING BRAKE CONTROL MODULE POWER SUPPLY VOLTAGE <ul style="list-style-type: none">• Always reconnect all disconnected connectors.• Connect the negative battery terminal. (See NEGATIVE BATTERY TERMINAL DISCONNECTION/CONNECTION.)• Measure the voltage at the following terminals (wiring harness-side):<ul style="list-style-type: none">— Electric parking brake control module terminal 1C— Electric parking brake control module terminal 1H• Is the voltage B+?	Yes	Go to the next step.

DTC U3003:17 [ELECTRIC PARKING BRAKE CONTROL MODULE]

SM2898092

id04023425600

Description	Electric parking brake control module high power supply voltage input
Detection condition	<ul style="list-style-type: none">Power supply voltage of 16 V or more is detected in the power supply circuit of the electric parking brake control module.
Fail-safe	Not applicable
Possible cause	<ul style="list-style-type: none">DTCs are stored in the PCM.Battery malfunctionGenerator malfunctionElectric parking brake control module malfunction
System wiring diagram	Not applicable

Diagnostic Procedure

Step	Inspection	Results	Action
1	VERIFY PCM DTCs <ul style="list-style-type: none">Retrieve the PCM DTCs using the M-MDS. (See ON-BOARD DIAGNOSTIC TEST [PCM (SKYACTIV-G 2.5 (WITHOUT CYLINDER DEACTIVATION))].) (See ON-BOARD DIAGNOSTIC TEST [PCM (SKYACTIV-G 2.5 (WITH CYLINDER DEACTIVATION))].) (See ON-BOARD DIAGNOSTIC TEST [PCM (SKYACTIV-D 2.2)].) (See ON-BOARD DIAGNOSTIC TEST [PCM (SKYACTIV-G 2.5T)].)Are any DTCs displayed?	Yes	Repair or replace the malfunctioning part according to the applicable DTC troubleshooting. (See DTC TABLE [PCM (SKYACTIV-G 2.5 (WITHOUT CYLINDER DEACTIVATION))] .) (See DTC TABLE [PCM (SKYACTIV-G 2.5 (WITH CYLINDER DEACTIVATION))] .) (See DTC TABLE [PCM (SKYACTIV-D 2.2)] .) (See DTC TABLE [PCM (SKYACTIV-G 2.5T)] .)
		No	Go to the next step.
2	INSPECT BATTERY <ul style="list-style-type: none">Inspect the battery. (See BATTERY INSPECTION.)Is the battery normal?	Yes	Go to the next step.
		No	Replace the battery, then go to Step 4. (See BATTERY REMOVAL/INSTALLATION [SKYACTIV-G 2.5 (WITHOUT CYLINDER DEACTIVATION)] .) (See BATTERY REMOVAL/INSTALLATION [SKYACTIV-G 2.5 (WITH CYLINDER DEACTIVATION)] .) (See BATTERY REMOVAL/INSTALLATION [SKYACTIV-D 2.2] .) (See BATTERY REMOVAL/INSTALLATION [SKYACTIV-G 2.5T] .)

Step	Inspection	Results	Action
1	VERIFY PCM DTCs <ul style="list-style-type: none"> Retrieve the PCM DTCs using the M-MDS. (See ON-BOARD DIAGNOSTIC TEST [PCM (SKYACTIV-G 2.5 (WITHOUT CYLINDER DEACTIVATION))].) (See ON-BOARD DIAGNOSTIC TEST [PCM (SKYACTIV-G 2.5 (WITH CYLINDER DEACTIVATION))].) (See ON-BOARD DIAGNOSTIC TEST [PCM (SKYACTIV-D 2.2)].) (See ON-BOARD DIAGNOSTIC TEST [PCM (SKYACTIV-G 2.5T)].) Are any DTCs displayed? 	Yes	Repair or replace the malfunctioning part according to the applicable DTC troubleshooting. (See DTC TABLE [PCM (SKYACTIV-G 2.5 (WITHOUT CYLINDER DEACTIVATION))] .) (See DTC TABLE [PCM (SKYACTIV-G 2.5 (WITH CYLINDER DEACTIVATION))] .) (See DTC TABLE [PCM (SKYACTIV-D 2.2)] .) (See DTC TABLE [PCM (SKYACTIV-G 2.5T)] .)
		No	Go to the next step.
2	INSPECT BATTERY <ul style="list-style-type: none"> Inspect the battery. (See BATTERY INSPECTION.) Is the battery normal? 	Yes	Go to the next step.
		No	Recharge or replace the battery, then go to Step 6. (See BATTERY RECHARGING .) (See BATTERY REMOVAL/INSTALLATION [SKYACTIV-G 2.5 (WITHOUT CYLINDER DEACTIVATION)] .) (See BATTERY REMOVAL/INSTALLATION [SKYACTIV-G 2.5 (WITH CYLINDER DEACTIVATION)] .) (See BATTERY REMOVAL/INSTALLATION [SKYACTIV-D 2.2] .) (See BATTERY REMOVAL/INSTALLATION [SKYACTIV-G 2.5T] .)
3	INSPECT GENERATOR <ul style="list-style-type: none"> Inspect the generator. (See GENERATOR INSPECTION [SKYACTIV-G 2.5 (WITHOUT CYLINDER DEACTIVATION)].) (See GENERATOR INSPECTION [SKYACTIV-G 2.5 (WITH CYLINDER DEACTIVATION)].) (See GENERATOR INSPECTION [SKYACTIV-D 2.2].) (See GENERATOR INSPECTION [SKYACTIV-G 2.5T].) Is the generator normal? 	Yes	Go to the next step.
		No	Replace the generator, then go to Step 6. (See GENERATOR REMOVAL/INSTALLATION [SKYACTIV-G 2.5 (WITHOUT CYLINDER DEACTIVATION)] .) (See GENERATOR REMOVAL/INSTALLATION [SKYACTIV-G 2.5 (WITH CYLINDER DEACTIVATION)] .) (See GENERATOR REMOVAL/INSTALLATION [SKYACTIV-D 2.2] .) (See GENERATOR REMOVAL/INSTALLATION [SKYACTIV-G 2.5T] .)
4	INSPECT ELECTRIC PARKING BRAKE CONTROL MODULE CONNECTOR CONDITION <ul style="list-style-type: none"> Switch the ignition off. Disconnect the negative battery terminal. (See NEGATIVE BATTERY TERMINAL DISCONNECTION/CONNECTION.) Disconnect the electric parking brake switch connector. Inspect the connector engagement and connection condition and inspect the terminals for damage, deformation, corrosion, or disconnection. Is the connector normal? 	Yes	Go to the next step.
		No	Repair or replace the connector, then go to Step 6.

Step	Inspection	Results	Action
			<ul style="list-style-type: none"> • Repair or replace the malfunctioning part. <p>If there is no common connector:</p> <ul style="list-style-type: none"> • Repair or replace the wiring harness which has an open circuit. <p>Go to the next step.</p>
6	VERIFY THAT REPAIRS HAVE BEEN COMPLETED <ul style="list-style-type: none"> • Always reconnect all disconnected connectors. • Connect the negative battery terminal. (See NEGATIVE BATTERY TERMINAL DISCONNECTION/CONNECTION.) • Clear the DTC for the electric parking brake control module using the M-MDS. (See CLEARING DTC [ELECTRIC PARKING BRAKE CONTROL MODULE].) • Perform the following procedure 3 times or more. <ul style="list-style-type: none"> — Pull up the electric parking brake switch to operate the electric parking brake. — Press down the electric parking brake switch to release the electric parking brake. • Retrieve the electric parking brake control module DTCs using the M-MDS. (See DTC INSPECTION [ELECTRIC PARKING BRAKE CONTROL MODULE].) • Is the same DTC displayed? 	Yes	<p>Repeat the inspection from Step 1.</p> <ul style="list-style-type: none"> • If the malfunction recurs, replace the electric parking brake control module. (See ELECTRIC PARKING BRAKE CONTROL MODULE REMOVAL/INSTALLATION.) <p>Go to the next step.</p>
		No	Go to the next step.
7	VERIFY IF OTHER DTCs DISPLAYED <ul style="list-style-type: none"> • Are any other DTCs displayed? 	Yes	<p>Repair or replace the malfunctioning part according to the applicable DTC troubleshooting. (See DTC TABLE [ELECTRIC PARKING BRAKE CONTROL MODULE].)</p>
		No	DTC troubleshooting completed.

Step	Inspection	Results	Action
5	VERIFY ELECTRIC PARKING BRAKE CONTROL MODULE POWER SUPPLY VOLTAGE <ul style="list-style-type: none">• Always reconnect all disconnected connectors.• Connect the negative battery terminal. (See NEGATIVE BATTERY TERMINAL DISCONNECTION/CONNECTION.)• Measure the voltage at the electric parking brake control module terminal 1C (wiring harness-side).• Is the voltage B+?	Yes	Go to the next step.

Sample

DTC U300A:62 [ELECTRIC PARKING BRAKE CONTROL MODULE]

SM2898095

id04023425650

Description	Ignition switch status mismatch
Detection condition	<ul style="list-style-type: none">• Electric parking brake control module detects the following mismatches.<ul style="list-style-type: none">— Condition of IG1 power supply supplied to instrument cluster— Condition of IG1 power supply supplied to electric parking brake control module
Fail-safe	Not applicable
Possible cause	<ul style="list-style-type: none">• DTCs are stored in the instrument cluster.<ul style="list-style-type: none">— Instrument cluster power supply circuit malfunction— Instrument cluster malfunction• Electric parking brake control module connector or terminal malfunction• Electric parking brake control module power supply circuit (IG1) malfunction<ul style="list-style-type: none">— Short to ground in wiring harness between IG1 relay terminal C and electric parking brake control module terminal 1AB— C/U IG1 15 A fuse malfunction— Open circuit in wiring harness between IG1 relay terminal C and electric parking brake control module terminal 1AB• Electric parking brake control module malfunction

Step	Inspection	Results	Action
4	VERIFY THAT REPAIRS HAVE BEEN COMPLETED <ul style="list-style-type: none"> • Always reconnect all disconnected connectors. • Connect the negative battery terminal. (See NEGATIVE BATTERY TERMINAL DISCONNECTION/CONNECTION.) • Clear the DTC for the electric parking brake control module using the M-MDS. (See CLEARING DTC [ELECTRIC PARKING BRAKE CONTROL MODULE].) • Perform the following procedure 3 times or more. <ul style="list-style-type: none"> — Pull up the electric parking brake switch to operate the electric parking brake. — Press down the electric parking brake switch to release the electric parking brake. • Retrieve the electric parking brake control module DTCs using the M-MDS. (See DTC INSPECTION [ELECTRIC PARKING BRAKE CONTROL MODULE].) • Is the same DTC displayed? 	Yes	Repeat the inspection from Step 1. <ul style="list-style-type: none"> • If the malfunction recurs, replace the electric parking brake control module. (See ELECTRIC PARKING BRAKE CONTROL MODULE REMOVAL/INSTALLATION.) Go to the next step.
		No	Go to the next step.
5	VERIFY IF OTHER DTCs DISPLAYED <ul style="list-style-type: none"> • Are any other DTCs displayed? 	Yes	Repair or replace the malfunctioning part according to the applicable DTC troubleshooting. (See DTC TABLE [ELECTRIC PARKING BRAKE CONTROL MODULE].)
		No	DTC troubleshooting completed.

DTC C1020:68 [ELECTRIC PARKING BRAKE CONTROL MODULE]

SM2898097

id04023425670

Description	Error signal received from DSC HU/CM
Detection condition	• Electric parking brake control module receives the error signals from the DSC HU/CM after 5 s or more since ignition was switched ON (engine on).
Fail-safe	Not applicable
Possible cause	• DTCs are stored in the DSC HU/CM. • DSC HU/CM malfunction
System wiring diagram	Not applicable

Diagnostic Procedure

Step	Inspection	Results	Action
1	VERIFY DSC HU/CM DTCs • Retrieve the DSC HU/CM DTCs using the M-MDS. (See DTC INSPECTION [DSC HU/CM].) • Are any DTCs displayed?	Yes	Repair or replace the malfunctioning part according to the applicable DTC troubleshooting. (See DTC TABLE [DSC HU/CM].)
		No	Go to the next step.
2	VERIFY THAT REPAIRS HAVE BEEN COMPLETED • Clear the DTC for the electric parking brake control module using the M-MDS. (See CLEARING DTC [ELECTRIC PARKING BRAKE CONTROL MODULE].) • Perform the following procedure 3 times or more. — Pull up the electric parking brake switch to operate the electric parking brake. — Press down the electric parking brake switch to release the electric parking brake. • Retrieve the electric parking brake control module DTCs using the M-MDS. (See DTC INSPECTION [ELECTRIC PARKING BRAKE CONTROL MODULE].) • Is the same DTC displayed?	Yes	Replace the DSC HU/CM, then go to the next step. (See DSC HU/CM REMOVAL/INSTALLATION [SKYACTIV-C 2.5 (WITHOUT CYLINDER DEACTIVATION)].) (See DSC HU/CM REMOVAL/INSTALLATION [SKYACTIV-C 2.5 (WITH CYLINDER DEACTIVATION)].) (See DSC HU/CM REMOVAL/INSTALLATION [SKYACTIV-D 2.2].) (See DSC HU/CM REMOVAL/INSTALLATION [SKYACTIV-C 2.5T].)
		No	Go to the next step.
3	VERIFY IF OTHER DTCs DISPLAYED • Are any other DTCs displayed?	Yes	Repair or replace the malfunctioning part according to the applicable DTC troubleshooting. (See DTC TABLE [ELECTRIC PARKING BRAKE CONTROL MODULE].)
		No	DTC troubleshooting completed.