

# Your Ultimate Source for OEM Repair Manuals

FactoryManuals.net is a great resource for anyone who wants to save money on repairs by doing their own work. The manuals provide detailed instructions and diagrams that make it easy to understand how to fix a vehicle.

## 2011 MAZDA Tribute OEM Service and Repair Workshop Manual

[Go to manual page](#)

Step	Inspection	Results	Action
4	<b>VERIFY IF MALFUNCTIONING LOCATION IS ELECTRIC PARKING BRAKE MOTOR GEAR UNIT (RH) DEPENDING ON REPEATABILITY</b> <ul style="list-style-type: none"> <li>• Switch the ignition off.</li> <li>• Disconnect the negative battery terminal. (See <b>NEGATIVE BATTERY TERMINAL DISCONNECTION/CONNECTION.</b>)</li> <li>• Always reconnect all disconnected connectors.</li> <li>• Connect the negative battery terminal. (See <b>NEGATIVE BATTERY TERMINAL DISCONNECTION/CONNECTION.</b>)</li> <li>• Clear the DTC for the electric parking brake control module using the M-MDS. (See <b>CLEARING DTC [ELECTRIC PARKING BRAKE CONTROL MODULE].</b>)</li> <li>• Perform the following procedure 3 times or more. <ul style="list-style-type: none"> <li>— Pull up the electric parking brake switch to operate the electric parking brake.</li> <li>— Press down the electric parking brake switch to release the electric parking brake.</li> </ul> </li> <li>• Retrieve the electric parking brake control module DTCs using the M-MDS. (See <b>DTC INSPECTION [ELECTRIC PARKING BRAKE CONTROL MODULE].</b>)</li> <li>• Is the same DTC displayed?</li> </ul>	Yes	Replace the electric parking brake motor gear unit (RH), then go to the next step. (See <b>ELECTRIC PARKING BRAKE MOTOR GEAR UNIT REMOVAL/INSTALLATION.</b> )
		No	Go to the Step 6.
5	<b>VERIFY THAT REPAIRS HAVE BEEN COMPLETED</b> <ul style="list-style-type: none"> <li>• Always reconnect all disconnected connectors.</li> <li>• Connect the negative battery terminal. (See <b>NEGATIVE BATTERY TERMINAL DISCONNECTION/CONNECTION.</b>)</li> <li>• Clear the DTC for the electric parking brake control module using the M-MDS. (See <b>CLEARING DTC [ELECTRIC PARKING BRAKE CONTROL MODULE].</b>)</li> <li>• Perform the following procedure 3 times or more. <ul style="list-style-type: none"> <li>— Pull up the electric parking brake switch to operate the electric parking brake.</li> <li>— Press down the electric parking brake switch to release the electric parking brake.</li> </ul> </li> <li>• Retrieve the electric parking brake control module DTCs using the M-MDS. (See <b>DTC INSPECTION [ELECTRIC PARKING BRAKE CONTROL MODULE].</b>)</li> <li>• Is the same DTC displayed?</li> </ul>	Yes	Repeat the inspection from Step 1. • If the malfunction recurs, replace the electric parking brake control module. (See <b>ELECTRIC PARKING BRAKE CONTROL MODULE REMOVAL/INSTALLATION.</b> ) Go to the next step.
		No	Go to the next step.
6	<b>VERIFY IF OTHER DTCs DISPLAYED</b> <ul style="list-style-type: none"> <li>• Are any other DTCs displayed?</li> </ul>	Yes	Repair or replace the malfunctioning part according to the applicable DTC troubleshooting. (See <b>DTC TABLE [ELECTRIC PARKING BRAKE CONTROL MODULE].</b> )
		No	DTC troubleshooting completed.

Step	Inspection	Results	Action
1	<b>INSPECT ELECTRIC PARKING BRAKE MOTOR GEAR UNIT (RH) CONNECTOR CONDITION</b> <ul style="list-style-type: none"> <li>• Switch the ignition off.</li> <li>• Disconnect the negative battery terminal. (See <b>NEGATIVE BATTERY TERMINAL DISCONNECTION/CONNECTION.</b>)</li> <li>• Disconnect the electric parking brake motor gear unit (RH) connector.</li> <li>• Inspect the connector engagement and connection condition and inspect the terminals for damage, deformation, corrosion, or disconnection.</li> <li>• Is the connector normal?</li> </ul>	Yes	Go to the next step.
		No	Repair or replace the connector, then go to Step 5.
2	<b>INSPECT ELECTRIC PARKING BRAKE CONTROL MODULE CONNECTOR CONDITION</b> <ul style="list-style-type: none"> <li>• Disconnect the electric parking brake control module connector.</li> <li>• Inspect the connector engagement and connection condition and inspect the terminals for damage, deformation, corrosion, or disconnection.</li> <li>• Is the connector normal?</li> </ul>	Yes	Go to the next step.
		No	Repair or replace the connector, then go to Step 5.
3	<b>INSPECT ELECTRIC PARKING BRAKE MOTOR GEAR UNIT (RH) CIRCUIT FOR OPEN CIRCUIT</b> <ul style="list-style-type: none"> <li>• Verify that the electric parking brake motor gear unit (RH) and electric parking brake control module connectors are disconnected.</li> <li>• Inspect for continuity between the following terminals (wiring harness-side): <ul style="list-style-type: none"> <li>— Electric parking brake motor gear unit (RH) terminal A–Electric parking brake control module terminal 1P</li> <li>— Electric parking brake motor gear unit (RH) terminal B–Electric parking brake control module terminal 1M</li> </ul> </li> <li>• Is there continuity?</li> </ul>	Yes	Go to the next step.
		No	Refer to the wiring diagram and verify whether or not there is a common connector between the following terminals: <ul style="list-style-type: none"> <li>• Electric parking brake motor gear unit (RH) terminal A–Electric parking brake control module terminal 1P</li> <li>• Electric parking brake motor gear unit (RH) terminal B–Electric parking brake control module terminal 1M</li> </ul> <b>If there is a common connector:</b> <ul style="list-style-type: none"> <li>• Determine the malfunctioning part by inspecting the common connector and the terminal for corrosion, damage, or pin disconnection, and the common wiring harness for an open circuit.</li> <li>• Repair or replace the malfunctioning part.</li> </ul> <b>If there is no common connector:</b> <ul style="list-style-type: none"> <li>• Repair or replace the wiring harness which has an open circuit.</li> </ul> Go to Step 5.


Step	Inspection	Results	Action
1	<b>VERIFY OTHER ELECTRIC PARKING BRAKE CONTROL MODULE DTCs</b> <ul style="list-style-type: none"> <li>• Clear the DTC for the electric parking brake control module using the M-MDS. (See <b>CLEARING DTC [ELECTRIC PARKING BRAKE CONTROL MODULE]</b>.)</li> <li>• Retrieve the electric parking brake control module DTCs using the M-MDS. (See <b>DTC INSPECTION [ELECTRIC PARKING BRAKE CONTROL MODULE]</b>.)</li> <li>• Are any DTCs other than DTC C2005:19 displayed?</li> </ul>	Yes	<p>If a procedure which verifies other DTCs is included in the diagnostic procedure of the displayed DTC:</p> <ul style="list-style-type: none"> <li>• Go to the next step.</li> </ul> <p>If a procedure which verifies other DTCs is not included in the diagnostic procedure of the displayed DTC:</p> <ul style="list-style-type: none"> <li>• Repair or replace the malfunctioning part according to the applicable DTC troubleshooting. (See <b>DTC TABLE [ELECTRIC PARKING BRAKE CONTROL MODULE]</b>.)</li> </ul>
		No	Go to the next step.
2	<b>INSPECT ELECTRIC PARKING BRAKE MOTOR GEAR UNIT (RH) CONNECTOR CONDITION</b> <ul style="list-style-type: none"> <li>• Switch the ignition off.</li> <li>• Disconnect the negative battery terminal. (See <b>NEGATIVE BATTERY TERMINAL DISCONNECTION/CONNECTION</b>.)</li> <li>• Disconnect the electric parking brake motor gear unit (RH) connector.</li> <li>• Inspect the connector engagement and connection condition and inspect the terminals for damage, deformation, corrosion, or disconnection.</li> <li>• Is the connector normal?</li> </ul>	Yes	Go to the next step.
		No	Repair or replace the connector, then go to Step 8.
3	<b>INSPECT ELECTRIC PARKING BRAKE CONTROL MODULE CONNECTOR CONDITION</b> <ul style="list-style-type: none"> <li>• Disconnect the electric parking brake control module connector.</li> <li>• Inspect the connector engagement and connection condition and inspect the terminals for damage, deformation, corrosion, or disconnection.</li> <li>• Is the connector normal?</li> </ul>	Yes	Go to the next step.
		No	Repair or replace the connector, then go to Step 8.
4	<b>INSPECT ELECTRIC PARKING BRAKE MOTOR GEAR UNIT (RH) CIRCUIT FOR SHORT TO GROUND</b> <ul style="list-style-type: none"> <li>• Verify that the electric parking brake motor gear unit (RH) and electric parking brake control module connectors are disconnected.</li> <li>• Inspect for continuity between the following terminals (wiring harness-side) and body ground: <ul style="list-style-type: none"> <li>— Electric parking brake motor gear unit (RH) terminal A</li> <li>— Electric parking brake motor gear unit (RH) terminal B</li> </ul> </li> <li>• Is there continuity?</li> </ul>	Yes	<p>Refer to the wiring diagram and verify whether or not there is a common connector between the following terminals:</p> <ul style="list-style-type: none"> <li>• Electric parking brake motor gear unit (RH) terminal A–Electric parking brake control module terminal 1P</li> <li>• Electric parking brake motor gear unit (RH) terminal B–Electric parking brake control module terminal 1M</li> </ul> <p><b>If there is a common connector:</b></p> <ul style="list-style-type: none"> <li>• Determine the malfunctioning part by inspecting the common connector and the terminal for corrosion, damage, or pin disconnection, and the common wiring harness for a short to ground.</li> <li>• Repair or replace the malfunctioning part.</li> </ul> <p><b>If there is no common connector:</b></p> <ul style="list-style-type: none"> <li>• Repair or replace the wiring harness which has a short to ground.</li> </ul> <p>Go to Step 8.</p>
		No	Go to the next step.

DTC C2006:11 [ELECTRIC PARKING BRAKE CONTROL MODULE]

SM2898063

id04023425250

Description	Electric parking brake motor gear unit (LH) circuit malfunction
Detection condition	<ul style="list-style-type: none"><li>• Electric parking brake control module detects a short to ground in the electric parking brake motor gear unit (LH) circuit.</li></ul>
Fail-safe	Not applicable
Possible cause	<ul style="list-style-type: none"><li>• Electric parking brake motor gear unit (LH) connector or terminal malfunction</li><li>• Electric parking brake control module connector or terminal malfunction</li><li>• Short to ground in wiring harness between the following terminals:<ul style="list-style-type: none"><li>— Electric parking brake motor gear unit (LH) terminal A–Electric parking brake control module terminal 1U</li><li>— Electric parking brake motor gear unit (LH) terminal B–Electric parking brake control module terminal 1Z</li></ul></li><li>• Electric parking brake motor gear unit (LH) malfunction</li><li>• Electric parking brake control module malfunction</li></ul>







Diagnostic Procedure

DTC C2006:12 [ELECTRIC PARKING BRAKE CONTROL MODULE]

SM2898064

id04023425260

Description	Electric parking brake motor gear unit (LH) circuit malfunction
Detection condition	<ul style="list-style-type: none"><li>• Electric parking brake control module detects a short to power supply in the electric parking brake motor gear unit (LH) circuit.</li></ul>
Fail-safe	Not applicable
Possible cause	<ul style="list-style-type: none"><li>• Electric parking brake motor gear unit (LH) connector or terminal malfunction</li><li>• Electric parking brake control module connector or terminal malfunction</li><li>• Short to power supply in wiring harness between the following terminals:<ul style="list-style-type: none"><li>— Electric parking brake motor gear unit (LH) terminal A–Electric parking brake control module terminal 1U</li><li>— Electric parking brake motor gear unit (LH) terminal B–Electric parking brake control module terminal 1Z</li></ul></li><li>• Electric parking brake motor gear unit (LH) malfunction</li><li>• Electric parking brake control module malfunction</li></ul>
<div><div><div>ELECTRIC PARKING BRAKE MOTOR GEAR UNIT (LH)</div></div><div><div>ELECTRIC PARKING BRAKE CONTROL MODULE</div></div></div> <div><div>ELECTRIC PARKING BRAKE MOTOR GEAR UNIT (LH) WIRING HARNESS-SIDE CONNECTOR</div></div> <div><div>ELECTRIC PARKING BRAKE CONTROL MODULE WIRING HARNESS-SIDE CONNECTOR</div></div>	

Diagnostic Procedure

Sample

Step	Inspection	Results	Action
4	<b>VERIFY IF MALFUNCTIONING LOCATION IS ELECTRIC PARKING BRAKE MOTOR GEAR UNIT (LH) DEPENDING ON REPEATABILITY</b> <ul style="list-style-type: none"> <li>• Always reconnect all disconnected connectors.</li> <li>• Connect the negative battery terminal. (See <b>NEGATIVE BATTERY TERMINAL DISCONNECTION/CONNECTION.</b>)</li> <li>• Clear the DTC for the electric parking brake control module using the M-MDS. (See <b>CLEARING DTC [ELECTRIC PARKING BRAKE CONTROL MODULE].</b>)</li> <li>• Perform the following procedure 3 times or more. <ul style="list-style-type: none"> <li>— Pull up the electric parking brake switch to operate the electric parking brake.</li> <li>— Press down the electric parking brake switch to release the electric parking brake.</li> </ul> </li> <li>• Retrieve the electric parking brake control module DTCs using the M-MDS. (See <b>DTC INSPECTION [ELECTRIC PARKING BRAKE CONTROL MODULE].</b>)</li> <li>• Is the same DTC displayed?</li> </ul>	Yes	Replace the electric parking brake motor gear unit (LH), then go to the next step. (See <b>ELECTRIC PARKING BRAKE MOTOR GEAR UNIT REMOVAL/INSTALLATION.</b> )
		No	Go to Step 6.
5	<b>VERIFY THAT REPAIRS HAVE BEEN COMPLETED</b> <ul style="list-style-type: none"> <li>• Always reconnect all disconnected connectors.</li> <li>• Connect the negative battery terminal. (See <b>NEGATIVE BATTERY TERMINAL DISCONNECTION/CONNECTION.</b>)</li> <li>• Clear the DTC for the electric parking brake control module using the M-MDS. (See <b>CLEARING DTC [ELECTRIC PARKING BRAKE CONTROL MODULE].</b>)</li> <li>• Perform the following procedure 3 times or more. <ul style="list-style-type: none"> <li>— Pull up the electric parking brake switch to operate the electric parking brake.</li> <li>— Press down the electric parking brake switch to release the electric parking brake.</li> </ul> </li> <li>• Retrieve the electric parking brake control module DTCs using the M-MDS. (See <b>DTC INSPECTION [ELECTRIC PARKING BRAKE CONTROL MODULE].</b>)</li> <li>• Is the same DTC displayed?</li> </ul>	Yes	Repeat the inspection from Step 1. • If the malfunction recurs, replace the electric parking brake control module. (See <b>ELECTRIC PARKING BRAKE CONTROL MODULE REMOVAL/INSTALLATION.</b> ) Go to the next step.
		No	Go to the next step.
6	<b>VERIFY IF OTHER DTCs DISPLAYED</b> <ul style="list-style-type: none"> <li>• Are any other DTCs displayed?</li> </ul>	Yes	Repair or replace the malfunctioning part according to the applicable DTC troubleshooting. (See <b>DTC TABLE [ELECTRIC PARKING BRAKE CONTROL MODULE].</b> )
		No	DTC troubleshooting completed.



Step	Inspection	Results	Action
5	<b>INSPECT ELECTRIC PARKING BRAKE MOTOR GEAR UNIT (LH) CIRCUIT FOR SHORT TO POWER SUPPLY</b> <ul style="list-style-type: none"> <li>• Verify that the electric parking brake motor gear unit (LH) and electric parking brake control module connectors are disconnected.</li> <li>• Connect the negative battery terminal. (See <b>NEGATIVE BATTERY TERMINAL DISCONNECTION/CONNECTION.</b>)</li> <li>• Switch the ignition ON (engine off or on).</li> <li>• Measure the voltage at the following terminals (wiring harness-side): <ul style="list-style-type: none"> <li>— Electric parking brake motor gear unit (LH) terminal A</li> <li>— Electric parking brake motor gear unit (LH) terminal B</li> </ul> </li> <li>• Is the voltage 0 V?</li> </ul>	Yes	Go to the next step.
		No	Refer to the wiring diagram and verify whether or not there is a common connector between the following terminals: <ul style="list-style-type: none"> <li>• Electric parking brake motor gear unit (LH) terminal A–Electric parking brake control module terminal 1U</li> <li>• Electric parking brake motor gear unit (LH) terminal B–Electric parking brake control module terminal 1Z</li> </ul> <b>If there is a common connector:</b> <ul style="list-style-type: none"> <li>• Determine the malfunctioning part by inspecting the common connector and the terminal for corrosion, damage, or pin disconnection, and the common wiring harness for a short to power supply.</li> <li>• Repair or replace the malfunctioning part.</li> </ul> <b>If there is no common connector:</b> <ul style="list-style-type: none"> <li>• Repair or replace the wiring harness which has a short to power supply.</li> </ul> Go to Step 8.
6	<b>INSPECT ELECTRIC PARKING BRAKE MOTOR GEAR UNIT (LH) CIRCUITS FOR SHORT CIRCUIT</b> <ul style="list-style-type: none"> <li>• Switch the ignition off.</li> <li>• Disconnect the negative battery terminal. (See <b>NEGATIVE BATTERY TERMINAL DISCONNECTION/CONNECTION.</b>)</li> <li>• Verify that the electric parking brake motor gear unit (LH) and electric parking brake control module connectors are disconnected.</li> <li>• Inspect for continuity between electric parking brake motor gear unit (LH) terminals A and B (wiring harness-side).</li> <li>• Is there continuity?</li> </ul>	Yes	Refer to the wiring diagram and verify whether or not there is a common connector between the following terminals: <ul style="list-style-type: none"> <li>• Electric parking brake motor gear unit (LH) terminal A–Electric parking brake control module terminal 1U</li> <li>• Electric parking brake motor gear unit (LH) terminal B–Electric parking brake control module terminal 1Z</li> </ul> <b>If there is a common connector:</b> <ul style="list-style-type: none"> <li>• Determine the malfunctioning part by inspecting the common connector and the terminal for corrosion, damage, or pin disconnection, and the common wiring harness for a short to each other.</li> <li>• Repair or replace the malfunctioning part.</li> </ul> <b>If there is no common connector:</b> <ul style="list-style-type: none"> <li>• Repair or replace the wiring harness which has a short to each other.</li> </ul> Go to Step 8.
		No	Go to the next step.

Fail-safe	<ul style="list-style-type: none"> <li>• U0001:88 <ul style="list-style-type: none"> <li>— Not applicable</li> </ul> </li> <li>• U0100:00 <ul style="list-style-type: none"> <li>— Not applicable</li> </ul> </li> <li>• U0101:00 <ul style="list-style-type: none"> <li>— Not applicable</li> </ul> </li> <li>• U0121:00 <ul style="list-style-type: none"> <li>— Not applicable</li> </ul> </li> <li>• U0151:00 <ul style="list-style-type: none"> <li>— Not applicable</li> </ul> </li> <li>• U0155:00 <ul style="list-style-type: none"> <li>— Not applicable</li> </ul> </li> </ul>
Possible cause	<ul style="list-style-type: none"> <li>• Malfunction in CAN bus communication line</li> <li>• Malfunction in CAN communication line between PCM and electric parking brake control module</li> <li>• Malfunction in CAN communication line between TCM and electric parking brake control module</li> <li>• Malfunction in CAN communication line between DSC HU/CM and electric parking brake control module</li> <li>• Malfunction in CAN communication line between SAS control module and electric parking brake control module</li> <li>• Malfunction in CAN communication line between instrument cluster and electric parking brake control module</li> </ul>
System wiring diagram	Not applicable

## Diagnostic Procedure

- Perform the malfunction diagnosis according to the troubleshooting procedure for the multiplex communication system. (See [CONTROLLER AREA NETWORK \(CAN\) MALFUNCTION DIAGNOSIS FLOW \[TYPE-A \(SKYACTIV-G 2.5\)\]](#).) (See [CONTROLLER AREA NETWORK \(CAN\) MALFUNCTION DIAGNOSIS FLOW \[TYPE-A \(SKYACTIV-G 2.5T, SKYACTIV-D 2.2\)\]](#).) (See [CONTROLLER AREA NETWORK \(CAN\) MALFUNCTION DIAGNOSIS FLOW \[TYPE-B\]](#).)