

Your Ultimate Source for OEM Repair Manuals

FactoryManuals.net is a great resource for anyone who wants to save money on repairs by doing their own work. The manuals provide detailed instructions and diagrams that make it easy to understand how to fix a vehicle.

2012 MAZDA CX-5 OEM Service and Repair Workshop Manual

[Go to manual page](#)

DTC P0883:00 [TCM (FW6A-EL, FW6AX-EL)]

SM2898262

id0502o682010

DTC P0883:00	TCM power supply voltage high
DETECTION CONDITION	• TCM power supply voltage is 18 V or more for 5 s.
FAIL-SAFE FUNCTION	• Set to emergency mode. • Inhibits learning control. • Inhibits manual mode. • Inhibits neutral idle control. • Inhibits AAS.
POSSIBLE CAUSE	• PCM DTC is stored. • Battery malfunction • Generator malfunction
SYSTEM WIRING DIAGRAM	Not applicable

Diagnostic procedure

STEP	INSPECTION		ACTION
1	RECORD VEHICLE STATUS WHEN DTC WAS DETECTED TO UTILIZE WITH REPEATABILITY VERIFICATION Note • Recording can be facilitated using the screen capture of the PC function. • Record the freeze frame data/snap shot data.	–	Go to the next step.
2	VERIFY RELATED REPAIR INFORMATION AVAILABILITY • Verify related Service Bulletins and/or on-line repair information availability. • Is any related repair information available?	Yes	Perform repair or diagnosis according to the available repair information. • If the vehicle is not repaired, go to the next step.
		No	Go to the next step.
3	VERIFY PCM DTC • Perform the PCM DTC inspection using the M-MDS. (See ON-BOARD DIAGNOSTIC TEST [PCM (SKYACTIV-G 2.5 (WITHOUT CYLINDER DEACTIVATION))].) (See ON-BOARD DIAGNOSTIC TEST [PCM (SKYACTIV-G 2.5 (WITH CYLINDER DEACTIVATION))].) • Are any DTCs present?	Yes	Go to the applicable DTC inspection. (See DTC TABLE [PCM (SKYACTIV-G 2.5 (WITHOUT CYLINDER DEACTIVATION))] .) (See DTC TABLE [PCM (SKYACTIV-G 2.5 (WITH CYLINDER DEACTIVATION))] .)
		No	Go to the next step.

STEP	INSPECTION	ACTION	
3	VERIFY DTC TROUBLESHOOTING COMPLETED • Clear the DTC using the M-MDS. (See ON-BOARD DIAGNOSTIC SYSTEM DTC INSPECTION [TCM (FW6A-EL, FW6AX-EL)].) • Perform the following procedure to ensure that the DTC has been resolved: 1. Drive the vehicle for 1 s or more under the following condition: • Vehicle speed: 16 km/h {9.9 mph} or more • Perform the DTC inspection using the M-MDS. (See ON-BOARD DIAGNOSTIC SYSTEM DTC INSPECTION [TCM (FW6A-EL, FW6AX-EL)].) • Are any DTCs present?	Yes	Go to the applicable DTC inspection. (See ON-BOARD DIAGNOSTIC SYSTEM DTC TABLE [TCM (FW6A-EL, FW6AX-EL)] .)
		No	DTC troubleshooting completed.

Sample

DTC P0729:00 [TCM (FW6A-EL, FW6AX-EL)]

SM2898265

id0502o682200

DTC P0729:00	6GR incorrect ratio
DETECTION CONDITION	• In D position, 6GR, the following phenomenon occurs: — There is difference between turbine/input shaft speed and output shaft speed sensor speed for 230 to 1,980 ms (varies with ATF temperature and ECT) during shift-up. — There is difference between turbine/input shaft speed and output shaft speed sensor speed for 1,500 to 3,900 ms (varies with ATF temperature) while driving without shifting.
FAIL-SAFE FUNCTION	• Inhibits malfunctioning gear. • Limits engine torque. • Inhibits learning control. • Inhibits manual mode. • Inhibits neutral idle control. • Inhibits AAS.
POSSIBLE CAUSE	• ATF is less than specified value • Clutch burnt • Shift solenoid malfunction • ATF leakage from clutch circuit • Control valve body malfunction
SYSTEM WIRING DIAGRAM	Not applicable

Diagnostic procedure

STEP	INSPECTION	ACTION
1	VERIFY DTC OUTPUT STATUS • Are any the following DTCs displayed? — P0746:00, P0751:00, P0752:00, P0756:00, P0757:00, P0761:00, P0762:00, P0766:00, P0767:00, P0771:00, P0772:00, P1738:00, P1784:00	Yes Go to the applicable DTC inspection. (See ON-BOARD DIAGNOSTIC SYSTEM DTC TABLE [TCM (FW6A-EL, FW6AX-EL)] .)
		No Go to the next step.
2	INSPECT ATF LEVEL • Inspect the ATF level. (See AUTOMATIC TRANSAXLE FLUID (ATF) INSPECTION [FW6A-EL, FW6AX-EL].) • Is there any malfunction?	Yes Adjust the ATF level to the specification, then go to the next step. (See AUTOMATIC TRANSAXLE FLUID (ATF) ADJUSTMENT [FW6A-EL, FW6AX-EL] .)
		No Go to the next step.

STEP	INSPECTION	ACTION	
3	VERIFY DTC TROUBLESHOOTING COMPLETED • Clear the DTC using the M-MDS. (See ON-BOARD DIAGNOSTIC SYSTEM DTC INSPECTION [TCM (FW6A-EL, FW6AX-EL)].) • Perform the following procedure to ensure that the DTC has been resolved: 1. Switch the ignition ON (engine off or on). • Perform the DTC inspection using the M-MDS. (See ON-BOARD DIAGNOSTIC SYSTEM DTC INSPECTION [TCM (FW6A-EL, FW6AX-EL)].) • Are any DTCs present?	Yes	Go to the applicable DTC inspection. (See ON-BOARD DIAGNOSTIC SYSTEM DTC TABLE [TCM (FW6A-EL, FW6AX-EL)] .)
		No	DTC troubleshooting completed.

Sample

STEP	INSPECTION		ACTION
5	INSPECT SELECTOR LEVER COMPONENT GROUND CIRCUIT FOR OPEN CIRCUIT • Verify that the selector lever component connector is disconnected. • Inspect for continuity between selector lever component terminal H (wiring harness-side) and body ground. • Is there continuity?	Yes	Go to the next step.
		No	Refer to the wiring diagram and verify whether or not there is a common connector between selector lever component terminal H and body ground. If there is a common connector: • Determine the malfunctioning part by inspecting the common connector and the terminal for corrosion, damage, or pin disconnection, and the common wiring harness for an open circuit. • Repair or replace the malfunctioning part. If there is no common connector: • Repair or replace the wiring harness which has an open circuit. Go to Step 11.
6	INSPECT INSTRUMENT CLUSTER CONNECTOR CONDITION • Disconnect the instrument cluster connector. • Inspect for poor connection (such as damaged/pulled-out pins, corrosion). • Is there any malfunction?	Yes	Repair or replace the connector and/or terminals, then go to Step 11.
		No	Go to the next step.
7	INSPECT SELECTOR LEVER COMPONENT CIRCUIT FOR SHORT TO GROUND • Verify that the selector lever component and instrument cluster connectors are disconnected. • Inspect for continuity between the following terminals (wiring harness-side) and body ground: — Selector lever component terminal E — Selector lever component terminal C — Selector lever component terminal F • Is there continuity?	Yes	Refer to the wiring diagram and verify whether or not there is a common connector between the following terminals: • Selector lever component terminal E–Instrument cluster terminal H • Selector lever component terminal C–Instrument cluster terminal F • Selector lever component terminal F–Instrument cluster terminal G If there is a common connector: • Determine the malfunctioning part by inspecting the common connector and the terminal for corrosion, damage, or pin disconnection, and the common wiring harness for a short to ground. • Repair or replace the malfunctioning part. If there is no common connector: • Repair or replace the wiring harness which has a short to ground. Go to Step 11.
		No	Go to the next step.

DTC P0842:00 [TCM (FW6A-EL, FW6AX-EL)]

SM2898268

id0502o682260

DTC P0842:00	Oil pressure switch No.1 (Oil pressure switch B) stuck on
DETECTION CONDITION	• Under the following conditions, oil pressure switch No.1 stuck-on detected by combination of gear ratio malfunction and oil pressure switch pattern malfunction: — Engine is running. — ATF temperature is 20 °C {68 °F} or more. — There is no difference between vehicle speed signal from DSC HU/CM and output shaft speed sensor signal. — Turbine/input shaft speed sensor and output shaft speed sensor DTC is not recorded.
FAIL-SAFE FUNCTION	• Limits engine torque. • Inhibits learning control. • Inhibits manual mode. • Inhibits neutral idle control. • Inhibits AAS.
POSSIBLE CAUSE	• Oil pressure switch No.1 malfunction • TCM malfunction
SYSTEM WIRING DIAGRAM	Not applicable

Diagnostic procedure

STEP	INSPECTION		ACTION
1	VERIFY DTC OUTPUT STATUS • Is the DTC P1738:00 also present?	Yes	Go to the applicable DTC inspection. (See DTC P1738:00 [TCM (FW6A-EL, FW6AX-EL)] .)
		No	Go to the next step.
2	RECORD VEHICLE STATUS WHEN DTC WAS DETECTED TO UTILIZE WITH REPEATABILITY VERIFICATION Note • Recording can be facilitated using the screen capture of the PC function. • Record the freeze frame data/snap shot data.	–	Go to the next step.
3	VERIFY RELATED REPAIR INFORMATION AVAILABILITY • Verify related Service Bulletins and/or on-line repair information availability. • Is any related repair information available?	Yes	Perform repair or diagnosis according to the available repair information. • If the vehicle is not repaired, go to the next step.
		No	Go to the next step.

STEP	INSPECTION		ACTION
4	VERIFY THAT DTC IS PRESENT - Clear the DTC using the M-MDS. (See ON-BOARD DIAGNOSTIC SYSTEM DTC INSPECTION [TCM (FW6A-EL, FW6AX-EL)].) - Perform the following procedure to ensure that the DTC has been resolved: - Start the engine. - Verify that the ATF temperature is 20 °C (68 °F) or more. - Perform the DTC inspection using the M-MDS. (See ON-BOARD DIAGNOSTIC SYSTEM DTC INSPECTION [TCM (FW6A-EL, FW6AX-EL)].) - Is the DTC P0843:00 present?	Yes	Replace the oil pressure switch B, then go to the next step. (See OIL PRESSURE SWITCH REMOVAL/INSTALLATION [FW6A-EL, FW6AX-EL] .)
		No	DTC troubleshooting completed.
5	RE-PERFORM ON-BOARD DIAGNOSTIC TEST - Perform the following procedure to ensure that the DTC has been resolved: - Start the engine. - Verify that the ATF temperature is 20 °C (68 °F) or more. - Perform the on-board diagnostic test. (See ON-BOARD DIAGNOSTIC TEST MODE [TCM (FW6A-EL, FW6AX-EL)].) - Are any DTCs present?	Yes	Go to the applicable DTC inspection. (See ON-BOARD DIAGNOSTIC SYSTEM DTC TABLE [TCM (FW6A-EL, FW6AX-EL)] .)
		No	DTC troubleshooting completed.

STEP	INSPECTION	ACTION	
7	INSPECT TCM POWER SUPPLY CIRCUIT • Always reconnect all disconnected connectors. • Access the PID VPWR using the M-MDS. (See ON-BOARD DIAGNOSTIC SYSTEM PID/DATA MONITOR INSPECTION [TCM (FW6A-EL, FW6AX-EL)].) • Is the PID value B+?	Yes	Go to the next step. Inspect the AT 15 A fuse. • If the fuse is blown: — Refer to the wiring diagram and verify whether or not there is a common connector between AT 15 A fuse and TCM terminal A. If there is a common connector: • Determine the malfunctioning part by inspecting the common connector and the terminal for corrosion, damage, or pin disconnection, and the common wiring harness for a short to ground. • Repair or replace the malfunctioning part. If there is no common connector: • Repair or replace the wiring harness which has a short to ground. • Replace the fuse.
		No	• If the fuse is deteriorated: — Replace the malfunctioning fuse. • If the fuse is normal: — Refer to the wiring diagram and verify whether or not there is a common connector between battery positive terminal and TCM terminal A. If there is a common connector: • Determine the malfunctioning part by inspecting the common connector and the terminal for corrosion, damage, or pin disconnection, and the common wiring harness for an open circuit. • Repair or replace the malfunctioning part. If there is no common connector: • Repair or replace the wiring harness which has an open circuit. Go to the next step.

DTC P0780:00 [TCM (FW6A-EL, FW6AX-EL)]

SM2898272

id0502o682450

DTC P0780:00	Gear shifting malfunction
DETECTION CONDITION	• Gear ratio malfunction while in any gear 1st to 6th or clutch-slip DTC (P0729:00, P0731:00, P0732:00, P0733:00, P0734:00, P0735:00, P1728:00) occurs and vehicle is driven under gear ratio malfunction condition from fail-safe, or use of gear speeds in which clutch slip occurs is restricted. • Determined that vehicle may be in danger due to clutch not engaging by TCM direction according to signal from the oil pressure switch.
FAIL-SAFE FUNCTION	• Inhibits learning control. • Inhibits manual mode. • Inhibits neutral idle control. • Inhibits AAS.
POSSIBLE CAUSE	• ATF is less than specified value • On/off solenoid malfunction • Pressure control solenoid malfunction • Shift solenoid malfunction • Oil pressure switch circuit malfunction • Oil pressure switch malfunction • Clutch slippage • ATF leakage from clutch circuit • Control valve body malfunction
SYSTEM WIRING DIAGRAM	Not applicable

Diagnostic procedure

STEP	INSPECTION	ACTION	
1	VERIFY DTC OUTPUT STATUS • Are any the following DTCs displayed? — P0746:00, P0751:00, P0752:00, P0756:00, P0757:00, P0761:00, P0762:00, P0766:00, P0767:00, P0771:00, P0772:00, P0842:00, P0843:00, P0847:00, P0848:00, P0872:00, P0873:00, P0877:00, P0878:00, P1784:00	Yes	Go to the applicable DTC inspection. (See ON-BOARD DIAGNOSTIC SYSTEM DTC TABLE [TCM (FW6A-EL, FW6AX-EL)] .)
		No	Go to the next step.
2	INSPECT ATF LEVEL • Inspect the ATF level. (See AUTOMATIC TRANSAXLE FLUID (ATF) INSPECTION [FW6A-EL, FW6AX-EL] .) • Is there any malfunction?	Yes	Adjust the ATF level to the specification, then go to the next step. (See AUTOMATIC TRANSAXLE FLUID (ATF) ADJUSTMENT [FW6A-EL, FW6AX-EL] .)
		No	Go to the next step.