

Your Ultimate Source for OEM Repair Manuals


FactoryManuals.net is a great resource for anyone who wants to save money on repairs by doing their own work. The manuals provide detailed instructions and diagrams that make it easy to understand how to fix a vehicle.

2014 MAZDA Flair OEM Service and Repair Workshop Manual

[Go to manual page](#)

3.Remove the engine cover. (See [ENGINE COVER REMOVAL/INSTALLATION \[SKYACTIV-D 2.2\].](#))

4.Detach the clip.




ac5wzw00008862

5.Remove the bolt.

6.Disconnect the engine ground.


7.Remove the clip for the vehicle wiring harness connector.



ac5wzw00008863

8.Remove the bolts.


9.Set the PCM out of the way.



5.Remove the bolt.

6.Disconnect the engine ground.

7.Remove the clip for the vehicle wiring harness connector.



8.Remove the bolts.

9.Set the PCM out of the way.

10.Disconnect the connector.


REFRIGERANT PRESSURE SENSOR INSPECTION [FULL-AUTO AIR CONDITIONER]

SM2898685

id0740a181740

SKYACTIV-G 2.5 (WITH COOLANT CONTROL VALVE)

1. Install the manifold gauge. (See [MANIFOLD GAUGE SET CONNECTION](#).)
 2. Verify the high-pressure side reading of the manifold gauge.
 3. Measure the terminal voltage at PCM terminal 2AZ, 2AV and 2AI.
 4. Using the graph below, measure and verify the terminal voltages at 2AV.
 5. Follow the PCM inspection when measuring the other terminal voltages. (See [PCM INSPECTION \[SKYACTIV-G 2.5 \(WITH CYLINDER DEACTIVATION\)\]](#).)
- Terminal 2AZ: Approx. 5 V (Ignition switch ON)
 - Terminal 2AI: 1.0 V or less
- If each voltage is not normal, inspect the related wiring harness.
- If there is any malfunction, replace the related wiring harness.
 - If the wiring harness is normal, replace the refrigerant pressure sensor.



SKYACTIV-D 2.2

1. Install the manifold gauge. (See [MANIFOLD GAUGE SET CONNECTION](#).)
2. Verify the high-pressure side reading of the manifold gauge.
3. Measure the terminal voltage at PCM terminal 2BB, 2BH and 2BD.
4. Using the graph below, measure and verify the terminal voltages at 2BH.
5. Follow the PCM inspection when measuring the other terminal voltages. (See [PCM INSPECTION \[SKYACTIV-D 2.2\]](#).)

- Terminal 2BB: Approx. 5 V (Ignition switch ON)
 - Terminal 2BD: 1.0 V or less
- If each voltage is not normal, inspect the related wiring harness.
- If there is any malfunction, replace the related wiring harness.
 - If the wiring harness is normal, replace the refrigerant pressure sensor.

AIR INTAKE ACTUATOR INSPECTION [MANUAL AIR CONDITIONER]

SM2898689

id0740a280150

Caution

- If the lever position exceeds the operation range shown in the figure, the circuit in the actuator could be damaged. Always perform an actuator operation inspection with the lever movement within the range shown in the figure.

1.Disconnect the negative battery terminal. (See [NEGATIVE BATTERY TERMINAL DISCONNECTION/CONNECTION.](#))


2.Remove the following parts:

- (1)Glove compartment (See [GLOVE COMPARTMENT REMOVAL/INSTALLATION.](#))
- (2)Dashboard under cover (See [DASHBOARD UNDER COVER REMOVAL/INSTALLATION.](#))

3.Remove the air intake actuator. (See [AIR INTAKE ACTUATOR REMOVAL/INSTALLATION \[MANUAL AIR CONDITIONER\].](#))

4.Apply battery positive voltage and connect the ground to the air intake actuator terminals as indicated in the table below and verify the operation condition.

B+ Terminal	Ground Terminal	Operation
B	A	FRESH → RECIRCULATE
A	B	RECIRCULATE → FRESH




ac5uuw00005818

- If not as indicated in the table, replace the air intake actuator. (See [AIR INTAKE ACTUATOR REMOVAL/INSTALLATION \[MANUAL AIR CONDITIONER\].](#))

5.Verify that the resistance between terminals C and D, D and E matches the air intake actuator operation as shown in the graph.


5. Verify that the resistance between terminals B and C, C and A matches the airflow mode actuator operation as shown in the graph.



ac5uuw00012013

- If the operation condition and resistance are not normal, replace the airflow mode actuator. (See [AIRFLOW MODE ACTUATOR REMOVAL \[MANUAL AIR CONDITIONER\]](#).) (See [AIRFLOW MODE ACTUATOR INSTALLATION \[MANUAL AIR CONDITIONER\]](#).)

Terminal	Signal name	Connected to	Measurement condition	Voltage (V)	Inspection item (s)
L	+5V	- Air intake actuator - Air mix actuator - Airflow mode actuator	Under any condition	5.0	- Related wiring harness - Air intake actuator - Air mix actuator - Airflow mode actuator - Climate control unit: terminal voltage (R)
M	Evaporator temperature sensor input	Evaporator temperature sensor	Compared with temperature detected by evaporator temperature sensor	Refer to graph 1	- Related wiring harness - Evaporator temperature sensor - Climate control unit: terminal voltage (R)
N	Blower fan speed control	Blower fan controller	(See Blower Fan Speed Control Signal)		- Related wiring harness - Blower fan controller
O	—	—	—	—	—
P	—	—	—	—	—
Q	MS_CAN_H	CAN related module	Because this terminal is for communication, integrity determination by terminal voltage is not possible.		
R	Sensor GND	- Air intake actuator - Air mix actuator - Airflow mode actuator - Evaporator temperature sensor	Under any condition	1.0 or less	Related wiring harness
S	MS_CAN_L	CAN related module	Because this terminal is for communication, integrity determination by terminal voltage is not possible.		
T	GND	Body ground	Under any condition	1.0 or less	Related wiring harness
U	—	—	—	—	—
V	—	—	—	—	—
W	B+	ROOM 15 A fuse	Under any condition	B+	- Related wiring harness - ROOM 15 A fuse
X	IG2	Front body control module (FBCM)	Switch the ignition ON (engine off or on)	B+	Related wiring harness
			Switch the ignition off	1.0 or less	Front body control module (FBCM)



AIR MIX ACTUATOR REMOVAL/INSTALLATION [MANUAL AIR CONDITIONER]

SM2898692


id0740a280240

1. Disconnect the negative battery terminal. (See [NEGATIVE BATTERY TERMINAL DISCONNECTION/CONNECTION.](#))

2. Remove the following parts:

- (1) Passenger-side front scuff plate (See [FRONT SCUFF PLATE REMOVAL/INSTALLATION.](#))
- (2) Passenger-side front side trim (See [FRONT SIDE TRIM REMOVAL/INSTALLATION.](#))
- (3) Glove compartment (See [GLOVE COMPARTMENT REMOVAL/INSTALLATION.](#))
- (4) Dashboard under cover (See [DASHBOARD UNDER COVER REMOVAL/INSTALLATION.](#))
- (5) Lower decoration panel (See [DECORATION PANEL REMOVAL/INSTALLATION.](#))
- (6) Passenger-side lower panel (See [LOWER PANEL REMOVAL/INSTALLATION.](#))
- (7) Passenger-side front heat duct (See [FRONT HEAT DUCT REMOVAL/INSTALLATION.](#))

3. Disconnect the connector.



ac5uuw00007123

4. Remove the screws.

5. Remove the air mix actuator.


6. Install in the reverse order of removal.

AMBIENT TEMPERATURE SENSOR REMOVAL/INSTALLATION [MANUAL AIR CONDITIONER]

SM2898694

id0740a280320

1. Disconnect the negative battery terminal. (See [NEGATIVE BATTERY TERMINAL DISCONNECTION/CONNECTION.](#))
2. Remove the front bumper. (See [FRONT BUMPER REMOVAL/INSTALLATION.](#))
3. Disconnect the connector.



ac5uuw00007124

4. Detach the clip and remove the ambient temperature sensor.
5. Install in the reverse order of removal.
6. Perform the 360° view monitor system aiming. (With 360° view monitor system) (See [360°VIEW MONITOR SYSTEM AIMING.](#))