


# Your Ultimate Source for OEM Repair Manuals

FactoryManuals.net is a great resource for anyone who wants to save money on repairs by doing their own work. The manuals provide detailed instructions and diagrams that make it easy to understand how to fix a vehicle.

## 2015 Ford Taurus Service and Repair Manual

[Go to manual page](#)




E261423

[Click here to learn about symbols, color coding, and icons used in this manual.](#)


4. Lubricate the torque converter pilot hub with multi-purpose grease.

**Material** : Motorcraft® Multi-Purpose Grease Spray / XL-5-A (ESB-M1C93-B)



E184344


[Click here to learn about symbols, color coding, and icons used in this manual.](#)



[Click here to learn about symbols, color coding, and icons used in this manual.](#)

7. Install the bellhousing bolt.

**Torque** : 35 lb.ft (48 Nm)




[Click here to learn about symbols, color coding, and icons used in this manual.](#)

10. Using the Heavy Duty Floor Crane, lower the engine assembly into the installed position.

- Remove the Heavy Duty Floor Crane.


Use the General Equipment: Floor Crane



[Click here to learn about symbols, color coding, and icons used in this manual.](#)

11. **Remove Special Service Tool** : 303-F047 Lifting Bracket, Engine

13. Position the vent hose and attach the retainer.



[Click here to learn about symbols, color coding, and icons used in this manual.](#)

14. **NOTICE**


Only use hand tools when tightening the engine mount through bolts or damage to the engine mount-to-cylinder block bracket can occur.

Install the new LH (left-hand) engine mount through bolt.

**Torque** : 258 lb.ft (350 Nm)

16. Position the generator and install the bolts.

**Torque** : 35 lb.ft (47 Nm)




E283374

[Click here to learn about symbols, color coding, and icons used in this manual.](#)

17. Install the accessory drive belt tensioner and the bolt.


**Torque** : 35 lb.ft (47 Nm)



E283375

[Click here to learn about symbols, color coding, and icons used in this manual.](#)

19. Attach the transmission wiring harness retainer.




E335426

[Click here to learn about symbols, color coding, and icons used in this manual.](#)

**Vehicles equipped with dual generators**

21. Install new thermostat housing gaskets.





[Click here to learn about symbols, color coding, and icons used in this manual.](#)

23. 1. Install the generator and the fasteners.

**Torque** : 35 lb.ft (47 Nm)

2. Position the wiring harness and install the bolt.


**Torque** : 177 lb.in (20 Nm)

3. Connect the generator electrical connector.

4. Install the B+ wire and the nut.

**Torque** : 150 lb.in (17 Nm)

5. Position the wiring protective cover.



[Click here to learn about symbols, color coding, and icons used in this manual.](#)

25.
  1. Install the coolant hose and clamp.  
Use the General Equipment: Hose Clamp Remover/Installer
  2. Install the coolant hose and connect the quick release coupling.
  3. Install the coolant hose and clamp.  
Use the General Equipment: Hose Clamp Remover/Installer
  4. Install the coolant hose and clamps.  
Use the General Equipment: Hose Clamp Remover/Installer