

Your Ultimate Source for OEM Repair Manuals

FactoryManuals.net is a great resource for anyone who wants to save money on repairs by doing their own work. The manuals provide detailed instructions and diagrams that make it easy to understand how to fix a vehicle.

2015 Mazda 3 Service and Repair Manual

[Go to manual page](#)

| DTC | | System malfunction location | Fail-safe function | Drive cycle | Self test type*1 | Memory function | Page |
|---------------|------------------------------|---|--------------------|-------------|------------------|-----------------|--|
| M-MDS display | Air bag system warning light | | | | | | |
| B1127:55 | Illuminated | Configuration setting error (passenger-side side air bag module structural malfunction) | – | – | C, D | × | (See DTC B1126:55/B1127:55 [SAS CONTROL MODULE (TWO-STEP DEPLOYMENT CONTROL SYSTEM - US/CANADA/ISRAEL SPEC.)].) |
| B1128:11 | Illuminated | Driver-side curtain air bag module circuit short to body ground | – | – | C, D | × | (See DTC B1128:11/B1128:12/B1128:13/B1128:19/B1128:1A [SAS CONTROL MODULE (TWO-STEP DEPLOYMENT CONTROL SYSTEM - US/CANADA/ISRAEL SPEC.)].) |
| B1128:12 | Illuminated | Driver-side curtain air bag module circuit short to power supply | – | – | C, D | × | |
| B1128:13 | Illuminated | Driver-side curtain air bag module circuit open circuit or resistance high | – | – | C, D | × | |
| B1128:19 | Illuminated | Short circuit to driver-side curtain air bag module and other air bag module circuits | – | – | C, D | × | |
| B1128:1A | Illuminated | Driver-side curtain air bag module circuit resistance low | – | – | C, D | × | |
| B1128:55 | Illuminated | Configuration setting error (driver-side curtain air bag module structural malfunction) | – | – | C, D | × | (See DTC B1128:55/B1129:55 [SAS CONTROL MODULE (TWO-STEP DEPLOYMENT CONTROL SYSTEM - US/CANADA/ISRAEL SPEC.)].) |

| DTC | | System malfunction location | Fail-safe function | Drive cycle | Self test type*1 | Memory function | Page |
|---------------|------------------------------|--|--------------------|-------------|------------------|-----------------|--|
| M-MDS display | Air bag system warning light | | | | | | |
| B1206:00 | — | SAS control module collision judgement signal output (fuel cut off signal output) | — | — | C, D | × | (See DTC B1206:00/B143A:00/B1A55:00/U2107:00 [SAS CONTROL MODULE (TWO-STEP DEPLOYMENT CONTROL SYSTEM - US/CANADA/ISRAEL SPEC.)].) |
| B1211:11 | Illuminated | Driver-side front pre-tensioner seat belt circuit short to body ground | — | — | C, D | × | (See DTC B1211:11/B1211:12/B1211:13/B1211:19/B1211:1A [SAS CONTROL MODULE (TWO-STEP DEPLOYMENT CONTROL SYSTEM - US/CANADA/ISRAEL SPEC.)].) |
| B1211:12 | Illuminated | Driver-side front pre-tensioner seat belt circuit short to power supply | — | — | C, D | × | |
| B1211:13 | Illuminated | Driver-side front pre-tensioner seat belt circuit open circuit or resistance high | — | — | C, D | × | |
| B1211:19 | Illuminated | Short circuit to driver-side front pre-tensioner seat belt and other air bag module circuits | — | — | C, D | × | |
| B1211:1A | Illuminated | Driver-side front pre-tensioner seat belt circuit resistance low | — | — | C, D | × | |
| B1211:55 | Illuminated | Configuration setting error (driver-side front pre-tensioner seat belt structural malfunction) | — | — | C, D | × | (See DTC B1211:55, B1214:55 [SAS CONTROL MODULE (TWO-STEP DEPLOYMENT CONTROL SYSTEM - US/CANADA/ISRAEL SPEC.)].) |

| DTC | | System malfunction location | Fail-safe function | Drive cycle | Self test type*1 | Memory function | Page |
|---------------|------------------------------|--|--------------------|-------------|------------------|-----------------|--|
| M-MDS display | Air bag system warning light | | | | | | |
| B1228:11 | Illuminated | Driver-side lap pre-tensioner seat belt circuit short to body ground | – | – | C, D | × | (See DTC B1228:11/B1228:12/B1228:13/B1228:19/B1228:1A [SAS CONTROL MODULE (TWO-STEP DEPLOYMENT CONTROL SYSTEM - US/CANADA/ISRAEL SPEC.)].) |
| B1228:12 | Illuminated | Driver-side lap pre-tensioner seat belt circuit short to power supply | – | – | C, D | × | |
| B1228:13 | Illuminated | Driver-side lap pre-tensioner seat belt circuit open circuit or resistance high | – | – | C, D | × | |
| B1228:19 | Illuminated | Short circuit to driver-side lap pre-tensioner seat belt and other air bag module circuits | – | – | C, D | × | |
| B1228:1A | Illuminated | Driver-side lap pre-tensioner seat belt circuit resistance low | – | – | C, D | × | |
| B1228:55 | Illuminated | Configuration setting error (driver-side lap pre-tensioner seat belt structural malfunction) | – | – | C, D | × | (See DTC B0072:55/B1228:55 [SAS CONTROL MODULE (TWO-STEP DEPLOYMENT CONTROL SYSTEM - US/CANADA/ISRAEL SPEC.)].) |
| B1410:11 | Illuminated | Driver-side rear pre-tensioner seat belt circuit short to body ground | – | – | C, D | × | (See DTC B1410:11/B1410:12/B1410:13/B1410:19/B1410:1A [SAS CONTROL MODULE (TWO-STEP DEPLOYMENT CONTROL SYSTEM - US/CANADA/ISRAEL SPEC.)].) |
| B1410:12 | Illuminated | Driver-side rear pre-tensioner seat belt circuit short to power supply | – | – | C, D | × | |
| B1410:13 | Illuminated | Driver-side rear pre-tensioner seat belt circuit open circuit or resistance high | – | – | C, D | × | |
| B1410:19 | Illuminated | Short circuit to driver-side rear pre-tensioner seat belt and other air bag module circuits | – | – | C, D | × | |
| B1410:1A | Illuminated | Driver-side rear pre-tensioner seat belt circuit resistance low | – | – | C, D | × | |

| DTC | | System malfunction location | Fail-safe function | Drive cycle | Self test type*1 | Memory function | Page |
|---------------|------------------------------|--|--------------------|-------------|------------------|-----------------|---|
| M-MDS display | Air bag system warning light | | | | | | |
| B1A55:00 | — | SAS control module collision judgement signal output (collision detection signal for MAZDA ERA-GLONASS output) | — | — | C, D | × | (See DTC B1206:00/B143A:00/B1A55:00/U2107:00 [SAS CONTROL MODULE (TWO-STEP DEPLOYMENT CONTROL SYSTEM - US/CANADA/ISRAEL SPEC.)].) |
| C0061:29 | — | Low-G sensor (lateral-G) in SAS control module (internal circuit disabled) | — | — | C, D | × | (See DTC C0061:29/C0062:29/C0063:29 [SAS CONTROL MODULE (TWO-STEP DEPLOYMENT CONTROL SYSTEM - US/CANADA/ISRAEL SPEC.)].) |
| C0062:29 | — | Low-G sensor (forward-G) in SAS control module (internal circuit disabled) | — | — | C, D | × | |
| C0063:29 | — | Yaw rate sensor in SAS control module (internal circuit disabled) | — | — | C, D | × | |
| [P062F:49] | — | SAS control module internal malfunction | — | — | C, D | × | (See DTC P062F:49 [SAS CONTROL MODULE (TWO-STEP DEPLOYMENT CONTROL SYSTEM - US/CANADA/ISRAEL SPEC.)].) |
| U0001:88 | Illuminated | Unit communication error (HS-CAN) | — | — | C, D | × | (See DTC U0001:88/U0100:00/U0101:00/U0155:00 [SAS CONTROL MODULE (TWO-STEP DEPLOYMENT CONTROL SYSTEM - US/CANADA/ISRAEL SPEC.)].) |
| U0100:00 | Illuminated | Communication error with PCM | — | — | C, D | × | |
| U0101:00 | Illuminated | Communication error with TCM | — | — | C, D | × | |
| U0155:00 | Illuminated | Communication error with instrument cluster | — | — | C, D | × | |
| U2100:00 | Illuminated | Configuration not set | — | — | C, D | × | (See DTC U2100:00 [SAS CONTROL MODULE (TWO-STEP DEPLOYMENT CONTROL SYSTEM - US/CANADA/ISRAEL SPEC.)].) |
| U2107:00 | — | SAS control module collision judgement signal output (ESS signal output) | — | — | C, D | × | (See DTC B1206:00/B143A:00/B1A55:00/U2107:00 [SAS CONTROL MODULE (TWO-STEP DEPLOYMENT CONTROL SYSTEM - US/CANADA/ISRAEL SPEC.)].) |


DTC B0002:11/B0002:12/B0002:13/B0002:19/B0002:1A [SAS CONTROL MODULE (TWO-STEP DEPLOYMENT CONTROL SYSTEM - US/CANADA/ISRAEL SPEC.)]

SM3600729

id0802c900020

Special Service Tool (SST)

49 N088 0A0
Fuel and thermometer checker



| | |
|-----------------------------|--|
| System malfunction location | <ul style="list-style-type: none">• B0002:11:Driver-side air bag module (inflator No.2) circuit short to body ground• B0002:12:Driver-side air bag module (inflator No.2) circuit short to power supply• B0002:13:Driver-side air bag module (inflator No.2) circuit open circuit or resistance high• B0002:19:Short circuit to driver-side air bag module (inflator No.2) and other air bag module circuits• B0002:1A:Driver-side air bag module (inflator No.2) circuit resistance low |
| Detection condition | <p>Warning</p> <p>• Detection conditions are for understanding the DTC outline before performing an inspection. Performing an inspection according to only the detection conditions may cause injury due to an operating error, or damage the system. When performing an inspection, always follow the inspection procedure.</p> <ul style="list-style-type: none">• Resistance other than 1.37–6.33 ohms detected in the driver-side air bag module (inflator No.2) circuit• Malfunction in the wiring harness between the driver-side air bag module (inflator No.2) and SAS control module |
| Fail-safe function | Not applicable |
| Possible cause | <ul style="list-style-type: none">• Driver-side air bag module (inflator No.2) connector (clock spring-side) malfunction• Clock spring malfunction• Open circuit in the wiring harness between the following terminals:<ul style="list-style-type: none">— Driver-side air bag module (inflator No.2) terminal 7A–Clock spring terminal 2D— Driver-side air bag module (inflator No.2) terminal 7B–Clock spring terminal 2C— SAS control module terminal 3U–Clock spring terminal 2D— SAS control module terminal 3W–Clock spring terminal 2C• Short circuit to body ground in the wiring harness between the following terminals:<ul style="list-style-type: none">— SAS control module terminal 3U–Clock spring terminal 2D— SAS control module terminal 3W–Clock spring terminal 2C• Short circuit to power supply in the wiring harness between the following terminals:<ul style="list-style-type: none">— SAS control module terminal 3U–Clock spring terminal 2D— SAS control module terminal 3W–Clock spring terminal 2C• Short circuit to each other in the wiring harness between the clock spring and SAS control module• Short circuit to other air bag module circuits in the wiring harness between the clock spring and SAS control module• Driver-side air bag module malfunction• SAS control module malfunction |

| Step | Inspection | Action |
|------|---|---|
| 3 | <p>INSPECT DRIVER-SIDE AIR BAG MODULE (INFLATOR NO.2) CIRCUIT FOR SHORT TO GROUND</p> <ul style="list-style-type: none"> • Remove the glove compartment. (See GLOVE COMPARTMENT REMOVAL/INSTALLATION.) • Disconnect the passenger-side air bag module connectors. (See PASSENGER-SIDE AIR BAG MODULE REMOVAL/INSTALLATION [TWO-STEP DEPLOYMENT CONTROL SYSTEM - US/CANADA/ISRAEL SPEC.].) • Disconnect the driver and passenger-side front seat connectors. (See FRONT SEAT REMOVAL/INSTALLATION.) • Remove the B-pillar lower trim. (See B-PILLAR LOWER TRIM REMOVAL/INSTALLATION.) • Disconnect the driver and passenger-side front pre-tensioner seat belt connectors. (See FRONT SEAT BELT REMOVAL/INSTALLATION.) • Disconnect the driver and passenger-side lap pre-tensioner seat belt connectors. (See FRONT SEAT BELT REMOVAL/INSTALLATION.) • Disconnect the driver and passenger-side rear pre-tensioner seat belt connectors. (See REAR SEAT BELT REMOVAL/INSTALLATION.) • Remove the headliner. (See HEADLINER REMOVAL/INSTALLATION.) • Disconnect the driver and passenger-side curtain air bag module connectors. (See CURTAIN AIR BAG MODULE REMOVAL/INSTALLATION [TWO-STEP DEPLOYMENT CONTROL SYSTEM - US/CANADA/ISRAEL SPEC.].) • Disconnect the all SAS control module connectors. (See SAS CONTROL MODULE REMOVAL/INSTALLATION [TWO-STEP DEPLOYMENT CONTROL SYSTEM - US/CANADA/ISRAEL SPEC.].) • Inspect for continuity between the following terminals (wiring harness-side) and body ground: <ul style="list-style-type: none"> — SAS control module terminal 3U — SAS control module terminal 3W <p>Note</p> <ul style="list-style-type: none"> • Inspect for continuity while shaking the wiring harness between the SAS control module and clock spring. <p>• Is there continuity?</p> | <p>Yes</p> <p>Refer to the wiring diagram and verify whether or not there is a common connector between SAS control module terminal and clock spring terminal.</p> <p>If there is a common connector:</p> <ul style="list-style-type: none"> • Determine the malfunctioning part by inspecting the common connector and the terminal for corrosion, damage, or pin disconnection, and the common wiring harness for a short to ground. • Replace the malfunctioning part. <p>If there is no common connector:</p> <ul style="list-style-type: none"> • Replace the wiring harness which has a short to ground. <p>Go to Step 10.</p> |
| | <p>No</p> | <p>Go to the next step.</p> |

| Step | Inspection | Action | |
|------|---|--------|--|
| 9 | INSPECT DRIVER-SIDE AIR BAG MODULE (INFLATOR NO.2) <ul style="list-style-type: none"> • Switch the ignition off. • Disconnect the negative battery terminal and wait for 1 min or more. (See NEGATIVE BATTERY TERMINAL DISCONNECTION/CONNECTION.) • Connect the SAS control module connectors. • Except for the driver-side air bag module (inflator No.2) connector, reconnect all disconnected connectors. • Connect the SST (49 N088 0A0) or apply 2 ohms resistance to driver-side air bag module (inflator No.2) connector terminals 7A and 7B (clock spring-side). • Set the SST (49 N088 0A0) to 2 ohms. • Connect the negative battery terminal. (See NEGATIVE BATTERY TERMINAL DISCONNECTION/CONNECTION.) • Switch the ignition ON (engine off or on). • Clear the DTC for the SAS control module using the M-MDS. (See CLEARING DTC [SAS CONTROL MODULE (TWO-STEP DEPLOYMENT CONTROL SYSTEM - US/CANADA/ISRAEL SPEC.).]) • Perform the DTC inspection for the SAS control module using the M-MDS. (See DTC INSPECTION [SAS CONTROL MODULE (TWO-STEP DEPLOYMENT CONTROL SYSTEM - US/CANADA/ISRAEL SPEC.).]) • Are the same DTCs present? | Yes | Go to the next step. |
| | | No | Replace the driver-side air bag module. (See DRIVER-SIDE AIR BAG MODULE REMOVAL [TWO-STEP DEPLOYMENT CONTROL SYSTEM - US/CANADA/ISRAEL SPEC.].) (See DRIVER-SIDE AIR BAG MODULE INSTALLATION [TWO-STEP DEPLOYMENT CONTROL SYSTEM - US/CANADA/ISRAEL SPEC.].) Then go to the next step. |
| 10 | PERFORM SAS CONTROL MODULE DTC INSPECTION <ul style="list-style-type: none"> • Switch the ignition off. • Disconnect the negative battery terminal and wait for 1 min or more. (See NEGATIVE BATTERY TERMINAL DISCONNECTION/CONNECTION.) • Disconnect the SST (49 N088 0A0) or the 2 ohms resistance. • Connect the driver-side air bag module (inflator No.2) connector. (See DRIVER-SIDE AIR BAG MODULE INSTALLATION [TWO-STEP DEPLOYMENT CONTROL SYSTEM - US/CANADA/ISRAEL SPEC.].) • Connect the negative battery terminal. (See NEGATIVE BATTERY TERMINAL DISCONNECTION/CONNECTION.) • Switch the ignition ON (engine off or on). • Clear the DTC for the SAS control module using the M-MDS. (See CLEARING DTC [SAS CONTROL MODULE (TWO-STEP DEPLOYMENT CONTROL SYSTEM - US/CANADA/ISRAEL SPEC.).]) • Perform the DTC inspection for the SAS control module using the M-MDS. (See DTC INSPECTION [SAS CONTROL MODULE (TWO-STEP DEPLOYMENT CONTROL SYSTEM - US/CANADA/ISRAEL SPEC.).]) • Are the same DTCs present? | Yes | Repeat the inspection from Step 1. • If the malfunction recurs, replace the SAS control module. (See SAS CONTROL MODULE REMOVAL/INSTALLATION [TWO-STEP DEPLOYMENT CONTROL SYSTEM - US/CANADA/ISRAEL SPEC.].) |
| | | No | DTC troubleshooting completed. |

| Step | Inspection | Action | |
|------|---|--------|---|
| 2 | <p>INSPECT PASSENGER-SIDE AIR BAG MODULE (INFLATOR NO.2) CIRCUIT FOR SHORT TO GROUND</p> <ul style="list-style-type: none">• Remove the column cover. (See COLUMN COVER REMOVAL/INSTALLATION.)• Disconnect the clock spring connector. (See CLOCK SPRING REMOVAL/INSTALLATION [TWO-STEP DEPLOYMENT CONTROL SYSTEM - US/CANADA/ISRAEL SPEC.].)• Disconnect the passenger-side air bag module (inflator No.1) connector. (See PASSENGER-SIDE AIR BAG MODULE REMOVAL/INSTALLATION [TWO-STEP DEPLOYMENT CONTROL SYSTEM - US/CANADA/ISRAEL SPEC.].)• Disconnect the driver and passenger-side front seat connectors. (See FRONT SEAT REMOVAL/INSTALLATION.)• Remove the B-pillar lower trim. (See B-PILLAR LOWER TRIM REMOVAL/INSTALLATION.)• Disconnect the driver and passenger-side front pre-tensioner seat belt connectors. (See FRONT SEAT BELT REMOVAL/INSTALLATION.)• Disconnect the driver and passenger-side lap pre-tensioner seat belt connectors. (See FRONT SEAT BELT REMOVAL/INSTALLATION.)• Disconnect the driver and passenger-side rear pre-tensioner seat belt connectors. (See REAR SEAT BELT REMOVAL/INSTALLATION.)• Remove the headliner. (See HEADLINER REMOVAL/INSTALLATION.)• Disconnect the driver and passenger-side curtain air bag module connectors. (See CURTAIN AIR BAG MODULE REMOVAL/INSTALLATION [TWO-STEP DEPLOYMENT CONTROL SYSTEM - US/CANADA/ISRAEL SPEC.].)• Disconnect the all SAS control module connectors. (See SAS CONTROL MODULE REMOVAL/INSTALLATION [TWO-STEP DEPLOYMENT CONTROL SYSTEM - US/CANADA/ISRAEL SPEC.].)• Inspect for continuity between the following terminals (wiring harness-side) and body ground:<ul style="list-style-type: none">— SAS control module terminal 3AA— SAS control module terminal 3Z <p>Note</p> <ul style="list-style-type: none">• Inspect for continuity while shaking the wiring harness between the SAS control module and passenger-side air bag module (inflator No.2). <p>• Is there continuity?</p> | Yes | <p>Refer to the wiring diagram and verify whether or not there is a common connector between SAS control module terminal and passenger-side air bag module (inflator No.2) terminal.</p> <p>If there is a common connector:</p> <ul style="list-style-type: none">• Determine the malfunctioning part by inspecting the common connector and the terminal for corrosion, damage, or pin disconnection, and the common wiring harness for a short to ground.• Replace the malfunctioning part. <p>If there is no common connector:</p> <ul style="list-style-type: none">• Replace the wiring harness which has a short to ground. <p>Go to Step 8.</p> |
| | | No | Go to the next step. |

| Step | Inspection | | Action |
|------|--|-----|--|
| 7 | INSPECT PASSENGER-SIDE AIR BAG MODULE (INFLATOR NO.2) <ul style="list-style-type: none"> • Switch the ignition off. • Disconnect the negative battery terminal and wait for 1 min or more. (See NEGATIVE BATTERY TERMINAL DISCONNECTION/CONNECTION.) • Connect the SAS control module connectors. • Except for the passenger-side air bag module (inflator No.2) connector, reconnect all disconnected connectors. • Connect the SST (49 N088 0A0) or apply 2 ohms resistance to the passenger-side air bag module (inflator No.2) connector (wiring harness-side) terminals 2A and 2B. • Set the SST (49 N088 0A0) to 2 ohms. • Connect the negative battery terminal. (See NEGATIVE BATTERY TERMINAL DISCONNECTION/CONNECTION.) • Switch the ignition ON (engine off or on). • Clear the DTC for the SAS control module using the M-MDS. (See CLEARING DTC [SAS CONTROL MODULE (TWO-STEP DEPLOYMENT CONTROL SYSTEM - US/CANADA/ISRAEL SPEC.).]) • Perform the DTC inspection for the SAS control module using the M-MDS. (See DTC INSPECTION [SAS CONTROL MODULE (TWO-STEP DEPLOYMENT CONTROL SYSTEM - US/CANADA/ISRAEL SPEC.).]) • Are the same DTCs present? | Yes | Go to the next step. |
| | | No | Replace the passenger-side air bag module. (See PASSENGER-SIDE AIR BAG MODULE REMOVAL/INSTALLATION [TWO-STEP DEPLOYMENT CONTROL SYSTEM - US/CANADA/ISRAEL SPEC.).]) Then go to the next step. |
| 8 | PERFORM SAS CONTROL MODULE DTC INSPECTION <ul style="list-style-type: none"> • Switch the ignition off. • Disconnect the negative battery terminal and wait for 1 min or more. (See NEGATIVE BATTERY TERMINAL DISCONNECTION/CONNECTION.) • Disconnect the SST (49 N088 0A0) or the 2 ohms resistance. • Connect the passenger-side air bag module (inflator No.2) connector. (See PASSENGER-SIDE AIR BAG MODULE REMOVAL/INSTALLATION [TWO-STEP DEPLOYMENT CONTROL SYSTEM - US/CANADA/ISRAEL SPEC.).]) • Connect the negative battery terminal. (See NEGATIVE BATTERY TERMINAL DISCONNECTION/CONNECTION.) • Switch the ignition ON (engine off or on). • Clear the DTC for the SAS control module using the M-MDS. (See CLEARING DTC [SAS CONTROL MODULE (TWO-STEP DEPLOYMENT CONTROL SYSTEM - US/CANADA/ISRAEL SPEC.).]) • Perform the DTC inspection for the SAS control module using the M-MDS. (See DTC INSPECTION [SAS CONTROL MODULE (TWO-STEP DEPLOYMENT CONTROL SYSTEM - US/CANADA/ISRAEL SPEC.).]) • Are the same DTCs present? | Yes | Repeat the inspection from Step 1. • If the malfunction recurs, replace the SAS control module. (See SAS CONTROL MODULE REMOVAL/INSTALLATION [TWO-STEP DEPLOYMENT CONTROL SYSTEM - US/CANADA/ISRAEL SPEC.).]) |
| | | No | DTC troubleshooting completed. |