

# Your Ultimate Source for OEM Repair Manuals

FactoryManuals.net is a great resource for anyone who wants to save money on repairs by doing their own work. The manuals provide detailed instructions and diagrams that make it easy to understand how to fix a vehicle.

## 2016 Mazda 3 Service and Repair Manual

[Go to manual page](#)

# DTC U0515:68 [INSTRUMENT CLUSTER]

SM2898892

id0902e898800

Description	Error signal received from start stop unit
Detection condition	• Instrument cluster receives the error signals from the start stop unit with the ignition switched ON (engine off or on).
Fail-safe function	Not applicable
Possible cause	• DTCs are stored in the start stop unit. • Start stop unit malfunction • Instrument cluster malfunction
System wiring diagram	Not applicable

## Diagnostic Procedure

Step	Inspection	Action
1	<b>VERIFY START STOP UNIT DTCs</b> • Retrieve the start stop unit DTCs using the M-MDS. (See <b>DTC INSPECTION [START STOP UNIT].</b> ) • Are any DTCs displayed?	Yes Repair or replace the malfunctioning part according to the applicable DTC troubleshooting. (See <b>DTC TABLE [START STOP UNIT].</b> )
		No Go to the next step.
2	<b>VERIFY IF MALFUNCTIONING LOCATION IS START STOP UNIT DEPENDING ON REPEATABILITY</b> • Clear the DTC for the instrument cluster using the M-MDS. (See <b>CLEARING DTC [INSTRUMENT CLUSTER].</b> ) • Switch the ignition ON (engine off or on) and wait for 20 s or more. • Retrieve the instrument cluster DTCs using the M-MDS. (See <b>DTC INSPECTION [INSTRUMENT CLUSTER].</b> ) • Is the same DTC displayed?	Yes Replace the start stop unit, then go to the next step. (See <b>START STOP UNIT REMOVAL/INSTALLATION.</b> )
		No Go to Step 4.
3	<b>VERIFY THAT REPAIRS HAVE BEEN COMPLETED</b> • Clear the DTC for the instrument cluster using the M-MDS. (See <b>CLEARING DTC [INSTRUMENT CLUSTER].</b> ) • Switch the ignition ON (engine off or on) and wait for 20 s or more. • Retrieve the instrument cluster DTCs using the M-MDS. (See <b>DTC INSPECTION [INSTRUMENT CLUSTER].</b> ) • Is the same DTC displayed?	Yes Replace the instrument cluster, then go to the next step. (See <b>INSTRUMENT CLUSTER REMOVAL/INSTALLATION.</b> )
		No Go to the next step.
4	<b>VERIFY IF OTHER DTCs DISPLAYED</b> • Are any other DTCs displayed?	Yes Repair or replace the malfunctioning part according to the applicable DTC troubleshooting. (See <b>DTC TABLE [INSTRUMENT CLUSTER].</b> )
		No DTC troubleshooting completed.

# DTC U0402:68 [INSTRUMENT CLUSTER]

SM2898894

id0902e898890

Description	Error signal received from TCM
Detection condition	• Instrument cluster received the error signals from the TCM for 1 s or more with the ignition switched ON (engine off or on).
Fail-safe function	Not applicable
Possible cause	• The TCM could not send a normal signal temporarily. (DTCs are stored in the TCM.) • TCM malfunction • Instrument cluster malfunction
System wiring diagram	Not applicable

## Diagnostic Procedure

Step	Inspection	Action
1	<b>VERIFY TCM DTCs</b> • Retrieve the TCM DTCs using the M-MDS. (See <b>ON-BOARD DIAGNOSTIC SYSTEM DTC INSPECTION [TCM (GW6A-EL, GW6AX-EL)]</b> .) • Are any DTCs displayed?	Yes Repair or replace the malfunctioning part according to the applicable DTC troubleshooting. (See <b>ON-BOARD DIAGNOSTIC SYSTEM DTC TABLE [TCM (GW6A-EL, GW6AX-EL)]</b> .)
		No Go to the next step.
2	<b>DRIVE VEHICLE THEN VERIFY DTCs FOR TCM AGAIN</b> • Drive the vehicle at a vehicle speed of 30 km/h (19 mph) or more for 100 s or more. • Retrieve the TCM DTCs using the M-MDS. (See <b>ON-BOARD DIAGNOSTIC SYSTEM DTC INSPECTION [TCM (GW6A-EL, GW6AX-EL)]</b> .) • Are any DTCs displayed?	Yes Repair or replace the malfunctioning part according to the applicable DTC troubleshooting. (See <b>ON-BOARD DIAGNOSTIC SYSTEM DTC TABLE [TCM (GW6A-EL, GW6AX-EL)]</b> .)
		No Go to the next step.
3	<b>VERIFY THAT REPAIRS HAVE BEEN COMPLETED</b> • Clear the DTC for the instrument cluster using the M-MDS. (See <b>CLEARING DTC [INSTRUMENT CLUSTER]</b> .) • Switch the ignition ON (engine off or on) and wait for 20 s or more. • Retrieve the instrument cluster DTCs using the M-MDS. (See <b>DTC INSPECTION [INSTRUMENT CLUSTER]</b> .) • Is the same DTC displayed?	Yes Replace the instrument cluster, then go to the next step. (See <b>INSTRUMENT CLUSTER REMOVAL/INSTALLATION</b> .)
		No Go to the next step.
4	<b>VERIFY IF OTHER DTCs DISPLAYED</b> • Are any other DTCs displayed?	Yes Repair or replace the malfunctioning part according to the applicable DTC troubleshooting. (See <b>DTC TABLE [INSTRUMENT CLUSTER]</b> .)
		No DTC troubleshooting completed.

Step	Inspection		Action
5	<b>VERIFY INSTRUMENT CLUSTER POWER SUPPLY VOLTAGE</b> <ul style="list-style-type: none"><li>• Always reconnect all disconnected connectors.</li><li>• Connect the negative battery terminal. (See <b>NEGATIVE BATTERY TERMINAL DISCONNECTION/CONNECTION.</b>)</li><li>• Display the PID VPWR using the M-MDS. (See <b>PID/DATA MONITOR INSPECTION [INSTRUMENT CLUSTER].</b>)</li><li>• Is the voltage B+?</li></ul>	Yes	Go to the next step.

Sample

# DTC U3000:41 [INSTRUMENT CLUSTER]

SM2898896

id0902e899950

Description	Instrument cluster internal malfunction
Detection condition	• Instrument cluster detects the internal malfunction.
Fail-safe	Not applicable
Possible cause	• Instrument cluster malfunction
System wiring diagram	Not applicable

## Diagnostic Procedure

Step	Inspection	Action
1	<b>PERFORM DTC INSPECTION AND VERIFY INSTRUMENT CLUSTER MALFUNCTION</b> <ul style="list-style-type: none"><li>• Clear the DTC for the instrument cluster using the M-MDS. (See <b>CLEARING DTC [INSTRUMENT CLUSTER]</b>.)</li><li>• Retrieve the instrument cluster DTCs using the M-MDS. (See <b>DTC INSPECTION [INSTRUMENT CLUSTER]</b>.)</li><li>• Is the same Pending DTC present?</li></ul>	Yes Replace the instrument cluster, then go to the next step. (See <b>INSTRUMENT CLUSTER REMOVAL/INSTALLATION</b> .)
		No Go to the next step.
2	<b>VERIFY IF OTHER DTCs DISPLAYED</b> <ul style="list-style-type: none"><li>• Are any other DTCs displayed?</li></ul>	Yes Repair or replace the malfunctioning part according to the applicable DTC troubleshooting. (See <b>DTC TABLE [INSTRUMENT CLUSTER]</b> .)
		No DTC troubleshooting completed.

DTC U0001:88/U0100:00/U0101:00/U0151:00/U0155:00/U0214:00 [POSITION MEMORY CONTROL MODULE]

SM2898899

id0902o746880

Description	<ul style="list-style-type: none"><li>• U0001:88<ul style="list-style-type: none"><li>— Module communication error (HS-CAN)</li></ul></li><li>• U0100:00<ul style="list-style-type: none"><li>— Communication error with PCM</li></ul></li><li>• U0101:00<ul style="list-style-type: none"><li>— Communication error with TCM</li></ul></li><li>• U0151:00<ul style="list-style-type: none"><li>— Communication error with SAS control module</li></ul></li><li>• U0155:00<ul style="list-style-type: none"><li>— Communication error with instrument cluster</li></ul></li><li>• U0214:00<ul style="list-style-type: none"><li>— Communication error with start stop unit</li></ul></li></ul>
Detection condition	<ul style="list-style-type: none"><li>• U0001:88<ul style="list-style-type: none"><li>— Position memory control module (front seat) the CAN bus communication line (HS-CAN) malfunction</li></ul></li><li>• U0100:00<ul style="list-style-type: none"><li>— Position memory control module (front seat) could not receive the CAN signal from the PCM for 5 s or more with the ignition switched ON (engine off or on).</li></ul></li><li>• U0101:00<ul style="list-style-type: none"><li>— Position memory control module (front seat) could not receive the CAN signal from the TCM for 5 s or more with the ignition switched ON (engine off or on).</li></ul></li><li>• U0151:00<ul style="list-style-type: none"><li>— Position memory control module (front seat) could not receive the CAN signal from the SAS control module for 5 s or more with the ignition switched ON (engine off or on).</li></ul></li><li>• U0155:00<ul style="list-style-type: none"><li>— Position memory control module (front seat) could not receive the CAN signal from the instrument cluster for 5 s or more with the ignition switched ON (engine off or on).</li></ul></li><li>• U0214:00<ul style="list-style-type: none"><li>— Position memory control module (front seat) could not receive the CAN signal from the start stop unit for 5 s or more with the ignition switched ON (engine off or on).</li></ul></li></ul>


FOREWORD [POSITION MEMORY CONTROL MODULE]

SM2898900

id0902o796010

• If there is any vehicle malfunction complaint lodged by a customer, perform malfunction diagnosis according to the troubleshooting procedure. (See [Troubleshooting Procedure](#).)

Troubleshooting Procedure



# DTC TABLE [POSITION MEMORY CONTROL MODULE]

SM2898903

id0902o796050

×: Applicable –: Not applicable

DTC No.	Warning/indicator light	Description	Fail-safe	Drive cycle	Self test type*1	Memory function	Page
B1B87:13	–	Lift motor and position sensor circuit malfunction	×	–	C	×	(See DTC B1B87:13 [POSITION MEMORY CONTROL MODULE].)
B1B89:13	–	Slide motor and position sensor circuit malfunction	×	–	C	×	(See DTC B1B89:13 [POSITION MEMORY CONTROL MODULE].)
B1B91:13	–	Tilt motor and position sensor circuit malfunction	×	–	C	×	(See DTC B1B91:13 [POSITION MEMORY CONTROL MODULE].)
B1B93:13	–	Recliner motor and position sensor circuit malfunction	×	–	C	×	(See DTC B1B93:13 [POSITION MEMORY CONTROL MODULE].)
U0001:88	–	Module communication error (HS-CAN)	×	–	C	×	(See DTC U0001:88/U0100:00/U0101:00/U0151:00/U0155:00/U0214:00 [POSITION MEMORY CONTROL MODULE].)
U0100:00	–	Communication error with PCM	×	–	C	×	
U0101:00	–	Communication error with TCM	×	–	C	×	
U0151:00	–	Communication error with SAS control module	×	–	C	×	
U0155:00	–	Communication error with instrument cluster	×	–	C	×	
U0214:00	–	Communication error with start stop unit	×	–	C	×	
U3003:16	–	Position memory control module power supply voltage low input	–	–	C	×	(See DTC U3003:16 [POSITION MEMORY CONTROL MODULE].)

\*1:C: CMDTC self test, D: ODDTC self test



Sample

Step	Inspection	Action
3	<b>INSPECT TILT MOTOR AND POSITION SENSOR CIRCUIT FOR SHORT TO GROUND</b> <ul style="list-style-type: none"> <li>• Verify that the tilt motor and position sensor and position memory control module (front seat) connectors are disconnected.</li> <li>• Inspect for continuity between the following terminals (wiring harness-side) and body ground: <ul style="list-style-type: none"> <li>— Tilt motor and position sensor terminal B</li> <li>— Tilt motor and position sensor terminal D</li> <li>— Tilt motor and position sensor terminal F</li> <li>— Tilt motor and position sensor terminal H</li> </ul> </li> <li>• Is there continuity?</li> </ul>	Refer to the wiring diagram and verify whether or not there is a common connector between the following terminals: <ul style="list-style-type: none"> <li>• Position memory control module (front seat) terminal 3C–Tilt motor and position sensor terminal B</li> <li>• Position memory control module (front seat) terminal 3D–Tilt motor and position sensor terminal D</li> <li>• Position memory control module (front seat) terminal 3K–Tilt motor and position sensor terminal F</li> <li>• Position memory control module (front seat) terminal 3L–Tilt motor and position sensor terminal H</li> </ul> <b>If there is a common connector:</b> <ul style="list-style-type: none"> <li>• Determine the malfunctioning part by inspecting the common connector and the terminal for corrosion, damage, or pin disconnection, and the common wiring harness for a short to ground.</li> <li>• Repair or replace the malfunctioning part.</li> </ul> <b>If there is no common connector:</b> <ul style="list-style-type: none"> <li>• Repair or replace the wiring harness which has a short to ground.</li> </ul> Go to Step 9.
		No Go to the next step.
		Yes Go to the next step.
4	<b>INSPECT TILT MOTOR AND POSITION SENSOR CIRCUIT FOR SHORT TO POWER SUPPLY</b> <ul style="list-style-type: none"> <li>• Verify that the tilt motor and position sensor and position memory control module (front seat) connectors are disconnected.</li> <li>• Connect the negative battery terminal. (See <b>NEGATIVE BATTERY TERMINAL DISCONNECTION/CONNECTION.</b>)</li> <li>• Switch the ignition ON (engine off or on).</li> <li>• Measure the voltage at the following terminals (wiring harness-side): <ul style="list-style-type: none"> <li>— Tilt motor and position sensor terminal B</li> <li>— Tilt motor and position sensor terminal D</li> <li>— Tilt motor and position sensor terminal F</li> <li>— Tilt motor and position sensor terminal H</li> </ul> </li> <li>• Is the voltage 0 V?</li> </ul>	Refer to the wiring diagram and verify whether or not there is a common connector between the following terminals: <ul style="list-style-type: none"> <li>• Position memory control module (front seat) terminal 3C–Tilt motor and position sensor terminal B</li> <li>• Position memory control module (front seat) terminal 3D–Tilt motor and position sensor terminal D</li> <li>• Position memory control module (front seat) terminal 3K–Tilt motor and position sensor terminal F</li> <li>• Position memory control module (front seat) terminal 3L–Tilt motor and position sensor terminal H</li> </ul> <b>If there is a common connector:</b> <ul style="list-style-type: none"> <li>• Determine the malfunctioning part by inspecting the common connector and the terminal for corrosion, damage, or pin disconnection, and the common wiring harness for a short to power supply.</li> <li>• Repair or replace the malfunctioning part.</li> </ul> <b>If there is no common connector:</b> <ul style="list-style-type: none"> <li>• Repair or replace the wiring harness which has a short to power supply.</li> </ul> Go to Step 9.
		No Go to the next step.