

Your Ultimate Source for OEM Repair Manuals

FactoryManuals.net is a great resource for anyone who wants to save money on repairs by doing their own work. The manuals provide detailed instructions and diagrams that make it easy to understand how to fix a vehicle.

2016 MAZDA BT-50 OEM Service and Repair Workshop Manual

[Go to manual page](#)

Step	Inspection	Action	
2	INSPECT FRONT BODY CONTROL MODULE (FBCM) CONNECTOR CONDITION • Switch the ignition off. • Disconnect the negative battery terminal. (See NEGATIVE BATTERY TERMINAL DISCONNECTION/CONNECTION.) • Disconnect the front body control module (FBCM) connector. • Inspect the connector engagement and connection condition and inspect the terminals for damage, deformation, corrosion, or disconnection. • Is the connector normal?	Yes	Go to the next step.
		No	Repair or replace the connector, then go to Step 5.
3	INSPECT FRONT BODY CONTROL MODULE (FBCM) IG2 POWER SUPPLY OUTPUT CIRCUIT FOR SHORT TO GROUND • Verify that the front body control module (FBCM) connector is disconnected. • Inspect for continuity between front body control module (FBCM) terminal 1C (wiring harness-side) and body ground. • Is there continuity?	Yes	Go to the next step.
		No	Go to Step 5.
4	INSPECT IG2 POWER SUPPLY OUTPUT CIRCUIT RELATED PARTS • Inspect the following parts: — Climate control unit (See CLIMATE CONTROL UNIT INSPECTION [FULL-AUTO AIR CONDITIONER].) (See CLIMATE CONTROL UNIT INSPECTION [MANUAL AIR CONDITIONER].) — A/C relay (See RELAY INSPECTION.) — PTC heater (See PTC (POSITIVE TEMPERATURE COEFFICIENT) HEATER INSPECTION.) — Rear seat warmer control unit (With rear seat warmer) (See REAR SEAT WARMER CONTROL UNIT INSPECTION.) • Are all parts normal?	Yes	Refer to the wiring diagram and verify whether or not there is a common connector between the following: • Climate control unit–Front body control module (FBCM) terminal 1C • A/C relay–Front body control module (FBCM) terminal 1C • PTC heater–Front body control module (FBCM) terminal 1C • Rear seat warmer control unit–Front body control module (FBCM) terminal 1C (With seat warmer) If there is a common connector: • Determine the malfunctioning part by inspecting the common connector and the terminal for corrosion, damage, or pin disconnection, and the common wiring harness for a short to ground. • Repair or replace the malfunctioning part. If there is no common connector: • Repair or replace the wiring harness which has a short to ground. Go to the next step.
		No	Repair or replace the malfunctioning part, then go to the next step. (See CLIMATE CONTROL UNIT REMOVAL/INSTALLATION [FULL-AUTO AIR CONDITIONER].) (See CLIMATE CONTROL UNIT REMOVAL/INSTALLATION [MANUAL AIR CONDITIONER].) (See RELAY LOCATION.) (See PTC (POSITIVE TEMPERATURE COEFFICIENT) HEATER REMOVAL/INSTALLATION.) (See REAR SEAT WARMER CONTROL UNIT REMOVAL/INSTALLATION.)


Step	Inspection	Action	
2	INSPECT TNS RELAY - Switch the ignition off. - Disconnect the negative battery terminal. (See NEGATIVE BATTERY TERMINAL DISCONNECTION/CONNECTION.) - Remove the TNS relay. (See RELAY LOCATION.) - Inspect the TNS relay. (See RELAY INSPECTION.) - Is the TNS relay normal?	Yes	Go to the next step.
		No	Replace the TNS relay, then go to Step 5. (See RELAY LOCATION.)
3	INSPECT FRONT BODY CONTROL MODULE (FBCM) CONNECTOR CONDITION - Disconnect the front body control module (FBCM) connector. - Inspect the connector engagement and connection condition and inspect the terminals for damage, deformation, corrosion, or disconnection. - Is the connector normal?	Yes	Go to the next step.
		No	Repair or replace the connector, then go to Step 5.
4	INSPECT FOR SHORT TO GROUND IN TNS RELAY CONTROL CIRCUIT - Verify that the TNS relay is removed. - Verify that the front body control module (FBCM) connector is disconnected. - Inspect for continuity between front body control module (FBCM) terminal 11 (wiring harness-side) and body ground. - Is there continuity?	Yes	Refer to the wiring diagram and verify whether or not there is a common connector between TNS relay terminal E and front body control module (FBCM) terminal 11. If there is a common connector: - Determine the malfunctioning part by inspecting the common connector and the terminal for corrosion, damage, or pin disconnection, and the common wiring harness for a short to ground. - Repair or replace the malfunctioning part. If there is no common connector: - Repair or replace the wiring harness which has a short to ground. Go to the next step.
		No	Go to the next step.
5	VERIFY THAT REPAIRS HAVE BEEN COMPLETED - Always reconnect all disconnected connectors. - Reconnect the negative battery terminal. (See NEGATIVE BATTERY TERMINAL DISCONNECTION/CONNECTION.) - Clear the DTC for the front body control module (FBCM) using the M-MDS. (See CLEARING DTC [FRONT BODY CONTROL MODULE (FBCM)].) - Operate the light switch to the TNS position. - Retrieve the front body control module (FBCM) DTCs using the M-MDS. (See DTC INSPECTION [FRONT BODY CONTROL MODULE (FBCM)].) - Is the same DTC displayed?	Yes	Repeat the inspection from Step 1. • If the malfunction recurs, replace the front body control module (FBCM). (See FRONT BODY CONTROL MODULE (FBCM) REMOVAL/INSTALLATION.) Go to the next step.
		No	Go to the next step.
6	VERIFY IF OTHER DTCs DISPLAYED Are any other DTCs displayed?	Yes	Repair or replace the malfunctioning part according to the applicable DTC troubleshooting. (See DTC TABLE [FRONT BODY CONTROL MODULE (FBCM)].)
		No	DTC troubleshooting completed.

DTC B13D2:12 [FRONT BODY CONTROL MODULE (FBCM)]

SM2898966

id0902p200870

Description	Front fog light relay circuit malfunction
Detection condition	• Front body control module (FBCM) detects a short to power supply in the front fog light relay circuit with the ignition switched ON (engine off or on).
Fail-safe	Not applicable
Possible cause	• Front fog light relay malfunction • Front body control module (FBCM) connector or terminal malfunction • Short to power supply in wiring harness between front fog light relay terminal E and front body control module (FBCM) terminal 2AB • Front body control module (FBCM) malfunction



Diagnostic Procedure

Step	Inspection	Action
1	VERIFY FRONT BODY CONTROL MODULE (FBCM) DTCs AGAIN • Clear the DTC for the front body control module (FBCM) using the M-MDS. (See CLEARING DTC [FRONT BODY CONTROL MODULE (FBCM)] .) • Operate the light switch to the HEAD position and the fog light switch to the F.FOG position. • Retrieve the front body control module (FBCM) DTCs using the M-MDS. (See DTC INSPECTION [FRONT BODY CONTROL MODULE (FBCM)] .) • Is the same DTC displayed?	Yes Go to the next step.
		No Go to Step 6.

Step	Inspection		Action
2	INSPECT HEADLIGHT LO RELAY No.1 • Switch the ignition off. • Disconnect the negative battery terminal. (See NEGATIVE BATTERY TERMINAL DISCONNECTION/CONNECTION.) • Remove the headlight LO relay No.1. (See RELAY LOCATION.) • Inspect the headlight LO relay No.1. (See RELAY INSPECTION.) • Is the headlight LO relay No.1 normal?	Yes	Go to the next step.
		No	Replace the headlight LO relay No.1, then go to Step 5. (See RELAY LOCATION.)
3	INSPECT FRONT BODY CONTROL MODULE (FBCM) CONNECTOR CONDITION • Disconnect the front body control module (FBCM) connector. • Inspect the connector engagement and connection condition and inspect the terminals for damage, deformation, corrosion, or disconnection. • Is the connector normal?	Yes	Go to the next step.
		No	Repair or replace the connector, then go to Step 5.
4	INSPECT FOR SHORT TO POWER SUPPLY IN HEADLIGHT LO RELAY No.1 CONTROL CIRCUIT • Verify that the headlight LO relay No.1 is removed. • Verify that the front body control module (FBCM) connector is disconnected. • Reconnect the negative battery terminal. (See NEGATIVE BATTERY TERMINAL DISCONNECTION/CONNECTION.) • Switch the ignition ON (engine off or on). • Measure the voltage at the front body control module (FBCM) terminal 2V (wiring harness-side). • Is the voltage 0 V?	Yes	Go to the next step.
		No	Refer to the wiring diagram and verify whether or not there is a common connector between headlight LO relay No.1 terminal A and front body control module (FBCM) terminal 2V. If there is a common connector: • Determine the malfunctioning part by inspecting the common connector and the terminal for corrosion, damage, or pin disconnection, and the common wiring harness for a short to power supply. • Repair or replace the malfunctioning part. If there is no common connector: • Repair or replace the wiring harness which has a short to power supply. Go to the next step.
5	VERIFY THAT REPAIRS HAVE BEEN COMPLETED • Always reconnect all disconnected connectors. • Connect the negative battery terminal. (See NEGATIVE BATTERY TERMINAL DISCONNECTION/CONNECTION.) • Clear the DTC for the front body control module (FBCM) using the M-MDS. (See CLEARING DTC [FRONT BODY CONTROL MODULE (FBCM)].) • Operate the light switch to the HEAD position. • Retrieve the front body control module (FBCM) DTCs using the M-MDS. (See DTC INSPECTION [FRONT BODY CONTROL MODULE (FBCM)].) • Is the same DTC displayed?	Yes	Repeat the inspection from Step 1. • If the malfunction recurs, replace the front body control module (FBCM). (See FRONT BODY CONTROL MODULE (FBCM) REMOVAL/INSTALLATION.) Go to the next step.
		No	Go to the next step.
6	VERIFY IF OTHER DTCs DISPLAYED • Are any other DTCs displayed?	Yes	Repair or replace the malfunctioning part according to the applicable DTC troubleshooting. (See DTC TABLE [FRONT BODY CONTROL MODULE (FBCM)].)
		No	DTC troubleshooting completed.

Step	Inspection	Action
6	VERIFY THAT REPAIRS HAVE BEEN COMPLETED • Always reconnect all disconnected connectors. • Connect the negative battery terminal. (See NEGATIVE BATTERY TERMINAL DISCONNECTION/CONNECTION.) • Clear the DTC for the front body control module (FBCM) using the M-MDS. (See CLEARING DTC [FRONT BODY CONTROL MODULE (FBCM)].) • Operate the light switch to the OFF position. • Retrieve the front body control module (FBCM) DTCs using the M-MDS. (See DTC INSPECTION [FRONT BODY CONTROL MODULE (FBCM)].) • Is the same DTC displayed?	Yes Repeat the inspection from Step 1. • If the malfunction recurs, replace the front body control module (FBCM). (See FRONT BODY CONTROL MODULE (FBCM) REMOVAL/INSTALLATION.) Go to the next step.
		No Go to the next step.
7	VERIFY IF OTHER DTCs DISPLAYED • Are any other DTCs displayed?	Yes Repair or replace the malfunctioning part according to the applicable DTC troubleshooting. (See DTC TABLE [FRONT BODY CONTROL MODULE (FBCM)].)
		No DTC troubleshooting completed.

Step	Inspection	Action	
5	VERIFY THAT REPAIRS HAVE BEEN COMPLETED • Always reconnect all disconnected connectors. • Connect the negative battery terminal. (See NEGATIVE BATTERY TERMINAL DISCONNECTION/CONNECTION.) • Clear the DTC for the front body control module (FBCM) using the M-MDS. (See CLEARING DTC [FRONT BODY CONTROL MODULE (FBCM)].) • Operate the rear window defogger by pushing the rear window defogger switch. • Retrieve the front body control module (FBCM) DTCs using the M-MDS. (See DTC INSPECTION [FRONT BODY CONTROL MODULE (FBCM)].) • Is the same DTC displayed?	Yes	Repeat the inspection from Step 1. • If the malfunction recurs, replace the front body control module (FBCM). (See FRONT BODY CONTROL MODULE (FBCM) REMOVAL/INSTALLATION.) Go to the next step.
		No	Go to the next step.
6	VERIFY IF OTHER DTCs DISPLAYED • Are any other DTCs displayed?	Yes	Repair or replace the malfunctioning part according to the applicable DTC troubleshooting. (See DTC TABLE [FRONT BODY CONTROL MODULE (FBCM)].)
		No	DTC troubleshooting completed.

Step	Inspection	Action
6	VERIFY THAT REPAIRS HAVE BEEN COMPLETED • Always reconnect all disconnected connectors. • Connect the negative battery terminal. (See NEGATIVE BATTERY TERMINAL DISCONNECTION/CONNECTION.) • Clear the DTC for the front body control module (FBCM) using the M-MDS. (See CLEARING DTC [FRONT BODY CONTROL MODULE (FBCM)].) • Retrieve the front body control module (FBCM) DTCs using the M-MDS. (See DTC INSPECTION [FRONT BODY CONTROL MODULE (FBCM)].) • Is the same DTC displayed?	Yes Repeat the inspection from Step 1. • If the malfunction recurs, replace the front body control module (FBCM). (See FRONT BODY CONTROL MODULE (FBCM) REMOVAL/INSTALLATION.) Go to the next step.
		No Go to the next step.
7	VERIFY IF OTHER DTCs DISPLAYED • Are any other DTCs displayed?	Yes Repair or replace the malfunctioning part according to the applicable DTC troubleshooting. (See DTC TABLE [FRONT BODY CONTROL MODULE (FBCM)].)
		No DTC troubleshooting completed.

DTC U3000:49 [FRONT BODY CONTROL MODULE (FBCM)]


SM2898983

id0902p201140

Description	Front body control module (FBCM) internal malfunction
Detection condition	• Front body control module (FBCM) detects the internal malfunction.
Fail-safe	Not applicable
Possible cause	• Front body control module (FBCM) malfunction
System wiring diagram	Not applicable

Diagnostic Procedure

Step	Inspection	Action	
1	VERIFY IF MALFUNCTIONING LOCATION IS FRONT BODY CONTROL MODULE (FBCM) DEPENDING ON REPEATABILITY • Clear the DTC for the front body control module (FBCM) using the M-MDS. (See CLEARING DTC [FRONT BODY CONTROL MODULE (FBCM)] .) • Retrieve the front body control module (FBCM) DTCs using the M-MDS. (See DTC INSPECTION [FRONT BODY CONTROL MODULE (FBCM)] .) • Is the same DTC displayed?	Yes	Replace the front body control module (FBCM), then go to the next step. (See FRONT BODY CONTROL MODULE (FBCM) REMOVAL/INSTALLATION .)
		No	Go to the next step.
2	VERIFY IF OTHER DTCs DISPLAYED • Are any other DTCs displayed?	Yes	Repair or replace the malfunctioning part according to the applicable DTC troubleshooting. (See DTC TABLE [FRONT BODY CONTROL MODULE (FBCM)] .)
		No	DTC troubleshooting completed.



Diagnostic Procedure

Step	Inspection	Action	
1	VERIFY FRONT BODY CONTROL MODULE (FBCM) DTCs AGAIN • Clear the DTC for the front body control module (FBCM) using the M-MDS. (See CLEARING DTC [FRONT BODY CONTROL MODULE (FBCM)].) • Switch the ignition ON (engine off or on) and wait for 10 s or more. • Retrieve the front body control module (FBCM) DTCs using the M-MDS. (See DTC INSPECTION [FRONT BODY CONTROL MODULE (FBCM)].) • Is the same DTC displayed?	Yes	Go to the next step.
		No	Go to Step 8.