

Your Ultimate Source for OEM Repair Manuals

FactoryManuals.net is a great resource for anyone who wants to save money on repairs by doing their own work. The manuals provide detailed instructions and diagrams that make it easy to understand how to fix a vehicle.

2017 FORD Fiesta Sedan OEM Service and Repair Workshop Manual

[Go to manual page](#)

No

If the PCM (powertrain control module) does not communicate with the scan tool, REFER to: [Controller Area Network \(CAN\) Module Communications Network](#) (418-00A Controller Area Network (CAN) Module Communications Network, Diagnosis and Testing).
Otherwise, the system is operating properly at this time. The DTC (diagnostic trouble code) may have been set previously during battery charging or while jump starting the vehicle.

PINPOINT TEST L : P0729

Normal Operation and Fault Conditions

The PCM (powertrain control module) monitors clutch applications for all gears. It sets a DTC (diagnostic trouble code) if it detects a ratio error but is unable to detect which clutch caused the issue. The transmission logic disables the gear in question. If multiple incorrect gear ratio diagnostic trouble codes (DTCs) are set, look for a common clutch involved in the operation of those gear applications. If no common clutch errors are found, look for a line pressure or pump pressure concern.

DTC Fault Trigger Conditions

DTC (diagnostic trouble code)	Description	Fault Trigger Condition
PCM (powertrain control module) P0729:00	Gear 6 Incorrect Ratio: No Sub Type Information	This DTC (diagnostic trouble code) indicates a gear ratio error either in or while shifting to 6th gear. The fault did not last long enough to set a more specific DTC (diagnostic trouble code) . The failsafe logic disables 6th gear for the remainder of the key cycle during which the fault occurred.

Possible Sources

- Transmission fluid contamination
- Low line pressure
- D clutch stuck off
- C clutch stuck on
- A clutch slipping
- E clutch slipping
- F clutch slipping

L1 CHECK THE PCM (POWERTRAIN CONTROL MODULE) FOR DTC (DIAGNOSTIC TROUBLE CODE) P0729

(DTCs) are set, look for a common clutch involved in the operation of those gear applications. If no common clutch errors are found, look for a line pressure or pump pressure concern.

DTC Fault Trigger Conditions

DTC (diagnostic trouble code)	Description	Fault Trigger Condition
PCM (powertrain control module) P0731:00	Gear 1 Incorrect Ratio: No Sub Type Information	This DTC (diagnostic trouble code) indicates a gear ratio error either in or while shifting to 1st gear. The fault did not last long enough to set a more specific DTC (diagnostic trouble code) . The failsafe logic disables 1st gear for the remainder of the key cycle during which the fault occurred.

Possible Sources

- Transmission fluid contamination
- Low line pressure
- A clutch stuck off or slipping
- D clutch stuck off or slipping
- E clutch stuck off or slipping
- Low one-way clutch slipping or damaged

M1 CHECK THE PCM (POWERTRAIN CONTROL MODULE) FOR DTC (DIAGNOSTIC TROUBLE CODE) P0731

- Ignition ON.
- Using a diagnostic scan tool, clear all diagnostic trouble codes (DTCs) from the PCM (powertrain control module) .
- Road test the vehicle.
- Using a diagnostic scan tool, retrieve all continuous memory diagnostic trouble codes (CMDTCs) from the PCM (powertrain control module) .

Is DTC (diagnostic trouble code) P0731 present in the PCM (powertrain control module) ?

Yes	<p>Check the A clutch for a does not apply or a slipping condition. REFER to: A Clutch (307-01A Automatic Transmission - 10-Speed Automatic Transmission – 10R80, Diagnosis and Testing).</p> <p>Check the D clutch for a does not apply or a slipping condition. REFER to: D Clutch (307-01A Automatic Transmission - 10-Speed Automatic Transmission – 10R80, Diagnosis and Testing).</p> <p>Check the E clutch for a does not apply or a slipping.</p>
------------	---

- Low one-way clutch slipping or damaged

N1 CHECK THE PCM (POWERTRAIN CONTROL MODULE) FOR DTC (DIAGNOSTIC TROUBLE CODE) P0732

- Ignition ON.
- Using a diagnostic scan tool, clear all diagnostic trouble codes (DTCs) from the PCM (powertrain control module) .
- Road test the vehicle.
- Using a diagnostic scan tool, retrieve all continuous memory diagnostic trouble codes (CMDTCs) from the PCM (powertrain control module) .

Is DTC (diagnostic trouble code) P0732 present in the PCM (powertrain control module) ?

<p>Yes</p>	<p>Check the C clutch for a does not apply or a slipping condition. REFER to: C Clutch (307-01A Automatic Transmission - 10-Speed Automatic Transmission – 10R80, Diagnosis and Testing).</p> <p>Check the E clutch for an always applied condition. REFER to: E Clutch (307-01A Automatic Transmission - 10-Speed Automatic Transmission – 10R80, Diagnosis and Testing).</p> <p>Check the A clutch for a slipping condition. REFER to: A Clutch (307-01A Automatic Transmission - 10-Speed Automatic Transmission – 10R80, Diagnosis and Testing).</p> <p>Check the D clutch for a slipping condition. REFER to: D Clutch (307-01A Automatic Transmission - 10-Speed Automatic Transmission – 10R80, Diagnosis and Testing).</p> <p>Check the low one-way clutch for a slipping condition. REFER to: Low One-Way Clutch Assembly (307-01A Automatic Transmission - 10-Speed Automatic Transmission – 10R80, Diagnosis and Testing).</p>
-------------------	---

<p>No</p>	<p>The fault is not present at this time and may be intermittent.</p>
------------------	---

PINPOINT TEST O : P0733

Check the A clutch for a slipping condition.

REFER to: [A Clutch](#)

(307-01A Automatic Transmission - 10-Speed Automatic Transmission – 10R80, Diagnosis and Testing).

Check the C clutch for a slipping condition.

REFER to: [C Clutch](#)

(307-01A Automatic Transmission - 10-Speed Automatic Transmission – 10R80, Diagnosis and Testing).

Check the D clutch for a slipping condition.

REFER to: [D Clutch](#)

(307-01A Automatic Transmission - 10-Speed Automatic Transmission – 10R80, Diagnosis and Testing).

Check the low one-way clutch for a seized condition.

REFER to: [Low One-Way Clutch Assembly](#)

(307-01A Automatic Transmission - 10-Speed Automatic Transmission – 10R80, Diagnosis and Testing).

No

The fault is not present at this time and may be intermittent.

PINPOINT TEST P : P0734

Normal Operation and Fault Conditions

The PCM (powertrain control module) monitors clutch applications for all gears. It sets a DTC (diagnostic trouble code) if it detects a ratio error but is unable to detect which clutch caused the issue. The transmission logic disables the gear in question. If multiple incorrect gear ratio diagnostic trouble codes (DTCs) are set, look for a common clutch involved in the operation of those gear applications. If no common clutch errors are found, look for a line pressure or pump pressure concern.

DTC Fault Trigger Conditions

DTC (diagnostic trouble code)	Description	Fault Trigger Condition
PCM (powertrain control module) P0734:00	Gear 4 Incorrect Ratio: No Sub Type Information	This DTC (diagnostic trouble code) indicates a gear ratio error either in or while shifting to 4th gear. The fault did not last long enough to set a more specific DTC (diagnostic trouble code) . The failsafe logic disables 4th gear for the remainder of the key cycle during which the fault occurred.

No

The fault is not present at this time and may be intermittent.

PINPOINT TEST Q : P0735**Normal Operation and Fault Conditions**

The PCM (powertrain control module) monitors clutch applications for all gears. It sets a DTC (diagnostic trouble code) if it detects a ratio error but is unable to detect which clutch caused the issue. The transmission logic disables the gear in question. If multiple incorrect gear ratio diagnostic trouble codes (DTCs) are set, look for a common clutch involved in the operation of those gear applications. If no common clutch errors are found, look for a line pressure or pump pressure concern.

DTC Fault Trigger Conditions

DTC (diagnostic trouble code)	Description	Fault Trigger Condition
PCM (powertrain control module) P0735:00	Gear 5 Incorrect Ratio: No Sub Type Information	This DTC (diagnostic trouble code) indicates a gear ratio error either in or while shifting to 5th gear. The fault did not last long enough to set a more specific DTC (diagnostic trouble code) . The failsafe logic disables 5th gear for the remainder of the key cycle during which the fault occurred.

Possible Sources

- Transmission fluid contamination
- Low line pressure
- E clutch stuck off or slipping
- D clutch stuck on
- A clutch slipping
- C clutch slipping
- F clutch slipping

Q1 CHECK THE PCM (POWERTRAIN CONTROL MODULE) FOR DTC (DIAGNOSTIC TROUBLE CODE) P0735

- Ignition ON.
- Using a diagnostic scan tool, clear all diagnostic trouble codes (DTCs) from the PCM (powertrain control module) .
- Road test the vehicle.

DTC (diagnostic trouble code)	Description	Fault Trigger Condition
PCM (powertrain control module) P0736:00	Reverse Incorrect Ratio: No Sub Type Information	This DTC (diagnostic trouble code) indicates a gear ratio error either in or while shifting to reverse. The fault did not last long enough to set a more specific DTC (diagnostic trouble code) . The failsafe logic disables reverse for the remainder of the key cycle during which the fault occurred.

Possible Sources

- Transmission fluid contamination
- Low line pressure
- A clutch stuck off or slipping
- B clutch stuck off or slipping
- D clutch stuck off or slipping
- F clutch stuck off or slipping

R1 CHECK THE PCM (POWERTRAIN CONTROL MODULE) FOR DTC (DIAGNOSTIC TROUBLE CODE) P0736

- Ignition ON.
- Using a diagnostic scan tool, clear all diagnostic trouble codes (DTCs) from the PCM (powertrain control module) .
- Road test the vehicle.
- Using a diagnostic scan tool, retrieve all continuous memory diagnostic trouble codes (CMDTCs) from the PCM (powertrain control module) .

Is DTC (diagnostic trouble code) P0736 present in the PCM (powertrain control module) ?

Yes	<p>Check the A clutch for a does not apply or a slipping condition. REFER to: A Clutch (307-01A Automatic Transmission - 10-Speed Automatic Transmission – 10R80, Diagnosis and Testing).</p> <p>Check the B clutch for a does not apply or a slipping condition. REFER to: B Clutch (307-01A Automatic Transmission - 10-Speed Automatic Transmission – 10R80, Diagnosis and Testing).</p> <p>Check the D clutch for a does not apply or a slipping condition. REFER to: D Clutch (307-01A Automatic Transmission - 10-Speed Automatic Transmission – 10R80, Diagnosis and Testing).</p> <p>Check the F clutch for a does not apply or a slipping condition.</p>
------------	---

		clutch, which allows only reverse and 6th and 8th gears.
PCM (powertrain control module) P0766:00	Shift Solenoid 'D' Performance/Stuck Off: No Sub Type Information	This DTC (diagnostic trouble code) indicates a non-electrical fault that caused the D clutch to fail to apply. When this DTC (diagnostic trouble code) is present, the failsafe logic disables all gears that use the D clutch, which allows only 5th and 9th gears.
PCM (powertrain control module) P0771:00	Shift Solenoid 'E' Performance/Stuck Off: No Sub Type Information	This DTC (diagnostic trouble code) indicates a non-electrical fault that caused the E clutch to fail to apply. When this DTC (diagnostic trouble code) is present, the failsafe logic disables all gears that use the E clutch, which allows only reverse and 2nd, 4th and 10th gears.
PCM (powertrain control module) P1744:00	Torque Converter Clutch Solenoid Circuit Performance: No Sub Type Information	This DTC (diagnostic trouble code) illuminates the wrench light in conjunction with P0741. Resolve the more specific DTC (diagnostic trouble code) first.
PCM (powertrain control module) P2707:00	Shift Solenoid 'F' Performance/Stuck Off: No Sub Type Information	This DTC (diagnostic trouble code) indicates a non-electrical fault that caused the F clutch to fail to apply. When this DTC (diagnostic trouble code) is present, the failsafe logic disables all gears that use the F clutch, which allows only 1st through 3rd gears.

Possible Sources

- Shift solenoid stuck off
- Stuck control valve
- Contamination in the main control valve body
- Hydraulic circuit leak
- Clutch damaged

S1 CHECK THE PCM (POWERTRAIN CONTROL MODULE) FOR DIAGNOSTIC TROUBLE CODES (DTCS)

- Ignition ON.
- Using a diagnostic scan tool, clear all diagnostic trouble codes (DTCS) from the PCM (powertrain control module) .
- Road test the vehicle.
- Using a diagnostic scan tool, retrieve all continuous memory diagnostic trouble codes (CMDTCs) from the PCM (powertrain control module) .

No

The fault is not present at this time and may be intermittent.

PINPOINT TEST T : P0752, P0757, P0762, P0767, P0772, P2708, P2758, P2783**Normal Operation and Fault Conditions**

The PCM (powertrain control module) monitors clutch applications. It sets a DTC (diagnostic trouble code) if it detects a non-electrical fault that causes a clutch to fail to release.

DTC Fault Trigger Conditions

DTC (diagnostic trouble code)	Description	Fault Trigger Condition
PCM (powertrain control module) P0752:00	Shift Solenoid 'A' Stuck On: No Sub Type Information	This DTC (diagnostic trouble code) indicates a non-electrical fault that caused the A clutch to remain applied when it was commanded off. When this DTC (diagnostic trouble code) is present, the failsafe logic disables all gears that do not use the A clutch, which allows only reverse and 1st through 6th gears.
PCM (powertrain control module) P0757:00	Shift Solenoid 'B' Stuck On: No Sub Type Information	This DTC (diagnostic trouble code) indicates a non-electrical fault that caused the B clutch to remain applied when it was commanded off. When this DTC (diagnostic trouble code) is present, the failsafe logic disables all gears that do not use the B clutch, which allows only reverse, 1st, 2nd and 8th through 10th gears.
PCM (powertrain control module) P0762:00	Shift Solenoid 'C' Stuck On: No Sub Type Information	This DTC (diagnostic trouble code) indicates a non-electrical fault that caused the C clutch to remain applied when it was commanded off. When this DTC (diagnostic trouble code) is present, the failsafe logic disables all gears that do not use the C clutch, which allows only 2nd through 5th and 7th, 9th and 10th gears.
PCM (powertrain control module) P0767:00	Shift Solenoid 'D' Stuck On: No Sub Type Information	This DTC (diagnostic trouble code) indicates a non-electrical fault that caused the D clutch to remain applied when it was commanded off. When this DTC (diagnostic trouble code) is present, the failsafe logic disables all gears that do not use the D clutch, which allows all gears except 5th and 9th.

Is DTC (diagnostic trouble code) P0752, P0757, P0762, P0767, P0772, P2708, P2758 and/or P2783 present in the PCM (powertrain control module) ?

Yes

For DTC (diagnostic trouble code) P0752, A clutch always applied condition,

REFER to: [A Clutch](#)

(307-01A Automatic Transmission - 10-Speed Automatic Transmission – 10R80, Diagnosis and Testing).

For DTC (diagnostic trouble code)

P0757, B clutch always applied condition,

REFER to: [B Clutch](#)

(307-01A Automatic Transmission - 10-Speed Automatic Transmission – 10R80, Diagnosis and Testing).

For DTC (diagnostic trouble code)

P0762, C clutch always applied condition,

REFER to: [C Clutch](#)

(307-01A Automatic Transmission - 10-Speed Automatic Transmission – 10R80, Diagnosis and Testing).

For DTC (diagnostic trouble code)

P0767, D clutch always applied condition,

REFER to: [D Clutch](#)

(307-01A Automatic Transmission - 10-Speed Automatic Transmission – 10R80, Diagnosis and Testing).

For DTC (diagnostic trouble code)

P0772, E clutch always applied condition,

REFER to: [E Clutch](#)

(307-01A Automatic Transmission - 10-Speed Automatic Transmission – 10R80, Diagnosis and Testing).

For DTC (diagnostic trouble code)

P2708, F clutch always applied condition,

REFER to: [F Clutch](#)

(307-01A Automatic Transmission - 10-Speed Automatic Transmission – 10R80, Diagnosis and Testing).

For DTC (diagnostic trouble code)

P2758, TCC (torque converter clutch)

always applied condition,

REFER to: [Torque Converter Clutch \(TCC\)](#)

(307-01A Automatic Transmission - 10-Speed Automatic Transmission – 10R80, Diagnosis and Testing).

For DTC (diagnostic trouble code)

P2783, REMOVE and DISASSEMBLE the main control valve body. INSPECT the TCC (torque converter clutch)