

Your Ultimate Source for OEM Repair Manuals

FactoryManuals.net is a great resource for anyone who wants to save money on repairs by doing their own work. The manuals provide detailed instructions and diagrams that make it easy to understand how to fix a vehicle.

2017 Mazda 3 Service and Repair Manual

[Go to manual page](#)

| Step | Inspection | Action | |
|------|---|--------|--|
| 1 | INSPECT KEYLESS ANTENNA (INTERIOR, REAR) CONNECTOR CONDITION <ul style="list-style-type: none"> • Switch the ignition off. • Disconnect the negative battery terminal. (See NEGATIVE BATTERY TERMINAL DISCONNECTION/CONNECTION.) • Disconnect the keyless antenna (interior, rear) connector. • Inspect the connector engagement and connection condition and inspect the terminals for damage, deformation, corrosion, or disconnection. • Is the connector normal? | Yes | Go to the next step. |
| | | No | Repair or replace the connector, then go to Step 7. |
| 2 | INSPECT LF CONTROL UNIT CONNECTOR CONDITION <ul style="list-style-type: none"> • Disconnect the LF control unit connector. • Inspect the connector engagement and connection condition and inspect the terminals for damage, deformation, corrosion, or disconnection. • Is the connector normal? | Yes | Go to the next step. |
| | | No | Repair or replace the connector, then go to Step 7. |
| 3 | INSPECT KEYLESS ANTENNA (INTERIOR, REAR) CIRCUIT FOR SHORT TO GROUND <ul style="list-style-type: none"> • Verify that the LF control unit and keyless antenna (interior, rear) connectors are disconnected. • Inspect for continuity between the following terminals (wiring harness-side) and body ground: <ul style="list-style-type: none"> — Keyless antenna (interior, rear) terminal B — Keyless antenna (interior, rear) terminal A • Is there continuity? | Yes | Refer to the wiring diagram and verify whether or not there is a common connector between the following terminals: <ul style="list-style-type: none"> • LF control unit terminal V–Keyless antenna (interior, rear) terminal B • LF control unit terminal T–Keyless antenna (interior, rear) terminal A If there is a common connector: <ul style="list-style-type: none"> • Determine the malfunctioning part by inspecting the common connector and the terminal for corrosion, damage, or pin disconnection, and the common wiring harness for a short to ground. • Repair or replace the malfunctioning part. If there is no common connector: <ul style="list-style-type: none"> • Repair or replace the wiring harness which has a short to ground. Go to Step 7. |
| | | No | Go to the next step. |
| 4 | INSPECT KEYLESS ANTENNA (INTERIOR, REAR) CIRCUIT FOR OPEN CIRCUIT <ul style="list-style-type: none"> • Verify that the LF control unit and keyless antenna (interior, rear) connectors are disconnected. • Inspect for continuity between the following terminals (wiring harness-side): <ul style="list-style-type: none"> — LF control unit terminal V–Keyless antenna (interior, rear) terminal B — LF control unit terminal T–Keyless antenna (interior, rear) terminal A • Is there continuity? | Yes | Go to the next step. |
| | | No | Refer to the wiring diagram and verify whether or not there is a common connector between the following terminals: <ul style="list-style-type: none"> • LF control unit terminal V–Keyless antenna (interior, rear) terminal B • LF control unit terminal T–Keyless antenna (interior, rear) terminal A If there is a common connector: <ul style="list-style-type: none"> • Determine the malfunctioning part by inspecting the common connector and the terminal for corrosion, damage, or pin disconnection, and the common wiring harness for an open circuit. • Repair or replace the malfunctioning part. If there is no common connector: <ul style="list-style-type: none"> • Repair or replace the wiring harness which has an open circuit. Go to Step 7. |
| 5 | INSPECT LF CONTROL UNIT <ul style="list-style-type: none"> • Inspect the LF control unit. (See LF CONTROL UNIT INSPECTION.) • Is the LF control unit normal? | Yes | Go to the next step. |
| | | No | Replace the LF control unit, then go to Step 7. (See LF CONTROL UNIT REMOVAL/INSTALLATION.) |

| Step | Inspection | Action | |
|------|---|--------|--|
| 1 | INSPECT KEYLESS ANTENNA (INTERIOR, CENTER) CONNECTOR CONDITION <ul style="list-style-type: none"> • Switch the ignition off. • Disconnect the negative battery terminal. (See NEGATIVE BATTERY TERMINAL DISCONNECTION/CONNECTION.) • Disconnect the keyless antenna (interior, center) connector. • Inspect the connector engagement and connection condition and inspect the terminals for damage, deformation, corrosion, or disconnection. • Is the connector normal? | Yes | Go to the next step. |
| | | No | Repair or replace the connector, then go to Step 6. |
| 2 | INSPECT START STOP UNIT CONNECTOR CONDITION <ul style="list-style-type: none"> • Disconnect the start stop unit connector. • Inspect the connector engagement and connection condition and inspect the terminals for damage, deformation, corrosion, or disconnection. • Is the connector normal? | Yes | Go to the next step. |
| | | No | Repair or replace the connector, then go to Step 6. |
| 3 | INSPECT KEYLESS ANTENNA (INTERIOR, CENTER) CIRCUIT FOR SHORT TO GROUND <ul style="list-style-type: none"> • Verify that the start stop unit and keyless antenna (interior, center) connectors are disconnected. • Inspect for continuity between the following terminals (wiring harness-side) and body ground: <ul style="list-style-type: none"> — Keyless antenna (interior, center) terminal B — Keyless antenna (interior, center) terminal A • Is there continuity? | Yes | Refer to the wiring diagram and verify whether or not there is a common connector between the following terminals: <ul style="list-style-type: none"> • Start stop unit terminal 2I–Keyless antenna (interior, center) terminal B • Start stop unit terminal 2K–Keyless antenna (interior, center) terminal A If there is a common connector: <ul style="list-style-type: none"> • Determine the malfunctioning part by inspecting the common connector and the terminal for corrosion, damage, or pin disconnection, and the common wiring harness for a short to ground. • Repair or replace the malfunctioning part. If there is no common connector: <ul style="list-style-type: none"> • Repair or replace the wiring harness which has a short to ground. Go to Step 6. |
| | | No | Go to the next step. |
| 4 | INSPECT KEYLESS ANTENNA (INTERIOR, CENTER) CIRCUIT FOR OPEN CIRCUIT <ul style="list-style-type: none"> • Verify that the start stop unit and keyless antenna (interior, center) connectors are disconnected. • Inspect for continuity between the following terminals (wiring harness-side): <ul style="list-style-type: none"> — Start stop unit terminal 2I–Keyless antenna (interior, center) terminal B — Start stop unit terminal 2K–Keyless antenna (interior, center) terminal A • Is there continuity? | Yes | Go to the next step. |
| | | No | Refer to the wiring diagram and verify whether or not there is a common connector between the following terminals: <ul style="list-style-type: none"> • Start stop unit terminal 2I–Keyless antenna (interior, center) terminal B • Start stop unit terminal 2K–Keyless antenna (interior, center) terminal A If there is a common connector: <ul style="list-style-type: none"> • Determine the malfunctioning part by inspecting the common connector and the terminal for corrosion, damage, or pin disconnection, and the common wiring harness for an open circuit. • Repair or replace the malfunctioning part. If there is no common connector: <ul style="list-style-type: none"> • Repair or replace the wiring harness which has an open circuit. Go to Step 6. |

| Step | Inspection | Action |
|------|--|---|
| 3 | INSPECT KEYLESS ANTENNA (INTERIOR, FRONT) CIRCUIT FOR SHORT TO GROUND <ul style="list-style-type: none"> Verify that the LF control unit and keyless antenna (interior, front) connectors are disconnected. Inspect for continuity between the following terminals (wiring harness-side) and body ground: <ul style="list-style-type: none"> — Keyless antenna (interior, front) terminal B — Keyless antenna (interior, front) terminal A Is there continuity? | Yes Refer to the wiring diagram and verify whether or not there is a common connector between the following terminals: <ul style="list-style-type: none"> LF control unit terminal K–Keyless antenna (interior, front) terminal B LF control unit terminal M–Keyless antenna (interior, front) terminal A If there is a common connector: <ul style="list-style-type: none"> Determine the malfunctioning part by inspecting the common connector and the terminal for corrosion, damage, or pin disconnection, and the common wiring harness for a short to ground. Repair or replace the malfunctioning part. If there is no common connector: <ul style="list-style-type: none"> Repair or replace the wiring harness which has a short to ground. Go to Step 7. |
| | | No Go to the next step. |
| 4 | INSPECT KEYLESS ANTENNA (INTERIOR, FRONT) CIRCUIT FOR OPEN CIRCUIT <ul style="list-style-type: none"> Verify that the LF control unit and keyless antenna (interior, front) connectors are disconnected. Inspect for continuity between the following terminals (wiring harness-side): <ul style="list-style-type: none"> — LF control unit terminal K–Keyless antenna (interior, front) terminal B — LF control unit terminal M–Keyless antenna (interior, front) terminal A Is there continuity? | Yes Go to the next step. |
| | | No Refer to the wiring diagram and verify whether or not there is a common connector between the following terminals: <ul style="list-style-type: none"> LF control unit terminal K–Keyless antenna (interior, front) terminal B LF control unit terminal M–Keyless antenna (interior, front) terminal A If there is a common connector: <ul style="list-style-type: none"> Determine the malfunctioning part by inspecting the common connector and the terminal for corrosion, damage, or pin disconnection, and the common wiring harness for an open circuit. Repair or replace the malfunctioning part. If there is no common connector: <ul style="list-style-type: none"> Repair or replace the wiring harness which has an open circuit. Go to Step 7. |
| 5 | INSPECT LF CONTROL UNIT <ul style="list-style-type: none"> Inspect the LF control unit. (See LF CONTROL UNIT INSPECTION.) Is the LF control unit normal? | Yes Go to the next step. |
| | | No Replace the LF control unit, then go to Step 7. (See LF CONTROL UNIT REMOVAL/INSTALLATION.) |
| 6 | VERIFY IF MALFUNCTIONING LOCATION IS KEYLESS ANTENNA (INTERIOR, FRONT) DEPENDING ON REPEATABILITY <ul style="list-style-type: none"> Always reconnect all disconnected connectors. Connect the negative battery terminal. (See NEGATIVE BATTERY TERMINAL DISCONNECTION/CONNECTION.) Clear the DTC for the start stop unit using the M-MDS. (See CLEARING DTC [START STOP UNIT].) Perform the following work: <ul style="list-style-type: none"> — Switch the ignition off. — Open the front door (LH). — Close all the doors and liftgate. Retrieve the start stop unit DTCs using the M-MDS. (See DTC INSPECTION [START STOP UNIT].) Is the same DTC displayed? | Yes Replace the keyless antenna (interior, front), then go to the next step. (See KEYLESS ANTENNA REMOVAL/INSTALLATION.) |
| | | No Go to Step 8. |

| Step | Inspection | | Action |
|------|--|-----|--|
| 2 | INSPECT START STOP UNIT CONNECTOR CONDITION <ul style="list-style-type: none"> • Disconnect the start stop unit connector. • Inspect the connector engagement and connection condition and inspect the terminals for damage, deformation, corrosion, or disconnection. • Is the connector normal? | Yes | Go to the next step. |
| | | No | Repair or replace the connector, then go to Step 4. |
| 3 | INSPECT ACC RELAY CIRCUIT FOR SHORT TO POWER SUPPLY <ul style="list-style-type: none"> • Always reconnect all disconnected connectors. • Connect the negative battery terminal. (See NEGATIVE BATTERY TERMINAL DISCONNECTION/CONNECTION.) • Measure the voltage at the start stop unit terminal 2C (wiring harness-side). • Is the voltage 2.5 V or more? | Yes | Refer to the wiring diagram and verify whether or not there is a common connector between ACC relay terminal E and start stop unit terminal 2C. If there is a common connector: <ul style="list-style-type: none"> • Determine the malfunctioning part by inspecting the common connector and the terminal for corrosion, damage, or pin disconnection, and the common wiring harness for a short to power supply. • Repair or replace the malfunctioning part. If there is no common connector: <ul style="list-style-type: none"> • Repair or replace the wiring harness which has a short to power supply. Go to the next step. |
| | | No | Go to the next step. |
| 4 | VERIFY THAT REPAIRS HAVE BEEN COMPLETED <ul style="list-style-type: none"> • Always reconnect all disconnected connectors. • Connect the negative battery terminal. (See NEGATIVE BATTERY TERMINAL DISCONNECTION/CONNECTION.) • Clear the DTC for the start stop unit using the M-MDS. (See CLEARING DTC [START STOP UNIT].) • Switch the ignition off and wait for 1 s or more. • Retrieve the start stop unit DTCs using the M-MDS. (See DTC INSPECTION [START STOP UNIT].) • Is the same DTC displayed? | Yes | Repeat the inspection from Step 1. <ul style="list-style-type: none"> • If the malfunction recurs, replace the start stop unit. (See START STOP UNIT REMOVAL/INSTALLATION.) Go to the next step. |
| | | No | Go to the next step. |
| 5 | VERIFY IF OTHER DTCs DISPLAYED <ul style="list-style-type: none"> • Are any other DTCs displayed? | Yes | Repair or replace the malfunctioning part according to the applicable DTC troubleshooting. (See DTC TABLE [START STOP UNIT].) |
| | | No | DTC troubleshooting completed. |


| Step | Inspection | Action | |
|------|---|--------|---|
| 6 | VERIFY IF MALFUNCTIONING LOCATION IS KEYLESS ANTENNA (EXTERIOR, LF) DEPENDING ON REPEATABILITY <ul style="list-style-type: none"> • Always reconnect all disconnected connectors. • Connect the negative battery terminal. (See NEGATIVE BATTERY TERMINAL DISCONNECTION/CONNECTION.) • Clear the DTC for the start stop unit using the M-MDS. (See CLEARING DTC [START STOP UNIT].) • Perform the following work: <ul style="list-style-type: none"> — Switch the ignition off. — Open the front door (LH). — Close all the doors and liftgate. • Retrieve the start stop unit DTCs using the M-MDS. (See DTC INSPECTION [START STOP UNIT].) • Is the same DTC displayed? | Yes | Replace the front outer handle (LH), then go to the next step. (See FRONT OUTER HANDLE REMOVAL/INSTALLATION.) |
| | | No | Go to Step 8. |
| 7 | VERIFY THAT REPAIRS HAVE BEEN COMPLETED <ul style="list-style-type: none"> • Always reconnect all disconnected connectors. • Connect the negative battery terminal. (See NEGATIVE BATTERY TERMINAL DISCONNECTION/CONNECTION.) • Clear the DTC for the start stop unit using the M-MDS. (See CLEARING DTC [START STOP UNIT].) • Perform the following work: <ul style="list-style-type: none"> — Switch the ignition off. — Open the front door (LH). — Close all the doors and liftgate. • Retrieve the start stop unit DTCs using the M-MDS. (See DTC INSPECTION [START STOP UNIT].) • Is the same DTC displayed? | Yes | Repeat the inspection from Step 1. • If the malfunction recurs, replace the start stop unit. (See START STOP UNIT REMOVAL/INSTALLATION.) Go to the next step. |
| | | No | Go to the next step. |
| 8 | VERIFY IF OTHER DTCs DISPLAYED <ul style="list-style-type: none"> • Are any other DTCs displayed? | Yes | Repair or replace the malfunctioning part according to the applicable DTC troubleshooting. (See DTC TABLE [START STOP UNIT].) |
| | | No | DTC troubleshooting completed. |

DTC B11C4:23 [START STOP UNIT]

SM2899082

id0902p602660

| | |
|---------------------|---|
| Description | Request switch (liftgate) circuit malfunction |
| Detection condition | <ul style="list-style-type: none">• Start stop unit detected any of the following conditions at a vehicle speed of 5 km/h {3 mph} or more.<ul style="list-style-type: none">— The request switch (liftgate) is continuously ON for 2 min or more.— The request switch (liftgate) was ON 7 times. |
| Fail-safe | Not applicable |
| Possible cause | <ul style="list-style-type: none">• Request switch (liftgate) connector or terminal malfunction• LF control unit connector or terminal malfunction• Short to ground in wiring harness between LF control unit terminal E and request switch (liftgate) terminal A• Request switch (liftgate) malfunction• LF control unit malfunction• Start stop unit malfunction |



Diagnostic Procedure

| Step | Inspection | | Action |
|------|---|-----|---|
| 1 | INSPECT REQUEST SWITCH (LIFTGATE) CONNECTOR CONDITION <ul style="list-style-type: none">• Switch the ignition off.• Disconnect the negative battery terminal. (See NEGATIVE BATTERY TERMINAL DISCONNECTION/CONNECTION.)• Disconnect the request switch (liftgate) connector.• Inspect the connector engagement and connection condition and inspect the terminals for damage, deformation, corrosion, or disconnection.• Is the connector normal? | Yes | Go to the next step. |
| | | No | Repair or replace the connector, then go to Step 6. |

| Step | Inspection | Action | |
|------|--|--------|---|
| 2 | INSPECT START STOP UNIT CONNECTOR CONDITION <ul style="list-style-type: none"> • Disconnect the start stop unit connector. • Inspect the connector engagement and connection condition and inspect the terminals for damage, deformation, corrosion, or disconnection. • Is the connector normal? | Yes | Go to the next step. |
| | | No | Repair or replace the connector, then go to Step 6. |
| 3 | INSPECT WIRING HARNESS BETWEEN START STOP UNIT AND LF CONTROL UNIT FOR SHORT TO GROUND <ul style="list-style-type: none"> • Verify that the start stop unit and LF control unit connectors are disconnected. • Inspect for continuity between LF control unit terminal G (wiring harness-side) and body ground. • Is there continuity? | Yes | Refer to the wiring diagram and verify whether or not there is a common connector between start stop unit terminal 2H and LF control unit terminal G. If there is a common connector: <ul style="list-style-type: none"> • Determine the malfunctioning part by inspecting the common connector and the terminal for corrosion, damage, or pin disconnection, and the common wiring harness for a short to ground. • Repair or replace the malfunctioning part. If there is no common connector: <ul style="list-style-type: none"> • Repair or replace the wiring harness which has a short to ground. Go to Step 6. |
| | | No | Go to the next step. |
| 4 | INSPECT WIRING HARNESS BETWEEN START STOP UNIT AND LF CONTROL UNIT FOR OPEN CIRCUIT <ul style="list-style-type: none"> • Verify that the start stop unit and LF control unit connectors are disconnected. • Inspect for continuity between start stop unit terminal 2H (wiring harness-side) and LF control unit terminal G (wiring harness-side). • Is there continuity? | Yes | Go to the next step. |
| | | No | Refer to the wiring diagram and verify whether or not there is a common connector between start stop unit terminal 2H and LF control unit terminal G. If there is a common connector: <ul style="list-style-type: none"> • Determine the malfunctioning part by inspecting the common connector and the terminal for corrosion, damage, or pin disconnection, and the common wiring harness for an open circuit. • Repair or replace the malfunctioning part. If there is no common connector: <ul style="list-style-type: none"> • Repair or replace the wiring harness which has an open circuit. Go to Step 6. |
| 5 | INSPECT LF CONTROL UNIT <ul style="list-style-type: none"> • Inspect the LF control unit. (See LF CONTROL UNIT INSPECTION.) • Is the LF control unit normal? | Yes | Go to the next step. |
| | | No | Replace the LF control unit, then go to the next step. (See LF CONTROL UNIT REMOVAL/INSTALLATION .) |
| 6 | VERIFY THAT REPAIRS HAVE BEEN COMPLETED <ul style="list-style-type: none"> • Always reconnect all disconnected connectors. • Connect the negative battery terminal. (See NEGATIVE BATTERY TERMINAL DISCONNECTION/CONNECTION.) • Clear the DTC for the start stop unit using the M-MDS. (See CLEARING DTC [START STOP UNIT].) • Switch the ignition ON (engine off or on) and wait for 5 s or more. • Retrieve the start stop unit DTCs using the M-MDS. (See DTC INSPECTION [START STOP UNIT].) • Is the same DTC displayed? | Yes | Repeat the inspection from Step 1. • If the malfunction recurs, replace the start stop unit. (See START STOP UNIT REMOVAL/INSTALLATION .) Go to the next step. |
| | | No | Go to the next step. |
| 7 | VERIFY IF OTHER DTCs DISPLAYED <ul style="list-style-type: none"> • Are any other DTCs displayed? | Yes | Repair or replace the malfunctioning part according to the applicable DTC troubleshooting. (See DTC TABLE [START STOP UNIT] .) |
| | | No | DTC troubleshooting completed. |

| Step | Inspection | Action | |
|------|---|--------|---|
| 6 | VERIFY IF MALFUNCTIONING LOCATION IS KEYLESS ANTENNA (EXTERIOR, RF) DEPENDING ON REPEATABILITY <ul style="list-style-type: none"> • Always reconnect all disconnected connectors. • Connect the negative battery terminal. (See NEGATIVE BATTERY TERMINAL DISCONNECTION/CONNECTION.) • Clear the DTC for the start stop unit using the M-MDS. (See CLEARING DTC [START STOP UNIT].) • Perform the following work: <ul style="list-style-type: none"> — Switch the ignition off. — Open the front door (RH). — Close all the doors and liftgate. • Retrieve the start stop unit DTCs using the M-MDS. (See DTC INSPECTION [START STOP UNIT].) • Is the same DTC displayed? | Yes | Replace the front outer handle (RH), then go to the next step. (See FRONT OUTER HANDLE REMOVAL/INSTALLATION.) |
| | | No | Go to Step 8. |
| 7 | VERIFY THAT REPAIRS HAVE BEEN COMPLETED <ul style="list-style-type: none"> • Always reconnect all disconnected connectors. • Connect the negative battery terminal. (See NEGATIVE BATTERY TERMINAL DISCONNECTION/CONNECTION.) • Clear the DTC for the start stop unit using the M-MDS. (See CLEARING DTC [START STOP UNIT].) • Perform the following work: <ul style="list-style-type: none"> — Switch the ignition off. — Open the front door (RH). — Close all the doors and liftgate. • Retrieve the start stop unit DTCs using the M-MDS. (See DTC INSPECTION [START STOP UNIT].) • Is the same DTC displayed? | Yes | Repeat the inspection from Step 1. • If the malfunction recurs, replace the start stop unit. (See START STOP UNIT REMOVAL/INSTALLATION.) Go to the next step. |
| | | No | Go to the next step. |
| 8 | VERIFY IF OTHER DTCs DISPLAYED <ul style="list-style-type: none"> • Are any other DTCs displayed? | Yes | Repair or replace the malfunctioning part according to the applicable DTC troubleshooting. (See DTC TABLE [START STOP UNIT].) |
| | | No | DTC troubleshooting completed. |

| Step | Inspection | Action |
|------|--|---|
| 2 | VERIFY LF CONTROL UNIT POWER SUPPLY VOLTAGE <ul style="list-style-type: none"> • Always reconnect all disconnected connectors. • Connect the negative battery terminal. (See NEGATIVE BATTERY TERMINAL DISCONNECTION/CONNECTION.) • Measure the voltage at the LF control unit terminal B (wiring harness-side). • Is the voltage 5 V or more or less than 8.5 V? | Refer to the wiring diagram and verify whether or not there is a common connector between battery positive terminal and LF control unit terminal B. If there is a common connector: <ul style="list-style-type: none"> • Determine the malfunctioning part by inspecting the common connector and the terminal for corrosion, damage, or pin disconnection, and the common wiring harness for a malfunction. • Repair or replace the malfunctioning part. If there is no common connector: <ul style="list-style-type: none"> • Inspect the wiring harness between battery positive terminal and LF control unit terminal B. <ul style="list-style-type: none"> — If there is any malfunction: <ul style="list-style-type: none"> • Repair or replace the wiring harness. — If there is no malfunction: <ul style="list-style-type: none"> • Replace the LF control unit. (See LF CONTROL UNIT REMOVAL/INSTALLATION.) Go to Step 4. |
| | | No Go to the next step. |
| 3 | INSPECT LF CONTROL UNIT <ul style="list-style-type: none"> • Inspect the LF control unit. (See LF CONTROL UNIT INSPECTION.) • Is the LF control unit normal? | Yes Go to the next step. |
| | | No Replace the LF control unit, then go to the next step (See LF CONTROL UNIT REMOVAL/INSTALLATION.) |
| 4 | VERIFY THAT REPAIRS HAVE BEEN COMPLETED <ul style="list-style-type: none"> • Always reconnect all disconnected connectors. • Connect the negative battery terminal. (See NEGATIVE BATTERY TERMINAL DISCONNECTION/CONNECTION.) • Clear the DTC for the start stop unit using the M-MDS. (See CLEARING DTC [START STOP UNIT].) • Switch the ignition ON (engine off) and wait for 5 s or more. • Retrieve the start stop unit DTCs using the M-MDS. (See DTC INSPECTION [START STOP UNIT].) • Is the same DTC displayed? | Yes Repeat the inspection from Step 1. • If the malfunction recurs, replace the start stop unit. (See START STOP UNIT REMOVAL/INSTALLATION.) Go to the next step. |
| | | No Go to the next step. |
| 5 | VERIFY IF OTHER DTCs DISPLAYED <ul style="list-style-type: none"> • Are any other DTCs displayed? | Yes Repair or replace the malfunctioning part according to the applicable DTC troubleshooting. (See DTC TABLE [START STOP UNIT].) |
| | | No DTC troubleshooting completed. |