

Your Ultimate Source for OEM Repair Manuals

FactoryManuals.net is a great resource for anyone who wants to save money on repairs by doing their own work. The manuals provide detailed instructions and diagrams that make it easy to understand how to fix a vehicle.

2020 Mazda CX-30 Service and Repair Manual

[Go to manual page](#)

Step	Inspection		Action
64	INSPECT PCM FOR SHORT TO POWER SUPPLY <ul style="list-style-type: none"> • Switch the ignition off. • Disconnect the negative battery terminal. (See NEGATIVE BATTERY TERMINAL DISCONNECTION/CONNECTION.) • Disconnect the PCM connector. • Connect connector C-53. • Connect the negative battery terminal. (See NEGATIVE BATTERY TERMINAL DISCONNECTION/CONNECTION.) • Switch the ignition ON (engine off). • Measure the voltage at DLC-2 terminals F and E. • Is the voltage between 1.5 – 3.5 V? 	Yes	Replace the PCM because there is a short to the power supply in the PCM. (See PCM REMOVAL/INSTALLATION [SKYACTIV-G 2.5 (WITH CYLINDER DEACTIVATION)].) (See PCM REMOVAL/INSTALLATION [SKYACTIV-G 2.5 (WITHOUT CYLINDER DEACTIVATION)].) (See PCM REMOVAL/INSTALLATION [SKYACTIV-G 2.5T].) (See PCM REMOVAL/INSTALLATION [SKYACTIV-D 2.2].)
		No	Repair or replace the wiring harness between the PCM and connector C-53 because the wiring harness is shorted to the power supply.

Step	Inspection	Action	
6	INSPECT BETWEEN FRONT BODY CONTROL MODULE (FBCM) AND CONNECTOR C-53 FOR SHORT BETWEEN CIRCUITS <ul style="list-style-type: none"> • Disconnect connector C-53. • Connect connector 2 which has front body control module (FBCM) terminals 2K and 2L. • Connect the negative battery terminal. (See NEGATIVE BATTERY TERMINAL DISCONNECTION/CONNECTION.) • Switch the ignition ON (engine off). • Measure the voltage at DLC-2 terminals F and E. • Is the voltage at DLC-2 terminals F and E the same? 	Yes	Repair or replace the wiring harness between the front body control module (FBCM) and connector C-53 because the wiring harness is shorted between circuits.
		No	Go to Step 12.
7	INSPECT BETWEEN FRONT BODY CONTROL MODULE (FBCM) AND CONNECTOR C-01 FOR SHORT BETWEEN CIRCUITS <ul style="list-style-type: none"> • Disconnect connector C-01. • Connect connector 2 which has front body control module (FBCM) terminals 2K and 2L. • Connect the negative battery terminal. (See NEGATIVE BATTERY TERMINAL DISCONNECTION/CONNECTION.) • Switch the ignition ON (engine off). • Measure the voltage at DLC-2 terminals F and E. • Is the voltage at DLC-2 terminals F and E the same? 	Yes	Repair or replace the wiring harness between the front body control module (FBCM) and connector C-01 because the wiring harness is shorted between circuits.
		No	Go to the next step.
8	INSPECT BETWEEN TCM AND CONNECTOR C-01 FOR SHORT BETWEEN CIRCUITS <ul style="list-style-type: none"> • Switch the ignition off. • Disconnect the negative battery terminal. (See NEGATIVE BATTERY TERMINAL DISCONNECTION/CONNECTION.) • Inspect for continuity between TCM terminals E and F. • Is there continuity? 	Yes	Go to the next step.
		No	Go to Step 11.
9	INSPECT TCM FOR SHORT BETWEEN CIRCUITS <ul style="list-style-type: none"> • Disconnect the TCM connector. • Inspect for continuity between TCM terminals E and F (wiring harness side). • Is there continuity? 	Yes	With i-stop : Go to the next step. Without i-stop : Repair or replace the wiring harness between the TCM and connector C-01 because the wiring harness is shorted between circuits.
		No	Replace the TCM because there is a short between circuits in the TCM. (See CONTROL VALVE BODY REMOVAL/INSTALLATION [FW6A-EL, FW6AX-EL].) (See CONTROL VALVE BODY REMOVAL/INSTALLATION [GW6A-EL, GW6AX-EL].)
10	INSPECT BETWEEN TCM AND CONNECTOR C-89 FOR SHORT BETWEEN CIRCUITS <ul style="list-style-type: none"> • Disconnect connector C-89. • Inspect for continuity between TCM terminals E and F (wiring harness side). • Is there continuity? 	Yes	Repair or replace the wiring harness between the TCM and connector C-89 because the wiring harness is shorted between circuits.
		No	Repair or replace the wiring harness between connector C-89 and connector C-01 because the wiring harness is shorted between circuits.

Step	Inspection		Action
23	INSPECT BETWEEN POWER LIFTGATE (PLG) CONTROL MODULE AND CONNECTOR C-74 FOR SHORT BETWEEN CIRCUITS <ul style="list-style-type: none"> • Switch the ignition off. • Disconnect the negative battery terminal. (See NEGATIVE BATTERY TERMINAL DISCONNECTION/CONNECTION.) • Inspect for continuity between power liftgate (PLG) control module terminals 1B and 1A. • Is there continuity? 	Yes	Go to the next step.
		No	Repair or replace the wiring harness between connector C-24 and connector C-74 because the wiring harness is shorted between circuits.
24	INSPECT POWER LIFTGATE (PLG) CONTROL MODULE FOR SHORT BETWEEN CIRCUITS <ul style="list-style-type: none"> • Disconnect the power liftgate (PLG) control module connector. • Inspect for continuity between power liftgate (PLG) control module terminals 1B and 1A (wiring harness side). • Is there continuity? 	Yes	Repair or replace the wiring harness between the power liftgate (PLG) control module and connector C-19 because the wiring harness is shorted between circuits.
		No	Replace the power liftgate (PLG) control module because there is a short between circuits in the power liftgate (PLG) control module. (See POWER LIFTGATE (PLG) CONTROL MODULE REMOVAL/INSTALLATION.)
25	INSPECT BETWEEN CONNECTOR C-87 AND INSTRUMENT CLUSTER FOR SHORT BETWEEN CIRCUITS <ul style="list-style-type: none"> • Switch the ignition off. • Disconnect the negative battery terminal. (See NEGATIVE BATTERY TERMINAL DISCONNECTION/CONNECTION.) • Disconnect connector C-87. • Connect the negative battery terminal. (See NEGATIVE BATTERY TERMINAL DISCONNECTION/CONNECTION.) • Switch the ignition ON (engine off). • Measure the voltage at DLC-2 terminals F and E. • Is the voltage at DLC-2 terminals F and E the same? 	Yes	Go to Step 35.
		No	Go to the next step.
26	INSPECT BETWEEN DOSING CONTROL UNIT AND CONNECTOR C-87 FOR SHORT BETWEEN CIRCUITS <ul style="list-style-type: none"> • Switch the ignition off. • Disconnect the negative battery terminal. (See NEGATIVE BATTERY TERMINAL DISCONNECTION/CONNECTION.) • Inspect for continuity between dosing control unit terminals BK and BL. • Is there continuity? 	Yes	Go to the next step.
		No	Go to Step 28.
27	INSPECT DOSING CONTROL UNIT FOR SHORT BETWEEN CIRCUITS <ul style="list-style-type: none"> • Disconnect the dosing control unit connector. • Inspect for continuity between dosing control unit terminals BK and BL (wiring harness side). • Is there continuity? 	Yes	Repair or replace the wiring harness between the dosing control unit and connector C-87 because the wiring harness is shorted between circuits.
		No	Replace the dosing control unit because there is a short between circuits in the dosing control unit. (See DOSING CONTROL UNIT REMOVAL/INSTALLATION [SKYACTIV-D 2.2].)
28	INSPECT BETWEEN NOx SENSOR No.1 / NOx SENSOR No.2 / PM SENSOR AND CONNECTOR C-87 FOR SHORT BETWEEN CIRCUITS <ul style="list-style-type: none"> • Inspect for continuity between NOx sensor No.1 / NOx sensor No.2 / PM sensor terminals B and C. • Is there continuity? 	Yes	Go to the next step.
		No	Repair or replace the wiring harness between connector C-87 and connector C-24 because the wiring harness is shorted between circuits.

Step	Inspection	Action	
47	INSPECT BETWEEN CONNECTOR C-19 AND INSTRUMENT CLUSTER FOR SHORT BETWEEN CIRCUITS <ul style="list-style-type: none"> • Switch the ignition off. • Disconnect the negative battery terminal. (See NEGATIVE BATTERY TERMINAL DISCONNECTION/CONNECTION.) • Disconnect connector C-19. • Connect the negative battery terminal. (See NEGATIVE BATTERY TERMINAL DISCONNECTION/CONNECTION.) • Switch the ignition ON (engine off). • Measure the voltage at DLC-2 terminals F and E. • Is the voltage at DLC-2 terminals F and E the same? 	Yes	Go to Step 50.
		No	Go to the next step.
48	INSPECT BETWEEN FORWARD SENSING CAMERA (FSC) AND CONNECTOR C-19 FOR SHORT BETWEEN CIRCUITS <ul style="list-style-type: none"> • Switch the ignition off. • Disconnect the negative battery terminal. (See NEGATIVE BATTERY TERMINAL DISCONNECTION/CONNECTION.) • Inspect for continuity between forward sensing camera (FSC) terminals M and N. • Is there continuity? 	Yes	Go to the next step.
		No	Repair or replace the wiring harness between connector C-19 and connector C-16 because the wiring harness is shorted between circuits.
49	INSPECT FORWARD SENSING CAMERA (FSC) FOR SHORT BETWEEN CIRCUITS <ul style="list-style-type: none"> • Disconnect the forward sensing camera (FSC) connector. • Inspect for continuity between forward sensing camera (FSC) terminals M and N (wiring harness side). • Is there continuity? 	Yes	Repair or replace the wiring harness between the forward sensing camera (FSC) and connector C-19 because the wiring harness is shorted between circuits.
		No	Replace the forward sensing camera (FSC) because there is a short between circuits in the forward sensing camera (FSC). (See FORWARD SENSING CAMERA (FSC) REMOVAL/INSTALLATION.)
50	INSPECT BETWEEN CONNECTOR C-64 AND INSTRUMENT CLUSTER FOR SHORT BETWEEN CIRCUITS <ul style="list-style-type: none"> • Switch the ignition off. • Disconnect the negative battery terminal. (See NEGATIVE BATTERY TERMINAL DISCONNECTION/CONNECTION.) • Disconnect connector C-64. • Connect the negative battery terminal. (See NEGATIVE BATTERY TERMINAL DISCONNECTION/CONNECTION.) • Switch the ignition ON (engine off). • Measure the voltage at DLC-2 terminals F and E. • Is the voltage at DLC-2 terminals F and E the same? 	Yes	Go to Step 55.
		No	Go to the next step.
51	INSPECT BETWEEN EPS CONTROL MODULE AND CONNECTOR C-64 FOR SHORT BETWEEN CIRCUITS <ul style="list-style-type: none"> • Switch the ignition off. • Disconnect the negative battery terminal. (See NEGATIVE BATTERY TERMINAL DISCONNECTION/CONNECTION.) • Inspect for continuity between EPS control module terminals 2B and 2D. • Is there continuity? 	Yes	Go to the next step.
		No	Go to Step 53.

M-MDS display	DTC	DTC output pattern and malfunctioning location						
DTC output module								
Blind spot monitoring (BSM) control module (LH)	U0155:00	×						
Rear body control module (RBCM)	U0155:00	×						
Gateway unit (GWU)	U0151:00							
	U0336:82							
	U2132:00							
M-MDS display module		Module displayed in red or blue						
Instrument cluster		×						×
Climate control unit			×					×
Parking assist unit				×				×
Blind spot monitoring (BSM) control module (LH)					×	×		×
Rear body control module (RBCM)					×		×	×
Gateway unit (GWU)								×
Diagnostic result								
Possible cause and inspection item	A	B	C	D	E	F	G	

A

Possible cause

- Connector terminal disconnection, poor contact, damage, deformation, corrosion
- Instrument cluster power supply voltage or body ground malfunction
- Open circuit in wiring harness between instrument cluster and connector C-63
- Connector C-63 malfunction
- Instrument cluster malfunction


System wiring diagram

With wireless charger (Qi)

Possible cause

- Connector terminal disconnection, poor contact, damage, deformation, corrosion
- Connector C-63 malfunction
- Connectors C-82, C-83 malfunction
- Connector C-64 malfunction
- Connector C-14 malfunction
- Open circuit in wiring harness between connector C-63 and connectors C-82, C-83
- Open circuit in wiring harness between connectors C-82, C-83 and connector C-64
- Open circuit in wiring harness between connector C-64 and connector C-14
- Open circuit in wiring harness between connector C-14 and rear body control module (RBCM)
- CAN circuit in rear body control module (RBCM) malfunction

System wiring diagram




ac5uuw00011719

Inspection item

- Rear body control module (RBCM) connector
- Connector C-63
- Connectors C-82, C-83
- Connector C-64
- Connector C-14

- Connector terminal disconnection, poor contact, damage, deformation, corrosion
- Rear body control module (RBCM) power supply voltage or body ground malfunction
- Rear body control module (RBCM) malfunction

System wiring diagram



ac5uuw00011721

Inspection item

- Rear body control module (RBCM) power supply voltage-related wiring harness and fuse
- Rear body control module (RBCM) body ground related wiring harness
- Rear body control module (RBCM)

G

Possible cause

- Connector terminal disconnection, poor contact, damage, deformation, corrosion

Step	Inspection	Action	
1	INSPECT FOR SHORT TO GROUND BETWEEN CONNECTOR C-63 AND REAR BODY CONTROL MODULE (RBCM) <ul style="list-style-type: none"> • Disconnect the negative battery terminal. (See NEGATIVE BATTERY TERMINAL DISCONNECTION/CONNECTION.) • Disconnect connector C-63. • Inspect for continuity at the following terminals: <ul style="list-style-type: none"> — Between rear body control module (RBCM) terminal 3E and body ground — Between rear body control module (RBCM) terminal 3G and body ground • Is there continuity? 	Yes	Go to Step 11.
		No	Go to the next step.
2	INSPECT FOR SHORT TO GROUND BETWEEN CONNECTOR C-63 AND CLIMATE CONTROL UNIT <ul style="list-style-type: none"> • Inspect for continuity at the following terminals: <ul style="list-style-type: none"> — Between climate control unit terminal 1K and body ground (with full-auto air conditioner) — Between climate control unit terminal 1M and body ground (with full-auto air conditioner) — Between climate control unit terminal Q and body ground (with manual air conditioner) — Between climate control unit terminal S and body ground (with manual air conditioner) • Is there continuity? 	Yes	Go to the next step.
		No	Go to Step 4.
3	INSPECT CAN LINE IN CLIMATE CONTROL UNIT FOR SHORT TO GROUND <ul style="list-style-type: none"> • Disconnect the climate control unit connector. • Inspect for continuity at the following terminals: <ul style="list-style-type: none"> — Between climate control unit terminal 1K (wiring harness side) and body ground (with full-auto air conditioner) — Between climate control unit terminal 1M (wiring harness side) and body ground (with full-auto air conditioner) — Between climate control unit terminal Q (wiring harness side) and body ground (with manual air conditioner) — Between climate control unit terminal S (wiring harness side) and body ground (with manual air conditioner) • Is there continuity? 	Yes	Repair or replace the wiring harness between the climate control unit and connector C-63 because the wiring harness is shorted to ground.
		No	Replace the climate control unit because there is a short to ground in the climate control unit. (See CLIMATE CONTROL UNIT REMOVAL/INSTALLATION [FULL-AUTO AIR CONDITIONER].) (See CLIMATE CONTROL UNIT REMOVAL/INSTALLATION [MANUAL AIR CONDITIONER].)

Step	Inspection		Action
17	INSPECT FOR SHORT TO GROUND BETWEEN CONNECTOR C-14 AND REAR BODY CONTROL MODULE (RBCM) <ul style="list-style-type: none"> • Disconnect the rear body control module (RBCM) connector. • Connect connector C-14. • Inspect for continuity at the following terminals: <ul style="list-style-type: none"> — Between DLC-2 terminal L and body ground — Between DLC-2 terminal K and body ground • Is there continuity? 	Yes	Repair or replace the wiring harness between connector C-14 and rear body control module (RBCM) because the wiring harness is shorted to ground.
		No	Go to the next step.
18	INSPECT FOR SHORT TO GROUND BETWEEN BLIND SPOT MONITORING (BSM) CONTROL MODULE (LH) AND REAR BODY CONTROL MODULE (RBCM) <ul style="list-style-type: none"> • Inspect for continuity at the following terminals: <ul style="list-style-type: none"> — Between rear body control module (RBCM) terminal 4I (wiring harness side) and body ground — Between rear body control module (RBCM) terminal 4L (wiring harness side) and body ground • Is there continuity? 	Yes	Go to the next step.
		No	Replace the rear body control module (RBCM) because there is a short to ground in the rear body control module (RBCM). (See REAR BODY CONTROL MODULE (RBCM) REMOVAL/INSTALLATION.)
19	INSPECT FOR SHORT TO GROUND BETWEEN BLIND SPOT MONITORING (BSM) CONTROL MODULE (LH) AND CONNECTOR C-39 <ul style="list-style-type: none"> • Disconnect connector C-39. • Inspect for continuity at the following terminals: <ul style="list-style-type: none"> — Between blind spot monitoring (BSM) control module (LH) terminal C and body ground — Between blind spot monitoring (BSM) control module (LH) terminal D and body ground • Is there continuity? 	Yes	Go to the next step.
		No	Repair or replace the wiring harness between the rear body control module (RBCM) and connector C-39 because the wiring harness is shorted to ground.
20	INSPECT CAN LINE IN BLIND SPOT MONITORING (BSM) CONTROL MODULE (LH) FOR SHORT TO GROUND <ul style="list-style-type: none"> • Disconnect the blind spot monitoring (BSM) control module (LH) connector. • Inspect for continuity at the following terminals: <ul style="list-style-type: none"> — Between blind spot monitoring (BSM) control module (LH) terminal C (wiring harness side) and body ground — Between blind spot monitoring (BSM) control module (LH) terminal D (wiring harness side) and body ground • Is there continuity? 	Yes	Repair or replace the wiring harness between the blind spot monitoring (BSM) control module (LH) and connector C-39 because the wiring harness is shorted to ground.
		No	Replace the blind spot monitoring (BSM) control module (LH) because there is a short to ground in the blind spot monitoring (BSM) control module (LH). (See BLIND SPOT MONITORING (BSM) CONTROL MODULE REMOVAL/INSTALLATION.)