

# Your Ultimate Source for OEM Repair Manuals

FactoryManuals.net is a great resource for anyone who wants to save money on repairs by doing their own work. The manuals provide detailed instructions and diagrams that make it easy to understand how to fix a vehicle.

**2020 Nissan Titan Service and Repair Manual** 

Go to manual page

### **DTC Description**

# **DTC DETECTION LOGIC**

DTC		CONSULT screen terms (Trouble diagnosis content)	DTC detection condition		
	29	E-driven intelligent brake unit circuit (Electrically-driven intelligent brake unit circuit)	Diagnosis condition	<ul><li>When vehicle is READY</li><li>When AEB system is ON</li></ul>	
C1F54			Signal (terminal)	—	
			Threshold	If ADAS control unit 2 detects an error signal that is received from electrically-driven intelligent brake unit via CAN communication	
			Diagnosis delay time	1 second or less	

#### **POSSIBLE CAUSE**

- Electrically-driven intelligent brake unit
- ADAS control unit 2

### FAIL-SAFE

The following system are cancelled.

- Lane keep function<sup>\*</sup>
- Lane change support function
- Overtaking support function
- Route driving support function

\*: ProPILOT Assist 2.0 display is blue

# **CONFIRMATION PROCEDURE**

#### **1. CHECK DTC PRIORITY**

If DTC "C1F54-29" is displayed with Network-DTC, first diagnose the Network-DTC.

Is applicable DTC detected?

YES>>

Perform diagnosis of applicable. Refer to DTC Index.

NO>>

#### <u>GO TO 2</u>.

#### 2. PERFORM DTC CONFIRMATION PROCEDURE

1. Set the vehicle to READY.

- 2. Turn the AEB system ON.
- 3. Perform "All DTC Reading" with CONSULT.
- 4. Check if the "C1F54-29" is detected as the current malfunction in "Self Diagnostic Result" of "ICC/ADAS 2".

Is "C1F54-29" detected as the current malfunction?

YES>>

Refer to DTC Diagnosis Procedure.

NO-1>>

To check malfunction symptom before repair: Refer to <u>Intermittent Incident</u>.

NO-2>>

Confirmation after repair: INSPECTION END



# **1. CHECK DTC PRIORITY**

If DTC "C1F54-29" is displayed with Network-DTC, first diagnose the Network-DTC.

Is applicable DTC detected?

YES>>

Perform diagnosis of applicable. Refer to DTC Index.

NO>>

<u>GO TO 2</u>.

#### 2. PERFORM SELF-DIAGNOSIS OF ELECTRICALLY-DRIVEN INTELLIGENT BRAKE UNIT

Check if any DTC is detected in "Self Diagnostic Result" of "BRAKE".

Is any DTC detected?

YES>>

Perform diagnosis on the detected DTC and repair or replace the malfunctioning parts. Refer to DTC Index.

NO>>

Replace the ADAS control unit 2. Refer to Removal and Installation.

# **DTC Description**

# **DTC DETECTION LOGIC**

DTC		CONSULT screen terms (Trouble diagnosis content)	DTC detection condition		
	82	E-driven intelligent brake unit circuit (Electrically-driven intelligent brake unit circuit)	Diagnosis condition	<ul><li>When vehicle is READY</li><li>When AEB system is ON</li></ul>	
C1F54			Signal (terminal)	—	
			Threshold	If ADAS control unit 2 detects an error signal that is received from electrically-driven intelligent brake unit via CAN communication	
			Diagnosis delay time	1 second or less	

#### **POSSIBLE CAUSE**

- Electrically-driven intelligent brake unit
- ADAS control unit 2

#### FAIL-SAFE

The following system are cancelled.

- Vehicle speed & vehicle-to-vehicle control function
- Lane keep function<sup>\*1</sup>
- Lane keep function<sup>\*2</sup>
- Lane change support function
- Overtaking support function
- Route driving support function
- AEB
- RAB
- I-FCW
- I-LI
- I-BSI
- TSR

\*1: ProPILOT Assist 2.0 display is green

\*2: ProPILOT Assist 2.0 display is blue

### **CONFIRMATION PROCEDURE**

#### **1. CHECK DTC PRIORITY**

If DTC "C1F54-82" is displayed with Network-DTC, first diagnose the Network-DTC.

Is applicable DTC detected?

YES>>

Perform diagnosis of applicable. Refer to <u>DTC Index</u>.

NO>>

<u>GO TO 2</u>.

#### 2. PERFORM DTC CONFIRMATION PROCEDURE

- 1. Set the vehicle to READY.
- 2. Turn the AEB system ON.
- 3. Perform "All DTC Reading" with CONSULT.
- 4. Check if the "C1F54-82" is detected as the current malfunction in "Self Diagnostic Result" of "ICC/ADAS 2".

Is "C1F54-82" detected as the current malfunction?

YES>>

Refer to DTC Diagnosis Procedure.

NO-1>>

To check malfunction symptom before repair: Refer to Intermittent Incident.

NO-2>>

Confirmation after repair: INSPECTION END

# **1. CHECK DTC PRIORITY**

If DTC "C1F54-82" is displayed with Network-DTC, first diagnose the Network-DTC.

Is applicable DTC detected?

YES>>

Perform diagnosis of applicable. Refer to DTC Index.

NO>>

<u>GO TO 2</u>.

#### 2. PERFORM SELF-DIAGNOSIS OF ELECTRICALLY-DRIVEN INTELLIGENT BRAKE UNIT

Check if any DTC is detected in "Self Diagnostic Result" of "BRAKE".

Is any DTC detected?

YES>>

Perform diagnosis on the detected DTC and repair or replace the malfunctioning parts. Refer to DTC Index.

NO>>

Replace the ADAS control unit 2. Refer to Removal and Installation.

# **DTC Description**

# **DTC DETECTION LOGIC**

DTC		CONSULT screen terms (Trouble diagnosis content)	DTC detection condition		
	83	E-driven intelligent brake unit circuit (Electrically-driven intelligent brake unit circuit)	Diagnosis condition	<ul><li>When vehicle is READY</li><li>When AEB system is ON</li></ul>	
C1F54			Signal (terminal)	—	
			Threshold	If ADAS control unit 2 detects an error signal that is received from electrically-driven intelligent brake unit via CAN communication	
			Diagnosis delay time	1 second or less	

#### **POSSIBLE CAUSE**

- Electrically-driven intelligent brake unit
- ADAS control unit 2

#### FAIL-SAFE

The following system are cancelled.

- Vehicle speed & vehicle-to-vehicle control function
- Lane keep function<sup>\*1</sup>
- Lane keep function<sup>\*2</sup>
- Lane change support function
- Overtaking support function
- Route driving support function
- AEB
- RAB
- I-FCW
- I-LI
- I-BSI
- TSR

\*1: ProPILOT Assist 2.0 display is green

\*2: ProPILOT Assist 2.0 display is blue

### **CONFIRMATION PROCEDURE**

#### **1. CHECK DTC PRIORITY**

If DTC "C1F54-83" is displayed with Network-DTC, first diagnose the Network-DTC.

Is applicable DTC detected?

YES>>

Perform diagnosis of applicable. Refer to <u>DTC Index</u>.

NO>>

<u>GO TO 2</u>.

#### 2. PERFORM DTC CONFIRMATION PROCEDURE

- 1. Set the vehicle to READY.
- 2. Turn the AEB system ON.
- 3. Perform "All DTC Reading" with CONSULT.
- 4. Check if the "C1F54-83" is detected as the current malfunction in "Self Diagnostic Result" of "ICC/ADAS 2".

Is "C1F54-83" detected as the current malfunction?

YES>>

Refer to DTC Diagnosis Procedure.

NO-1>>

To check malfunction symptom before repair: Refer to Intermittent Incident.

NO-2>>

Confirmation after repair: INSPECTION END

# **1. CHECK DTC PRIORITY**

If DTC "C1F54-83" is displayed with Network-DTC, first diagnose the Network-DTC.

Is applicable DTC detected?

YES>>

Perform diagnosis of applicable. Refer to <u>DTC Index</u>.

NO>>

<u>GO TO 2</u>.

#### 2. PERFORM SELF-DIAGNOSIS OF ELECTRICALLY-DRIVEN INTELLIGENT BRAKE UNIT

Check if any DTC is detected in "Self Diagnostic Result" of "BRAKE".

Is any DTC detected?

YES>>

Perform diagnosis on the detected DTC and repair or replace the malfunctioning parts. Refer to DTC Index.

NO>>

Replace the ADAS control unit 2. Refer to Removal and Installation.