


Your Ultimate Source for OEM Repair Manuals

FactoryManuals.net is a great resource for anyone who wants to save money on repairs by doing their own work. The manuals provide detailed instructions and diagrams that make it easy to understand how to fix a vehicle.

2021 Ford Transit Connect Service and Repair Manual

[Go to manual page](#)

Torque : 97 lb.in (11 Nm)




[Click here to learn about symbols, color coding, and icons used in this manual.](#)

Installation


1. To install, reverse the removal procedure.

Copyright © Ford Motor Company



[Click here to learn about symbols, color coding, and icons used in this manual.](#)

3. Release the retaining clips and remove the PCM (powertrain control module) cover.



[Click here to learn about symbols, color coding, and icons used in this manual.](#)


4. Release the retainer clips and remove the PCM (powertrain control module) .

4. **NOTE**

This step is only necessary when installing a new component.

Using the scan tool, perform the Misfire Monitor Neutral Profile Correction procedure, following the on-screen instructions.

Copyright © Ford Motor Company




[Click here to learn about symbols, color coding, and icons used in this manual.](#)

3. Remove the bolts and the intake VCT (variable camshaft timing) oil control solenoid.

Torque :

Stage 1: 71 lb.in (8 Nm)

Stage 2: 30°



[Click here to learn about symbols, color coding, and icons used in this manual.](#)

6. Remove the bolts and the intake VCT (variable camshaft timing) oil control solenoid.

Torque :

Stage 1: 71 lb.in (8 Nm)

Stage 2: 30°

Specifications

| | |
|---|---|
| 303-14D Electronic Engine Controls - 5.0L 32V Ti-VCT | 2022 F-150 |
| Specifications | Procedure revision date: 12/2/2021 |

Specifications

Reference Value Symptom Chart

NOTE

The Reference Value Symptom Chart provides guidance in selecting the appropriate parameter identification (PID) or measured signal related to the fault area. Select a symptom from the symptom chart along with the category number and go to the PID/Measured Signal Chart. For multiple symptoms, select the symptom that is the most evident.

| Symptom Occurs During | Symptom | Category Number |
|-----------------------|-----------------------|-----------------|
| Startup: | No start/Normal crank | 1 |
| | Hard start/Long crank | 2 |
| | Stall after start | 3 |
| | Diesels/Runs on | 4 |
| Idle: | MIL | 5 |
| | Stalls/Quits | 6 |
| | Slow | 7 |

| | | |
|----------------------|----------------------------|----|
| | Lack/Loss of power | 16 |
| | Surge | 17 |
| | Spark knock | 18 |
| | Cooling system temperature | 19 |
| | Poor fuel economy | 20 |
| | Emissions compliance | 21 |
| Deceleration: | Stalls/Quits | 6 |
| | Backfires | 13 |

Reference Value Parameter Identification (PID)/Measured Signal Chart

NOTE

The following listing reflects PIDS and/or measured values which may reveal a possible concern within each system shown. Match the category number with the related PID/measured signal and go to the Typical Diagnostic Reference Value Charts.

| Category Number | Related PIDS/Measured Signals |
|--|-------------------------------|
| 5, 10, 17 | ACP |
| 1, 23 | APP1 |
| 1, 23 | APP2 |
| 23 | BOO1/BOO2 |
| 18, 19 | CHT |
| 1, 2, 3, 5, 6, 7, 11, 12, 13, 14, 15, 16, 17, 20, 21 | CKP |
| 1, 2, 3, 5, 6, 7, 11, 12, 13, 14, 15, 16, 17, 20, 21 | CMP |

| | |
|--|-----------------------|
| 5, 14, 15, 16, 17, 20 | IMTV |
| 4, 5, 16, 18, 19, 20, 21 | KS |
| 19 | LFC |
| 1 through 21 | LONGFT1/2 |
| 1 through 23 | MAF |
| 1 through 23 | MAP |
| 1 through 22 | MISF |
| 1 through 21 | O2S11/12/21/22 |
| 22 | OSS |
| 10 | PSP |
| 5 | PTO |
| 1 through 23 | RPM |
| 5, 14, 16, 17 | SCICP |
| 1 through 21 | SHRTFT1/2/11/12/21/22 |
| 15, 16, 18, 19, 20, 21 | SPARKADV ^a |
| 1, 23 | TP |
| 2, 4, 5, 9, 10, 11, 16, 17, 18, 19, 20, 21 | VCT |
| 2, 4, 5, 9, 10, 11, 16, 17, 18, 19, 20, 21 | VCTDC/VCTDC2 |
| 1, 2, 3, 5, 6, 11, 12, 13, 14 | VPWR |
| 22, 23 | VSS |

Typical Diagnostic Reference Values

| | | | | | | |
|---|------------------|------------|------|------|------|------|
| Temperature Sensor Voltage) (V) | | | | | | |
| PCM (powertrain control module) AEIS_ACTION (Number of Drive Cycles where Automatic Engine Idle Shutdown Occurred) (Undefined / Not Used) | NUMERIC VALUE | PID | 0 | 0 | 0 | 0 |
| PCM (powertrain control module) AEIS_POSS (Number of Drive Cycles in which Automatic Engine Idle Shutdown Possible) (Undefined / Not Used) | NUMERIC VALUE | PID | 0 | 0 | 0 | 0 |
| PCM (powertrain control module) APP (Accelerator Pedal Position) (%) | % | APP Sensor | 0 | 0 | 13 | 18 |
| PCM (powertrain control module) APP1 (Accelerator pedal position sensor 1) (V) | VOLTS | APP Sensor | 0.77 | 0.77 | 1.18 | 1.33 |
| PCM (powertrain control module) APP1_[APP_D] (Accelerator Pedal Position D) (%) | % | APP Sensor | 15 | 15 | 24 | 26 |
| PCM (powertrain control module) APP2 (Accelerator pedal position sensor 2) (V) | VOLTS | APP Sensor | 0.40 | 0.40 | 0.62 | 0.69 |