

Your Ultimate Source for OEM Repair Manuals

FactoryManuals.net is a great resource for anyone who wants to save money on repairs by doing their own work. The manuals provide detailed instructions and diagrams that make it easy to understand how to fix a vehicle.

1992 CHEVROLET Corvette C4 Convertible OEM Service and Repair Workshop Manual

[Go to manual page](#)

Callout	Component Name
	<p data-bbox="344 188 488 221">Procedure</p> <ol data-bbox="316 246 1374 398" style="list-style-type: none"><li data-bbox="316 246 1235 280">1. Using a plastic pry tool, gently pry on the sides to release the switch.<li data-bbox="316 304 826 338">2. Disconnect the electrical connectors.<li data-bbox="316 362 1374 398">3. Refer to <a data-bbox="475 362 831 398" href="#">Control Module References for programming and set up procedures.

Sample

Callout	Component Name
<p>Eye protection must be worn when drilling rivets to reduce the chance of personal injury.</p>	
<p>Preliminary Procedure Remove the body side upper front applique. Refer to Body Side Upper Front Applique Replacement.</p>	
1	Front Side Door Window Front Weatherstrip Retainer Rivet (Qty: 4)
2	<p>Front Side Door Window Front Weatherstrip Retainer</p> <p>Procedure</p> <ol style="list-style-type: none"> 1. Use a solution of 50/50 isopropyl alcohol and water to clean the adhesive surface. 2. Replace the foam sealing tape if reusing the retainer. <ul style="list-style-type: none"> • Extend the tape 2.0 mm (0.08 in) beyond the retainer ends. • Do not stretch the tape to fit. The tape may shrink back, or creep, after installation, resulting in a gap which may cause a leak. <p>NOTE</p> <p>Note Water test the vehicle to ensure no leaks.</p>

Callout	Component Name
	<p>Pull up and away from inner panel to remove from the door.</p> <div>NOTE</div> <div>Note Inspect the door for proper operation before installing the door trim panel.</div>

Sample

Callout	Component Name
	<div>CAUTION</div> <div>Caution Refer to Fastener Caution.</div> <div><div>Tighten</div><div>2.5 N·m (22 lb in)</div></div>
2	<div>Front Side Door Window Outer Sealing Strip</div> <div>Procedure Pull the outer sealing strip up and away from the upper door flange.</div> <div>NOTE</div> <div>Note Inspect the door for proper operation before installing the door trim panel.</div>