

# Your Ultimate Source for OEM Repair Manuals

FactoryManuals.net is a great resource for anyone who wants to save money on repairs by doing their own work. The manuals provide detailed instructions and diagrams that make it easy to understand how to fix a vehicle.

2012 FORD F-150 Super Cab OEM Service and Repair Workshop Manual


Go to manual page



2. 80-120 grit sand paper.

E204572

Sand to remove old adhesive and clean.



5. Apply adhesive.

*Material*: Metal Bonding Adhesive / TA-1, TA-1-B, 3M™ 08115, LORD Fusor® 108B, Henkel Teroson EP 5055



Click here to learn about symbols, color coding, and icons used in this manual.

6. Install the replacement pickup box outer side panel and clamp in position.

Use the General Equipment: Locking Pliers



# 8. NOTE

E204578

Blind rivets, solid rivet fasteners or aluminum MIG (metal inert gas) plug welds may be used in place of SPR (self-piercing rivet) fasteners after enlarging holes to 6.5 mm.

## Install fasteners.

Item	SPR (self- piercing rivet) Number	SPR (self- piercing rivet) Code	Henrob®, Car-OLiner ®, CMO®, Chief®, Spanesi®, Wielander and Schill® Mandrel	Pro-Spot® Mandrel	Blind Rivet	Solid Rivet	Rivnut®
1	-	-	-	-	W707638- S900C	-	-

Use the General Equipment: Blind Rivet Gun


## 10. **NOTE**

Blind rivets, solid rivet fasteners or aluminum MIG (metal inert gas) plug welds may be used in place of SPR (self-piercing rivet) fasteners after enlarging holes to 6.5 mm.

#### Install fasteners.

ltem	SPR (self- piercing rivet) Number	SPR (self- piercing rivet) Code	Henrob®, Car-OLiner ®, CMO®, Chief®, Spanesi®, Wielander and Schill® Mandrel	Pro-Spot® Mandrel	Blind Rivet	Solid Rivet	Rivnut®
1	-	-	-		W707638- S900C	-	-


# Use the General Equipment: Blind Rivet Gun



Click here to learn about symbols, color coding, and icons used in this manual.


11. Drill for fastener installation.

Use the General Equipment: 6.5 mm Drill Bit




13. Drill for fastener installation.

Use the General Equipment: 6.5 mm Drill Bit



E334449



# 16. **NOTE**


Blind rivets, solid rivet fasteners or aluminum MIG (metal inert gas) plug welds may be used in place of SPR (self-piercing rivet) fasteners after enlarging holes to 6.5 mm.

## Install fasteners.

Item	SPR (self- piercing rivet) Number	SPR (self- piercing rivet) Code	Henrob®, Car-OLiner ®, CMO®, Chief®, Spanesi®, Wielander and Schill® Mandrel	Pro-Spot® Mandrel	Blind Rivet	Solid Rivet	Rivnut®
1	-	-	-	-	W707638- S900C	-	-

Use the General Equipment: Blind Rivet Gun

19. Install NVH (noise, vibration and harshness) pads as noted during removal.




Click here to learn about symbols, color coding, and icons used in this manual.

20. Drill for plug welds.

Use the General Equipment: 6.5 mm Drill Bit



E334447



E334449


Click here to learn about symbols, color coding, and icons used in this manual.

23. Drill for plug welds.

Use the General Equipment: 6.5 mm Drill Bit



E334445



26. Install aluminum MIG (metal inert gas) plug welds.

Use the General Equipment: MIG/MAG Welding Equipment

