

Your Ultimate Source for OEM Repair Manuals

FactoryManuals.net is a great resource for anyone who wants to save money on repairs by doing their own work. The manuals provide detailed instructions and diagrams that make it easy to understand how to fix a vehicle.

1991 CHEVROLET Tahoe 5 doors OEM Service and Repair Workshop Manual

[Go to manual page](#)

293_BN/VT 293 BN/VT

CM8 ROOF-CONVERTIBLE, FOLDING, POWER, REMOTE CONTROL

[Schematics RPO Code List](#)

6133 Body Control Module LIN Bus 2

SD Serial Data

Data_Communication_Schematics_REF Data Communication Schematics

[Data Communication Schematics](#)

193 Rear Defogger Relay Control

CAV_19 19

CONN_X2 X2

CAV_24 24

193_BN/VT 193 BN/VT

193_BN/VT 193 BN/VT

7531_L-GN/YE 7531 L-GN/YE

CAV_4 4

CONN_X2 X2

CAV_9 9

CONN_X1 X1

293_BN/VT 293 BN/VT

G301 G301

[G301](#)

[G301, G304](#)

G403 G403

[G403, G404 and G405](#)

[G400, G403, G404](#)

F8RA F8RA 40A

[F6RA, F8RA, F9RA, F11RA, F17RA, F18RA, F25RA, F26RA, F27RA, F28RA, and F31RA Fuses](#)

[X53A Fuse Block - Rear Body Top View](#)

F6RA F6RA 10A

Front of Instrument Panel Components

P17 Info Display Module X1

P17 Info Display Module X4

P17 Info Display Module X5

K33 K33 HVAC Control Module

HVAC Assembly Components

K33 HVAC Control Module X1

K33 HVAC Control Module X2

K33 HVAC Control Module X3

K33 HVAC Control Module X4

Sample

745 Left Front Door Ajar Switch Signal

745_GY 745 GY

CAV_6 6

3379 Window Switch Driver Up Signal

CAV_3 3

CAV_6 6

3381 Window Switch Driver Express Signal

CAV_5 5

CAV_2 2

3380 Driver Window Main Control Down Switch Signal

CAV_7 7

CAV_3 3

1150 Ground

1150_BK 1150 BK

CAV_1 1

1150_BK 1150 BK

CAV_1 1

2150 Ground

6134 Body Control Module LIN Bus 3

6134_L-GN/YE 6134 L-GN/YE

CAV_4 4

6134_L-GN/YE 6134 L-GN/YE

CAV_5 5

1842_RD/L-BU 1842 RD/L-BU

1940_RD/VT 1940 RD/VT

1940_RD/VT 1940 RD/VT

CAV_1 1

[Master Electrical Component List](#)

[Power Windows Description and Operation](#)

G301

G301, G304

F1RA F1RA 30A

F2BA, F3BA, F1RA, F5RA, F12RA, F15RA, F16RA, F21RA, F24RA, F30RA, F32RA, and F34RA Fuses

X53A Fuse Block - Rear Body Top View

F14RA F14RA 5A

F14RA, and F37RA Fuses

X53A Fuse Block - Rear Body Top View

X500 X500

Body Harness Routing - Left Front of Passenger Compartment

Driver Door Harness Routing

X500 Driver Door Harness to Body Harness

J321 J321

Body Harness Routing - Right Rear of Passenger Compartment

Body Harness Routing - Left Side of Rear Compartment

X500 X500

Body Harness Routing - Left Front of Passenger Compartment

Driver Door Harness Routing

X500 Driver Door Harness to Body Harness

X515 X515

Driver Door Trim Panel Harness Routing

Driver Door Harness Routing

X515 Driver Door Harness to Driver Door Trim Harness

J503 J503

Driver Door Trim Panel Harness Routing

J328 J328

Body Harness Routing - Left Front of Passenger Compartment

X505 X505

Driver Door Trim Panel Harness Routing

Driver Door Harness Routing