


Your Ultimate Source for OEM Repair Manuals

FactoryManuals.net is a great resource for anyone who wants to save money on repairs by doing their own work. The manuals provide detailed instructions and diagrams that make it easy to understand how to fix a vehicle.


1991 VOLVO 460 OEM Service and Repair Workshop Manual

Go to manual page




Courtesy of VOLVO CARS CORPORATION

Remove the screws. Loosen the clip. Remove the marked part.



Remove the screws. **Torque:** Bracket to front fender, 6Nm




Release the catches. Remove the marked part.


PARKING ASSISTANCE SENSOR, FRONT, OUTER > PARKING ASSISTANCE SENSOR, FRONT, OUTER [2018-2020 | 2021-2022, B4204T18 | 2021-2022, B4204T47] > INSTALLATION

NOTE: The following steps are only necessary when installing a new component.

Component is to be painted in the same color as the vehicle. To install, reverse the removal procedure.


PARKING ASSISTANCE SENSOR, FRONT, OUTER > PARKING ASSISTANCE SENSOR, FRONT, OUTER [2021-2022, E400V6] > REMOVAL






Couriesy of VOLVO CARS CORPORATION

Remove the screws. Loosen the clip. Remove the marked part.



Disconnect the connectors.




Release the catches. Remove the marked part.

PARKING ASSISTANCE SENSOR, FRONT, OUTER > PARKING ASSISTANCE SENSOR, FRONT, OUTER [2021-2022, E400V6] > INSTALLATION

NOTE: The following steps are only necessary when installing a new component.

Component is to be painted in the same color as the vehicle. To install, reverse the removal procedure.

PARKING ASSISTANCE SENSOR, FRONT, SIDE > PARKING ASSISTANCE SENSOR, FRONT, SIDE [2018-2021 | 2022, B4204T18 | 2022, B4204T47] > REMOVAL



Disconnect the connector.

