


Your Ultimate Source for OEM Repair Manuals


FactoryManuals.net is a great resource for anyone who wants to save money on repairs by doing their own work. The manuals provide detailed instructions and diagrams that make it easy to understand how to fix a vehicle.

1996 VOLVO C70 OEM Service and Repair Workshop Manual

Go to manual page




Remove the marked part.




Press the clip(s) into position.


DIAGNOSTIC SOCKET OBD 2 > DIAGNOSTIC SOCKET OBD 2 [2018-2022] > REMOVAL

Set the vehicle to Inactive mode, described in user mode. Refer to: USAGE MODE





Remove the screws.



Loosen the nut.


Disconnect the connector.

EXTRA POWER SOCKET 12V, LUGGAGE COMPARTMENT > EXTRA POWER SOCKET 12V, LUGGAGE COMPARTMENT [2018-2022] > INSTALLATION

To install, reverse the removal procedure.

HEATED REAR SEAT SWITCH > HEATED REAR SEAT SWITCH [2018-2022] > REMOVAL

Set the vehicle to Inactive mode, described in user mode. Refer to: USAGE MODE



Caution
Release the catches.
Remove the part carefully

HEATED REAR SEAT SWITCH > HEATED REAR SEAT SWITCH [2018-2022] > INSTALLATION

To install, reverse the removal procedure.

HEATED STEERING WHEEL MODULE > HEATED STEERING WHEEL MODULE (HSWM) [2018-2022] > REMOVAL


Remove steering wheel module (SWM). Refer to: STEERING WHEEL MODULE


PASSENGER DOOR MODULE > PASSENGER DOOR MODULE (PDM) [2018-2022] > REMOVAL

Set the vehicle to Inactive mode, described in user mode. Refer to: USAGE MODE Remove panel side door front. Refer to: PANEL FRONT DOOR


POWER OPERATED TAILGATE SWITCH > POWER OPERATED TAILGATE SWITCH [2018-2022] > REMOVAL

Set the vehicle to Inactive mode, described in user mode. Refer to: USAGE MODE





Remove the marked part.



Remove the screws.