


Your Ultimate Source for OEM Repair Manuals


FactoryManuals.net is a great resource for anyone who wants to save money on repairs by doing their own work. The manuals provide detailed instructions and diagrams that make it easy to understand how to fix a vehicle.

1999 VOLVO C70 Convertible OEM Service and Repair Workshop Manual


Go to manual page




Fold the wing liner aside.



Use hands only.
Remove the marked part.



Remove the marked part.




CAUTION: First the paint must dry after painting.

To install, reverse the removal procedure.

PARKING ASSISTANCE SENSOR, REAR, INNER > PARKING ASSISTANCE SENSOR, REAR, INNER [2021-2022, B4204T18 | 2021-2022, B4204T47] > REMOVAL

Set the vehicle to Inactive mode, described in user mode. Refer to: USAGE MODE




Release the catches.

Remove the marked part.

Disconnect the connector.

VEHICLES WITH INTEGRATED EXHAUST END PIPES

Remove casing bumper rear. Refer to: COVER BUMPER REAR




Release the catches.
Remove the marked part.

PARKING ASSISTANCE SENSOR, REAR, INNER > PARKING ASSISTANCE SENSOR, REAR, INNER [2021-2022, E400V6] > INSTALLATION


To install, reverse the removal procedure.

PARKING ASSISTANCE SENSOR, REAR, OUTER > PARKING ASSISTANCE SENSOR, REAR, OUTER [2021-2022, E400V6] > REMOVAL

Set the vehicle to Inactive mode, described in user mode. Refer to: USAGE MODE




Remove the screws.



Courtesy of VOLVO CARS CORPORATION

Raise the car.

Disconnect the connector.



Loosen the marked detail. Fold marked part aside.