


Your Ultimate Source for OEM Repair Manuals

FactoryManuals.net is a great resource for anyone who wants to save money on repairs by doing their own work. The manuals provide detailed instructions and diagrams that make it easy to understand how to fix a vehicle.


2005 VOLVO C70 OEM Service and Repair Workshop Manual

Go to manual page




Courtesy of VOLVO CARS CORPORATION

Remove the clips.




Courtesy of VOLVO CARS CORPORATION


Disconnect the connector.



Remove the clips.
Remove the marked part.




Remove the clips.
Remove the marked part.



NOTE: Orientation view


The graphic shows the back of the component.



Disconnect the connector. Remove the marked part.

HEADLAMPS > HEADLAMPS [2021, E400V6] > INSTALLATION


To install, reverse the removal procedure.



Disconnect the connector. Remove the marked part.

HEADLAMPS > HEADLAMPS [2018-2022 | 2021, B4204T18; B4204T47] > INSTALLATION

To install, reverse the removal procedure.



Disconnect the connector. Remove the marked part.

HIGH MOUNTED STOP LAMP > HIGH MOUNTED STOP LAMP [2018-2022] > INSTALLATION

To install, reverse the removal procedure.

LICENSE PLATE LAMP > LICENSE PLATE LAMP [2018-2022] > REMOVAL


Remove handle outer boot lid. Refer to: OUTER TAILGATE/TRUNK LID HANDLE

LICENSE PLATE LAMP > LICENSE PLATE LAMP [2018-2022] > INSTALLATION

To install, reverse the removal procedure.

TAIL LAMP > TAIL LAMP [2018-2022] > REMOVAL

NOTE: Removal steps in this procedure may contain



NOTE: Orientation view

The graphic shows the back of the component.